



Foreword

This manual was prepared to help you understand the operation and maintenance of your vehicle so that you may enjoy many kilometres (miles) of driving pleasure. Please read through this manual before operating your vehicle.

A separate Warranty Information & Maintenance Booklet explains in detail the warranty coverage that applies to your vehicle.

Your NISSAN dealer knows your vehicle best. When you require any service or have any questions, your NISSAN dealer will be glad to assist you with the extensive resources available for you.

IMPORTANT SAFETY INFORMATION REMINDERS!

Follow these important driving rules to help ensure a safe and complete trip for you and your passengers!

- NEVER drive under the influence of alcohol or drugs.
- ALWAYS observe posted speed limits and never drive too fast for conditions.
- ALWAYS give your full attention to driving and avoid using vehicle features or taking other actions that could distract you.
- ALWAYS use your seat belts and appropriate child restraint systems. Preteen children should be seated in the rear seat.
- ALWAYS provide information about the proper use of vehicle safety features to all occupants of the vehicle.
- ALWAYS review this Owner's Manual for important safety information.

WHEN READING THE MANUAL

This manual includes information for all options available on this model. Therefore, you may find some information that does not apply to your vehicle.

Throughout this manual, some illustrations may only show the layout for Left-Hand Drive (LHD) models. For Right-Hand Drive (RHD) models, the illustrated shape and location of some components may differ.

All information, specifications and illustrations in this manual are those in effect at the time of printing. NISSAN reserves the right to change specifications or designs at any time without notice and without obligation.

MODIFICATION OF YOUR VEHICLE

This vehicle should not be modified. Modifications could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from modifications may not be covered under NISSAN warranties.

A WARNING

Installing an aftermarket On-Board Diagnostic (OBD) plug-in device that uses the port during normal driving, for example remote insurance company monitoring, remote vehicle diagnostics or telematics, may cause interference or damage to vehicle systems.

We do not recommend or endorse the use of any aftermarket OBD plug-in devices, unless specifically approved by NISSAN. The vehicle warranty may not cover damage caused by any aftermarket plug-in device.

READ FIRST — THEN DRIVE SAFELY

Before driving your vehicle, read this Owner's Manual carefully. This will ensure familiarity with controls and maintenance requirements, assisting you in the safe operation of your vehicle.

Throughout this manual the following symbols and words are used:

A WARNING


Indicates the presence of a hazard that could cause death or serious personal injury. To avoid or reduce the risk, the procedures described must be followed precisely.

CAUTION

Indicates the presence of a hazard that could cause minor or moderate personal injury, or damage to your vehicle. To avoid or reduce the risk, the procedures described must be followed carefully.

NOTE:

Indicates additional helpful information.



This symbol means "Do not do this" or "Do not let this happen".





Arrows in an illustration that are similar to these point to the front of the vehicle.









Arrows in an illustration that are similar to these indicate movement or action









Arrows in an illustration that are similar to these call attention to an item in the illustration.

[]:

Square brackets are used to indicate messages, keys, or items displayed on a screen.



Chevrons or angle brackets are used to indicate texts on controls like buttons or switches inside or on the vehicle.

Air bag warning labels (where fitted):



Example

"NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur."

Be sure to read the "Airbag warning labels" description in the Safety section of this manual; and the "Airbag label" description at the end of this manual.

BATTERY DISPOSAL



Pre-installed remote controller (for Intelligent Key and/or Remote keyless entry system) battery type CR2032 complies with the essential requirements of Regulation (EU)2023/1542.

Pre-installed TPMS sensor battery - type CR2032 complies with the essential requirements of Regulation (EU)2023/1542.

CAUTION

An improperly disposed battery can harm the environment. Always confirm local regulations for battery disposal.

Examples of the batteries that the vehicle contains:

- Vehicle battery
- Remote controller battery (for Intelligent Key and/or Remote keyless entry system)
- Tyre Pressure Monitoring System (TPMS) sensor battery
- Remote controller battery (for Mobile Entertainment system)

If in doubt, contact your local authority, or a NISSAN dealer, or a qualified workshop for advice on disposal.

TRADEMARKS

Bluetooth*

Bluetooth® is a trademark owned by Bluetooth SIG, Inc. and licensed to Visteon Corporation, Clarion Co., Ltd and Daewoo IS Corp.



iPod® is a trademark of Apple Inc.



Gracenote® and CDDB are registered trademarks of Gracenote, Inc. The Gracenote logo and logo type, and the "Powered by Gracenote" logo are trademarks of Gracenote.

QR code

The term "QR code" is a registered trademark of DENSO WAVE INCORPORATED in Japan and other countries.

© 2024 Nissan Automotive Europe SAS, France

Contents


Hybrid system	HS
Illustrated table of contents	0
Safety — seats, seat belts and supplemental restraint system	1
Instruments and controls	2
Pre-driving checks and adjustments	3
Display screen, heater and air conditioner, and audio system	4
Starting and driving	5
In case of emergency	6
Appearance and care	7
Maintenance and do-it-yourself	8
Technical information	9
Regulatory information	10
Index	11

		•	1

Hybrid system

Hybrid system overview	2
Lithium-ion (Li-ion) traction battery	2
Hybrid system precautions	3
High voltage components	3
Road accident cautions	4
Emergency shut-off system	5
Operation of the hybrid system	5
Starting and slow speed driving	6
Medium or high speed driving	6
Rapid acceleration	6
Deceleration and braking	6
Stopping	6
Energy monitors	6
Power gauge	6
Energy flow	
Regenerative brake	7
When the vehicle starts the engine	8
Efficient use of your vehicle	
Before driving	8

When driving	8
Hybrid system drive mode	9
How to change the drive mode	9
Customising ECO mode	10
[ECO Cruise Control]	10
[ECO Climate Control]	10
EV mode	10
How to use the EV mode	10
e-Pedal step	11
e-Pedal step system operation	11
System Activation	12
System Deactivation	12
e-Pedal Step driving features	12
e-Pedal Step system limitations	13
e-Pedal Step system malfunction	13
Approaching vehicle sound for pedestrians	
(VSP) system	14



- 1. 12-volt battery
- 2. Lithium-ion (Li-ion) traction battery
- 3. High voltage power cable (orange)
- 4. Electric motor
- 5. Combustion engine

The hybrid vehicle system uses an electric motor

to improve the performance of the combustion engine (acceleration, starting etc.).

The vehicle has more acceleration torque available while consuming less fuel.

The vehicle may also move in all-electric operating mode without any assistance from the combustion engine. The vehicle uses energy stored in the Li-ion traction battery.

A WARNING

Your vehicle contains a sealed Lithium ion (Liion) high voltage battery. If the Li-ion battery is disposed of improperly, there is a risk of severe burns and electrical shock that may result in serious injury or death and there is also a risk of environmental damage.

CAUTION

- Do not misuse the Li-ion battery
- Do not use the Li-ion battery for any other purpose

This battery, located underneath the rear floor, stores the energy required for the electric motor to operate correctly.

As with any battery, it discharges when it is used. The traction battery is charged:

- during the vehicle deceleration phases;
- when the combustion engine starts automatically in order to act as a generator.

Your vehicle range in electric operating mode depends on the charge level of the traction battery, and also on your driving style and the components consuming energy (air conditioning, heating system etc.).


In the event of traction battery discharge, the combustion engine alone moves the vehicle until the traction battery is sufficiently recharged.

HYBRID SYSTEM PRECAUTIONS

A WARNING

- The hybrid system uses high voltage up to approximately 230 volts. Obey the caution labels attached to the high voltage components.
- Never touch high voltage harnesses, their connectors or high voltage parts (electric motor for driving and Lithium ion (Li-ion) battery, etc.). Touching, disassembling, removing or replacing those parts and harnesses can cause severe burns or electric shock that may result in serious injury or death.
- Do not drive through floods if the depth of water is above the lower edge of the wheel rims.

HIGH VOLTAGE COMPONENTS



The hybrid system consists of the following high voltage parts.

- 1. High voltage harnesses (orange) These harnesses are high voltage and orange colored.
- Be sure not to touch the harnesses or remove the connector on the base of the cable.
- 2. Inverter (including DC-DC converter) This device controls various functions related to the hybrid system.

Be careful because it can be hot after driving.

ROAD ACCIDENT CAUTIONS

The DC/DC converter is integrated in the inverter.

3. Electric motor for driving

This motor is for running the vehicle. Be careful because it can be hot after driving.

4. Service plug

This plug is used to cut-off the high voltage when performing maintenance. Never touch this plug.

5. Lithium ion (Li-ion) traction battery

This battery is charged from the electric power generated by the power generator and/or the regenerative power from the electric motor (driving). The Li-ion battery also supplies the electric power to the electric motor (driving) while driving.

A WARNING

In case of a collision or an accident, be sure to observe the following warnings.

- Pull your vehicle off the road, place the vehicle in the "P" (Park) position, apply the parking brake and turn the hybrid system off.
- Never touch the high voltage parts or harnesses if they are exposed. For the locations of the high voltage parts and harnesses, see "High voltage components" (P.3) earlier in this section.
- Inspect the ground under the vehicle. If you noticed liquid spilled from the Lithium ion (Li-ion) battery, contact a NISSAN dealer or emergency services as soon as possible. Ignoring such conditions may lead to a fire.
- Never touch the liquid leaked on interior surfaces or outside the vehicle. If the liquid spilled from the Li-ion battery comes into contact with skin or clothes, immediately flush the area with plenty of clean water and see a doctor.
- If the vehicle receives a strong impact to the floor while driving, stop the vehicle in a safe location and check the floor. If the floor is damaged, never touch it and contact a NISSAN dealer as soon as possible.
- If a fire occurs in the Li-ion battery or high voltage parts, leave the vehicle as soon as possible. When extinguishing the fire, use a

type ABC, BC or C fire extinguisher that is meant for use on electrical fires. Water can be used only when a large amount of water from a fire hydrant is available. Never attempt to extinguish a fire in an inappropriate way, as this can be dangerous.

- When towing your vehicle, lift the front wheels or all four wheels. If the vehicle is towed with front wheels on the ground, the electric motor for driving may generate electric power and cause damage to the vehicle.
- If you are not able to safely assess the vehicle due to vehicle damage, do not touch the vehicle. Leave the vehicle and contact a NISSAN dealer or emergency services. Advise 1st responders that this is a vehicle equipped with a hybrid system.
- In the event of an accident that requires body repair and painting, contact a NISSAN dealer. When the vehicle body is largely damaged or deformed, electrical leakage or shock depending on the damage condition could occur. Never touch the high voltage parts, such as Li-ion battery, and the orange-colored harnesses connected to them.
- Do not drive the vehicle with any exterior lights damaged. If water has leaked inside the light, it may lead to fumes or a fire.

EMERGENCY SHUT-OFF SYSTEM OPERATION OF THE HYBRID SYSTEM

NOTE:

If the vehicle collides or a malfunction of the hybrid system occurs, the READY to drive indicator light may be turned off since the high voltage system has been turned off. This is designed to minimize the risk of injury and accidents and is not a malfunction.

The emergency shut-off system is activated and the high-voltage system automatically turns off in the following conditions:

- Front and side collisions in which the supplemental air bags are deployed.
- Certain rear collisions.
- Certain hybrid system malfunctions.

For the above collisions and the certain hybrid system malfunctions, the READY to drive indicator light will turn off. See "Push-button ignition switch" (P.192). The emergency shut-off system activates for the above collisions to minimize risk of an event that could cause an injury or an accident. If the emergency shut-off system activates, the power switch may not switch to the READY to drive position. If this occurs, contact a NISSAN dealer or qualified workshop. Even if the power switch is switched to the READY to drive position, the system may shut-off suddenly. Therefore, drive cautiously to the nearest NISSAN dealer or qualified workshop or contact a NISSAN dealer or qualified workshop as soon as possible.

To start the hybrid system:

- 1. Depress the brake pedal and place the ignition switch in the ON position when the hybrid gearbox is in the P (Park) position or N (Neutral) position (P is recommended) to start the hybrid system. (For more details, see "Emergency shut-off system" (P.5).)
- The READY to drive indicator light flashes, then remains illuminated (the hybrid system switches to the READY to drive mode when the indicator light illuminates).

When the READY to drive indicator light # illuminates, the vehicle can be driven, even if the petrol engine is not running.

NOTE:

If you use the system with the hybrid system off (ignition switch placed in the ACC position) for a long time, it will discharge the 12-volt battery power, and the hybrid system will not start.

The petrol engine starts and stops automatically. It may stop during low speed driving, deceleration or when the vehicle is stopped.

The petrol engine may automatically run in the following conditions:

- The level of remaining charge in the Lithium ion (Li-ion) battery is low. The engine runs to charge the Li-ion battery and to provide power to drive the vehicle.
- The temperature of the engine coolant is low.
- Based on driving conditions.

ENERGY MONITORS

 The shift lever is shifted to the P (Park) position, the driver's seat belt is released and the driver's side door is then opened.

The hybrid system operates as follows based on driving conditions and the Li-ion battery charge.

STARTING AND SLOW SPEED DRIVING

The vehicle is driven by the electric motor depending on the available Li-ion battery charge.

MEDIUM OR HIGH SPEED DRIVING

The system automatically controls the petrol engine and electric motor in order to obtain the optimum fuel mileage and performance, depending on the driving situation and available Li-ion battery charge.

When the remaining battery level is low, the Li-ion battery is charged by the electric motor that is driven to generate electric power while the vehicle is driving.

RAPID ACCELERATION

The vehicle is accelerated using both the petrol engine and the electric motor depending on the available Li-ion battery charge.

DECELERATION AND BRAKING


The Li-ion battery is charged by the electric motor that changes the energy of the rotating wheels into electric power. See "Regenerative brake" (P.7) later in this section.

STOPPING

The petrol engine may stop running to save fuel depending on the available Li-ion battery charge.

The hybrid system monitors the status of power being sent to theelectric motor and the Lithium ion (Li-ion) battery state of charge. The status is shown on the power gauge in the display and the energyflow/remaining Li-ion battery charge in the display. System statuscan also be shown on the vehicle information display when the screenis in the energy flow mode.

POWER GAUGE




This gauge indicates the actual power consumption and the charging power to the Li-ion battery. For additional information, See "POWER GAUGE" (P.70).

REGENERATIVE BRAKE

ENERGY FLOW

When you use this system, make sure the hybrid system is in the READY to drive mode. See "Operation of the hybrid system" (P.5).

Energy monitor for various operating modes can be displayed in the vehicle information display. (See "General information and warnings" (P.92).)



Example: Running using EV power & petrol engine charging the Li-ion battery

This is an example of the Energy Flow display. The Energy Flow display changes depending on the following operating conditions. The graphic indicates the amount of power in the Li-ion battery.

The following operating modes are displayed on the Energy Flow screen.

- When the vehicle is powered only by the electric motor.
- When the vehicle is powered by the electric motor and the petrol engine is charging the Liion battery.

- When the vehicle is powered by both the electric motor and the petrol engine.
- When the vehicle is powered by the petrol engine and is charging the Li-ion battery.
- When both the vehicle and the petrol engine are charging the Li-ion battery.
- When the vehicle is charging the Li-ion battery
- When the vehicle is powered only by the petrol engine.

The regenerative brake is a function that can reduce the vehicle speed by using the electric motor instead of the engine braking for the petrol engine vehicle. The Lithium ion (Li-ion) battery can be charged by the generated electric power when the vehicle decelerates, saving electric power consumption and improving fuel efficiency.

The electric motor converts the energy of the rotating wheels into electric power when the accelerator pedal is released, the brake pedal is depressed or the e-Pedal released.

The regeneration amount will change depending on Drive mode. With e-Pedal on, you will feel maximum regeneration. Sport mode will give a higher than usual level whereas Eco will give less than usual to allow more coasting

NOTE:

The regenerative brake may provide less deceleration when the Li-ion battery is fully charged while driving on a long downhill road, when the outside temperature is low or when driving on a slipperv road.

WHEN THE VEHICLE STARTS THE ENGINE

EFFICIENT USE OF YOUR VEHICLE

In the hybrid system, the engine may run under the following conditions:

- When selecting Sport mode.
- When the Lithium ion (Li-ion) battery charge is low (to generate electric power).
- When depressing the accelerator pedal strongly
- When driving on a long downhill (to generate deceleration without using fuel).
- When the engine is cold (to warm up the engine).
- When opening the bonnet with the hybrid system running (to avoid an accident when performing maintenance).
- When turning on the air conditioner.
- When engine start is required by maintenance mode.
- When the accelerator pedal is depressed while the vehicle is stationary and hybrid gearbox is in P (Park) position.
- When the Li-ion battery is fully charged and regeneration is continued the electric motor may turn the engine to dissipate the excess electricity generated. In this mode the engine is not using fuel, this will maintain vehicle control.

The fuel consumption varies considerably depending upon road conditions, weather, temperature, and number of occupants, etc. Keeping the following points in mind to help improve the fuel efficiency.

BEFORE DRIVING

- Plan for the route with less power consumption by the vehicle. Driving on uphill roads increases fuel consumption. If you choose the route where there are few uphill roads, the vehicle can reduce fuel consumption.
- Do not leave unnecessary cargo loaded. Removing unnecessary cargo from the vehicle to reduce vehicle weight can reduce fuel consumption.
- Keep the tyres inflated to the correct pressure.
 Low tyre pressure increases fuel consumption.

WHEN DRIVING

- Drive your vehicle with smooth start and acceleration.
 - Abrupt starting and acceleration will decrease fuel economy.
 - You can accelerate the vehicle with less fuel consumption by checking the condition of the power consumption in the power gauge.
- Keep a distance from the vehicle in front of you. Do not decelerate the vehicle more than necessary so that you can decrease the fuel consumption to accelerate again.
- Do not drive at excessive speeds on a highway.

- Driving at excessive speeds consumes fuel more than necessary.
- Set the air conditioner at a moderate temperature and turn it off if unnecessary. Redundant fuel consumption can be reduced by the air conditioner.
- Do not use the defogger more than necessary. After removing fog from the windshield, switching to the other air flow mode reduces the engine operation frequency and improve the fuel economy.
- Drive the vehicle in ECO mode. Then the driving force response to accelerator operation is gentler than in STANDARD / SPORT mode; it suppresses unnecessary acceleration / deceleration and realizes fuel saving.
- The fuel efficiency improves in the following order:

SPORT mode \rightarrow STANDARD mode \rightarrow ECO mode. ECO mode is the most fuel-efficient mode.

NOTE:

The following are some conditions in which the fuel economy decreases significantly:


- When driving on a route where there are many uphill roads.
- When continuing driving at a high speed on a highway.
- When starting, accelerating or braking abruptly.

HYBRID SYSTEM DRIVE MODE


There are three drive modes of the hybrid system.

Drive mode	Features
SPORT	This mode balances EV like quick response characteristics and fuel economy. The drive response to accelerator operation is better than the STANDARD mode, and high acceleration performance is achieved (emphasizes the characteristics of electric motor drive).
	 The feeling of deceleration when releasing the accelerator pedal is similar to that of a vehicle powered by a petrol engine only.
ECO	This mode places emphasis on fuel economy. By making the driving force response to accelerator operation gentler than in STANDARD mode, it suppresses unnecessary acceleration / deceleration and realizes fuel saving. Further, in order to suppress unnecessary deceleration, the regenerative brake by accelerator operation is less to allow for more coasting.
STANDARD	 This mode is recommended for normal driving. Smooth acceleration with good accelerator response. The feeling of deceleration when releasing the accelerator pedal is similar to that of a vehicle powered by a regular petrol engine.

HOW TO CHANGE THE DRIVE MODE



Right hand drive



Left hand drive

- The drive mode can be changed when the power switch is in the ON position. Push the drive mode switch up or down to change the mode as follows:
 - SPORT \leftrightarrow STANDARD \leftrightarrow ECO.
- When the mode is switched, the selected mode is displayed in the vehicle information display.

NOTE:

- If a system malfunction occurs when SPORT mode or ECO mode is selected, the deceleration force is weaker than usual. Apply the foot brake as necessary for the deceleration.
- The mode setting is changed to STANDARD mode every time the power switch is placed in the ON position.

EV MODE

[ECO Drive Mode] is a function that can change the priority of the air conditioner function and the Cruise Control (where fitted) or the Intelligent Cruise Control (ICC) function to make fuel efficiency improvements.

Two menu options are available under [ECO Drive Model:

- [ECO Cruise Control]
- [ECO Climate Control]

[ECO CRUISE CONTROL]

This setting can be selected in [ECO Drive Mode] under the [ECO Settings] menu of the vehicle information display. When the setting is ON, the fuel efficiency while cruising will be improved by lowering the acceleration target from normal (setting OFF) mode. (See "[ECO Settings]" (P.88).)

NOTE:

When the vehicle speed is reduced (for example, when the vehicle is driven on an uphill road from a flat road), it will take more time to return to the previously set speed than normal mode.

[ECO CLIMATE CONTROL]

This setting can be selected in [ECO Drive Mode] under the [ECO Settings] menu of the vehicle information display. Select the menu and turn [ECO Climate Control] to ON or OFF. (See "[ECO Settings]" (P.88).)

NOTE:

When the [ECO Drive Mode] ([ECO Climate Control]) is turned ON (fuel efficiency-oriented), the fuel efficiency is improved by reducing the performance of the air conditioner.

- The [ECO Climate Control] setting maintains the status until the setting is changed, even if the power switch is placed in the "OFF" position.
- The air conditioner function will be prioritized even when the [ECO Climate Control] ([ECO Air Conditioning]) is turned ON under the following conditions.
 - When the A/C setting temperature is set at 28°C (82°F) or higher.


(When the A/C setting temperature is set at 27.5°C (82°F) or lower, the fuel efficiency will be prioritized again.)

- When the A/C setting temperature is set at 18°C (64°F).
 - (When the A/C setting temperature is set at 18.5°C (65°F) or higher, the fuel efficiency will be prioritized again.)
- When the front defogger is activated.

When EV mode is selected, you can drive the vehicle with the chance of engine starting reduced as much as possible. This mode is used when you wish to drive the vehicle quietly on a road such as a residential street in an early morning or a late at night, provided the following conditions are met.


- The Lithium ion (Li-ion) battery is sufficiently charged. (above 1/2 charge is required which you can see in the combination meter or the energy flow display)
- The vehicle speed is below approximately 50 km/h (32 MPH).

HOW TO USE THE EV MODE



Left hand drive

e-Pedal STFP



Right hand drive

- When the READY to drive indicator light illuminates, EV mode can be turned on by pushing the EV mode switch.
- EV mode cannot be used when SPORT mode is selected.
- When EV mode is on, the EV mode indicator illuminates in the vehicle information display.
- When the outside temperature is low, the engine may start. However, when the EV mode is turned on before the engine starts, the vehicle can be driven by only the Li-ion battery.

NOTE:

- If the system malfunction occurs, EV mode is automatically turned off.
- If the accelerator pedal is depressed when the shift position is in the "P" (Park) position, the engine starts and EV mode is turned off.
- If the Li-ion battery is fully charged by the regenerative braking on a long downhill road, EV mode is turned off to protect the Li-ion battery.

- When the accelerator pedal is depressed to the floor on an uphill road or by abrupt acceleration, the engine starts and EV mode is turned off.
- If the bonnet is opened when the READY to drive indicator light illuminates, the engine starts automatically and EV mode is turned off.
- When the front defogger switch is turned on, the engine starts due to a warm-up operation, and EV mode cannot be used or it is turned off.
- If the system judges that the forced charging is necessary, EV mode is turned off and the engine starts.
- If the system judges that the warm-up operation is necessary. EV mode is turned off and the engine starts.
- When the outside temperature is low, EV mode may not be available.
- When the Li-ion battery charge is low, EV mode may not be used or is turned off.


A WARNING

Never rely solely on the e-Pedal Step system, as there is a performance limit to the system function. Always drive carefully and attentively. The brake pedal should be operated to slow or stop the vehicle, depending on traffic or road conditions.

The e-Pedal Step system enables the driver to slow the vehicle, by operating only the accelerator pedal.


This assists the driver by reducing the number of times required to move their foot between the accelerator pedal and the brake pedal.

e-Pedal STEP SYSTEM OPERATION




- Acceleration
- Deceleration (instead of brake pedal)

When the e-Pedal Step system is activated, the regenerative brake is enhanced and the driver can adjust the vehicle speed by only depressing or returning the accelerator pedal. When you release (take your foot off) the accelerator pedal, the vehicle slows down smoothly without depressing the brake pedal.



Left hand drive



Right hand drive

The e-Pedal system will be turned **ON** or **OFF** each time the e-Pedal switch is pressed. (The e-Pedal indicator in the Vehicle Information Display shows the status of the e-Pedal system.)

When the e-Pedal system is activated, the characteristics of the accelerator pedal change significantly and the accelerator pedal operates differently than a conventional one operates. Be sure to confirm the status of the e-Pedal system (ON or OFF) in the Vehicle Information Display before driving.

SYSTEM ACTIVATION

To activate the e-Pedal system, place the power switch in the **ON** position and press the e-Pedal switch located on the centre console.

SYSTEM DEACTIVATION

To deactivate the e-Pedal system, depress the brake pedal and press the e-Pedal switch.

If the brake pedal is not depressed when the e-Pedal Step system switch is operated, a reminder message will be shown in the Vehicle Information Display.

NOTE:

- When the e-Pedal Step system is switched to ON or OFF, the degree of vehicle deceleration will change.
- The e-Pedal Step system is automatically turned OFF when the hybrid system is restarted.

e-Pedal STEP DRIVING FEATURES

The e-Pedal Step system provides the following driving features:

When driving the vehicle:

- Depressing or returning the accelerator pedal will change the degree of acceleration and deceleration accordingly.
- Returning the accelerator pedal generates more deceleration than normal. (The maximum deceleration changes according to the vehicle speed.)
- Releasing (taking your foot off) the accelerator pedal reduces the vehicle speed to ~8 km/h (~5 MPH). The brake pedal must be used to bring the vehicle to a full a stop.
- The vehicle's brake lights illuminate when the deceleration level reaches an ordinary braking operation.

If the deceleration is not sufficient when the accelerator pedal is returned or released, depress the brake pedal. The brake pedal can be operated to reduce the vehicle speed in the same way as normal even when the e-Pedal Step system is activated.

When reversing the vehicle:

With the shift position in the \mathbf{R} (Reverse), operating the accelerator pedal can adjust the vehicle speed (acceleration and deceleration) in the same way as in the \mathbf{D} (Drive) position.

Other driving tips for the e-Pedal Step system:

 For smooth deceleration when the e-Pedal Step system is activated, it is recommended to adjust the accelerator pedal while driving with your foot on it (depressing or returning, but not releasing).

- The e-Pedal Step system will not function under the following conditions:
 - When the vehicle is placed in the P (Park) or N (Neutral) position.
 - When cruise control (where fitted), ProPILOT Assist (where fitted), or Intelligent Emergency Braking operates, these Driver Assistance systems have priority over e-Pedal Step.
- Brake pedal may move depending on deceleration, you might hear a noise when the e-Pedal Step is active. This is normal and does not indicate malfunction
- The characteristics of deceleration change according to the vehicle speed. At low speed, the motor continues to apply torque to move vehicle slowly forward (so-called "creep"), similar to a conventional vehicle with a automatic gearbox. Remember to depress the brake pedal firmly to slow or stop the vehicle.

e-Pedal STEP SYSTEM LIMITATIONS

A WARNING

Listed below are the system limitations for the e-Pedal Step system. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.

If [Press brake pedal to prevent rolling] warning message appears in the Vehicle

- Information Display, depress the brake pedal. The vehicle may start moving.
- If the deceleration force provided by the e-Pedal Step system is not sufficient, depress the brake pedal.
- Under the following conditions, place the vehicle in the P (Park) position and make sure the parking brake is securely applied. The vehicle may start moving suddenly.
 - When getting in and out of the vehicle.
 - When loading and unloading the vehicle.
 - When stopping the vehicle for a long period of time.
- Under the following conditions the e-Pedal Step system may not decelerate or may not stop the vehicle sufficiently. Depress the brake pedal whenever necessary.
 - When excessively heavy baggage is loaded in the vehicle.
 - When driving on steep downhill roads.
 - When driving on icv roads.

CAUTION

- Turn the e-Pedal Step system OFF and place the vehicle in the N (Neutral) position under the following conditions:
 - When the vehicle enters an automatic car wash.
 - When the vehicle is towed.

- Be careful not to operate the e-Pedal switch mistakenly or unintentionally.
- At low speed, the motor continues to apply torque to move vehicle slowly forward (socalled "creep"), similar to a conventional vehicle with a automatic gearbox. Remember to depress the brake pedal firmly to slow or stop the vehicle.


e-Pedal STEP SYSTEM MALFUNCTION

If the e-Pedal Step system malfunctions, [e-Pedal system failure! Press brake pedal to slow or stopl warning message appears in the Vehicle Information Display. When the warning message appears, the e-Pedal Step system will be turned off automatically. Have the system checked as soon as possible by a NISSAN dealer or qualified workshop.

APPROACHING VEHICLE SOUND FOR PEDESTRIANS (VSP) SYSTEM

The Approaching Vehicle Sound for Pedestrians (VSP) system is a function that uses sound to help alert pedestrians of the presence of the vehicle when it is being driven at a low speed. The VSP sounds when the READY to drive indicator light is illuminated under the following conditions:

- When the vehicle speed is within 30 km/h (19 mph) and running with electric motor only.
- When the vehicle speed is less than 25 km/h (16 mph) and decelerating with electric motor only.
- When the vehicle is in the R (Reverse) position. The sound stops when the vehicle stops.



A WARNING

If the sound from the VSP system is not heard while driving, stop the vehicle in a safe and quiet location. Open a window, and then place the vehicle in the "R" (Reverse) position with the brake pedal firmly depressed. Check that the operating sound can be heard from the front side of the vehicle. If the sound from the


VSP system is not heard, contact a NISSAN dealer or qualified workshop.

O Illustrated table of contents

Seat belts and supplemental restraint system	16
Exterior front	17
Exterior rear	18
Passenger compartment	19
Cockpit	20
Left hand drive	20
Right hand drive	21
Instrument panel	23
Left hand drive	23
Right hand drive	24

Meters and gauges	25
Models with analogue meter and colour display	25
Models with full-screen display	26
Engine compartment	27
HR16DE engine	27
Driving aids (where fitted)	28


SEAT BELTS AND SUPPLEMENTAL RESTRAINT SYSTEM



- 1. Supplemental air bags (P.33)
- 2. Front seat belts (P.36)
- 3. Head restraints (P.34)
- 4. Rear outboard seat belts (P.36)
- 5. ISOFIX child restraint system (P.43)
- 6. Rear centre seat belt (P.36)

- 7. Rear seats (P.33)
 - Child restraints (P.43)
- 8. Pre-tensioner seat belt system (P.41)
- 9. Front seats (P.33)
 - Child restraints (P.43)
- 10. Front passenger air bag switch* (P.61)
- *: where fitted

EXTERIOR FRONT




- Bonnet (P.137)
- Windscreen wipers and washers
 - Switch operation (P.105)
 - Blade replacement (P.329)
 - Window washer fluid (P.324)
 - ThermaClear* (P.107)

- Power windows (P.119) 3.
- Towing eye (P.303)
- Headlights, front side lights, turn signal lights
 - Switch (P.108)
 - Location and bulb replacement (P.331)
- 6. Tyres
 - Tyres and wheels (P.334 and P.344)

- Flat tyre (P.292)
- Tyre Pressure Monitoring System (TPMS)* (P.186)
- Outside rear-view mirrors (P.144)
 - Side turn signal light (P.111)
 - Blind Spot Warning (BSW) system (P.200)
 - Intelligent Around View Monitor (IAVM)* (P.153)
- Doors
 - Keys (P.124)
 - Door locks (P.133)
 - Remote keyless entry system* (P.125)
- where fitted

EXTERIOR REAR




- 1. Rear window
 - Defogger switch (P.108)
- 2. Rear wiper and washer
 - Wiper and washer switch (P.105)
 - wiper and washer switch (i
 - Wiper replacement (P.329)
 - Washer fluid (P.324)

- 3. Tail light
 - Switch location (P.108)
- 4. High-mounted brake light (P.332)
- 5. Rear turn signal light
 - Switch location (P.111)
 - Bulb replacement (P.332)

- 6. Shark antenna (P.173)
- 7. Doors
 - Keys (P.124)
 - Door locks (P.133)
 - Child safety lock (P.135)
 - Remote keyless entry system* (P.125)
- 8. Fuel filler lid (P.137)
- 9. Brake light (P.331)
- 10. Reversing light (P.331)
- 11. Rear fog light* (P.111)
- 12. Towing eye (P.303)
- 13. Rear view camera*
 - Rear-View Monitor* (P.148)
 - ited view morned (1.146)
 - Intelligent Around View Monitor (IAVM)*
 (P.153)
- 14. Number plate lights (P.331)
- 15. Tailgate
 - Door locks (P.135)
 - Remote keyless entry system* (P.125)
- *: where fitted

PASSENGER COMPARTMENT



Inside rear-view mirror (P.143)


- Map light (P.121)
- eCall button* (P.288) 3.
- Sun visors (P.142)
- Door armrest
 - Outside mirror folding switch* (P.144)
 - Outside mirror remote control (P.144)

- Power windows controls (P.119)
- Power door lock switch (P.134)
- 6. Interior (room) light (P.121)
- 7. Inside door handle (P.134)
- Luggage (boot) compartment
 - Parcel shelf (P.117)
 - Luggage floor (P.118)

- Luggage hooks (P.119)
- Fuse box
 - Fuses (P.330)
 - USB port for TSA map update* (P.284)
- where fitted

COCKPIT

LEFT HAND DRIVE




- Passenger's supplemental front-impact air bag (P.60)
- Shift lever (P.196)
- 3. EV mode switch (P.10)

- 4. Hazard warning flasher switch (P.288)
- 5. Power outlet (P.113)
- 6. Wiper and washer switch (P.105)
- Steering wheel switches
 - ProPILOT Assist switch* (P.225)

- Cruise control* (P.221)
- Speed limiter* (P.223)
- Mobile phone integration for NissanConnect* **
- 8. Steering wheel
 - Electric power steering system (P.271)
 - Horn (P.112)
 - Driver's supplemental front-impact air bag (P.60)
- Steering wheel switches
 - Vehicle information display switches (P.82)
 - Audio switches* (P.179)
- 10. Headlight and turn signal switch (P.108)
- 11. Upper switch panel
 - Instrument brightness switch (P.70)
 - Heated steering wheel switch (P.112)
 - Steering Assist switch* (P.227)
- 12. Lower switch panel
 - Headlight aiming control switch* (P.112)
- 13. Bonnet release handle (P.137)
- 14. Push button ignition switch (P.192)
- Electric parking brake* and automatic brake hold*
 - Electric parking brake switch* (P.138)
 - Automatic brake hold switch (P.140)
- 16. Front cup holders (P.116)
- 17. Drive mode switch* (P.197)

- e-Pedal switch (P.11)
- where fitted
- Refer to the separately provided NissanConnect Owner's Manual.

RIGHT HAND DRIVE



- Passenger's supplemental front-impact air bag (P.60)
- Shift lever (P.196)
- EV mode switch (P.10)
- Hazard warning flasher switch (P.288)


- Power outlet (P.113) 5.
- Headlight and turn signal switch (P.108)
- Steering wheel switches
 - Vehicle information display switches (P.82)
 - Audio switches* (P.179)

- 8. Steering wheel
 - Electric power steering system (P.271)
 - Horn (P.112)
 - Driver's supplemental front-impact air bag (P.60)
- 9. Steering wheel switches
 - ProPILOT Assist switch* (P.225)
 - Cruise control* (P.221)
 - Speed limiter* (P.223)
 - Mobile phone integration for NissanConnect* **
- 10. Wiper and washer switch (P.105)
- 11. Upper switch panel
 - Instrument brightness switch (P.70)
 - Heated steering wheel switch (P.112)
 - Steering Assist switch* (P.227)
- Lower switch panel
- Headlight aiming control switch* (P.112)
- 13. Push button ignition switch (P.192)
- 14. Electric parking brake* and automatic brake hold*
 - Electric parking brake switch* (P.138)
 - Automatic brake hold switch (P.140)
- 15. Front cup holders (P.116)
- 16. Drive mode switch* (P.197)
- 17. Bonnet release handle (P.137)
- 18. e-Pedal switch (P.11)
- *: where fitted

**: Refer to the separately provided NissanConnect Owner's Manual.

INSTRUMENT PANEL

LEFT HAND DRIVE




- Left, centre and right side vents (P.166)
- Steering wheel switches
 - Vehicle information display switches (P.82)
 - Audio control* (P.179)

- Meters, gauges, warning/indicator lights, vehicle information display (P.67, P.72, P.82)
- Steering wheel switches
 - ProPILOT Assist switch* (P.225)
 - Cruise control* (P.221)
 - Speed limiter* (P.223)

- Mobile phone integration for NissanConnect* **
- Audio system* (P.170)
 - NissanConnect* **
 - without NissanConnect* (P.170)
- Front passenger's supplemental front-impact air bag (P.60)
- 7. Glove box (P.115)
- Heater and air conditioner (P.166)
- Push Button ignition switch (P.192)
- where fitted
- Refer to the separately provided NissanConnect Owner's Manual.

RIGHT HAND DRIVE




- 1. Left, centre and right side vents (P.166)
- 2. Steering wheel switches
 - Vehicle information display switches (P.82)
 - Audio control* (P.179)

- 3. Meters, gauges, warning/indicator lights, vehicle information display (P.67, P.72, P.82)
- 4. Steering wheel switches
 - ProPILOT Assist switch* (P.225)
 - Cruise control* (P.221)
 - Speed limiter* (P.223)

- Mobile phone integration for NissanConnect* **
- 5. Audio system* (P.170)
 - NissanConnect* **
- Front passenger's supplemental front-impact air bag (P.60)
- 7. Glove box (P.115)
- 8. Heater and air conditioner (P.166)
- 9. Push Button ignition switch (P.192)
- *: where fitted
- **: Refer to the separately provided NissanConnect Owner's Manual.

METERS AND GAUGES

MODELS WITH ANALOGUE METER AND COLOUR DISPLAY




7 inch display

- Power gauge (P.70)
 - Warning and indicator lights (P.72)
- Vehicle information display (P.82)
- Speedometer (P.69)
 - Warning and indicator lights (P.72)

- Fuel gauge (P.70)
- Battery charge indicator (P.70)

MODELS WITH FULL-SCREEN DISPLAY



- 1. Power gauge (P.70)
- 2. Vehicle information display (P.82)
- 3. Warning and indicator lights (P.72)
- 4. Speedometer (P.69)


- 5. Battery charge indicator (P.70)
- 6. Personal display (P.88)
- 7. Fuel gauge (P.70)

CAUTION

- For cleaning, use a soft cloth, dampened with water. Never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or cause discolouration to the lens.
- Do not spray any liquid such as water on the meter lens. Spraying liquid may cause the system to malfunction.

ENGINE COMPARTMENT

HR16DE ENGINE



- Engine coolant reservoir (P.317)
- Window washer fluid reservoir (P.324) 2.
- Engine oil dipstick (P.320) 3.
- Engine oil filler cap (P.320)

- Bonnet release lever (P.137)
- 6. Brake fluid reservoir* (P.323)
- Inverter/Battery coolant reservoir (P.318)
- Battery 12V positive terminal

DRIVING AIDS (where fitted)

System name	Abbrevia- tion	lcon	Description	Page
Lane Assist*			The Lane Assist system warns the driver when the vehicle is beginning to leave the driving lane.	215
Steering Assist*		•	The Steering Assist system assists the driver in keeping the vehicle in the centre of the travelling lane.	241
Cruise Control*		3	The Cruise Control system allows the driver to set and keep a constant vehicle speed.	221
ProPILOT* Assist or Drive Assist*		0	The ProPILOT Assist or Drive Assist systems combine the Intelligent Cruise Control, Steering Assist and Blind Spot Intervention.	225
Speed limiter*		1(5)	The speed limiter allows you to set the desired vehicle speed limit.	223
Blind Spot Warn- ing*	BSW		While driving, the BSW system helps alert the driver to the presence of other vehicles in adjacent lanes.	200
Intelligent Blind Spot Intervention*			The Intelligent Blind Spot Intervention system helps alert the driver to the presence of other vehicles in adjacent lanes when changing lanes and helps assist the driver to return the vehicle to the centre of the travelling lane.	200

System name	Abbrevia- tion	Icon	Description	Page
Traffic Sign Assist*	TSA	60 &F	The Traffic Sign Assist system provides the driver with information about the most recently detected speed limit, using the speed limit display and overspeed warning function.	279
Intelligent Emer- gency Braking*	IEB		The IEB system can assist the driver when there is a risk of a forward collision with the vehicle ahead in the travelling lane or with a pedestrian or cyclist.	250
Rear Cross Traffic Alert*	RCTA		When the vehicle is in reverse, the RCTA system is designed to detect other vehicles approaching from the right or left of the vehicle.	210
Anti-lock Braking System	ABS	(6)	The ABS controls the brakes so the wheels do not lock during hard braking or when braking on slippery surfaces.	273
Electronic Stability Programme	ESP	₽	The ESP system adjusts wheel brake pressure and engine torque to assist in improving vehicle stability.	274
Hill Start Assist*	HSA	©	The Hill Start Assist system automatically keeps the brakes applied to help prevent the vehicle from rolling backwards when stopped on a hill.	277
Intelligent Driver Alertness*	IDA	333	The intelligent Driver Attention Alert system helps alert the driver if the system detects a lack of attention or driving fatigue.	262

^{*:} Where fitted

MEMO

1 Safety — seats, seat belts and supplemental restraint system

S	eats	32		
	Front seats	33		
	Seat heater (where fitted)	33		
	Rear seats	33		
	Front armrest	34		
Н	ead restraints	34		
	Rear head restraint components	34		
	Remove	34		
	Install	35		
	Adjust	35		
S	Seat belts			
	Precautions on seat belt usage	36		
	Child safety	37		
	Pregnant women	38		
	Injured persons	38		
	Seat belt reminders	38		
	Three-point type seat belt	39		
	Seat belt maintenance	41		
Ρ	re-tensioner seat belt system	41		

Ch	ild safety	42
	Infants and small children	43
	Larger children	43
	Legal requirements	43
Ch	ild restraints	43
	Precautions on child restraints	43
	Child restraint and ISOFIX information	44
	ISOFIX child restraint system	49
	Child restraint anchorage	50
	Child restraint installation using ISOFIX	50
	Child restraint installation using three-point type	
	seat belt	53
up	pplemental Restraint System (SRS)	57
	Precautions on Supplemental Restraint	
	System (SRS)	57
	Supplemental air bag systems	60
	Repair and replacement procedure	64





MSSS0133Z

Sit upright and well back

A WARNING

- Do not ride in a moving vehicle when the seatback is reclined. This can be dangerous. The shoulder belt will not be against your body. In an accident, you could be thrown into it and receive neck or other serious injuries. You could also slide under the lap belt and receive serious internal injuries.
- For the most effective protection when the vehicle is in motion, the seat should be upright. Always sit well back and upright in the seat with both feet on the floor and adjust the seat properly. See "Precautions on seat belt usage" (P.36).
- Do not adjust the driver's seat while driving. The seat may move suddenly and could cause loss of control of the vehicle.
- After adjustment, gently rock in the seat to make sure it is securely locked.


- Do not leave children unattended inside the vehicle. They could unknowingly activate switches or controls, or make the vehicle move. Unattended children could become involved in serious accidents.
- To help avoid risk of injury or death through unintended operation of the vehicle and/or its systems, do not leave children, people who require the assistance of others, or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.
- The seatback should not be reclined any more than needed for comfort. Seat belts are most effective when the passenger sits well back and upright in the seat. If the seatback is reclined, the risk of sliding

- under the lap belt and being injured is increased.
- When returning the seatbacks to the upright position, be certain that they are completely secured in the latched position. If they are not completely secured, passengers may be injured in an accident or sudden stop. When operating the seatback release always rock the seatback afterwards to check that it is locked.
- When the vehicle is being used to carry cargo, properly secure all cargo to help prevent it from sliding or shifting. Do not place cargo higher than the seatbacks. In a sudden stop or collision, unsecured cargo could cause personal injury.
- Never allow anyone to ride in the luggage area or on the rear seat when it is in the folded-down position. Use of these areas by passengers without proper restraints could result in serious injury or death in an accident or sudden stop.

CAUTION

When adjusting the seat positions, be sure not to contact any moving parts to avoid possible injuries and/or damage.

FRONT SEATS



Seat adjustment

Forward and backward:

Pull the lever (1) up and hold it while sliding the seat forward or backward to the preferred position. Release the lever to lock the seat in position.

Reclining:

CAUTION

When moving the seats forward or backward, or returning a rear-reclined seatback to its upright position, make sure you hold onto the seatback while operating. If the seatback is not held, the seat or seatback will move suddenly and could cause injury.

To recline the seatback pull and hold the lever 2 up, keeping the lever fully lifted, and lean back. To bring the seatback forward pull and hold the lever up, keeping the lever fully lifted, and lean forward. Keep the lever fully lifted whilst adjusting the seatback. Release the lever when the seatback is stationery and in the desired recline position.

The reclining feature allows adjustment of the seatback for occupants of different sizes for added comfort and to help obtain proper seat belt fit, see "Precautions on seat belt usage" (P.36). Also, the seatback can be reclined to allow occupants to rest when the vehicle is stopped and the vehicle is in the P (Park) position or N (Neutral) position with the parking brake applied.

Seat lifter (where fitted):


Repeatedly pull up or push down the adjusting lever 3, to adjust the seat height to the desired position.

SEAT HEATER (where fitted)

The front seats can be warmed by built-in heaters. The switches are located on the instrument panel and can be operated independently of each other. For more information on the seat heater, see "Seat heater (where fitted)" (P.33).

REAR SEATS


Folding



The luggage compartment loading capacity can be increased by folding the rear seats forward as shown

To fold the seat:

1. Ensure head restraints are properly stowed, see "Head restraints" (P.34).



HEAD RESTRAINTS

- When folding the rear seat forward, the outer seat belts can be stored out of the way using the storage holder shown in the illustration.
- Release the seatback lock by pressing the latch.
- 4 Fold the seat forward as shown


To return the seat to an upright position:

- Make sure the seat belts are clear of the seat latch mechanism.
- 2. Lift the seatback up and push firmly to lock.
- Ensure lock button has returned to up position and pull seatback firmly to check it is securely latched.

CAUTION

Always ensure that the seat belt is not trapped in the release lever or any other vehicle part.

FRONT ARMREST




A WARNING

Head restraints supplement the other vehicle safety systems. They may provide additional protection against injury in certain rear end collisions. Adjust the head restraints properly, as specified in this section. Check the adjustment after someone else uses the seat. Do not attach anything to the head restraint stalks or remove the head restraint. Do not use the seat if the head restraint has been removed. If the head restraint was removed, reinstall and properly adjust the head restraint before an occupant uses the seating position. Failure to follow these instructions can reduce the effectiveness of the head restraints. This may increase the risk of serious injury or death in a collision.


- The rear head restraints have a single locking notch to secure them to the seat frame.
- Proper Adjustment:
 - For the rear head restraint, raise into locking position before use. The seat should not be occupied with the head restraint in the lower storage position.
- If the head restraint has been removed, ensure that it is reinstalled and locked in place before riding in that designated seating position.

REAR HEAD RESTRAINT COMPONENTS



- Removable head restraint
- 2. Single notch
- Lock knob
- Stalks

REMOVE




The console box lid A can be used as an armrest.

Use the following procedure to remove the head restraint.

- 1. Fold the rear seat forward. See "Rear seats" (P.33).
- 2. Pull the head restraint up to the highest position.
- 3. Push and hold the lock knob.
- Remove the head restraint from the seat
- 5. Store the head restraint properly in a secure place so it is not loose in the vehicle.
- 6. Reinstall and properly adjust the head restraint before an occupant uses the seating position.

INSTALL




Align the head restraint stalks with the holes in the seat. Make sure that the head restraint is facing the correct direction. The stalk with the adjustment notch must be installed in the hole with the lock knob.

- 2. Push and hold the lock knob and push the head restraint down.
- 3. Properly adjust the head restraint before an occupant uses the seating position.


ADJUST

Raise



To raise the head restraint, pull it up as shown.

Lower



To lower, push and hold the lock knob and push the head restraint down as shown

SEAT BELTS

PRECAUTIONS ON SEAT BELT USAGE

If you are wearing your seat belt properly adjusted, and you are sitting upright and well back in your seat, your chances of being injured or killed in an accident and/or the severity of injury may be greatly reduced. NISSAN strongly encourages you and all of your passengers to buckle up every time you drive, regardless of whether or not your seating position includes a supplemental air bag.



Sit upright and well back



Sit upright and well back

A WARNING

Be sure to observe the following warnings when using seat belts. Failure to do so could increase the chance and/or severity of injury in an accident.


- Every person who drives or rides in this vehicle should use a seat belt at all times.
 Children should be in the rear seats and in an appropriate restraint.
- The seat belt should be properly adjusted to a snug fit. Failure to do so may reduce the effectiveness of the entire restraint system and increase the chance or severity of injury in an accident. Serious injury or death can occur if the seat belt is not worn properly.
- Always route the shoulder belt over your shoulder and across your chest. Never put the belt behind your back, under your arm or across your neck. The belt should be

- away from your face and neck, but not falling off your shoulder.
- Position the lap belt as low and snug as possible AROUND THE HIPS, NOT THE WAIST. A lap belt worn too high could increase the risk of internal injuries in an accident.
- Seat belts are designed to bear upon the bony structure of the body, and should be worn low across the front of the pelvis or the pelvis, chest and shoulders, as applicable; wearing the lap section of the belt across the abdominal area must be avoided.
- No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.
- Seat belts should be adjusted as firmly as possible, consistent with comfort, to provide the protection for which they have been designed. A slack belt will greatly reduce the protection afforded to the wearer.
- Be sure the seat belt tongue is securely fastened to the proper buckle.
- Do not wear the seat belt inside out or twisted. Doing so may reduce its effectiveness.
- Do not allow more than one person to use the same seat belt.

- Never carry more people in the vehicle than there are seat belts.
- Each belt assembly must only be used by one occupant; it is dangerous to put a belt around a child being carried on the occupant's lap.
- If the seat belt warning light illuminates continuously while the ignition switch is in the ON position, with all doors closed, and all seat belts fastened, it may indicate a malfunction in the system. Have the system checked by a NISSAN dealer or qualified workshop.
- No changes should be made to the seat belt system. For example, do not modify the seat belt, add material, or install devices that may change the seat belt routing or tension. Doing so may affect the operation of the seat belt system. Modifying or tampering with the seat belt system may result in serious personal iniurv.
- Once a seat belt pre-tensioner has been activated, it cannot be reused and must be replaced together with the retractor. See a NISSAN dealer or qualified workshop.
- Removal and installation of the pre-tensioner seat belt system components should be done by a NISSAN dealer or qualified workshop.
- All seat belt assemblies, including retractors and attaching hardware, should be inspected by a NISSAN dealer or qualified workshop after any collision. NISSAN re-

- commends that all seat belt assemblies in use during a collision be replaced unless the collision was minor and the belts show no damage and continue to operate properly. Seat belt assemblies not in use during a collision should also be inspected and replaced if either damage or improper operation is noted.
- All child restraints and attaching hardware should be inspected after any collision. Always follow the restraint manufacturer's inspection instructions and replacement recommendations. The child restraints should be replaced if they are damaged.
- It is essential to replace the entire assembly after it has been worn in a severe impact even if damage to the assembly is not obvious.
- Care should be taken to avoid contamination of the webbing with polishes, oils and chemicals, and particularly battery acid. Cleaning may safely be carried out using mild soap and water. The belt should be replaced if webbing becomes frayed, contaminated or damaged.

CHILD SAFETY



Infants or small children

NISSAN recommends that infants or small children should be seated in a child restraint on the rear seats. According to accident statistics, children are safer when properly restrained in the rear seat than in the front seat. See "Child restraints" (P.43). You should choose a child restraint system which fits your vehicle and always follow the manufacturer's instructions for installation and use.

Children

Children who are too large for child restraints should be seated and restrained by the seat belts that are provided.

The use of a booster seat (commercially available) may help to avoid the shoulder belt coming across the face or neck area of a child's seating position. The booster seat should raise the child so that the shoulder belt is properly positioned across the top, middle portion of the shoulder and the lap belt is low on the hips. The booster seat should fit the vehicle's seat. Once the child has grown so the shoulder belt is no longer on or near the face and neck, use the shoulder belt without the booster seat.

A WARNING

Never let a child stand or kneel on any seat and do not allow a child in the cargo areas while the vehicle is moving.

PREGNANT WOMEN

NISSAN recommends that pregnant women use seat belts. The seat belt should be worn snug, and always position the lap belt as low as possible around the hips, not the waist. Place the shoulder belt over your shoulder and across your chest. Never put the lap/shoulder belt over your abdominal area. Contact your doctor for specific recommendations.

INJURED PERSONS

NISSAN recommends that injured persons use seat belts, depending on the injury. Check with your doctor for specific recommendations.

SEAT BELT REMINDERS

The Seat Belt Reminders will alert the driver if any occupant in the vehicle does not have their seat belt securely fastened.

A WARNING

NISSAN strongly encourages you and all of your passengers to buckle up every time you drive. Failure to do so may reduce the effectiveness of the entire restraint system and greatly increase the chance or severity of being injured in an accident. Serious injury or death can occur if the seat belt is not worn.

Some infants and children may not require use of the vehicle's seat belt when using an appropriate ISOFIX Child Restraint System with integrated restraints. See "Child restraints" (P.43).

👸 Seatbelt warning light


The Seat Belt Warning Light located in the camera cover (Windscreen)will immediately illuminate whenever the ignition switch is placedin the ON or START position and any vehicle occupant's seat belt isnot fastened. See "Warning lights, indicator lights and audible reminders" (P.72) for further details.

If the vehicle speed exceeds 15 km/h (approximately 10 MPH) thelight will flash and a chime will sound.

The chime will continue for at least 95 seconds or until all occupantshave their seat belts securely fastened.

The light will continue to flash until all occupants have theirseat belts securely fastened.

Occupant status display



In addition to the Seat Belt Warning Light, the Occupant Status Display will be shown in the Vehicle Information Display (See "Vehicle information display" (P.82)) when any vehicle occupant's seat belt is not fastened.

The display will remain until occupants have their seat belts securely fastened, or until acknowl-

edged by the driver pushing the <OK> steering wheel switch.

If an occupant unfastens a seat belt or the vehicle speed exceeds 15 km/h (approximately 10 MPH) while a seat belt is not fastened, the Occupant Status Display will reappear.

The driver seat is always considered occupied.



Red Seat with exclamation symbol: The corresponding seat is occupied and seat belt is not fastened.



Green Seat with tick symbol: The corresponding seat belt is fastened.



Grey Seat: The corresponding seat is unoccupied.

A WARNING

- Lighter passengers, including children, may not be detected by the Seat Belt Reminder system.
- When heavy cargo is placed on the seat, the Seat Belt Reminder may be triggered. Such cargo should be secured in the boot as in a sudden stop or collision, unsecured cargo could cause injury. Only use the seat belts to restrain people or universal Child Restraint Systems (See "Child restraints" (P.43)). Never use them to secure cargo, as this may cause damage, reducing their

effectiveness during an accident when subsequently worn by people.

- If the Seat Belt Warning Light illuminates continuously while the ignition switch is in the ON position, with all doors closed, and all seat belts fastened, it may indicate a malfunction in the system. Have the system checked by a NISSAN dealer or qualified workshop.
- No changes should be made to the Seat Belt Reminder system.

THREE-POINT TYPE SEAT BELT

A WARNING

- Do not ride in a moving vehicle when the seatback is reclined. This can be dangerous. The shoulder belt will not be against vour body. In an accident, you could be thrown into it and receive neck or other serious iniuries. You could also slide under the lap belt and receive serious internal injuries.
- For the most effective protection when the vehicle is in motion, the seat should be upright. Always sit well back and upright in the seat with both feet on the floor and adjust the seat belt properly.

Fastening the seat belts

- 1. Adjust the seat. (See "Seats" (P.32).)
- Slowly pull the seat belt out of the retractor

and insert the tongue into the buckle until you hear and feel the latch engage.



- The retractor is designed to lock during a sudden stop or on impact. A slow pulling motion permits the belt to move and allows vou some freedom of movement in the seat.
- If the seat belt cannot be pulled from its fully retracted position, firmly pull the belt and release it. Then smoothly pull the belt out of the retractor.
- 3. Position the lap belt portion low and snug on the hips as shown.



Pull the shoulder belt portion toward the retractor to take up extra slack. Be sure the shoulder belt is routed over your shoulder and across your chest.

Unfastening the seat belts



To unfasten the seat belt, push the button on the buckle. The seat belt automatically retracts.

Checking seat belt operation

Seat belt retractors are designed to lock seat belt movement by two separate methods:


- When the belt is pulled quickly from the retractor.
- When the vehicle slows down rapidly.

To increase your confidence in the seat belts, check the operation as follows:

 Grasp the shoulder belt and pull forward quickly. The retractor should lock and restrict further belt movement.

If the retractor does not lock during this check or if you have any questions about seat belt operation, see a NISSAN dealer or qualified workshop.

Shoulder belt height adjustment



The shoulder belt anchor height should be adjusted to the position that is best for you. (See "Precautions on seat belt usage" (P.36).)


To adjust, pull the adjustment button $\ensuremath{\mbox{\scriptsize \Large{0}}}$, and then


move the shoulder belt anchor to the preferred position ② so that the belt passes over the centre of the shoulder. The belt should be away from your face and neck, but not falling off of your shoulder. Release the adjustment button to lock the shoulder belt anchor into position.

A WARNING

- After adjustment, release the adjustment button and then try to move the shoulder belt anchor up and down to make sure that it is securely fixed in position.
- The shoulder belt anchor height should be adjusted to the position that is best for you. Failure to do so may reduce the effectiveness of the entire restraint system and increase the chance or severity of injury in an accident.

Centre of rear seat






Selecting the correct seat buckle:

The centre seat belt tongue is longer than outer seat belt tongues, and can only be fastened into the centre seat belt buckle. The outer seat belt tongues can only be fastened into the outer buckles.

Rear seat belt storage



When folding the rear seat forward, the outer seat belts can be stored out of the way using the storage holder shown in the illustration.

SEAT BELT MAINTENANCE

- To clean the seat belt webbing, apply a mild soap solution or any solution recommended for cleaning upholstery or carpets. Then wipe with a cloth and allow the seat belts to dry in the shade. Do not allow the seat belts to retract until they are completely dry.
- If dirt builds up in the shoulder belt guide of the seat belt anchors, the seat belts may retract slowly. Wipe the shoulder belt guide with a clean, dry cloth.
- Periodically check to see that the seat belt and the metal components, such as buckles, tongues, retractors, flexible wires and anchors, work properly. If loose parts, deterioration, cuts or other damage on the webbing is found, the entire seat belt assembly should be replaced.

A WARNING

- The pre-tensioner seat belt cannot be reused after activation. It must be replaced together with the retractor as a unit.
- If the vehicle is involved in a frontal collision but the pre-tensioner is not activated, be sure to have the pre-tensioner system checked and, if necessary, replaced by a NISSAN dealer or qualified workshop.
- No unauthorised changes should be made to any components or wiring of the pretensioner seat belt system. This is to prevent accidental activation of the pretensioner seat belt or damage to the pretensioner seat belt operation. Tampering with the pre-tensioner seat belt system may result in serious personal injury.
- Work on and around the pre-tensioner system should be done by an authorised NISSAN dealer or qualified workshop. Installation of electrical equipment should also be done by a NISSAN dealer or qualified workshop. Unauthorised electrical test equipment and probing devices should not be used on the pre-tensioner seat belt system.
- If you need to dispose of the pre-tensioner or scrap the vehicle, contact a NISSAN dealer or qualified workshop. Correct pretensioner disposal procedures are set forth in the appropriate NISSAN Service Manual. Incorrect disposal procedures could cause personal injury.

CHILD SAFETY

The front seat pre-tensioner seat belt system is activated in conjunction with the front air bag system. It helps tighten the seat belt when the vehicle is involved in certain types of collisions by restraining the seat occupants via the seat belt retractor.

The pre-tensioner is encased with the seat belt's retractor. These seat belts are used in the same way as conventional seat belts.

Additionally, the driver's side pre-tensioner seat belt system is also equipped with a lap pretensioner. Both the retractor pre-tensioner and lap pre-tensioner provide significant protection against injury in an accident and increase the safety performance of your vehicle.

When the pre-tensioner seat belt system activates, smoke is released and a loud noise may be heard. The smoke is harmless, but care should be taken not to inhale it as it may cause irritation and choking.

When the ignition switch is in the ON or START position, the Supplemental Restraint System (SRS) air bag warning light will illuminate. The SRS air bag warning light will turn off after approximately 7 seconds if the system is operational. If any of the following conditions occur, the air bag and/or pretensioner seat belt need servicing and your vehicle must be taken to the nearest NISSAN dealer or qualified workshop.

- The air bag warning light remains on after approximately 7 seconds.
- The air bag warning light flashes intermittently.

 The air bag warning light does not come on at all.

Unless checked and repaired, the Supplemental Restraint System (SRS) and/or pre-tensioner seat belt may not function properly. It must be checked and repaired.

When selling your vehicle, we request that you inform the buyer about the pre-tensioner seat belt system and guide the buyer to the appropriate sections in this Owner's Manual.

Children need adults to help protect them.

They need to be properly restrained.

In addition to the general information in this manual, child safety information is available from many other sources, including doctors, teachers, government traffic safety offices, and community organisations. Every child is different, so be sure to learn the best way to transport your child.

There are two basic types of child restraint system:

- Rear-facing child restraints
- Front-facing child restraints

The proper restraint depends on the child's size. Generally, infants (up to about 1 year and less than 9 kg) should be placed in rear-facing child restraints. Front-facing child restraints are available for children who outgrow rear-facing child restraints and are at least 1 year old.

A WARNING

Infants and children need special protection. The vehicle's seat belts may not fit them properly. The shoulder belt may come too close to the face or neck. The lap belt may not fit over their small hip bones. In an accident, an improperly fitting seat belt could cause serious or fatal injury. Always use appropriate child restraints.

A child restraint may be secured in the vehicle by using either the ISOFIX child restraint system or with the vehicle seat belt, see "Child restraints" (P.43) for more information.

NISSAN recommends that all pre-teens and children be restrained in the rear seat. According

CHILD RESTRAINTS

to accident statistics, children are safer when properly restrained in the rear seat than in the front seat.

This is especially important because your vehicle has a supplemental restraint system (air bag system) for the front passenger. (See "Supplemental Restraint System (SRS)" (P.57).)

INFANTS AND SMALL CHILDREN

NISSAN recommends that infants and small children be seated in a child restraint system. You should choose a child restraint system that fits your vehicle and the child, and always follow the manufacturer's instructions for installation and use


LARGER CHILDREN

Children who are too large for a child restraint system should be seated and restrained by the seat belts that are provided. If the child's seating position has a shoulder belt that fits close to the face or neck, the use of a booster seat (commercially available) may help overcome this. The booster seat should raise the child so that the shoulder belt is properly positioned across the top, middle portion of the shoulder and the lap belt is low on the hips. The booster seat should also fit the vehicle seat. Once the child has grown so that the shoulder belt is no longer on or near the face or neck of the child, use the shoulder belt without the booster seat. In addition, there are many types of child restraint system available for larger children that should be used for maximum protection.

LEGAL REQUIREMENTS

Check any legal requirements applicable in your location. For example, the U.K. has legal requirements to use child restraints based on height and age, see "Child restraints" (P.43) for more information

PRECAUTIONS ON CHILD RESTRAINTS



A WARNING

- Infants and small children should always be placed in an appropriate child restraint system while riding in the vehicle. Failure to use a child restraint system can result in serious injury or death.
- Infants and small children should never be carried on your lap. It is not possible for even the strongest adult to resist the forces of a severe accident. The child could be crushed between the adult and parts of the vehicle. Also, do not put the same seat belt around a child and yourself.
- Infants and children need special protection. The vehicle's seat belts may not fit them properly. The shoulder belt may come too close to the face or neck. The lap belt may not fit over their small hip

bones. In an accident, an improperly fitting seat belt could cause serious or fatal injury.

- NISSAN recommends that the child restraint system be installed in the rear seat.
 According to accident statistics, children are safer when properly restrained in the rear seat rather than in the front seat.
- Child restraint systems specially designed for infants and small children are available from several manufacturers. When selecting any child restraint systems, place your child in the child restraint system and check the various adjustments to be sure that the child restraint system is compatible with your child. Always follow the manufacturer's instructions for installation and use.
- Follow all of the child restraint manufacturer's instructions for installation and use.
 When purchasing a child restraint, be sure to select one which will fit your child and vehicle. It may not be possible to properly install some types of child restraint in your vehicle.
- Check the child restraint system in your vehicle to be sure that it is compatible with the vehicle's seat belt system.
- For a front-facing child restraint system, check to make sure the shoulder belt does not fit close to the child's face or neck.
- Never install a rear-facing child restraint system on the front passenger seat without first deactivating the passenger air bag with the front passenger air bag

switch (where fitted), see "Supplemental front-impact air bag system" (P.61). In a frontal collision, supplemental front-impact air bags inflate with great force. An inflating supplemental front-impact air bag could seriously injure or kill your child.

- Adjustable seatbacks should be positioned to fit the child restraint system, but as upright as possible.
- If the seat belt in the position where a child restraint system is installed requires a locking device and if it is not used, injuries could result from a child restraint system tipping over during normal vehicle braking or cornering.
- After attaching a child restraint system, test it before you place the child in it. Push it from side to side and tug it forward to make sure that it is held securely in place. The child restraint system should not move more than 25 mm (1 in). If the restraint is not secure, tighten the belt as necessary, or install the restraint in another seat and test it again.
- If a child restraint system is not anchored properly, the risk of a child being injured in a collision or a sudden stop greatly increases.
- Improper use of a child restraint system can increase the risk or severity of injury for both the child and other occupants in the vehicle.
- When the child restraint system is not in use, keep it secured with the ISOFIX child

restraint system or a seat belt to prevent it from being thrown around in case of a sudden stop or accident.

NISSAN recommends that infants and small children be seated in a child restraint system. You should choose a child restraint system that fits your vehicle and always follow the manufacturer's instructions for installation and use. In addition, there are many types of child restraint systems available for larger children that should be used for maximum protection.

CAUTION

Remember that a child restraint left in a closed vehicle can become very hot. Check the seating surface and buckles before placing your child in a child restraint.

CHILD RESTRAINT AND ISOFIX INFORMATION

When selecting any child restraint, keep the following points in mind:

- Choose a child restraint that complies with the latest European safety standard, ECE Regulation 44.04 and i-Size regulation R129 where applicable.
- Place your child in the child restraint and check the various adjustments to be sure the child restraint is compatible with your child.
 Always follow all of the recommended procedures.
- Check the child restraint in your vehicle to be sure it is compatible with the vehicle's seat belt system.

 Refer to the tables later in this section for a list of the recommended fitment positions and the approved child restraints for your vehicle.

Approved universal child restraint positions

		Seating position					
Ma	ss group	Front passenger seat Air bag ON	Front passenger seat Air bag OFF	Rear outer seat	Rear centre seat		
0	<10 kg	Х	U, L *3	U, L *2	U *2, 4		
0+/I	<18 kg	X	U, L *3	U, L *2	U *2, 4		
1	9 to 18 kg	X	U, L *3	U, L *1, 2	U *1, 2, 4		
11/111	15 to 36 kg	X	U, L *3	U, L *1, 2	U *1, 2, 4		

- U: Suitable for "universal" category child restraints, forward and rearward facing, approved for use in this mass group
- L: Suitable for particular child restraints systems of the "Specific for the vehicle", "Restricted", or "Semi-universal" categories, approved for this mass group.

 X: Seat position not suitable for children in this mass group.
- 1 (Rear seats only) Move the head restraint to the upper most position or, if necessary, remove it in case of any interference with the child restraint. Do not remove head restraint when using a booster cushion only.
- *2 Adjust the front seat(s) slide position sufficiently forward and/or the seat height adjustment (where fitted) to the upper most position to ensure no contact between child seat and back of front seat.
- *3 Move the front passenger seat as far rearward as possible and/or the seat height adjustment (where fitted) to the upper most position.
- *4 Suitable only for "Universal" category of child restraints. Do not install child restraints with support leg.

Approved ISOFIX child restraint positions

				Seating	position		
Mass group		Front passenger seat Air bag ON	Front passen- ger seat Air bag OFF	Rear outer seat	Rear centre seat	Recommended Child Restraint Systems	
Carnicat	F	ISO/L1	×	×	×	×	
Carry-cot	G	ISO/L2	×	×	×	×	_
0 (< 10 kg)	Е	ISO/R1	×	×	IL *2	×	
	E	ISO/R1	×	×	IL *2	×	Britax Roemer Babysafe Plus SHR II + Isofix Base
0+ (< 13 kg)	D	ISO/R2	×	×	IL *2	×	biltax Roeifiel Babysale Plus SHR II + Isolix Base
	С	ISO/R3	×	×	IL *2	×	
	D	ISO/R2	×	×	IL *2	×	
	С	ISO/R3	×	×	IL *2	×	
I (9 to 18 kg)	В	ISO/F2	×	×	IUF/IL *1,2	×	Britax Roemer Duo Plus
	B1	ISO/F2X	×	×	IUF/IL *1,2	×	
	Α	ISO/F3	×	×	IUF/IL *1,2	×	
II (15 to 25 kg)	-	_	×	×	IUF/IL *1,2	×	Britax Roemer KidFix ² R *3
II/III (15-36kg)	_	-	×	×	IL *1,2	×	Britax Roemer KidFix ² R *3

- Position not suitable for ISOFIX child restraint system.
- IUF: Suitable for ISOFIX forward-facing child restraint system approved for this weight (mass) group.
- Suitable for particular ISOFIX child restraint systems of the "Specific for the vehicle", "Restricted", or "Semi-universal" categories, approved for this type of vehicle.
- (Rear seats only) Move the head restraint to the upper most position or, if necessary, remove it in case if any interference with the child restraint. Do not remove head restraint when using a booster cushion only.
- *2: Adjust the front seat(s) slide position sufficiently forward and/or the seat height adjustment (where fitted) to the uppermost position to ensure no contact between child seat and back of front seat.

*3: Use this child restraint system with backrest attached and 'SecureGuard' in place.

Approved i-Size ISOFIX child restraint positions

		Seating			
	Front passenger seat Air bag ON	Front passenger seat Air bag OFF	Rear outer seat	Rear centre seat	Recommended Child Restraint Systems
i-Size child restraint sys- tems	×	×	i-U *1,2	×	Maxi Cosi 2way Pearl & 2wayFIX BeSafe iZi Kid X2 i-Size
Carris	×	×	i-UF *1,2	Х	BeSafe iZi Flex FIX i-Size

- Seating position not suitable for i-Size "universal" child restraint systems.
- i-U: Suitable for i-Size "ISOFIX" forward and rearward facing child restraint systems.
- i-UF: Suitable for forward-facing i-Size "universal" child restraint systems only.
- (Rear seats only) Move the head restraint to the upper most position or, if necessary, remove it in case if any interference with the child restraint. Do not remove head restraint when using a booster cushion only.
- Adjust the front seat(s) slide position sufficiently forward and/or the seat height adjustment (where fitted) to the uppermost position to ensure no contact between child seat and back of front seat.

A WARNING

Never install a rear-facing child restraint system on the front passenger seat without first deactivating the passenger air bag with the front passenger air bag switch (where fitted), see "Supplemental front-impact air bag system" (P.61). In a frontal collision, supplemental front-impact air bags inflate with great force. An inflating supplemental front-impact air bag could seriously injure or kill your child.

NOTE:


Child restraints approved to ECE Regulation NO. 44.04 are clearly marked with the categories such as Universal, Semi-universal or ISOFIX.

ISOFIX CHILD RESTRAINT SYSTEM


Your vehicle is equipped with special anchor points that are used with ISOFIX child restraint systems.

ISOFIX lower anchor point locations

The ISOFIX anchor points are provided to install child restraints in the rear outer seating positions only. Do not attempt to install a child restraint in the centre position using the ISOFIX anchors.




Rear ISOFIX anchor point locations



ISOFIX cover removal (rear seats)

The ISOFIX anchor points are located, under covers labelled ISOFIX, at the bottom of the rear seat cushions as shown. To access an ISOFIX anchor point insert your finger into the cover and pull the cover off as shown.

ISOFIX child restraint anchor attachments



Anchor attachment

ISOFIX child restraints include two rigid attach-

ments that can be connected to two anchors located in the seat. Check your child restraint for a label stating that it is compatible with the ISOFIX child restraints. This information may also be in the instructions provided by the child restraint manufacturer.

ISOFIX child restraints generally require the use of a top tether strap or other anti-rotation devices such as support legs. When installing ISOFIX child restraints, carefully read and follow the instructions in this manual and those supplied with the child restraints

CHILD RESTRAINT ANCHORAGE

Your vehicle is designed to accommodate a child restraint system on the rear seat. When installing a child restraint system, carefully read and follow the instructions in this manual and those supplied with the child restraint system.


A WARNING

- Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle. Doing so could damage the child restraint anchorages. The child restraint will not be properly installed using the damaged anchorage, and a child could be seriously injured or killed in a collision.
- The child restraint top tether strap may be damaged by contact with the parcel shelf or items in the luggage area. Remove the

parcel shelf from the vehicle or secure it in the luggage area. See "Parcel shelf" (P.117). Also secure any items in the luggage area. Your child could be seriously injured or killed in a collision if the top tether strap is damaged.

Anchorage location

Rear passenger seat anchors:



Anchor points are located on the seatback behind the rear outer seating positions and should only be used for child restraints in the rear outer positions.

CHILD RESTRAINT INSTALLATION USING ISOFIX

A WARNING

Attach ISOFIX child restraints only at the specified locations. For the ISOFIX lower anchor locations, see "ISOFIX lower anchor point locations" (P.49). If a child restraint is


- not secured properly, your child could be seriously injured or killed in an accident.
- Do not install child restraints that require the use of a top tether strap to seating positions that do not have a top tether anchor.
- Do not secure a child restraint in the centre rear seating position using the ISOFIX lower anchors. The child restraint will not be secured properly.
- Inspect the lower anchors by inserting your fingers into the lower anchor area and feeling to make sure there are no obstructions over the ISOFIX anchors, such as seat belt webbing or seat cushion material. The child restraint will not be secured properly if the ISOFIX anchors are obstructed.
- Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstance are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.
- Never install a rear-facing child restraint system on the front passenger seat without first deactivating the passenger air bag with the front passenger air bag switch (where fitted), see "Supplemental front-impact air bag system" (P.61). In a frontal collision, supplemental front-impact air bags inflate with great force. An inflating supplemental front-impact air bag could seriously injure or kill your child.

- NISSAN recommends that a child restraint be installed on the rear seat. However, if vou must install a child restraint on the front passenger's seat, move the passenger's seat to the rearmost position.
- Child restraints for infants must be used in the rear-facing direction and therefore must not be used on the front passenger's seat when the front passenger's air bag has not been deactivated.

Installation on front passenger and rear outer seats For details of front seat adjustment during installation, see "Child restraint installation using threepoint type seat belt" (P.53).


Front-facing:

Be sure to follow the manufacturer's instructions for the proper use of your child restraint. Follow these steps to install a front-facing child restraint on the front passenger and rear outer seats using ISOFIX:



Steps 1 and 2

- 1. Position the child restraint on the seat (1).
- 2. Secure the child restraint anchor attachments to the ISOFIX lower anchors (2).
- 3. The back of the child restraint should be secured against the vehicle seat back. If necessary, adjust or remove the head restraint to obtain the correct child restraint fit. (See "Head restraints" (P.34).) If the head restraint is removed, store it in a secure place. Be sure to install the head restraint when the child restraint is removed. If the seating position does not have an adjustable head restraint and it is interfering with the proper child restraint fit, try another seating position or a different child restraint



Step 4

- Shorten the rigid attachment to have the child restraint firmly tightened; press downward 3 and rearward 4 firmly in the centre of the child restraint with your knee to compress the vehicle seat cushion and seatback.
- If the child restraint is equipped with a top tether strap, route the top tether strap and secure the tether strap to the tether anchor point. (See "Child restraint anchorage" (P.50).)
- If the child restraint is equipped with other anti-rotation devices such as support legs, use them instead of the top tether strap following the child restraint manufacturer's instructions




Step 7

- Test the child restraint before you place the child in it (5). Push the child restraint from side to side and tug it forward to make sure that it is held securely in place.
- Check to make sure that the child restraint is properly secured prior to each use. If the child restraint is loose, repeat steps 3 through 7.

Rear-facing:

Be sure to follow the manufacturer's instructions for the proper use of your child restraint. Follow these steps to install a rear-facing child restraint on the front passenger and rear outer seats using ISOFIX:



Steps 1 and 2


- . Position the child restraint on the seat ①.
- Secure the child restraint anchor attachments to the ISOFIX lower anchors (2).



Step 3

 Shorten the rigid attachment to have the child restraint firmly tightened; press downward 3 and rearward 4 firmly in the centre of the child restraint with your hand to compress the vehicle seat cushion and seatback. If any contact occurs between the child restraint and the front seat, slide the front seat forward until contact no longer occurs.

- 4. If the child restraint is equipped with a top tether strap, route the top tether strap and secure the tether strap to the tether anchor point. (See "Child restraint anchorage" (P.50).)
- 5. If the child restraint is equipped with other anti-rotation devices such as support legs, use them instead of the top tether strap following the child restraint manufacturer's instructions.




Step 6

- 6. Test the child restraint before you place the child in it 6. Push the child restraint from side to side and tug it forward to make sure that it is held securely in place.
- 7. Check to make sure that the child restraint is properly secured prior to each use. If the child restraint is loose, repeat steps 3 through 6.

CHILD RESTRAINT INSTALLATION USING THREE-POINT TYPE SEAT BELT

Installation on rear seats


Front-facing:



Step 1


Be sure to follow the manufacturer's instructions for the proper use of your child restraint. Follow these steps to install a front-facing child restraint on the rear seats using 3-point type seat belt without automatic locking mode:

1. Position the child restraint on the seat ①. If any contact occurs between the child restraint and the front seat, slide the front seat forward until contact no longer occurs.



Step 2

- 2. Route the seat belt tongue through the child restraint and insert it into the buckle (2) until you hear and feel the latch engage.
- 3. To prevent slack in the seat belt webbing, it is necessary to secure the seat belt in place with locking devices attached to the child restraint.



Step 4

4. Remove any additional slack from the seat belt; press downward ③ and rearward ⑥ firmly in the centre of the child restraint with your knee to compress the vehicle seat cushion and seatback while pulling up on the seat belt.


If the child restraint is equipped with a top tether strap, route the top tether strap and secure the tether strap to the tether anchor point. (See "Child restraint anchorage" (P.50).)



Step 5

- Test the child restraint before you place the child in it (§). Push the child restraint from side to side and tug it forward to make sure that it is held securely in place.
- Check to make sure that the child restraint is properly secured prior to each use. If the child restraint is loose, repeat steps 3 through 5.


Rear-facing:



Step 1

Be sure to follow the manufacturer's instructions for the proper use of your child restraint. Follow these steps to install a rear-facing child restraint on the rear seats using 3-point type seat belt without automatic locking mode:

1. Position the child restraint on the seat (1).




Step 2

- Route the seat belt tongue through the child restraint and insert it into the buckle 2 until you hear and feel the latch engage.
- To prevent slack in the seat belt webbing, it is necessary to secure the seat belt in place with locking devices attached to the child restraint.



Step 4


4. Remove any additional slack from the seat belt; press downward 3 and rearward 4 firmly in the centre of the child restraint with your hand to compress the vehicle seat cushion and seatback while pulling up on the seat belt.



Step 5

- 5. Test the child restraint before you place the child in it (5). Push the child restraint from side to side and tug it forward to make sure that it is held securely in place.
- 6 Check to make sure that the child restraint is properly secured prior to each use. If the child restraint is loose, repeat steps 3 through 5.

Installation on front passenger's seat



A WARNING


- Never install a rear-facing child restraint system on the front passenger seat without first deactivating the passenger air bag with the front passenger air bag switch (where fitted), see "Front passenger air bag status light (where fitted)" (P.62). In a frontal collision, supplemental front-impact air bags inflate with great force. An inflating supplemental front-impact air bag could seriously injure or kill your child.
- NISSAN recommends that a child restraint be installed on the rear seat. However, if you must install a child restraint on the front passenger's seat, move the passenger's seat to the rearmost and highest position.
- Child restraints for infants must be used in the rear-facing direction and therefore

must not be used on the front passenger's seat when the front passenger's air bag has not been deactivated.

Front-facing:

Be sure to follow the manufacturer's instructions for the proper use of your child restraint. Follow these steps to install a front-facing child restraint on the front passenger's seat using a 3-point type seat belt without automatic locking mode:

Turn off the front passenger air bag using the front passenger air bag switch. (See "Front passenger air bag status light (where fitted)" (P.62).) Turn the ignition switch to the ON position and make sure that the front air bag status light == illuminates.




Step 2

- 2. Move the seat to the rearmost position (1).
- 3. Position the child restraint in the seat.




Steps 4 and 5

- Route the seat belt tongue through the child restraint and insert it into the buckle 3 until you hear and feel the latch engage.
- To prevent slack in the seat belt webbing, it is necessary to secure the seat belt in place with locking devices attached to the child restraint.



Step 6

6. Remove any additional slack from the seat belt; press downward (a) and rearward (5) firmly in the centre of the child restraint with your knee to compress the vehicle seat cushion and seatback while pulling up on the seat belt.



Steps 7 and 8


7. Test the child restraint before you place the child in it. Push the child restraint from side to

- side and tug it forward to make sure that it is held securely in place.
- Check to make sure that the child restraint is properly secured prior to each use. If the child restraint is loose, repeat steps 5 through 8.

Rear facing:

If you must install a child restraint system in the front seat, follow these steps:

 Turn off the front passenger air bag using the front passenger air bag switch. (See "Front passenger air bag status light (where fitted)" (P.62).) Turn the ignition switch to the ON position and make sure that the front air bag status light illuminates.




Steps 2 and 3

- . Move the seat to the rearmost position ①.
- 3. Position the child restraint system in the front passenger seat.

Always follow the child restraint system manufacturer's instructions for installation and use.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)



Route the seat belt tongue through the child restraint system and insert it into the buckle until you hear and feel the latch engage.

To prevent slack in the lap belt, secure the shoulder belt in place with a locking clip (A). Use a locking clip attached to the child restraint system, or one which is equivalent in dimensions and strength.

Be sure to follow the child restraint system manufacturer's instructions for belt routing.

- Slide the seat forwards so that the seat belt fully tightens the child restraint system and the child restraint reaches the vehicle dashboard.
- 6. Test the child restraint system before you place the child in it. Check that it does not tilt too far from side to side. Try to tug it forwards and check if it is held securely in place.

PRECAUTIONS ON SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

This Supplemental Restraint System (SRS) section contains important information concerning the driver's and passenger's supplemental front impact air bags, front seat-mounted side-impact supplemental air bags, roof-mounted curtain side-impact air bags, and pre-tensioner seat belts.

Supplemental front-impact air bag system

This system can help cushion the impact force to the head and chest area of the driver and/or front passenger in certain frontal collisions. The supplemental front-impact air bag is designed to inflate on the front where the vehicle is impacted.

Front seat-mounted side-impact supplemental air bag system (where fitted)

This system can help cushion the impact force to the chest and pelvis areas of the driver and front passenger in certain side-impact collisions. The front seat-mounted side-impact supplemental air bag is designed to inflate on the side where the vehicle is impacted.

Roof-mounted curtain side-impact supplemental air bag system (where fitted)

This system can help cushion the impact force to the head of the driver and passengers in front and rear outer seating positions in certain side-impact collisions. The roof-mounted curtain side-impact supplemental air bag is designed to inflate on the side where the vehicle is impacted.

The SRS is designed to **supplement** the crash

protection provided by the driver and front passenger seat belts and is not designed to substitute them. Seat belts should always be correctly worn and the driver and front passenger seated a suitable distance away from the steering wheel, instrument panel and front door finishers. For additional information, see "Seat belts" (P.36).

After placing the ignition switch in the ON or START position, the air bag warning light will illuminate. The air bag warning light will turn off after approximately 7 seconds if the system is operational. For further details, see "Warning lights, indicator lights and audible reminders" (P.72).

The air bag will operate only when the ignition switch is in the ON or START position.




Correct (rear) seating positions

Driver and front passenger air bags:

A WARNING

- The supplemental front-impact air bags ordinarily will not inflate in the event of a side impact, rear impact, rollover, or lower severity frontal collision. Always wear the seat belts to help reduce the risk or severity of injury in accidents.
- The seat belts and the supplemental frontimpact air bags are most effective when you are sitting well back and upright in the seat. The front-impact air bags inflate with great force. If you are unrestrained, leaning forward, sitting sideways, or out of position in any way, you are at greater risk of injury or death in an accident. You may also receive serious or fatal injuries from the supplemental front-impact air bag if you are up against it when it inflates. Always sit back against the seatback and as far away as practical from the steering wheel. Always use the seat belts.



A WARNING

- Never install a child restraint system in the front seat. An inflating supplemental frontimpact air bag could seriously injure or kill your child (see "Air bag warning labels" (P.59)).
- Children may be severely injured or killed when the air bags inflate if they are not properly restrained, see "Child restraints" (P.43).
- Never let children ride unrestrained or extend their hands or face out of the window. Do not attempt to hold them in your lap or arms.

Side and curtain air bags (where fitted):

A WARNING

- The front seat-mounted side-impact supplemental air bags and roof-mounted curtain side-impact supplemental air bags ordinarily will not inflate in the event of a front impact, rear impact, rollover, or lower severity side collision. Always wear the seat belts to help reduce the risk or severity of injury in accidents.
- The seat belts, the front seat-mounted side-impact supplemental air bags and roof-mounted curtain side-impact supplemental air bags are most effective when you are sitting well back and upright in the seat. The front seat-mounted side-impact supplemental air bags and roof-mounted curtain side-impact supplemental air bags

- inflate with great force. If you and your passengers are unrestrained, leaning forward, sitting sideways, or out of position in any way, you and your passengers are at greater risk of injury or death in an accident.
- Do not allow anyone to place their hands, legs, or face near the front seat-mounted side-impact supplemental air bags and roof-mounted curtain side-impact supplemental air bags on the sides of the seat-back of the front seats or near the side roof rails. Do not allow anyone sitting in the front seats or rear outer seats to extend their hands out of the windows or lean against the doors.
- When sitting in the rear seats, do not hold onto the seatback of the front seats. If the front seat-mounted side impact supplemental air bags and roof-mounted curtain side-impact supplemental air bags inflate, you may be seriously injured. Be especially careful with children, who should always be properly restrained.
- Do not use seat covers on the front seatbacks. They may interfere with the front seat-mounted side-impact supplemental air bag inflations.

NOTE:


For an overview, see "Seat belts and supplemental restraint system" (P.16).

Pre-tensioner seat belt system

The pre-tensioner seat belt system may activate with the supplemental air bag system in certain types of collisions.

Working with the seat belt retractor and anchor, it helps tighten the seat belt the instant the vehicle becomes involved in certain types of collisions, helping to restrain front seat occupants. See "Pretensioner seat belt system" (P.41).

Air bag warning labels



- SRS air bag warning label: The warning label is located on the surface of the front passenger sun visor.
- SRS side air bag warning label: The warning label is located on the side of the passenger side centre pillar, and on the base of the front seats

SRS front-impact passenger air bag:

The warning label (1) is located on the sun visor.

"NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur."


The BACK SEAT is the SAFEST place for children aged 12 and under. Always use seat belts and child restraints. For maximum safety protection in all types of crashes, you must always wear your safety belt. Do not sit or lean unnecessarily close to the airbag. Do not place any objects over the airbag or between the airbag and yourself. If the airbag warning light stays on or is flashing when the ignition switch is placed in the ON position, go to a NISSAN dealer or qualified workshop. Airbags can only be removed or disposed of by a NISSAN dealer or qualified workshop.

Be sure to read the "AIRBAG LABEL" description at the end of this manual

In vehicles equipped with a front-impact passenger air bag system, use a rear-facing child restraint system only on the rear seats.

When installing a child restraint system in your vehicle, always follow the child restraint system manufacturer's instructions for installation. For information, see "Child restraints" (P.43).

SRS air bag warning light



The SRS air bag warning light, displaying 🥻 in the camera cover (Windscreen), monitors the circuits of the supplemental front-impact air bag, front seat-mounted side-impact supplemental air bag (where fitted), supplemental curtain side-impact air bags (where fitted), and pre-tensioner seat belt systems. The circuits monitored by the SRS air bag warning light are the diagnosis sensor unit, crash zone sensor, satellite sensors, front impact air bag modules, front seat-mounted side-impact supplemental air bag modules (where fitted), roofmounted curtain side-impact supplemental air bag modules (where fitted), pre-tensioner seat belt systems, and all related wiring.

After placing the ignition switch in the ON or START position, the supplemental air bag warning light illuminates. The air bag warning light will turn off after approximately 7 seconds if the system is operational.


Have the air bag systems and/or pre-tensioner

seat belt systems serviced at the nearest NISSAN dealer or qualified workshop if any of the following conditions occur:

- The SRS air bag warning light remains on after approximately 7 seconds.
- The SRS air bag warning light flashes intermittently.
- The SRS air bag warning light does not illuminate at all.

Under these conditions, the air bag systems and/ or pre-tensioner seat belt systems may not operate properly. They must be checked and repaired. Contact a NISSAN dealer or qualified workshop immediately.

SUPPLEMENTAL AIR BAG SYSTEMS



- Crash zone sensor
- 2. Supplemental front-impact air bag modules
- 3. Supplemental side-impact air bag modules
- Supplemental curtain side-impact air bag modules
- Supplemental curtain side-impact air bag inflators
- Satellite sensors
- 7. Pre-tensioner seat belt retractors
- 8. Supplemental air bag diagnosis sensor unit

A WARNING

- Do not place any objects on the steering wheel pad. Do not place any objects between the driver and steering wheel pad. Such objects may become dangerous projectiles and cause injury if a supplemental air bag inflates.
- Immediately after inflation, several supplemental air bag system components will be hot. Do not touch them: you may severely burn yourself.
- No unauthorised changes should be made to any components or wiring of the supplemental air bag systems. This is to prevent accidental inflation of the supplemental air bags or damage to the supplemental air bag systems.
- Do not make unauthorised changes to your vehicle's electrical system, suspension system or front end structure. This could affect proper operation of the supplemental air bag systems.
- Tampering with the supplemental air bag systems may result in serious personal injury. Tampering includes changes to the steering wheel by placing materials over the steering wheel pad and above, and by installing additional trim materials around the supplemental air bag systems.
- Work around and on the supplemental air bag systems should be done by a NISSAN dealer or qualified workshop. The SRS wiring should not be modified or disconnected. Unauthorised electrical test equip-

- ment and probing devices should not be used on the supplemental air bag systems.
- The SRS wiring harness connectors are vellow and/or orange for easy identification.
- Never install a rear-facing child restraint system on the front passenger seat without first deactivating the passenger air bag with the front passenger air bag switch (where fitted), see "Front passenger air bag status light (where fitted)" (P.62). In a frontal collision, supplemental front-impact air bags inflate with great force. An inflating supplemental front-impact air bag could seriously injure or kill your child.

When the air bags inflate, a fairly loud noise may be heard, followed by the release of smoke. This smoke is not harmful and does not indicate a fire. However, care should be taken not to inhale it, as it may cause irritation and choking. Occupants with a history of breathing difficulties, such as asthma, should get fresh air promptly.

Supplemental air bags, along with the use of seat belts, help to cushion the impact force on the chest of the front occupants. Curtain air bags help to cushion the impact force to the head of occupants in the front and rear outer seating positions. They can help save lives and reduce serious injuries. However, an inflating side air bag and curtain air bag may cause abrasions or other injuries. Supplemental side air bags and curtain air bags do not provide restraint to the lower body.

Supplemental front-impact air bag system

The driver's supplemental front-impact air bag is located at the centre of the steering wheel. The passenger's supplemental front-impact air bag is located at the instrument panel above the glove box.

The supplemental front-impact air bag system is designed to inflate in higher severity frontal collisions, although it may inflate if the forces in another type of collision are similar to those of a higher severity frontal impact. It may not inflate in certain frontal collisions. Vehicle damage (or lack of it) is not always an indication of proper supplemental front-impact air bag system operation.

A WARNING

Never install a rear-facing child restraint system on the front passenger seat without first deactivating the passenger air bag with the front passenger air bag switch (where fitted), see "Front passenger air bag status light (where fitted)" (P.62). In a frontal collision, supplemental front-impact air bags inflate with great force. An inflating supplemental front-impact air bag could seriously injure or kill vour child.

For models with front passenger air bag switch: The front passenger air bag is designed to be turned off using the front passenger air bag switch, only if absolutely necessary.

Front passenger air bag status light (where fitted):

PASSENGER OFF AIR BAG


MSSS0676Z



A WARNING

 Since your vehicle is equipped with a front passenger air bag, it is not permitted to install a rearward facing child restraint on the front passenger seat unless the front passenger air bag has been deactivated first.

 Do not fit a rearward facing child seat on the front passenger seat if the air bag activation/deactivation system (where fitted) is malfunctioning. Your vehicle must immediately be taken to a NISSAN dealer or qualified workshop in such a situation.



The front passenger air bag status lights == 4 and empty are located in the camera cover.

When the ignition is placed in the **ON** position, the front passenger air bag status ON and OFF lights illuminate and then turn off or remain on depending on the front passenger air bag status.

When the ignition is placed in the ON position and the front passenger air bag is active, both the front passenger air bag status OFF light and the Supplemental Restraint System (SRS) air bag warning light * in the combination meter ① will turn off after about 7 seconds.


The front passenger air bag status ON light will illuminate and then turn off after about 60 seconds when the front passenger air bag switch is in the ON position.

The front passenger air bag status OFF light will illuminate and remain on as long as the front passenger air bag switch is in the OFF position.

If the front passenger air bag status light operates in a way other than described above, the front passenger air bag may not function properly. Have the system checked, and if necessary repaired, by a NISSAN dealer or qualified workshop promptly.

Front passenger air bag switch (where fitted):


The front passenger air bag can be turned off with the front passenger air bag switch (A) located inside the glove box.



- Air bag switch (where fitted)
- Left Hand Drive models
- Right Hand Drive models

To turn off the front passenger air bag:


- Place the ignition switch in the **OFF** position.
- Open the glove box.
- Push and turn the front passenger air bag switch to the OFF position.
- Place the ignition switch in the ON position. The front passenger air bag status OFF light will illuminate and remain on.



To turn on the front passenger air bag:

- Place the ignition switch in the OFF position.
- Open the glove box.
- Push and turn the front passenger air bag switch to the ON position.
- 4. Place the ignition switch in the ON position. The front passenger air bag status ON light will illuminate ①, and after about 60 seconds turn off.

Supplemental side-impact air bag system



The supplemental side air bags are located in the outside of the seatback of the front seats.

The supplemental side-impact air bag system is designed to inflate in higher severity side collisions, although it may inflate if the forces in another type of collision are similar to those of a higher severity side impact. It may not inflate in certain side collisions. Vehicle damage (or lack of it) is not always an indication of proper supplemental sideimpact air bag system operation.

The seat belts should be correctly worn and the driver and passenger seated upright, and as far as is practical, away from the side air bag. The side air bags inflate quickly in order to help protect the front occupants. Because of this, the force of the side air bags inflating can increase the risk of injury if the occupant is too close to, or is against, these air bag modules during inflation. The side air bag will deflate quickly after the collision is over.

Supplemental side-impact curtain air bag system (where fitted)

The supplemental side-impact curtain air bag is located in the roof side trims.

The supplemental side-impact curtain air bag system is designed to inflate in higher severity side collisions, although it may inflate if the forces in another type of collision are similar to those of a higher severity side impact. It may not inflate in certain side collisions. Vehicle damage (or lack of it) is not always an indication of proper supplemental curtain side-impact air bag system operation.

The seat belts should be correctly worn and the rear seat passengers should be seated as far away as practical from the door finishers and side roof rails. The curtain air bags inflate quickly in order to help protect the front and rear occupants. Because of this, the force of the curtain air bag inflating can increase the risk of injury if the occupant is too close to, or is against, these air bag modules during inflation. The curtain air bag will deflate quickly after the collision is over.

A WARNING

- Directly after inflation, several air bag system components will be hot. Do not touch them; you may severely burn yourself.
- No unauthorised changes should be made to any components or wiring of the air bag system. This is to prevent accidental inflation of the air bag or damage to the air bag system.
- Tampering with the air bag system may result in serious personal injury. Tamper-

ing includes making changes to the steering wheel and the instrument panel assembly by placing material over the steering pad and above the dashboard, or by installing additional trim material around the air bag system.

- Do not attach any objects to the steering wheel pad or to the instrument panel.
 Objects attached to the steering wheel pad and instrument panel may become dangerous projectiles and cause injury if the air bag inflates.
- Work on and around the air bag system should be done by a NISSAN dealer or qualified workshop. Installation of electrical equipment should be done by a NISSAN dealer or qualified workshop. The yellow SRS wiring harnesses* should not be modified or disconnected. Unauthorised electrical test equipment and probing devices should not be used on the air bag system.
- * SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or on the complete harness, for easy identification.

REPAIR AND REPLACEMENT PROCEDURE

A WARNING

Once the air bags have been inflated, the air bag modules will not function and must be replaced. The air bag modules must be replaced by a NISSAN dealer or qualified

- workshop. The inflated air bag modules cannot be repaired.
- The air bag systems should be inspected by a NISSAN dealer or qualified workshop if there is any damage to the front end portion of the vehicle.
- When selling your vehicle, we request that you inform the buyer about the air bag system and guide the buyer to the appropriate sections in this Owner's Manual.
- If you need to dispose of the SRS or scrap the vehicle, contact a NISSAN dealer or qualified workshop. Correct disposal procedures are set forth in the appropriate NISSAN Service Manual. Incorrect disposal procedures could cause personal injury.

The air bags and pre-tensioner seat belts are designed to activate on a one-time-only basis. As a reminder, unless the SRS air bag warning light is damaged, the SRS air bag warning light remains illuminated after inflation has occurred. The repair and replacement of the SRS should be done only by a NISSAN dealer or qualified workshop.

When maintenance work is required on the vehicle, information about the air bags, pre-tensioner seat belts and related parts should be pointed out to the person performing the maintenance. The ignition switch should always be in the LOCK position when working under the bonnet or inside the vehicle.

2 Instruments and controls

Meters and gauges				
Models with analogue meter and colour display	67			
Models with full-screen display	68			
Speedometer	69			
Trip odometer/distance to empty meter	69			
Fuel gauge	70			
POWER GAUGE	70			
BATTERY CHARGE INDICATOR	70			
Instrument panel brightness control	70			
Warning lights, indicator lights and				
audible reminders				
Checking lights				
Warning lights				
Indicator lights				
Audible reminders	81			
Vehicle information display	82			
Operation	83			
Settings	86			
General information and warnings	92			
Vehicle information display driving aids warnings a	and			
guidance messages	98			
Clock and outside air temperature 1	104			
Wiper and washer switch 1	105			
Windscreen 1	105			
Rear window 1	106			

ThermaClear Heated Windscreen button	107			
ThermaClear Heated Windscreen (where fitted)	107			
Defogger switch	108			
Headlight and turn signal switch	108			
Headlight switch	108			
Turn signal switch	111			
Fog light switch	111			
Front fog light (where fitted)	111			
Rear fog light	111			
Headlight aiming control	112			
Headlight aiming control switch	112			
Horn				
Heated steering wheel (where fitted)	112			
Heated steering wheel (where fitted)	112			
Seat heating (where fitted)				
Power outlet				
Wireless charger (where fitted)	114			
Wireless charger indicator	114			
Operation of the wireless charger	115			
Storage	115			
Storage trays	115			
Glove box	115			
Console box	116			
Card holder	116			
Cup holders	116			


Bottle holder	116	Windows	119
Coat hooks	117	Power windows	119
Seat pocket (where fitted)	117	Interior lights	121
Parcel shelf	117	Front room light	121
Luggage compartment/boot floor		Front map lights	121
(where fitted)	118	Rear interior light	121
Luggage hooks	119	Luggage compartment light	122

METERS AND GAUGES

NOTE:

For an overview, see "Meters and gauges" (P.25) and see "Instrument panel" (P.23).

MODELS WITH ANALOGUE METER AND COLOUR DISPLAY




- 1. Power gauge
- Warning and indicator lights
- Vehicle information display
- Speedometer
- Battery charge indicator
- Fuel gauge

CAUTION

- For cleaning, use a soft cloth, dampened with water. Never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or cause discolouration to the lens.
- Do not spray any liquid such as water on the meter lens. Spraying liquid may cause the system to malfunction.

MODELS WITH FULL-SCREEN DISPLAY




- 1. Power gauge
- 2. Vehicle information display
- 3. Warning and indicator lights
- 4. Speedometer

- 5. Battery charge indicator
- 6. Personal display
- 7. Fuel gauge

CAUTION

- For cleaning, use a soft cloth, dampened with water. Never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or cause discolouration to the lens.
- Do not spray any liquid such as water on the meter lens. Spraying liquid may cause the system to malfunction.

Changing the meter screen view (models with full-screen display)



For models with full-screen display, the meter screen view can be changed from Classic View to Enhanced View to expand the vehicle information display area.

To change the meter screen view:


- 1. Push the control switch on the left side of the steering wheel.
 - [Shortcut Menu] appears on the vehicle information display area.
- 2. Select [Change Display View] by pressing ' A ' to scroll up or ' ▼ ' to scroll down and press the <OK> button to change the view.

SPEEDOMETER



The speedometer indicates the vehicle speed. Scale resolution on the meter varies with models.

TRIP ODOMETER/DISTANCE TO EMPTY METER



Example

The odometer is displayed in the vehicle information display when the ignition is in the **ON** position.

The available range or distance to empty meter (1) displays an estimation of the distance that can be driven before refuelling is required.

The odometer 2 displays the total distance the vehicle has been driven

Trip odometer display

A trip odometer is available in the vehicle information display. See "Vehicle information display" (P.82).

FUEL GAUGE

The fuel gauge is active when the ignition is in the **ON** position.

The gauge may move slightly during braking, turning, acceleration, or when going uphill or downhill.

The symbol indicates that the fuel filler lid is located on the right side of the vehicle.

NOTE:

A low fuel warning comes on in the vehicle information display when the fuel level is getting low. Refuel as soon as it is convenient. There should be a small reserve of fuel in the tank when the fuel gauge needle reaches the empty level.

The available range or distance to empty is permanently shown at the bottom of the vehicle information display.


CAUTION

Refill the fuel tank before the range displays [0], or [---], and the gauge registers empty to protect the HEV System.

Do not attempt to drive the vehicle without fuel.

Do not attempt to restart the vehicle if the engine stops due to lack of fuel until additional fuel is added.

POWER GAUGE



CHARGE

This area shows the regeneration status. Regenerated energy is used to charge the Liion battery.

② ECO

The hybrid system is optimising the fuel efficiency by occasionally starting and stopping the engine, depending on the circumstances.

③ POWER

The engine and electric motor are both driving the vehicle for optimum performance.

④ Charge indicator

The gauge indicates the approximate remaining Lithium-ion (Li-ion) battery charge available to drive the vehicle.

The power gauge indicates the total amount of power the hybrid system is delivering. When decelerating or braking, it indicates the amount of regenerative power that is produced.


BATTERY CHARGE INDICATOR


The gauge indicates the approximate remaining Lithium ion (Li-ion) battery charge available to drive the vehicle.

NOTE:

 Li-ion battery temperature affects the amount of remaining Li-ion battery charge.

INSTRUMENT PANEL BRIGHTNESS CONTROL





The instrument brightness control switch can be operated when the ignition is in the ${\bf ON}$ position. When the switch is operated, the brightness adjustment mode appears at the bottom of the vehicle information display.


Push the \oplus side of the switch to brighten the meter panel lights and instrument panel lights. The bar (1) moves to the \oplus side.

Push the \ominus side of the switch to dim the lights. The bar (1) moves to the \ominus side.

When the instrument brightness control is not operated for a few seconds the brightness adjustment mode no longer appears.

WARNING LIGHTS, INDICATOR LIGHTS AND AUDIBLE REMINDERS

(19)	Anti-lock Braking System (ABS) warning light	×	Traffic Sign Assist* (TSA) Mute warning light	≣A	High beam assist indicator light*
(0)	Brake warning light (red) Non-electric parking brake system warning light	/ _\	Lane Assist* warning light	(]≢	Rear fog light indicator light*
≕	Charge warning light	$\langle T \rangle$	Low tyre pressure warning light*	EDdE	Side light indicator light
(C)	Electric Parking brake indicator light*	<u> </u>	Master warning light	\$	Slip indicator light*
⊛!	Electric Power Steering warning light	\$	Seat belt (driver and front passenger) warning light	⇔ ⇔	Turn signal/hazard indicator lights
~ ~ ~.	Engine oil pressure light	*	Supplemental Restraint System (SRS) air bag warning light	#	READY to drive indicator light
***	Intelligent Emergency Braking (IEB) system warning light*	(A) HOLD	Automatic brake hold indicator light	EV	Electric Vehicle mode indicator
₽	Hands OFF warning light	(Dipped beam indicator light	e-Pedal	e-Pedal ON indicator lights
(I) OFF	Approaching Vehicle Sound for Pedestrians (VSP) OFF warning light	£	Door lock indicator light**	e-Pedal OFF	e-Pedal OFF indicator lights



^{*:} where fitted

^{**:} located above the inside mirror

CHECKING LIGHTS

With all doors closed, apply the parking brake, fasten the seat belts and place the ignition in the ON position without starting the hybrid system. The following lights (where fitted) will illuminate:



The following lights (where fitted) come on briefly and then go off:

(O), (U), (回), 斧, 桑, 夷, 🗀 🖦 (D)Y, 🦠 If any light fails to come on, it may indicate a

burned-out bulb or an open circuit in the electrical system. Have the system checked, and repaired promptly by a NISSAN dealer or qualified workshop.

Some indicators and warnings are also displayed in the vehicle information display between the speedometer and tachometer, see "Vehicle information display" (P.82).

NOTE:

The set or light (where fitted), located on the centre console below the heater and air conditioner controls, comes on and stays on depending on the front passenger air bag switch position.

WARNING LIGHTS

Also see "Vehicle information display" (P.82).

Anti-lock Braking System (ABS) warning light

When the ignition is placed in the ON position, the Anti-lock Braking System (ABS) warning light illuminates and then turns off. This indicates the ABS is operational.

If the ABS warning light illuminates while the hybrid system is running, or while driving, it may indicate the ABS is not functioning properly. Have the system checked by a NISSAN dealer or qualified workshop.

If an ABS malfunction occurs, the anti-lock function is turned off. The brake system then operates normally, but without anti-lock assistance (see "Brake system" (P.272)).



BRAKE warning light (red)

A WARNING

- Your brake system may not be working properly if the warning light is on. Driving could be dangerous. Even if you judge the brake system to be safe, drive carefully to the nearest service station for repairs. Otherwise, have your vehicle towed because driving it could be dangerous.
- Pressing the brake pedal when the ignition is not in the ON position and/or when the brake fluid level is low may increase the stopping distance, and braking will require greater pedal effort as well as pedal travel.
- If the brake fluid level is below the minimum or <MIN> mark on the brake fluid reservoir, do not drive until the brake system has been checked at a NISSAN dealer or qualified workshop.

When the ignition is placed in the **ON** position, the light remains illuminated for a few seconds. If the light illuminates at any other time, it may indicate that the brake system is not functioning properly. If the BRAKE warning light illuminates, stop the vehicle immediately and contact a NISSAN dealer or qualified workshop.

Low brake fluid warning light:

When the ignition is in the ON position, the light warns of a low brake fluid level. If the light illuminates while the ignition is in the ON position with the parking brake not applied, stop the vehicle and perform the following steps:

- 1. Check the brake fluid level. If brake fluid level is low, add fluid and have the system checked by a NISSAN dealer or qualified workshop. See "Brake fluid" (P.323).
- 2. If the brake fluid level is correct, have the warning system checked by a NISSAN dealer or qualified workshop.

Charge warning light

When the ignition is in the ON position, the charge warning light illuminates. After starting the hybrid system, the charge warning light turns off. This indicates that the charging system is operational.

If the charge warning light illuminates while the engine is running, or while driving, it may indicate that the charging system is not functioning properly and may need servicing.

If the charge warning light remains illuminated, have the charging system checked by a NISSAN dealer or qualified workshop promptly.

CAUTION

Do not continue driving if the charge warning light is on.

Electric Parking brake indicator light (where fitted)

	·	Me	Switch			
	Indicator	Warning light	Master warn- ing light	Display text	Buzzer	LED
Parking brake applied	(B)	-	-	-	-	LED
Dynamic park- ing brake	(P)	_	<u> </u>	[Release Parking Brake]	Beep	LED
System failure	Depends on status	Warning light ON	<u> </u>	-	-	Depends on status
Parking brake switch pressed with- out brake pedal pressed	(P)	_	_	[Press Brake Pedal]	-	LED
Parking brake cannot be re- leased auto- matically	(D)	-	-	[Release Parking Brake]	-	LED
Parking brake malfunction	(P) Flashing	Warning light ON	-	-	-	LED Flashing

The electric parking brake indicator light indicates that the electric parking brake system is operating.

When the ignition is placed in the ON position, the electric parking brake indicator light illuminates. When the hybrid system started and the parking brake is released, the warning light turns off.

If the parking brake is not fully released, the electric parking brake indicator light remains on. Be sure that the electric parking brake indicator light has turned off before driving.

If the electric parking brake warning light illuminates or flashes while the electric parking brake system hybrid system light (yellow) illuminates, it may indicate that the electric parking brake system is not functioning properly. Have the brake system checked, and if necessary repaired, by a NISSAN dealer or qualified workshop promptly.

A WARNING

- Your brake system may not be working properly if the warning light is on. Driving could be dangerous. Even if you judge the brake system to be safe, drive carefully to the nearest service station for repairs. Otherwise, have your vehicle towed because driving it could be dangerous.
- Pressing the brake pedal when the ignition is not in the ON position and/or when the brake fluid level is low may increase the stopping distance and braking will require greater pedal effort as well as pedal travel.
- If the brake fluid level is below the minimum or <MIN> mark on the brake fluid reservoir, do not drive until the brake

system has been checked at a NISSAN dealer or qualified workshop.

For further parking brake operation information see "Electric parking brake" (P.138).

[A] Electric Power Steering warning light

A WARNING

- If the hybrid system is not running or is turned off while driving, the power assist for the steering will not work. Steering will be harder to operate.
- When the Electric Power Steering warning light illuminates with the hybrid system running, there will be no power assist for the steering. You will still have control of the vehicle but the steering will be harder to operate. Have the Electric Power Steering system checked by a NISSAN dealer or qualified workshop.

When the ignition is placed in the ON position, the Electric Power Steering warning light illuminates. After starting the hybrid system, the Electric Power Steering warning light turns off. This indicates that the electric power steering system is operational.

If the Electric Power Steering warning light illuminates while the hybrid system is running, it may indicate the Electric Power Steering system is not functioning properly and may need servicing. Have the Electric Power Steering system checked by a NISSAN dealer or qualified workshop. See "Power steering" (P.271).



Lane Assist warning light

For details about the Lane Assist system see "Lane Assist system" (P.215).



Lane Assist OFF warning light

For details about the Lane Assist system see "Lane Assist system" (P.215).



Engine oil pressure warning light

When the ignition switch is in the ON position, the engine oil pressure warning light illuminates. After starting the hybrid system, the engine oil pressure warning light turns off. This indicates that the oil pressure sensors in the engine are operational.

If the engine oil pressure warning light illuminates or blinks while the hybrid system is running, it may indicate that the engine oil pressure is low.

Stop the vehicle safely as soon as possible. Stop the hybrid system immediately and call a NISSAN dealer or qualified workshop.

CAUTION

- Running the hybrid system with the engine oil pressure warning light illuminated could cause serious damage to the engine.
- The engine oil pressure warning light is not designed to indicate a low oil level. The oil level should be checked using the dipstick. (See "Engine oil" (P.320).)

Intelligent Emergency Braking (IEB) system warning light (where fitted)

This light illuminates when the Intelligent Emergency Braking (IEB) system is set to OFF in the vehicle information display.

If the light illuminates when the IEB system is ON, it may indicate that the system is unavailable. See "Intelligent Emergency Braking (IEB) system (where fitted)" (P.250) for more details.

Disabling the ESP system with the vehicle information display causes the IEB system to become unavailable. This is not a malfunction.



Intelligent Driver Attention Alert failure warning light (where fitted)

This warning light (yellow) illuminates if the Intelligent Driver Attention Alert system malfunctions.

For details about the Intelligent Driver Attention Alert system, see "Intelligent Driver Alertness (where fitted)" (P.262).



Intelligent Driver Attention Alert warning light (where fitted)

This warning light (white) illuminates when the Intelligent Driver Attention Alert system operates.

For details about the Intelligent Driver Attention Alert system, see "Intelligent Driver Alertness (where fitted)" (P.262).



A Hands OFF warning light

When the Steering Assist is activated, it monitors the driver's steering wheel operation.

Vehicles fitted with ProPILOT Assist: If the steering wheel is not operated or the driver takes his/ her hands off the steering wheel for a period of time, the warning light illuminates. If the driver does not operate the steering wheel after the warning light has been illuminated, an audible alert sounds and the warning flashes in the vehicle information display, followed by a quick brake application to request the driver to take control of the vehicle again. If the driver remains unresponsive, the vehicle will automatically turn on the hazard lights and slow to a complete stop. (See "Hands on detection" (P.243).)

Approaching Vehicle Sound for Pedestrians (VSP) OFF warning light

The Approaching Vehicle Sound for Pedestrians (VSP) warning light illuminates when a malfunction occurs in the VSP system.

Have the VSP system checked by a NISSAN dealer or qualified workshop.



(D) BRAKE system warning light (yellow)

A WARNING

Depressing the brake pedal when the power switch position is not in the ON or READY to drive position and/or low brake fluid level may increase the stopping distance and braking will require greater pedal effort as well as pedal travel.

- If the brake fluid level is below the minimum or MIN mark on the brake fluid reservoir, do not drive until the brake system has been checked by a NISSAN dealer or qualified workshop.
- The cooperative regenerative brake system may not be working properly if the brake system warning light illuminates when the READY to drive indicator light is ON. If you judge it to be safe, drive carefully to the nearest service station for repairs. Otherwise, have your vehicle towed because driving could be dangerous.

The brake system warning light functions for both the cooperative regenerative brake and the electronically driven intelligent brake systems. When the power switch is placed in the ON position or in the READY to drive position, the light remains illuminated for about a few seconds. If the light illuminates at any other time, it may indicate that the cooperative regenerative brake and/or the electronically driven intelligent brake systems are not functioning properly. Have the system checked by a NISSAN dealer or qualified workshop. If the brake warning light (red) also illuminates, stop the vehicle immediately and contact a NISSAN dealer or qualified workshop. For additional information, see "Brake system" (P.272).

If this warning light illuminates it may also indicate that the electric parking brake system is not functioning properly.



Hybrid system fail indicator light

When the power switch is in the ON position, the hybrid system warning fail indicator light illuminates and then turns off

If the hybrid system fail indicator light illuminates while driving, it may indicate that there is a malfunction in the hybrid system.

Stop the vehicle in a safe place immediately and contact a NISSAN dealer.



(1) Low tyre pressure warning light (where fitted)

Your vehicle is equipped with a Tyre Pressure Monitoring System (TPMS) (where fitted) that monitors the tyre pressure of all tyres except the spare.

The low tyre pressure warning light warns of low tyre pressure or indicates that the TPMS is not functioning properly.

After the ignition is placed in the ON position, this light illuminates for about 1 second and turns off.

Low tyre pressure warning:

If the vehicle is being driven with low tyre pressure, the warning light will illuminate. A low tyre pressure warning (e.g., [Low tyre pressure]) also appears in the vehicle information display.

When the low tyre pressure warning light illuminates, you should stop and adjust the tyre pressure of all 4 tyres to the recommended COLD tyre pressure shown on the tyre placard located on the driver side centre pillar, see "Tyre placard" (P.346). The low tyre pressure warning light does not automatically turn off when the tyre pressure is adjusted. After the tyre is inflated to the recommended pressure, the vehicle must be driven at speeds above 25 km/h (16 MPH) to activate the TPMS and turn off the low tyre pressure warning light. Use a tyre pressure gauge to check the tyre pressure.

The low tyre pressure (e.g., [Low tyre pressure Add Air]) warning appears each time the ignition is placed in the **ON** position as long as the low tyre pressure warning light remains illuminated.

For additional information, see "General information and warnings" (P.92) and "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186).

TPMS resetting must also be performed after a tyre or a wheel is replaced, or the tyres are rotated.

Depending on a change in the outside temperature, the low tyre pressure warning light may illuminate even if the tyre pressure has been adjusted properly. Adjust the tyre pressure to the recommended COLD tyre pressure again when the tyres are cold, and reset the TPMS.

If the low tyre pressure warning light still continues to illuminate after the resetting operation, it may indicate that the TPMS is not functioning properly. Have the system checked by a NISSAN dealer or qualified workshop.

For additional information, see "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186) and "General information and warnings" (P.92).

TPMS malfunction:

If the TPMS is not functioning properly, the low tyre pressure warning light will flash for approximately 1 minute when the ignition is placed in the ON position. The light will remain on after 1 minute. Have the system checked by a NISSAN dealer or qualified workshop. The low tyre pressure warning does not appear if the low tyre pressure warning light illuminates to indicate a TPMS malfunction.

For additional information, see "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186).

A WARNING

- Radio waves could adversely affect electric medical equipment. Those who use a pacemaker should contact the electric medical equipment manufacturer for the possible influences before use.
- If the light does not illuminate with the ignition placed in the ON position, have the vehicle checked by a NISSAN dealer or qualified workshop as soon as possible.
- If the low tyre pressure warning light illuminates while driving, avoid sudden steering manoeuvres or abrupt braking, reduce vehicle speed, pull off the road to a safe location and stop the vehicle as soon as possible. Driving with under-inflated tyres may permanently damage the tyres and increase the likelihood of tyre failure. Serious vehicle damage could occur and may lead to an accident and could result in serious personal injury. Check the tyre pressure for all four tyres. Adjust the tyre

pressure to the recommended COLD tyre pressure shown on the tyre placard, located on the driver side centre pillar, to turn the low tyre pressure warning light off. If the light still illuminates while driving after adjusting the tyre pressure, a tyre may be flat. If you have a flat tyre, repair it with the emergency tyre puncture repair kit (where fitted) or replace it with a spare tyre (where fitted) as soon as possible.

- After adjusting the tyre pressure, be sure to reset the TPMS. Unless the resetting is performed, the TPMS will not warn of the low tyre pressure correctly.
- When a spare tyre is mounted or a wheel is replaced, the TPMS will not function and the low tyre pressure warning light will flash for approximately 1 minute. The light will remain on after 1 minute. Contact a NISSAN dealer or qualified workshop as soon as possible for tyre replacement and/ or system resetting.
- Replacing tyres with those not originally specified by NISSAN could affect the proper operation of the TPMS.

CAUTION

- The TPMS is not a substitute for regular tyre pressure checking. Be sure to check the tyre pressure regularly.
- If the vehicle is being driven at speeds of less than 25 km/h (16 MPH), the TPMS may not operate correctly.

Be sure to install the specified size of tyres to all four wheels correctly.

Master warning light

When the ignition is in the ON position, the master warning light illuminates if any of the following are displayed in the vehicle information display (see "Vehicle information display" (P.82)):

- Door/Boot Open Warning
- Parking Brake release warning
- Low tyre pressure warning (where fitted)
- System Fault Display
- No key warning (where fitted)
- Key ID incorrect warning (where fitted)
- Intelligent Key system warning (where fitted)
- Chassis Control System fault warning

If the driver assist system warnings (where fitted) appear in the vehicle information display, the master warning light also illuminates. See "Lane Assist system" (P.215), and/or "Intelligent Emergency Braking (IEB) system (where fitted)" (P.250).

Seat belt warning light

The seat belt warning light reminds you to fasten your seat belts. The light illuminates whenever the ignition is placed in the ON or START position and any vehicle occupant's seat belt is not fastened. It remains illuminated until the seat belts are fastened

If the vehicle speed exceeds 15 km/h (approximately 10 MPH) the light will flash and a chime will sound. The chime will continue for at least 95 seconds or until all occupants have their seat belts securely fastened.

The light will continue to flash until all occupants have their seat belts securely fastened. See "Seat belt reminders" (P.38) or "Precautions on seat belt usage" (P.36).

Supplemental Restraint System (SRS) air bag warning light

A WARNING

If the supplemental air bag warning light is on, it could mean that the front air bag, side air bag (where fitted), curtain air bag (where fitted) and/or pre-tensioner systems will not operate in an accident. To help avoid injury to yourself or others, have your vehicle checked by a NISSAN dealer or qualified workshop as soon as possible.

When the ignition is in the ON or START position, the Supplemental Restraint System (SRS) air bag warning light illuminates for approximately 7 seconds and then turns off this indicates the system is operational.

If any of the following conditions occur, the air bag systems and pre-tensioner systems need servicing and the vehicle must be taken to a NISSAN dealer or qualified workshop:

 The supplemental air bag warning light remains on after approximately 7 seconds.

- The supplemental air bag warning light flashes intermittently.
- The supplemental air bag warning light does not come on at all.

Unless checked and repaired, the SRS air bag system and/or the pre-tensioner seat belt system may not function properly.

For additional details, see "SRS air bag warning light" (P.59).

INDICATOR LIGHTS

Automatic brake hold indicator light (white/green)

This light illuminates to show the status of Automatic brake hold system.

Automatic brake hold indicator light (white) illuminates when Automatic brake hold system is on standby.

Automatic brake hold indicator (green) illuminates when Automatic brake hold system is operating.

Dipped beam indicator light

This light comes on when the switch is turned to the position: 1 The headlights will come on and front side, tail, number plate and instrument lights remain on

⊕ Door lock indicator light (where fitted)

The door lock indicator light located in the camera cover illuminates when all the doors are locked while the ignition is in the ON position.

- When the doors are locked with the power door lock switch, the door lock warning assembly indicator light will illuminate for 30 minutes.
- When the doors are locked by pushing the LOCK button on the Intelligent Key or any request switch (where fitted), the door lock indicator light will illuminate for 1 minute.
- The door lock warning assembly indicator light turns off when any door is unlocked.

For locking or unlocking doors, see "Doors" (P.133).

Electronic Stability Programme (ESP) OFF indicator light (where fitted)

The light comes on when the Electronic Stability Programme (ESP) is switched OFF in the vehicle information display. This indicates that the ESP system is not operating.

Disabling the ESP system causes the Intelligent Emergency Braking (IEB) system to become unavailable. See "Intelligent Emergency Braking (IEB) system (where fitted)" (P.250) for more details.

This light also comes on briefly when the ignition is placed in the **ON** position. The light will turn off after approximately 1 second if the ESP system is operational.


When the ESP OFF indicator light and SLIP indicator light (see "SLIP indicator light (where fitted)" (P.81)) come on with the ESP system turned on, it alerts the driver to the fact that the system's fail-safe mode is operating. This means that the system may not be functioning properly. Have the

system checked by your NISSAN dealer or qualified workshop.

If an abnormality occurs in the system, the ESP system function will be cancelled, but the vehicle is still driveable. For additional information, see "Electronic Stability Programme (ESP) system (where fitted)" (P.274).

Front fog light indicator light

The light comes on when the front fog lights are switched on (see "Fog light switch" (P.111)).



The front passenger air bag status light (===) located on the camera cover above the inside mirror will illuminate when the front passenger air bag is turned OFF with the front passenger air bag is turned on, the front passenger air bag status light ON () will illuminate.

For more details, see "Supplemental front-impact air bag system" (P.61).



The light illuminates when the conditions of the Hill Start Assist (HSA) system are satisfied when the vehicle is stopped on a hill.

Then, the light blinks when the brake pedal is released, which indicates that the Hill Start Assist (HSA) system is activated.

For additional information, see "Hill Start Assist (HSA) (where fitted)" (P.277).

High beam assist indicator light (where fitted)

The indicator light illuminates when the headlights come on while the headlight switch is in the AUTO position with the high beam selected. This indicates that the high beam assist system is operational. (See "Dynamic high beam assistant" (P.109).)

High beam indicator light

This light comes on when the headlight high beam is on and goes out when the low beam is selected.

Malfunction Indicator light (MIL) (yellow)

When the ignition is placed in the **ON** position, the orange Malfunction Indicator light illuminates. This means that the system is operational.

If the orange Malfunction Indicator light comes on steady or blinks (where fitted) while the hybrid system is running, it may indicate a hybrid control system malfunction or misfire.

On steady:

A hybrid system malfunction has been detected. Have the vehicle inspected by a NISSAN dealer or qualified workshop. You do not need to have your vehicle towed to the dealer.

Blinking (where fitted):

An engine misfire has been detected which may damage the hybrid control system.

To reduce or avoid hybrid control system damage:

- Do not drive at speeds above 70 km/h (43 MPH).
- Avoid hard acceleration or deceleration.
- Avoid steep uphill grades.
- If possible, reduce the load being carried or towed.

The Malfunction Indicator light may stop blinking and come on steady.

Have the vehicle inspected by a NISSAN dealer or qualified workshop. You do not need to have your vehicle towed to the dealer.

CAUTION

Continued vehicle operation without having the hybrid control system checked and repaired as necessary could lead to poor driveability, reduced fuel economy and possible damage to the hybrid control system, which may affect your warranty coverage.

○ Rear fog light indicator light (where fitted)

The light comes on when the rear fog light is switched on (see "Rear fog light" (P.111)).

इच्च Side light indicator light

This light comes on when the side light position is selected, see "Headlight and turn signal switch" (P.108) for further details.



SLIP indicator light (where fitted)

The SLIP indicator blinks when the Electronic Stability Programme (ESP) system is operating, thus alerting the driver to the fact that the road surface is slippery and the vehicle is nearing its traction limits.

You may feel or hear the system working, this is normal.

The light will continue to blink for a few seconds after the ESP system stops limiting wheel spin.

For additional information, see "Electronic Stability Programme (ESP) OFF indicator light (where fitted)" (P.80) and "Electronic Stability Programme (ESP) system (where fitted)" (P.274).

口口 Turn signal/hazard indicator lights

The direction indicator lights will flash when the turn signal switch or hazard warning flasher switch is turned on. See "Headlight and turn signal switch" (P.108) and see "Hazard warning flasher switch" (P.288) for further details.

READY READY to drive indicator light

The READY to drive indicator light illuminates when the hybrid system is powered and the vehicle may be driven.

If the light is blinking, keep pushing the power switch with the brake pedal depressed until the light stops blinking (illuminates).

EV Electric Vehicle mode indicator

This illuminates to indicate the vehicle is being driven powered only by the electric motor.



e-Pedal indicator lights

These indicators show the status of the e-Pedal Step system in the Vehicle Information Display.

AUDIBLE REMINDERS

In addition to the audible reminders described in this section, a number of other vehicle systems also provide audible warnings or reminders. These include:

- Moving Object Detection (MOD) (where fitted)
- Blind Spot Warning (BSW) (where fitted)
- Intelligent Blind Spot Intervention (where fitted)
- Rear Cross Traffic Alert (RCTA) (where fitted)
- Lane Assist (where fitted)
- Driver Attention Alert (DAA) (where fitted)
- ProPILOT Assist system (ICC) (where fitted)
- Intelligent Emergency Braking (IEB)
- Driver Attention Alert

Door open reminder chime

The chime will sound if any door other than the driver's door is left open and the power door lock switch is held down.

The external buzzer will sound if the vehicle is being locked remotely or using an outside door lock switch and any door is open.

VEHICLE INFORMATION DISPLAY

Parking brake reminder buzzer

A buzzer will sound when driving away if the parking brake has not been released. Stop the vehicle and release the parking brake.

Light reminder chime

A chime will sound for 10 seconds if the driver's door is opened while the external lights are turned on and the ignition is in the **OFF** or **LOCK** position.

See "Headlight and turn signal switch" (P.108) for further details on the headlight operation.

Fog light reminder chime

A chime will sound if the ignition is in the **OFF** or **LOCK** position and the headlight switch is in the <AUTO> position (where fitted) and the fog lights are left on.

See "Fog light switch" (P.111) for further details.

Seat belt reminder chime

A chime will sound for approximately 95 seconds if the vehicle's speed exceeds 15 km/h (9 MPH) and an occupant's seat belt is not securely fastened. See "Seat belt reminders" (P.38).


Key reminder buzzer (where fitted)

The external buzzer will beep 3 times if:

- The Intelligent Key is removed from the vehicle while the ignition is not in the LOCK position.
- The vehicle is being locked remotely or using an outside door lock switch and the Intelligent Key has been left inside the vehicle.

Park reminder chime (where fitted)

A chime will sound if the ignition is placed in the **LOCK** position and the shift lever is not in the P (Park) position.




The Vehicle Information Display ① is located between the power gauge and the speedometer, and it displays warnings and information.

- Drive computer
- Vehicle settings
- Trip computer information
- Hybrid system energy flow graphics
- Driver Assistance
- Cruise control system information
- ProPILOT Assist
- Intelligent Key operation information
- Audio information
- Navigation turn by turn
- Guidance and warnings
- Tyre pressure information
- Other information

OPERATION

Vehicle Information Display



▲ and ▼ buttons:

Press ▲ to scroll up or ▼ to scroll down through the items in the Vehicle Information Display.

■ and ▶ buttons:


Press the
or
button on the steering wheel to change between the available Vehicle Information Display screens.

3. <OK> button:

Press the <OK> button on the steering wheel to select a menu function, confirm a selection, or toggle a setting.

button:

Press the (BACK) button to return to the previous display screen or menu level, or to cancel the selection if it is not completed.



When the ignition is switched ON, the vehicle information display may display the following screens if the vehicle is equipped with them:

- 1. [Home]
- 2. [Blank]
- 3. [Drive Computer] [Average Speed] (Distance & Time)

- 4. [Fuel Economy]
- 5. [Energy Flow]
- 6. [Tyre Pressures]
- 7. [Chassis Control]
- 8. [Navigation] (where fitted)
- 9. [Navigation] (where fitted)
- 10. [Compass] (where fitted)

- 11. [Audio]
- 12. Telephone
- 13. [Driving Aids] (where fitted)
- 14. ProPILOT Assist/ICC (where fitted)
- 15. [Traffic Sign] (where fitted)
- 16. [Settings]
- Warnings. Warnings will only display if there are any present. For more information on

warnings and indicators, see "Warning lights, indicator lights and audible reminders" (P.72).

To control what items display in the vehicle information display, see "[Personal Display]" (P.88).

1 Home

The Home mode shows the following information

- · Vehicle speed
- Navigation (where fitted)
- Audio
- 2. Blank

Blank display.

Drive Computer

The Drive computer shows the average fuel economy, average vehicle speed, driving time and driving distance. You can switch between [Since Reset], [Since Start] and [Since Refuel] by pushing the <OK> button.

[Since Reset] can be reset manually by pressing the <OK> button for more than 2 secs or until reset page appears.

[Since Start] will reset after 30 minutes from last ignition OFF. It can be also reset manually by pressing the <OK> button for more than 2 secs or until reset page appears.

[Since Refuel] will be reset automatically each time when refuelling and when vehicle speed is greater than 10 km/h (6 MPH) or if vehicle travelled 500m or more. It can be also reset manually by pressing the <OK> button for more than 2 secs or until reset page appears.

Average fuel consumption: The average fuel consumption shows the average fuel consumption since the last reset.

Average speed: The average speed shows the average vehicle speed since the last reset.

Trip odometer: The trip odometer shows the total distance the vehicle has been driven since the last reset.

Elapsed time: The elapsed time shows the time since the last reset.

4. Fuel economy display

Current fuel consumption: The Fuel economy display mode shows the current fuel consumption.

Average fuel consumption: The Fuel economy display mode shows the average fuel consumption since the last reset. There are three modes of operation. You can switch between [Since Reset], [Since Start] and [Since Refuel] by pushing the scroll dial.

[Since Reset] can be reset manually by using the scroll dial.

[Since Start] (where fitted) can be reset manually by using the scroll dial, or will be reset automatically each time the ignition is switched OFF.

[Since Refuel] will be reset automatically each time when refuelling and either "Vehicle Speed ≥ 10 km/h" or "vehicle cruised 500 m" is satisfied

Energy flow

Energy monitor for various operating modes

can be displayed in the vehicle information display. The following operating modes are displayed on the Energy Flow screen.

- When the vehicle is powered only by the electric motor.
- When the vehicle is powered by the electric motor and the petrol engine is charging the Li-ion battery.
- When the vehicle is powered by both the electric motor and the petrol engine.
- When the vehicle is powered by the petrol engine and is charging the Li-ion battery.
- When both the vehicle and the petrol engine are charging the Li-ion battery.
- When the vehicle is charging the Li-ion battery.
- When the vehicle is powered only by the petrol engine.
- 6. Tyre Pressures

The tyre pressure mode shows the pressure of all four tyres while the vehicle is driven.

When the [Low Tyre Pressure] warning appears, the display can be switched to the tyre pressure mode by pushing the up and down buttons to reveal additional details on the displayed warning.

Chassis Control

This mode shows the operating condition of the following systems:

Intelligent Trace Control system

- Intelligent Ride Control system
- Automatic Brake Hold function
- 8. Navigation (where fitted)

When the route guidance is set in the navigation system, this item shows the navigation route information.

9. Navigation (where fitted)

When this display is selected the map information can be viewed from the navigation system.

10. Compass (where fitted)

This display indicates the heading direction of the vehicle

11. Audio

The audio mode shows the status of the audio system.

12. Telephone

The telephone mode shows the status of telephone information.

Driver Assistance

The Driver Assistance mode shows the operating condition for the following systems.

- Forward:
 - Intelligent Emergency Braking (IEB) (where fitted)
- Blind Spot:
 - Blind Spot Warning (BSW) (where fitted)
- Lane

Lane Assist

NOTE:

If a flashing yellow speaker icon is displayed, it indicates that the system is temporarily unavailable

14. ProPILOT Assist (where fitted)

The ProPILOT Assist mode shows the operating conditions for the following systems:

- Intelligent Cruise Control (ICC)
- Steering Assist

The display will also be shown when the ProPILOT Assist is turned on. For additional information, see "ProPILOT Assist (where fitted)" (P.225).

15. Traffic Sign Assist (where fitted)

The Traffic Sign Assist (TSA) system provides the driver with information about the most recently detected speed limit. See "Traffic Sign Assist (where fitted)" (P.279) for more details.


16. [Settings]

The setting mode allows user to change the information displayed in the vehicle information display and some settings. See the next section.

SETTINGS

The setting mode allows you to change the information displayed in the Vehicle Information Display:

- [ESP Setting]
- [Driver Assistance]
- [Personal Display]
- [ECO Settings]
- [Tyre Pressures]
- [Clock]
- [Vehicle Settings]
- [Maintenance]
- [Display Settings]
- [Unit / Language]
- [Factory Reset]



[Shortcut Menu]

A [Shortcut Menu] is available to quickly access certain items. The menu can be accessed by pressing the shortcut switch (A) on the steering wheel and using the <OK> button to select the required item. The following items are available:

[Driver Assist Custom] (where fitted)

The setting of [Driver Assist Custom], along with [Custom Mode Setup] will allow you to configure your Driver Assistance Settings to vour preference, and quickly access these settings by two button pushes.

The setting of [Driver Assist Custom] will be turned OFF when the hybrid system is restarted

By turning it ON, you can activate the settings selected in [Custom Mode Setup].

When you turn [Driver Assist Custom] ON, the status of the items selected in the [Custom Mode Setup] cannot be changed from the [Driver Assistance] Menu. These settings will be greyed out, to indicate this.

- [Change Display View]
- [Audio Source]
- [Personal Display]
- [Custom Mode Setup] (where fitted)

The setting of [Custom Mode Setup] is where you can select which Driver Assistance Settings will be activated when you turn [Driver Assist Custom] setting ON.

The setting selected in [Custom Mode Setup] will be retained even if the hybrid system is restarted

The settings of [Custom Mode Setup] will be activated when you turn [Driver Assist Custom] ON.

The status can be selected for the following items:

- [Emergency Lane]
- [Advanced Lane]
- [Speed Limit]
- [New Limit Alert]
- Driver Attention Alert]

[ESP Setting]

Select [ESP Setting] using the ▲ or ▼ switches and press <OK> and use the <OK> button to toggle between turning ESP on or off. (For more information, see "Electronic Stability Programme (ESP) system (where fitted)" (P.274).)

[Driver Assistance] (where fitted)

Use the ▲ or ▼ switches and the <OK> button to change the status, warnings or turn on or off any of the systems/warnings displayed in the [Driver Assistance] menu. The following menu options are available:

- [Lane Assist]
 - Gives access to the following items:
 - [Emergency Lane]
 - [Advanced Lane]
- [Blind Spot]

Gives access to the following items:

– [Warning] (where fitted)

- Intervention (where fitted)
- [Emergency Brake] (Intelligent Emergency) Braking (IEB) system) (where fitted) You can turn IEB on or off.
- [Traffic Sign Assist] (where fitted) (For more information, see "Traffic Sign Assist (where fitted)" (P.279).)
- [Parking Aids] (where fitted)

(For more information, see "Ultrasonic Parking Sensors (where fitted)" (P.266) and "Intelligent Around View Monitor (IAVM) (where fitted)" (P.153))

Gives access to the following items:

- [Moving Object] (where fitted) Allows user to turn the Moving Object Detection (MOD) ON/OFF.
- [Front] (where fitted) Allows user to turn the front sonar sensors ON/OFF.
- [Rear] Allows user to turn the rear sonar sensors ON/OFF.
- [Distance] (where fitted) Allows user to select the sonar sensor's detection distance ([Far], [Medium] or [Nearl).
- [Display] (where fitted) Allows user to turn the sonar system or the Rear Sonar System (RSS) display ON/OFF.
- [Volume]

Allows user to select the volume of the sonar tone ([High], [Medium] or [Low]).

- [Rear Cross Traffic Alert] (where fitted)
 You can use this setting to turn RCTA on or off.
 (For more information, see "Rear Cross Traffic Alert (RCTA) system (where fitted)" (P.210)).
- [Driver Attention Alert] (where fitted)

The [Driver Attention Alert] option can be used to activate or deactivate the Intelligent Driver Alertness (IDA) feature (where fitted). This system is able to detect whether the driver is displaying a lack of attention, or is distracted. It does this by monitoring driving style, and steering behaviour, and it notes deviations from the normal pattern. If the system detects that driver attention is decreasing, the system uses an audible and visual warning to suggest that the driver takes a break.

[Timer Alert]

Allows user to adjust the Timer Alert or reset.

- (Current Time)/(Set Time)
- Reset
- [Low Temp. Alert]

This allows you to turn on or off the low temperature warning.

[Chassis Control]

This allows you to turn on or off Intelligent Trace Control (for more information, see "Chassis control" (P.276)).

[Personal Display]

A selection can be made what is shown in the personal display:

[Blank]

- [Navigation]
- [Time to Destination]
- [Fuel Economy]
 - [Since Reset]
 - [Since Start]
 - [Since Refuel]
- [Trip]
 - [Since Reset]
 - [Since Start]
 - [Since Refuel]
- [Gear position]
- [Average speed]
 - [Since Reset]
 - [Since Start]
 - [Since Refuel]
- [Brake Lamp]

When selected, an image of the rear side of the car is visible in the personal display and shows when the brake lamps come on.

[ECO Settings]

The following menu options are available:

[ECO Drive Mode]

This allows you turn on or off ECO mode for:

- [ECO Cruise Control]
 - Note that the Drive Mode switch must be in the ECO position before [ECO Cruise Control] can be activated. For more information, see "Drive mode" (P.278).
- [ECO Climate Control]
- [ECO Info settings]

Turn on or off the ECO indicator and/or ECO drive report

[View history]
 View or reset ECO history bar display.

[Tyre Pressures]

The settings in the Tyre pressures menu are all related to the Tyre Pressure Monitoring System TPMS (see "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186)).

- [Target Front]
- [Target Rear]
- [Tyre Pressure Unit]
- [Calibrate]

[Target Front]:

The [Target Front] tyre pressure is the pressure specified for the front tyres on the tyre placard (see "Tyre placard" (P.346) and "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186)).

Use the \blacktriangle or \blacktriangledown and the <OK> buttons to select and change the value for the [Target Front] tyre pressure.

[Target Rear]:

The [Target Rear] tyre pressure is the pressure specified for the rear tyres on the tyre placard (see "Tyre placard" (P.346) and "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186)).

Use the \blacktriangle or \blacktriangledown and the <OK> buttons to select and change the value for the [Target Rear] tyre pressure.

[Tyre Pressure Unit]:

The unit for tyre pressure that displays in the Vehicle Information Display can be changed to:

- kPa
- bar
- kaf/cm²
- psi

Use the ▲ or ▼ and the <OK> buttons to select and change the unit.

Pressure units conversion table

kPa	psi	bar	kgf/cm²	
200	29	2.0	2.0	
210	30	2.1	2.1	
220	32	2.2	2.2	
230	33	2.3	2.3	
240	35	2.4	2.4	
250	36	2.5	2.5	
250	36	2.5	2.5	
260	38	2.6	2.6	
270	39	2.7	2.7	
280	41	2.8	2.8	
290	42	2.9	2.9	
300	44	3.0	3.0	
310	45	3.1	3.1	
320	46	3.2	3.2	
330	48	3.3	3.3	
340	49	3.4	3.4	

[Calibrate]:

The tyre pressure is affected by the temperature of the tyre; the tyre temperature increases when the vehicle is driven. The TPMS system uses temperature sensors in the tyres to compensate for changes in temperature in order to prevent false TPMS warnings.

The [Calibrate] function resets the previously stored temperature value. It is recommended that this function is performed after the tyre pressures are adjusted.

See "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186).

Use the ▲ or ▼ and the <OK> buttons to start or cancel the calibration process. While the calibration process is active, the message: [Calibrate] will be displayed.

[Clock]

Allows user to adjust the clock settings and time within the vehicle information display.

- [Display] (where fitted)
- [Clock Mode] (where fitted)
- [Clock Format]
- [Summer Time] (where fitted)
- [Time Zone] (where fitted)
- Set Clock Manually

The clock may also be set in the centre display. For additional information, refer to the separate NissanConnect Owner's Manual.

[Vehicle Settings]

Use the ▲ or ▼ switches and the <OK> button to change the status, warnings or turn on or off any of the systems/warnings displayed in the [Vehicle Settings] menu. The following menu options (where fitted), each leading to a further submenu, are available:

- [Lighting]
- [Locking]
- [Wipers]
- [Mirror Fold]

[Liahtina]:

The [Lighting] menu has the following options:

[Welcome Light]:

The welcome lighting can be set to be ON or OFF. From the [Lighting] menu, select [Welcome Light]. Use the <OK> button to turn this feature ON or OFF. When set to ON, front and rear lamps will stay on for 30 seconds after unlocking. They will also stay on for 15 seconds after locking.

The front and rear lamps may turn on again for 10 seconds when the Intelligent Kev is moved outside of the set detection zone (approx. 2.8m) or after 2 mins if the Intelligent Kev remains motionless within the set detection zone.

[Auto Room Lamp]:

The internal light timer can be set to be ON or OFF. From the [Lighting] menu, select [Auto Room Lamp]. Use the <OK> button to turn this feature ON or OFF.

[Mood Lighting] (where fitted):

The mood lighting can be dimmed or brightened. From the [Lighting] menu, select [Mood Lighting]. Use the <OK> button and the ▲ or ▼ switches to adjust the brightness.

[Locking]:

There are a number of options (where fitted) in the [Locking] menu:

• [I-Key Door Lock] (where fitted)

When this item is turned on, the request switch on the door is activated. From the [Locking] menu, select [I-Key Door Lock]. Use the <OK>button to activate or deactivate this function.

[Selective Unlock]

When this item is turned on, and the door handle request switch on the driver's or front passenger's side door is pushed, only the corresponding door is unlocked. All the doors can be unlocked if the door handle request switch is pushed again within 5 seconds. When this item is turned to off, all the doors will be unlocked when the door handle request switch is pushed once. From the [Locking] menu, select [Selective Unlock]. Use the <OK>button to activate or deactivate this function.

- When the shift lever is moved to P (Park).
- At the moment the hybrid system is turned off.
- [Walk Away Lock]

This allows user to turn the walk away lock function ON or OFF. (See "Walk-away lock function (where fitted)" (P.130).)

[Approach Unlock]

This allows user to turn the approach unlock function ON or OFF. (See "Approach unlock function (where fitted)" (P.130).)

[Wipers]:

[Speed Dependent] (where fitted)

The Speed Dependent wiper feature can be set to be ON or OFF. From the [Wipers] menu, select [Speed Dependent]. Use the <OK> button to turn this feature ON or OFF.

[Auto Wipe]

The Rain Sensor feature can be activated or deactivated. From the [Wipers] menu, select [Auto Wipe]. Use the <OK> button to turn this feature ON or OFF.

[Reverse Link] (where fitted)

The Reverse Link wiper feature can be set to be ON or OFF. From the [Wipers] menu, select [Reverse Link]. Use the <OK> button to turn this feature ON or OFF. If set to ON, the rear wiper will operate if the front wipers are switched on and the gear shift is in the R (Reverse) position.

• [Drip Wipe] (where fitted)

The Drip Wipe feature can be set to be ON or OFF. From the [Wipers] menu, select [Drip Wipe]. Use the <OK> button to turn this feature ON or OFF. If set to ON, the wiper will operate once about 3 seconds after using the washer. This operation is to wipe washer fluid that has dripped on the windscreen.

[Mirror Fold]:

There are three options (where fitted) in the [Mirror Fold] menu:

[Auto Fold Off] (where fitted)

When this item is turned on, the auto fold feature for the outside rear-view mirrors is disabled. Use the <OK> button to select this function.

[Unfold at Ignition] (where fitted)

When this item is turned on, The outside rearview mirrors automatically fold when the ignition is switched off, and unfold when the ignition is switched on. Use the <OK> button to select this function.

[Unfold at Unlock] (where fitted)

When this item is turned on, The outside rearview mirrors automatically fold when the vehicle doors are locked, and unfold when the vehicles doors are unlocked. Use the <OK> button to select this function.

[Maintenance]

- [Service]
- 2. [Air Filter]
- Tyre]
- 4. [Other]

The maintenance mode allows you to set or check alerts for the reminding of maintenance intervals. To change an item:

Select [Maintenance] using the ▲ or ▼ switches and press <OK>.

[Service]:

This indicator appears when the set distance comes for changing the engine oil and oil filter.

For scheduled maintenance items and intervals. see your NISSAN Service and Maintenance Guide.

[Air Filter]:

This indicator appears when the set distance comes for changing the air filter. You can set or reset the distance for checking or replacing the air filter

For scheduled maintenance items and intervals. see your NISSAN Service and Maintenance Guide.

[Tvre]:

This indicator appears when the customer set distance comes for replacing tyres. You can set or reset the distance for replacing tyres.

A WARNING

The tyre replacement indicator is not a substitute for regular tyre checks, including tyre pressure checks. See "Wheels and tyres" (P.334). Many factors including tyre inflation. alignment, driving habits and road conditions affect tyre wear and when tyres should be replaced. Setting the tyre replacement indicator for a certain driving distance does not mean your tyres will last that long. Use the tyre replacement indicator as a guide only and always perform regular tyre checks. Failure to perform regular tyre checks, including tyre pressure checks could result in tyre failure. Serious vehicle damage could occur and may lead to a collision, which could result in serious personal injury or death.

[Other]:

This indicator appears when the customer set distance comes for checking or replacing maintenance items other than the engine oil, oil filter. air filter, and tyres. Other maintenance items can include such things as tyre rotation. You can set or reset the distance for checking or replacing the items.

[Display Settings]

Use the ▲ or ▼ switches to scroll and the <OK> button to change the status, warnings or turn on or off any of the systems/warnings displayed in the [Display Settings] menu. The following menu options are available:

- [Contents Selection]
- [Route Guidance]
- [AUTO Cruise Display]
- [Welcome Effect]
- [Operation Guidance]

[Contents Selection]:

The items that display when the ignition is placed in the ON position can be enabled/disabled. To change the items that are displayed, use the or v buttons to scroll and the <OK> button to select a menu item: The following items (where fitted) are available in the [Contents Selection] menu:

[Energy Flow]

- [Home]
- [Compass]
- [Blank]
- [Fuel Economy]
- [Drive Computer]
- [Tyre Pressures] (where fitted)
- [Traffic Sign] (where fitted)
- [Navigation] (where fitted)
- [Audio]
- [Driver Assistance] (where fitted)
- [Cruise] (where fitted)
- [Chassis Control]

[Route Guidance]:

Choose whether or not to show alerts from the navigation system prompting you to turn, for example.

[AUTO Cruise Display]:

The [AUTO Cruise Display] item allows user to turn the cruise screen transition on or off

[Welcome Effect]:

You can choose whether or not to display the welcome screen when the ignition is placed in the ACC (where fitted) or ON position. You can also choose the following items to define how the welcome screen looks:

- [Animation]
- [Sound]

To enable/disable the welcome screen, and set how it appears:

- Use the ▲ or ▼ buttons to select [Settings], and press <OK>.
- Select [Welcome Effect] using the ▲ or ▼ buttons and press <OK> to select this menu.
 Use the ▲ or ▼ buttons to navigate between the menu options and press <OK> to turn each function ON or OFF.

[Operation Guidance]:

The [Operation Guidance] displays the available operation guidance settings.

- [Lights]
- [Wiper]
 - [Front]
 - [Rear]

[Unit / Language]

- [Distance / Fuel]
- [Tyre Pressures]
- [Temperature]
- [Language]

[Distance / Fuel]:

The unit for the mileage and fuel consumption that displays in the Vehicle Information Display can be changed to:

- km, I/100km
- km, km/l
- miles, MPG

Use the \blacktriangle or \blacktriangledown and the <OK> buttons to select and change the unit.

[Tyre Pressures]:

The unit for tyre pressure that displays in the Vehicle Information Display can be changed to:

- kPa
- bar
- kgf/cm²
- psi

Use the \blacktriangle or \blacktriangledown and the <OK> buttons to select and change the unit.

[Temperature]:

The temperature that displays in the Vehicle Information Display can be changed from:

- °C (Celsius)
- °F (Fahrenheit)

Use the <OK> button to toggle choices.

[Language]:

The language of the vehicle information display can be changed.

Use the \blacktriangle or \blacktriangledown and <OK> buttons to select and change the language of the vehicle information display.

[Factory Reset]


The settings in the Vehicle Information Display can be reset back to the factory default. To reset the Vehicle Information Display:


- Use the ▲ or ▼ buttons to select [Settings], and press the <OK> button.
- Select [Factory Reset] using the ▲ or ▼ buttons and press the <OK> button.

Select [Yes] to return all settings back to default by pressing the <OK> button.

To cancel the reset operation select [Cancel] or press the BACK button located on the left side of the steering wheel.

GENERAL INFORMATION AND WARNINGS





NOTE:

Depending on the specification of your vehicle, some of the warnings and indicators described in this section may not be applied.

1. Hybrid system start operation indicator

This indicator appears when the shift lever is in the P (Park) position.

This indicator indicates that the hybrid system will start by pushing the ignition switch with the brake pedal depressed.

2. Hybrid system start operation indicator

This indicator indicates that the ignition switch is unable to unlock the steering lock. Turn the steering wheel slightly while pushing the ignition switch

3. [No key detected] warning

The warning appears when the door is closed with the Intelligent Key left outside the vehicle and the ignition in the ACC or ON position. Make sure that the Intelligent Key is inside the vehicle.

See "Intelligent Key system" (P.127) for more details.

4. [No Key] [Press and Hold to Stop Engine] warning

This warning appears you try to turn off the engine when the door is closed with the Intelligent Key left outside the vehicle and the engine is running.

Press and hold the push button ignition switch to turn off the engine.

See "Intelligent Key system" (P.127) for more details.

5. [Key battery low] indicator

This indicator appears when the Intelligent Key battery is running out of power.

If this indicator appears, replace the battery with a new one. See "Intelligent Key battery replacement" (P.327).

6. Engine start operation for Intelligent Key system indicator

This indicator appears when the Intelligent Key battery is running out of power and the Intelligent Key system and vehicle are not communicating normally.

If this indicator appears, touch the ignition switch with the Intelligent Key while depressing the brake pedal. (See "Push-button ignition switch" (P.192).)

7. [Key System Fault See Owner's Manual] warning This warning appears if there is a malfunction in

the Intelligent Key system.

If this warning appears while the engine is stopped, the engine cannot be started. If this warning appears while the engine is running, the vehicle can be driven. However, it is recommended that you visit a NISSAN dealer or qualified workshop for repair as soon as possible.

8-9. [Tyre Pressure] guidance messages

The tyre pressure mode shows the pressure of all four tyres while the vehicle is driven.

10. [Low Tyre Pressure] warning

This warning appears when the low tyre pressure warning light in the meter illuminates and low tyre pressure is detected. The warning appears each time the ignition is switched ON as long as the low tyre pressure warning light remains illuminated. If this warning appears, stop the vehicle and adjust the pressure to the recommended COLD tyre pressure shown on the tyre placard. (See "Low tyre pressure warning light (where fitted)" (P.77) and "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186).)

11. Occupant Status Display (where fitted)

In vehicles fitted with Rear Occupant Detection, in addition to the Seat Belt Warning Light, the Occupant Status Display will be shown in the Vehicle Information Display when any vehicle occupant's seat belt is not fastened. The display will remain until occupants have their seat belts securely fastened, or until acknowledged by the driver.

For precautions on seat belt usage, see "Seat belts" (P.36).

12. Rear Passenger Seat Belt Display (Where Fitted)

Dependent on vehicle specification, this warning will appear for 65 seconds after the ignition is switched ON. It will also display if the total number of rear buckled seat belt is less than the maximum seem during the journey.

For precautions on seat belt usage, see "Seat belts" (P.36).

13. [Low fuel level] warning

This warning appears when the fuel level in the tank is getting low. Refuel as soon as it is convenient, preferably before the fuel gauge reaches the empty (0) position.

There is a small reserve of fuel remaining in the tank when the fuel gauge reaches the empty (0) position.

14. [Headlights] guidance

This message is displayed when a change is made to the position of the headlight switch. See "Headlight and turn signal switch" (P.108).

15. [Reminder Turn OFF Headlights] warning

This warning appears when the driver side door is opened with the headlight switch is left ON and the ignition is switched OFF. Place the headlight switch in OFF (where fitted) or AUTO position. For additional information, (See "Headlight and turn signal switch" (P.108).)

16. [Headlight System Fault: See Owner's Manual] warning This warning appears if the LED headlights are malfunctioning. Have the system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service.

17. [Not Available Requires AUTO lights] warning

This warning is displayed of you try to turn on the dynamic high beam assistant and/or adaptive driving beam but the Headlight switch is not in the AUTO position. (See "Dynamic high beam assistant" (P.109).)

18-19. [Front Wipers] guidance

This message is displayed when a change is made to the position of the wiper switch. See "Wiper and washer switch" (P.105).

20. [Parking Aids] Parking Sensor System guidance Parking Sensor system (where fitted).

Press **<OK>** on the steering wheel to disable parking sensors.

See "Ultrasonic Parking Sensors (where fitted)" (P.266).

21. [Parking sensor system fault See Owner's Manual] warning This warning appears when there is a malfunction with the Parking Sensor system (where fitted) or the Rear Parking sensor System (where fitted). (See "Ultrasonic Parking Sensors (where fitted)" (P.266).)

22. [Driver Attention Alert] [Take a Break?] guidance This message appears when the Intelligent Driver Alertness (IDA) system detect that the driver attention is decreasing. (See "Intelligent Driver Alertness (where fitted)" (P.262).)

23. [System fault See Owner's Manual] (IDA) warning

This warning appears when the Intelligent Driver Alertness (IDA) system malfunctions. (See "Intelligent Driver Alertness (where fitted)" (P.262).)

24. Door/tailgate open warning

This warning appears if any of the doors and/or the tailgate are open or not closed securely. The

vehicle icon indicates which door or the tailgate is open on the display.

25. Transmission position guidance (where fitted)

This indicator shows the Transmission shift position.

See "Driving the vehicle" (P.196) for further details.

26. Blind Spot Warning (BSW)/Intelligent Emergency Braking guidance

This appears when one or more of the following systems are engaged:

- Blind Spot Warning (BSW)
- Intelligent Emergency Braking (IEB (where fitted)
- Blind Spot Intervention (BSI)
- Lane Assist

27. [Power will turn off to save the battery] warning Under the specific conditions, this warning may appear after the ignition switch is ON for a certain period of time.

28. [Power turned off to save the battery] warning Under the specific conditions, this warning may appear after the ignition is automatically turned OFF to save the battery.

29. [Release Parking Brake] warning

This warning appears when the accelerator pedal is depressed when the electric parking brake automatic release function cannot be used. Release the electric parking brake manually.

30. [Drive Mode Selector] indicator

When a driving mode is selected using the [Drive Mode Selector], the selected mode is displayed.

- [STANDARD]
- [ECO]
- [SPORT]

(See "Drive mode" (P.278).)

31. [Press Brake Pedal] warning (where fitted)

The vehicle is stopped on a steep hill and there is a possibility of moving backward, even if the electric parking brake is applied. Depress the brake pedal to stop the vehicle moving. (See "Electric parking brake" (P.138).)

32. [Press Brake Pedal] guidance (where fitted)

This message appears if an attempt is made to release the electric parking brake manually without depressing the brake pedal. (See "Electric parking brake" (P.138).)

33. [Press Brake Pedal to prevent rolling] warning

This warning appears and a chime sounds if the vehicle moves while the Automatic brake hold function is activated. Apply the foot brake to stop the vehicle moving. (See "Automatic Brake Hold" (P.140).)

34. [Autohold] [Caution Steep slope] guidance

This message appears and a chime sounds when the Automatic brake hold function is activated while the vehicle is on a steep hill. Apply the foot brake to stop the vehicle moving. (See "Automatic Brake Hold" (P.140).)

35. [Autohold] [Steep Slope Apply foot brake] guidance

This message appears and a chime sounds if the [Caution Steep slope] guidance has appeared for over about 3 minutes. Then, the parking brake will automatically be applied and the braking force of Automatic brake hold will be released, and vehicle may move or roll away unexpectedly. Apply the foot brake to stop the vehicle moving. (See "Automatic Brake Hold" (P.140).)

36. [Autohold] [Press brake to operate switch] guidance

This message appears if the Automatic brake hold switch is pushed without depressing the brake pedal while the Automatic brake hold function is activated. Press the foot brake and push the switch to deactivate Automatic brake hold. (See "Automatic Brake Hold" (P.140).)

37. [Exhaust filter maintenance See owner's manual] warning (where fitted)

If your vehicle is fitted with a petrol engine, your vehicle may also be fitted with a Gasoline Particulate Filter (GPF). Under certain less-favourable driving conditions, the GPF may become saturated or clogged because these driving conditions prevent automatic regeneration of the filter. In this case, a warning message (where fitted) will be displayed in the vehicle information display. For additional details, see "Gasoline particulate filter (GPF) (where fitted)" (P.191).

38. [Shift to Park] warning

This warning appears when the driver's door is opened while the transmission is in any position other than P (Park).

If this warning appears, move the shift lever into the P (Park) position.

An inside warning chime will also sound. (See "Push-button ignition switch" (P.192).)

39. [Shipping Mode On Push Storage Fuse] warning (where fitted)

This warning may appear if the extended storage switch is not pushed in. When this warning appears, push in the extended storage switch to turn off the warning. (See "Fuses" (P.330).)

40. Battery management fault warning

This warning appears if a fault is detected with the battery management system. Have the system checked. It is recommended you contact a NISSAN dealer or qualified workshop for this service.

41–44. Engine warning (where fitted)

Malfunctions or high engine temperature will result in one of these warning messages being displayed. For additional details, see "If your vehicle overheats" (P.302).

45. [Tyre Size Incorrect See Owner's Manual] (where fitted)

This warning may appear if there is a large difference between the diameters of front and rear wheels and tyres. Pull off the road in a safe area, with the engine idling. Check that all the tyre sizes, brand, construction and tread pattern are the same, that the tyre pressures are correct and

that the tyres are not excessively worn. If you have any problems, change tyres or adjust tyre pressures correctly. (See "Wheels and Tyres" (P.344).)

46. [Gearbox Fault Stop safely] warning

This warning appears when there is a malfunction with the transmission system. If this warning appears, stop the vehicle in a safe place.

Have the system checked. It is recommended you visit a NISSAN dealer or qualified workshop for this service.

47. [Service Gearbox Power reduced] warning

This warning appears when there is a malfunction with the transmission system. Engine power and, under some conditions, vehicle speed will be decreased automatically to reduce the chance of transmission damage. Vehicle speed can be controlled with the accelerator pedal, but the engine and vehicle speed may be reduced. If this warning appears, have the system checked. It is recommended you visit a NISSAN dealer or qualified workshop for this service.

48. [Gearbox Fault Service now] warning

This warning appears when there is a malfunction with the transmission system. If this warning appears, have the system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service.

49. [Gearbox Hot Power reduced] warning

The transmission has a high fluid temperature protection mode. If the fluid temperature becomes too high (for example, climbing steep grades in high temperatures with heavy loads, such as when towing a trailer), engine power and, under some conditions, vehicle speed will be decreased automatically to reduce the chance of transmission damage. Vehicle speed can be controlled with the accelerator pedal, but the engine and vehicle speed may be reduced.

50. [Stop the vehicle safely] warning

This warning appears when the system detects that the vehicle is moving backwards on an uphill road with the transmission in D (Drive), or moving forward on a downhill road with the transmission in R (Reverse). Stop vehicle movement by depressing the brake pedal.

51. [Apply parking brake] warning

This warning appears if a malfunction occurs in the shift control system. Contact a NISSAN dealer or qualified workshop as soon as possible.


When parking the vehicle, make sure that the parking brake is applied. If the parking brake is not applied, the ignition switch may not be switched off.


52. [Chassis control system fault See Owner's Manual] warning

This warning appears if the chassis control module detects a malfunction in the chassis control system. Have the system checked. It is recommended that you visit a NISSAN dealer or qualified

workshop for this service. (See "Chassis control" (P.276).)

VEHICLE INFORMATION DISPLAY DRIVING AIDS WARNINGS AND GUIDANCE MESSAGES





1-5. [Not Available] [System Fault] warning

This warning appears is one or more of the following systems malfunction.

- Blind Spot Warning (BSW) (where fitted)
- ProPILOT Assist (where fitted)
- Intelligent Cruise Control (ICC) (where fitted)
- Blind Spot Intervention (BSI)
- Lane Assist

If the warning continues to display, have the system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service.

6-7. [System fault] warning

This warning appears when the following systems malfunction.

- Rear Cross Traffic Alert (RCTA) (where fitted)
- Intelligent Emergency Braking (IEB) (where fitted)

If the warning continues to display, have the system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service

8. [System fault See Owner's Manual] warning (where fitted) This warning appears when the following systems malfunction

Traffic Sign Assist (TSA) (where fitted)

If the warning continues to display, have the system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service

9-11. [Unavailable Camera Temperature High] warning

This warning appears if the interior temperature of the vehicle has reached such a high temperature that the sensors for the following systems can no longer function reliably.

- Intelligent Blind Spot Intervention (where fitted)
- Steering Assist (where fitted)

Once the interior temperature has reached normal levels, the warning should disappear.

If the warning continues to display, have the system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service.

12-14. [Temporarily Disabled Front Radar Blocked] warning

If the front radar sensor area on the front of the vehicle is covered with dirt or obstructed, making it impossible to detect a vehicle ahead, the following system is automatically turned off.

 Intelligent Cruise Control (ICC) (ProPILOT Assist system) (where fitted)

If the warning message appears, park the vehicle in a safe location and turn the hybrid system off.

Check to see if the sensor area is blocked. If the sensor area is blocked, remove the blocking material. Restart the hybrid system. If the warning message continues to appear, have the system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service.

15. Steering Assist Not Available Cannot Detect Lane] guidance (where fitted)

This message may appear when the Steering Assist system is engaged. The Steering Assist system is automatically cancelled when the lane markers in the travelling lane cannot be correctly detected for a period of time due to such items as a snow rut, reflection of light on a rainy day or several unclear lane markers are present.

If you want to use the Steering Assist system again, cancel the ProPILOT Assist system and set it again when lane markers are clearly visible.

16-19. [Currently not available] warning

This warning appears when the Intelligent Blind Spot Intervention (where fitted) or the Intelligent Cruise Control (ICC) system (where fitted) becomes unavailable in the following conditions:

• The Electronic Stability Programme (ESP) system is turned off

20-23. [Unavailable Slippery Road] warning (where fitted)

This warning appears when the following systems become unavailable because the road is slippery.

- Intelligent Blind Spot Intervention (where fitted)
- ProPILOT Assist (where fitted)

24-25. [Not available Side Radar Obstructed] warning (where fitted)

This warning appears when the following systems become unavailable because a radar blockage is detected.

- Blind Spot Warning (BSW) (where fitted)
- Intelligent Blind Spot Intervention (where fitted)
- Rear Cross Traffic Alert (RCTA) (where fitted)

26-27. [Temporarily Disabled Camera Blocked See Owner's Manual] guidance (where fitted)

The camera area of the windscreen is fogged up or covered with dirt, water, drops, ice, snow, etc.

28. [Not Available Visibility is impaired] guidance (where fitted) This message may appear when the Steering

Assist system is engaged.

Under the following conditions, the Steering Assist system is automatically cancelled:

- When the wiper (HI) operates.
- When lane markers in the travelling lane cannot be correctly detected for a period of time due to such items as a snow rut. reflection of light on a rainy day or several unclear lane markers are present.

29. [Not Available, Parking Brake On] guidance (where fitted)

This message may appear when the ProPILOT Assist (where fitted) Intelligent Cruise Control (ICC) system is engaged.

Under the following condition, the ICC system is automatically cancelled:

The Electric Parking Brake is applied.

The above system cannot be used when the Electric Parking Brake is activated.

30. [Not Available Seat Belt Not Fastened] guidance (where fitted)

This message may appear when the ProPILOT Assist (where fitted) Intelligent Cruise Control (ICC) system is engaged.

Under the following condition, the ICC system is automatically cancelled:

 When the driver's seat belt is not fastened. The ICC system cannot be used when the driver's seat belt is not fastened.

31. [Press Brake Pedal] guidance (where fitted)

This message may appear when the ProPILOT Assist Intelligent Cruise Control (ICC) system is engaged and the following condition occurs:

 While the vehicle is stopped by ProPILOT Assist, the driver's door is opened but the Electric Parking Brake was not activated.

Step on the brake pedal immediately.

32. [System OFF] warning

This warning is displayed if the RCTA is switched off. See "Rear Cross Traffic Alert (RCTA) system (where fitted)" (P.210).

33. [Unavailable Select Driving Aids in Settings] warning This warning is displayed if no Driver Assistance features are enabled

34-36. Hands on detection warning (where fitted)

This warning may appear when the Steering Assist system is engaged and the following condition(s) occur:

- When not holding the steering wheel
- When there is no steering wheel operation.

Hold on the steering wheel immediately. When the steering operation is detected, the warning turns off. For additional information, refer to "Hands on detection" (P.243).

37. Intelligent Emergency Braking (IEB) emergency warning (where fitted)

This warning appears along with an audible warning, when the Intelligent Emergency Braking (IEB) system detects the possibility of a forward collision.

See "Intelligent Emergency Braking (IEB) system (where fitted)" (P.250).

38. Intelligent Emergency Braking (IEB) system guidance (where fitted)

This screen appears to indicate the status of the Intelligent Emergency Braking (IEB) system.

See "Intelligent Emergency Braking (IEB) system (where fitted)" (P.250).

39-40. Steering Assist guidance (where fitted)

This message appears when the Steering Assist system is turned on or off.

See "ProPILOT Assist (where fitted)" (P.225).

41. [Only Available with Cruise Control ON] guidance (where fitted)

This message appears when the Steering Assist switch has been pressed while the Cruise Control is not switched on

See "ProPILOT Assist (where fitted)" (P.225).

42. [System fault See Owner's Manual] warning (where fitted) This warning appears when the Traffic Sign Assist system (where fitted) malfunctions.

43. [Currently Unavailable Front Camera High Temperature] warning (where fitted)

This warning appears if the interior temperature of the vehicle has reached such a high temperature that the sensor for the Traffic Sign Assist system (where fitted) can no longer function reliably.

44. [Currently Unavailable] warning (where fitted)

This warning appears under the following conditions when the Traffic Sign Assist (TSA) system or the Intelligent Emergency Braking with pedestrian Detection system is activated.

For the TSA system:

When the data communication between systems is temporarily interrupted

For the Intelligent Emergency Braking with Pedestrian Detection system:

- When the system check for the warning function did not end normally
- When the vehicle is towed

45. [Temporarily Disabled Camera Blocked See Owner's Manual warning (where fitted)

If the front camera sensor area on the front of the vehicle is covered with dirt or obstructed, making it impossible to detect the traffic signs, the Traffic Sign Assist system (where fitted) automatically turns off.

If the warning message appears, park the vehicle in a safe location and turn the hybrid system off. Check to see if the sensor area is blocked. If the sensor area is blocked, remove the blocking material. Restart the hybrid system. If the warning message continues to appear, have the system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service.

46. [Speed Limit Database Error Please Install Latest Database Again] warning (where fitted)

This message appears if updating the map data for the TSA system was not successful.

47. [OK to Accept Speed Warning] guidance (where fitted) This indicator appears when the Traffic Sign Assist (TSA) system sounds an overspeed warning chime. Slow down or push the <OK> button on the steering wheel to stop the warning chime. (See "Traffic Sign Assist (where fitted)" (P.279).)

48. [Currently Unavailable ESP OFF] warning (where fitted) This warning appears when the Electronic Stability Program (ESP) system is turned off with the Lane Assist system activated.

49. [Temporarily Disabled Camera Blocked See Owner's Manual] warning (where fitted)

This warning appears when the Lane Assist system is turned off automatically under the following conditions:

- The camera area of the windshield is covered with moisture, snow, ice, dirt or some other object.
- The camera area of the windshield is continuously covered with dirt, etc.

50. [Currently Unavailable Front Camera High Temperature] warning (where fitted)

This warning appears if the interior temperature of the vehicle has reached such a high temperature that the sensors for the Lane Assist system can no longer function reliably.

Once the interior temperature has reached normal levels, the warning should disappear.

If the warning continues to display, have the system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service.

51. [Currently Not Available] warning (where fitted)

This warning appears when the Lane Assist system (where fitted) becomes unavailable when the direction of the front camera is significantly misalianed.

52. [Currently Unavailable Poor Visibility] warning (where fitted)

This warning appears under the following conditions when the Intelligent Emergency Braking system is activated:

 Strong light, such as sunlight or high beams from oncoming vehicles, enter the front camera.

53. [Currently Unavailable Front Camera High Temperature] warning (where fitted)

This warning is displayed when the Intelligent Emergency Braking system is disabled because the cabin temperature is high.

54. [Currently Unavailable ESP OFF] warning (where fitted) This warning is displayed when the ESP system is turned off.

55. [Currently Unavailable] warning (where fitted) This warning is displayed when Intelligent Emergency Braking is disabled because the system check has not completed properly.

56. [Currently Unavailable Radar Inhibited] warning (where fitted) This warning is displayed when Intelligent Emergency Braking is disabled because the radar sensor is receiving interference from other radar sources.

57. [Temporarily Disabled Camera Blocked See Owner's Manual] warning (where fitted)

This warning is displayed when Intelligent Emergency Braking is disabled because the camera area of the windscreen is misted or frozen, or continuously covered with dirt, etc.

58. [Temporarily Disabled Front Radar Blocked See Owner's Manual] warning (where fitted)

If the front radar sensor area on the front of the vehicle is covered with dirt or obstructed, making it impossible to detect a vehicle ahead, the following systems (where fitted) are automatically turned off.

- Lane Assist
- Intelligent Emergency Braking with Pedestrian Detection

If the warning message appears, park the vehicle in a safe location and turn the engine off.


Check to see if the sensor area is blocked. If the sensor area is blocked, remove the blocking material. Restart the engine. If the warning message continues to appear, have the system checked. It is recommended that you visit a NISSAN dealer for this service.

59. [Unavailable Low Visibility] guidance (where fitted) This message may appear when the Steering Assist system is engaged.

Under the following conditions, the Steering Assist system is automatically canceled:

- The camera area of the windshield is fogged up or covered with dirt, water, drops, ice, snow, etc.
- Strong light, such as sunlight or high beams from oncoming vehicles, enter the front camera

CLOCK AND OUTSIDE AIR TEMPERATURE



The clock ① and outside air temperature ② are displayed on the upper side of the Vehicle Information Display.

[Clock]

For details of how to set the clock, see "[Clock]" (P.89) or the separately provided NissanConnect Owner's manual.

[Low Temp. Alert] (°C or °F)

The outside air temperature is displayed in $^{\circ}$ C or $^{\circ}$ F in the range of -40 to 60 $^{\circ}$ C (-40 to 140 $^{\circ}$ F).

The outside air temperature mode includes a low temperature warning feature. If the outside air temperature is below 3°C (37°F), the warning 3 is displayed on the screen (where fitted).

The outside temperature sensor is located in front of the radiator. The sensor may be affected by road or engine heat, wind directions and other driving conditions. The display may differ from the

WIPER AND WASHER SWITCH

actual outside temperature or the temperature displayed on various signs or billboards.


A WARNING

In freezing temperatures the washer fluid may freeze on the windscreen and obscure your vision. Warm the windscreen with the defogger before you wash it.

CAUTION

- Do not open/release the bonnet when the front wiper arms are raised from their original position.
- Do not operate the washer continuously for more than 15 seconds.
- Do not operate the washer if the reservoir tank is empty or frozen.

WINDSCREEN



The windscreen wiper and washer can be operated when the ignition switch is in the ON position.

Wiper operation

Move the lever up or down to operate the wiper at the following speeds:

- (1): <AUTO>(= =) operates the rain-sensing auto wiper system. (See "Rain sensor" (P.106).)
 - The wiper operation speed will vary in accordance with the vehicle speed in the <AUTO> position. For example, when the vehicle speed is high, the intermittent operation speed will be faster.
- ② : Low () for continuous low speed operation.
- 3 : High () for continuous high speed operation.
- 4: for a single sweep operation of the wiper.

The selected position of the wiper lever is shown in the Vehicle Information Display.

Washer operation

Pull the lever towards you (5) to operate the washer.

Wiper drip wipe system (where fitted):

The wiper will also operate once about 3 seconds after using the washer. This operation is to wipe washer fluid that has dripped on the windscreen.

Pulling up the wiper arms:

The wiper arms should be in the service (up) position when replacing the wiper blades.

To pull the wiper arms up to the service position: within 1 minute of placing the ignition switch in the **OFF** position, push the lever up 4 twice in quick succession. The wiper operation stops in midoperation. The wiper arms can then be pulled up to the service position.


To return the wiper arms to their normal position, place the wiper arms in the down position and then push the lever 4 up once.

For more information on replacing the windscreen wiper blades, see "Wiper blades" (P.329).

CAUTION

- This function can be operated even if the ignition switch is in the ON position. However, to prevent an accident or damage when pulling up the wiper arms, be sure to observe the following precautions.
 - Make sure the shift lever is in the P (Park) position.
 - Never allow the passengers to operate the windscreen wiper switch inadvertently.
- Do not operate the windscreen wiper while the wiper arms are pulled up. The wiper arms may be damaged.

Rain sensor



The sensor (1) of the rain-sensing auto wiper system located on the upper part of the windscreen, in front of the rear view mirror, can automatically turn on the wipers and adjust the wiper speed depending on the rainfall intensity and the vehicle speed when the lever in the <AUTO> position.


The sensitivity can be adjusted by rotating the ring of the wiper switch forward - less sensitive, or backward - more sensitive

NOTE:

- Be sure to turn off the rain-sensing auto wiper system when the car is in the car wash.
- Leaving the lever in <AUTO> position will not harm the rain sensor system, although occasional unexpected activation of the wipers may occur.

- If the switch is left in the <AUTO> position. the wipers may operate unexpectedly when dirt, fingerprints, oil film or insects are covering the windscreen of the rain sensor location. The wipers may also operate when exhaust gas or moisture affects the rain sensor.
- Do not touch or cover the windscreen where the rain sensor is located. The wipers may operate unexpectedly when the wiper switch is in the <AUTO> position and the ignition switch is in the ON position. This can cause an injury or may damage a wiper.

REAR WINDOW



A WARNING

In freezing temperatures the washer solution may freeze on the rear window and obscure vour vision. Warm the rear window with the rear window defogger before using the rear wipers.

CAUTION

- Do not operate the washer continuously for more than 15 seconds.
- Do not operate the washer if the reservoir tank is empty or frozen.

The rear window wiper and washer operates when the ignition switch is in the ON position.

Wiper operation

Turn the switch clockwise to the intermittent (= =. 1) position or continuous () position for wiper operation.

To stop the wiper operation, turn the switch back to the OFF position.

The selected position of the wiper lever is shown in the Vehicle Information Display.

Washer operation:

To operate the washer, push the lever towards the front of the vehicle (3) until the desired amount of washer fluid is spread on the rear window. The wiper will automatically operate several times.

Wiper drip wipe system (where fitted):

The wiper will also operate once about 3 seconds after using the washer. This operation is to wipe washer fluid that has dripped on the windscreen.

The mode can be turned off. For details, see "[Vehicle Settings]" (P.89) .

Reverse synchronisation function (where fitted)


When the windscreen wiper switch is in either the intermittent or <AUTO>, low or high speed position, placing the shift lever in the R (Reverse) position will operate the rear window wiper.

The mode can be turned off. For details, see "[Vehicle Settings]" (P.89).

NOTE:

In the <AUTO> position , the rear wiper will not begin to sweep when the shift lever is placed in the R position. It waits until the front wipers have made the first sweep.

THERMACLEAR HEATED WINDSCREEN (where fitted)



ThermaClear Heated Windscreen On/Off

To defog/defrost the windscreen glass, start the engine and push the ThermaClear button (A). The indicator light will come on. Push the button again to turn the ThermaClear system off.

The ThermaClear system will turn off automatically after approximately 6 minutes - if the windscreen clears before this time, push the button again to turn the ThermaClear system off.

NOTE:


- The ThermaClear system can only be activated while the engine is running.
- Before activating the ThermaClear system make sure to remove excess snow/ice from the windscreen.
- Electrical conductors embedded in the windscreen provide the heating of the windscreen. If damage occurs to the windscreen

DEFOGGER SWITCH

HEADLIGHT AND TURN SIGNAL SWITCH

have the ThermaClear system checked by a NISSAN dealer or qualified workshop.

- Reduced performance or deactivation of the ThermaClear Heated Windscreen may be noticed to preserve the battery. This is not a malfunction.
- NISSAN recommends using the ThermaClear system to support defogging of the windscreen. For more information, see "Automatic air conditioner" (P.167).



The rear window defogger switch will only operate when the engine is running.

The defogger is used to reduce the moisture, fog or frost on the rear window surface and outside door mirror surface to improve the rear view.

When the defogger switch ① is pushed, the indicator light ② illuminates and the defogger operates for approximately 20 minutes. After the preset time has passed, the defogger will turn off automatically.


To turn off the defogger manually, push the defogger switch again.

CAUTION

When cleaning the inner side of the window, be careful not to scratch or damage the electrical conductors on the surface of the window.

NISSAN recommends you to consult the local regulations concerning the use of lights.

HEADLIGHT SWITCH



Lighting

Turn the switch to the spas position:

The front side, tail, number plate and instrument lights will come on. The indicator light ${\tt SPQE}$ in the instrument panel will come on.

Turn the switch to the $\ \bigcirc \$ position:

The headlights will come on and all the other lights remain on.

The selected position of the headlight switch is shown in the Vehicle Information Display.

CAUTION


Never leave the light switch on for extended periods of time while the engine is not running.

Daytime light system (where fitted)

The front daytime running lights will come on when the engine is running.

When the light switch is turned to the EpgE position, the daytime running lights will turn off.

Autolight system ($\langle AUTO \rangle - \rangle$



The autolight system allows the headlights to be set so they turn on and off automatically. When active, the autolight system will:

- Turn on the headlights, front side, tail, number plate and instrument panel lights automatically when it gets dark.
- Turn off all the lights when it gets light.


To activate the autolight system:

- Turn the headlight switch to the <AUTO> position.
- Place the ignition in the ON position.

To disable the autolight system:


Turn the switch to the ⇒q; , or ≨○ position.

High beam select



- To select the high beam when in the 40 position, push the lever forward. The high beam lights come on and the D indicator light illuminates.
- Pull the lever back to select the low beam (C position).
- Pulling the lever towards you will flash the headlight high beam.

Dynamic high beam assistant



A camera-controlled high beam assistant which

changes from low beam to high beam automatically.

Precautions:

A WARNING

The dynamic high beam assistant cannot compensate for road and weather circumstances while driving. The system saves the driver from having to operate the switch. The driver always remains responsible for choosing the correct light setting.

Specific situations in which to operate the headlight switch manually:

- In heavy rain, snowy conditions. (general poor visibility and bad weather conditions).
- When the vehicle sensors are dirty, covered or broken.

Dynamic high beam assistant activated:

When the headlight switch is in the <AUTO> position, the light sensor detects darkness, and the lever is pushed forward (into high beam position), the dynamic high beam assistant is operational. The dynamic high beam assistant indicator light **≣**(**A**) in the instrument panel is on.

The system operates as follows:

 High beam comes on automatically in dark conditions:

If the vehicle speed is over 40 km/h (25 MPH) and no other road users are recognised.

The \blacksquare D high beam light (blue) comes on additionally.

High beam turns off automatically:
 If the vehicle speed drops below 25 km/h (15 MPH) or other road users are detected.
 The ED High beam light (blue) turns off.

NOTE:

If the dynamic high beam assistant cannot function (for example: up to 15 seconds after start up, snow covering front camera or similar) the headlights will operate as if the switch was in the manual position. At all times, the status of the dynamic high beam assistant status system is shown by the indicator lights in the instrument panel. Full dynamic high beam assistant operation is shown by the $\exists \triangle$ indicator light. If the system cannot function, only the $\exists \bigcirc$ high beam indicator light and/or $s\bigcirc$ dipped beam indicator light is illuminated, depending on the current switch position.

To disable the dynamic high beam assistant:

To turn the dynamic high beam assistant off turn the headlight switch to the EPAE, or $\mbox{\em CP}$ position.

"Friendly Lighting"

The "Friendly Lighting" function is a convenience facility. It allows you to provide lighting from the vehicle after the ignition has been placed in the LOCK position and the headlight switch is in the <AUTO> (where fitted) position. Pulling the headlight switch toward you once will activate the headlight for approximately 30 seconds. After that period of time, it will automatically switch off.

It is possible to pull the headlight switch up to four

times to increase the lighting period up to 2 minutes.

NOTE:

The "Friendly Lighting" function can be cancelled by placing the ignition in the ACC or ON position again.

Battery save function

The battery save feature prevents your vehicle from discharging the battery after you have left the external lights, map lamps or room lamps on when exiting the vehicle. This occurs when the ignition is placed in the OFF or LOCK position after the engine has been running.

NOTE:

The next time the engine is started the external lights, map lamps or room lamp will come on again.

Battery save function for external lights:

If the ignition is placed in the OFF position after driving but the external lights are accidentally left on, the external lights will automatically be switched off as soon as the driver's door is opened.

It is possible to leave the external lights on permanently by switching them back on using the headlight switch while the ignition is still in the LOCK or OFF position. In this case, the light reminder chime will sound when the driver's door is opened.


Battery save function for interior light:

The interior light will automatically be switched off

FOG LIGHT SWITCH

after a period of time if it has been accidentally left on.

TURN SIGNAL SWITCH



Direction indicator


Move the lever up or down ① to indicate right or left. When the turn is completed, the turn signal is automatically cancelled.

Lane change signal


Move the lever only part of the way up or down ② to signal a lane change (right or left). The indicator lights will flash three times before cancelling automatically.

NOTE:

This feature will only work if the 3 flash turn signal setting has been set to ON in the Vehicle Settings menu of the vehicle information display (see "[Vehicle Settings]" (P.89)).



Type A: Rear fog light only



Type B: Front and rear fog lights

FRONT FOG LIGHT (where fitted)

The front fog lights should only be used when visibility is seriously reduced – generally, to less than 100 m (328 ft).

but will not operate if the headlight switch is in the <AUTO> position and low beam is not activated.

To turn the front fog lights on, turn the fog light switch to the ※ position. The front fog lights and indicator light will come on. The fog light switch will return to the OFF position (–). For additional information, see "Warning lights, indicator lights and audible reminders" (P.72).

To turn the front fog lights off, turn the fog light switch to the 幻 position again. The front fog lights and indicator light will turn off. The fog light switch will return to the OFF position.

REAR FOG LIGHT


The rear fog light should only be used when visibility is seriously reduced – generally, to less than 100 m (328 ft).

The rear fog lights can be operated in any headlight switch position (spq: or si or <AUTO>), but will not operate if the headlight switch is in the <AUTO> position and low beam is not activated.

To turn the rear fog light on, turn the fog light switch to the Opposition. The rear fog light and indicator light will come on. The fog light switch will return to the OFF position (–). For additional information, see "Warning lights, indicator lights and audible reminders" (P.72).

To turn the rear fog light off, turn the fog light switch to the $\bigcirc \ddagger$ position again.

HEADLIGHT AIMING CONTROL SWITCH




Depending on the number of occupants in the vehicle and the load it is carrying, the headlight axis may be higher than desired. If the vehicle is travelling on a hilly road, the headlights may directly hit the rear-view mirror of the vehicle ahead or the windscreen of an oncoming vehicle. The light axis can be lowered using the switch located on the driver's side of the instrument panel, next to the steering wheel.

The higher the number designated on the switch, the lower the axis.


When travelling with no heavy load on a flat road, select position 0.

NISSAN recommends consulting local regulations on the use of lights.



To sound the horn, push the centre pad area ① of the steering wheel.


HEATED STEERING WHEEL (where fitted)



Push the heated steering wheel switch to warm the steering wheel after the hybrid system starts.

The indicator light on the switch will illuminate. If the surface temperature of the steering wheel is below 30°C (86°F), the system will heat the steering wheel and cycle off and on to maintain a temperature between 25 and 45°C (77 to 113°F) dependent on cabin temperature. The indicator light will remain on as long as the system is on.

The heated steering wheel system is automatically turned off after 30 minutes. Push the switch again to turn the heated steering wheel system off manually. The indicator light will turn off.



The seats can be warmed by built-in heaters. The switches (1) and (2) located on the heater and air conditioning unit can be operated independently of each other.


- Start the engine.
- Select heat range.
 - For high heat, push the button once (both indicator lights will illuminate).
 - For low heat, push the button again (one indicator light will illuminate).
- 3. To turn off the heater, push the button again. Make sure the indicator lights turns off.

The heater is controlled by a thermostat, automatically turning the heater on and off. The indicator light will remain on as long as the switch is on

When the vehicle's interior is warmed, be sure to turn off the switch(es).

CAUTION

- The battery could run down if the seat heater is operated while the engine is not running.
- Do not use the seat heater for extended periods or when no one is using the seat.
- Do not put anything on the seat which insulates heat, such as a blanket, cushion, seat cover, etc. Otherwise, the seat may become overheated.
- Do not place anything hard or heavy on the seat or pierce it with a pin or similar object. This may result in damage to the seat heater.
- Any liquid spilled on the heated seat should be removed immediately with a dry cloth.
- When cleaning the seat, never use petrol, thinner, or any similar materials.
- If any malfunctions are found or the heated seat does not operate, turn the switch off and have the system checked by a NISSAN dealer or qualified workshop.



A WARNING


Take care as the power outlet and plug may be hot during or immediately after use.

CAUTION

- This power outlet is not designed for use with a cigarette lighter unit.
- Do not use with accessories that exceed a 12 volt, 120 W (10 A) power draw. Do not use double adaptors or more than one electrical accessory.
- Use this power outlet with the engine running (do not use for extended periods of time with the engine stopped or idling).
- Avoid using when the air conditioner, headlights or rear window defogger are on.
- When not in use, be sure that the cap is closed. Do not allow water to come into contact with the outlet.

WIRELESS CHARGER (where fitted)

- Before inserting or disconnecting a plug, be sure to turn off the power switch of the electrical accessory being used or remove the key from the ignition to turn the ACC power of the vehicle off.
- Fully push the plug in sufficiently. If sufficient contact is not made, the plug may overheat or the internal temperature fuse may blow.



- 1 Charging pad
- 2 Indicator
- A <Qi> logo

The wireless charger is located on the front of the centre console. Lay the smartphone on the <Qi>logo (A) on the charging pad of the wireless charger. Charging will start automatically. The smartphone will be charged continuously while the ignition is ON.

A WARNING

- Never put metallic materials between the wireless charger and a smartphone.
- Those who use a pacemaker or other medical equipment should contact the electric medical equipment manufacturer for the possible influences before use.
- Never put cloth over the smartphone during charging process.
- Never charge a smartphone when it is wet.
- Never put metallic materials or small

goods such as a cigarette lighter, Intelligent Key or memory drive on the charging pad.

CAUTION

 Do not put an RFID/NFC/credit card between the wireless charger and a smartphone.

This could cause data corruption in the card.

- Do not use the wireless charger with dust accumulated or dirt on the pad.
- Do not hit the surface of the wireless charger.
- Do not spill liquid (water, drinks, etc.) on the charging pad.
- Do not use grease, oil or alcohol for cleaning charging pad.
- Do not remove rubber mat (including non wireless charger mat).

WIRELESS CHARGER INDICATOR

The indicator t will illuminate in orange when the charging process is started.

When the charging has completed, the indicator illuminates in green (not applicable to all wireless charge devices).

If a malfunction occurs or the charging process has stopped, the indicator will blink in orange for 8 seconds then turn off.

STORAGE

OPERATION OF THE WIRELESS CHARGER

To use the wireless charger, it is necessary to seat the smartphone well within the charging pad. To maximise charging performance, ensure the smartphone is fully seated on the centre of the charging pad over the <Qi> logo (A). Because the location of the power receiver may vary depending on the smartphone, you will need to try and find the area that suits your smartphone.

Because some smartphone cases or accessories may adversely affect charging, remove them before wireless charging.

Turn off the vibration function of the smartphone before wireless charging.

NOTE:

- Only a <Qi> certified smartphone can be used.
- The smartphone may become warm during the charging process and the charging may be stopped by the protection function of the wireless charger. The indicator will blink in orange then turn off. This is not a malfunction.

If this occurs, remove the smartphone from the wireless charging pad and let it cool down before putting it back on the charging pad.

- The wireless charging process may be stopped by the status of the smartphone (battery temperature, etc.).
- If a radio noise interference occurs during charging process, put the smartphone onto

the centre (<Qi> logo) position of the wireless charger.


- The wireless charging process will stop during process of searching the Intelligent Key.
- The wireless charging process will not be started when a USB (Universal Serial Bus) cable is connected to the smartphone. The indicator may illuminate in orange or blink if the smartphone is put on the wireless charger with a USB cable connected. However, charging is not performed.
- Depending on the type of the smartphone, the indicator may remain illuminated in orange even when the charging process has been completed.

STORAGE TRAYS

A WARNING

To help prevent injury in an accident or sudden stop, do not place sharp objects in the trays.

GLOVE BOX




A WARNING

Keep the glove box lid closed while driving to help prevent injury in an accident or a sudden stop.

To open the glove box, lift the latch and lower the lid.

CONSOLE BOX




A WARNING

The centre console box should not be used while driving so that full attention may be given to vehicle operation.

To open the console box lid, pull the lever 1 and pull up the lid.


To close, push the lid down until the lock latches.

CARD HOLDER



The console box lid contains a designated storage area for cards.

CUP HOLDERS



A WARNING


Cup holders should not be used while driving so that full attention may be given to vehicle operation.

To access the rear cup holders (where fitted), lower the centre armrest.

CAUTION

- Avoid abrupt starting and braking when the cup holder is being used to prevent spillage. If the liquid is hot, it can scald you or your passenger.
- Use only soft cups in the cup holder. Hard objects can injure you in an accident.


BOTTLE HOLDER



CAUTION

- Do not use the bottle holder for any other objects that could be thrown about in the vehicle and possibly injure people during sudden braking or an accident.
- Do not use the bottle holder for open liquid containers.

COAT HOOKS




CAUTION

Do not apply a load of more than 1 kg (2 lb) to the hook.

The coat hook is fitted to the rear assist grip on the driver's side only.


SEAT POCKET (where fitted)



Seat pocket (where fitted)

A seat pocket (where fitted) is located on the back of the driver and/or passenger seat.

PARCEL SHELF




A WARNING

- Never put anything on the parcel shelf, no matter how small. Any object on it could cause an injury in case of an accident or if the brakes are applied suddenly.
- Do not leave the parcel shelf in position when it is disengaged from the grooves.

- Properly secure all cargo to help prevent it from sliding or shifting. Do not place cargo higher than the seatbacks. In a sudden stop or collision, unsecured cargo could cause personal injury.
- Properly secure cargo and do not allow it to contact the top tether strap when it is attached to the top tether anchor. Cargo that is not properly secured or cargo that contacts the top tether strap may damage the top tether strap during a collision. If the cargo cover contacts the top tether strap when it is attached to the top tether anchor, remove the cargo cover from the vehicle or store it in its storage space. If the cargo cover is not removed, it may damage the top tether strap during a collision. Your child could be seriously injured or killed in a collision if the child restraint top tether strap is damaged.

LUGGAGE COMPARTMENT/BOOT FLOOR (where fitted)



- Do not put objects heavier than 50 kg (110
 lb) on the load floor.
 - Never allow anyone to ride in the luggage area. It is extremely dangerous to ride in a luggage area inside of a vehicle. In a collision, people riding in these areas are more likely to be seriously injured or killed.
- Only two anchorage points identified by the top tether labels can be used for top tether strap anchorage. Under no circumstances should the luggage hooks be used for top tether strap anchorage.

The luggage (cargo) compartment or boot floor has a dual position system with a loose floorboard that allow different luggage compartment arrangements.

CAUTION


 The load should be distributed evenly and should not exceed 50 kg (110 lb) on the boards.

A WARNING

 Properly secure all cargo with ropes or straps to help prevent it from sliding or shifting. Do not place cargo higher than the seatbacks. In a sudden stop or collision, unsecured cargo could cause personal injury.

WINDOWS

LUGGAGE HOOKS



The luggage hooks are for shopping bags, etc.

A WARNING

Do not apply a total load of more than 3 kg (7 lb) to the hook.

POWER WINDOWS

The power window switches are located on the door panels and will only operate when the ignition is in the **ON** position.

A WARNING


- Make sure that all passengers have their hands, etc. inside the vehicle before operating the power windows.
- To help avoid risk of injury or death through unintended operation of the vehicle and/or its systems, do not leave children, people who require the assistance of others or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.
- It is recommended to instruct all occupants in the safe operation of power windows with particular emphasis given to the safety and supervision of children.

The power windows operate when the ignition is in the ON position or for approximately 45 seconds after the ignition is placed in the OFF position. If the drivers or front passenger's door is opened during this period of approximately 45 seconds, power to the windows is cancelled.

To open a window, push down the power window switch.

To close a window, pull up the power window switch.

Driver's side main window switch



The driver's switch, which is the main switch, can control all of the windows.

Locking passengers' windows:

When the lock button (1) is pushed in, only the driver's window can be operated.


To cancel the passengers' windows lock, push the lock button (1) again.

Passenger's window switch



The passenger's switch can control its corresponding window.

Automatic function



The automatic operation is available for the switch that has an /A| mark on its surface.

The automatic function enables a window to fully open or close without holding the switch down or up.

To fully open the window, push the power window

switch down to the second detent and release the switch. To fully close the window, pull the power window switch up to the second detent and release the switch. The switch does not have to be held during window operation.

To stop the window open/close operation during the automatic function, push down or pull up the switch in opposite direction.

Window timer:

The window timer allows the window switch to be operated for approximately 45 seconds even if the ignition is placed in the **OFF** position. The window timer will be cancelled when the driver's or front passenger's door is opened or the preset time has expired.

Auto-reverse function:

A WARNING

There is a small distance just before the closed position which cannot be detected. Make sure that all passengers have their hands, etc. inside the vehicle before closing the windows.

The auto-reverse function enables a window to automatically reverse when something is caught in the window as it is closing by the automatic function. When the control unit detects an obstacle, the window will be lowered immediately.

Depending on the environment or driving conditions, the auto-reverse function may activate if an impact or load similar to something being caught in the window occurs

NOTE:

The auto-reverse function is only available for windows with the automatic function.

If the windows do not close automatically

If the power window automatic function (closing only) does not operate properly, perform the following procedure to initialise the power window system.

- Place the ignition in the ON position.
- Close the door.
- Open the window completely by operating the power window switch.
- Pull the power window switch and hold it to close the window, and then hold the switch more than 3 seconds after the window is closed completely.
- Release the power window switch. Operate the window by the automatic function to confirm the initialisation is complete.
- Perform steps 2 through 5 above for other windows.

If the power window automatic function does not operate properly after performing the procedure above, have your vehicle checked by a NISSAN dealer or qualified workshop.

INTERIOR LIGHTS


CAUTION

Do not use for extended periods of time with the engine stopped. This could discharge the batterv.

NOTE:

The interior lights will go off after a period of time unless the ignition switch is in the ACC or ON position.

FRONT ROOM LIGHT



The room light (A) has a three-position switch. When the switch is in the on position 3, the light illuminates

When the switch is in the centre position (2), the room light illuminates when a door is opened.

The interior light timer will keep the room light on for a period of time when:

The ignition is placed in the OFF or LOCK position.

- The doors are unlocked with the UNLOCK button (on the Intelligent Key) or the request switch with the power placed in the LOCK position.
- Any door is opened and then closed with the power placed in the LOCK position.

The interior light timer will be cancelled when:

- The driver's door is locked.
- The power is placed in the ON position.

When the switch is in the <OFF> position ①, the room light does not illuminate, regardless of any condition.

Room light timer (where fitted)

The room light will stay on for a period of time when:

- The ignition is switched off.
- The doors are unlocked.
- Any door is opened and then closed.


The timer is cancelled, and the interior light will turn off when:

- The doors are locked.
- The ignition switch is turned to the ON position.

FRONT MAP LIGHTS

To turn on the front map light (B), push the on switch (2), and the light illuminates. To turn off, push the off switch (1).

REAR INTERIOR LIGHT



The light switch has three positions: <ON> , <DOOR> and <OFF>.

ON position

When the switch is in the <ON> position (1), the light will illuminate.

DOOR position

When the switch is in the <DOOR> position (2), the light will illuminate when a door is opened.

OFF position

When the switch is in the <OFF> position 3, the light does not illuminate, regardless of any condition.


LUGGAGE COMPARTMENT LIGHT

The light comes on automatically when the tailgate is opened. When the tailgate is closed, the light goes off.

3 Pre-driving checks and adjustments

Keys	124
NISSAN Anti-Theft System (NATS) key	124
Intelligent Key	124
Key number	124
New keys	125
Emergency/mechanical key	125
Remote keyless entry system (where fitted)	125
Using the remote keyless entry system	126
Key fob operation failure	127
Intelligent Key system	127
Intelligent Key operating range	128
Using Intelligent Key system	128
Door locks/unlocks precaution	129
Doors locking/unlocking	129
Starting the hybrid system with the	
Intelligent Key	131
Troubleshooting guide	132
Doors	133
Super Lock system (RHD models)	133
Locking/unlocking with the key (vehicle	
dead battery)	
Inside door handle	
Power door lock switch	
Child safety lock — rear doors	
Tailgate lock	135

Security system	136
Alarm system (where fitted)	136
NISSAN Anti-Theft System (NATS) (where fitted)	136
Bonnet	137
Fuel-filler lid and cap	137
Fuel filler lid	137
Fuel filler cap	137
Electric parking brake	138
Driving away when towing a trailer	139
Automatic Brake Hold	140
How to activate/deactivate the automatic brake	
hold function	140
How to use the Automatic Brake Hold function	141
Steering wheel	142
Sun visors	142
Mirrors	143
Inside rear-view mirror	143
Automatic anti-dazzling inside mirror	
(where fitted)	143
Outside rear-view mirrors	144
Vanity mirror	145



Intelligent Key

- Intelligent Key
- Emergency/Mechanical key (inside the Intelligent Key), see "Emergency/mechanical key" (P.125).
- Key number plate

NISSAN ANTI-THEFT SYSTEM (NATS)* KEY

Your vehicle can only be driven with the keys specific to your vehicle. Only NISSAN Anti-Theft System (NATS)* keys can be used with your vehicle (see "Security system" (P.136).).

INTELLIGENT KEY

Your vehicle can only be driven with the Intelligent Kevs, which are registered to your vehicle's Intelligent Key system components and NISSAN Anti-Theft System (NATS*) components. As many as 4 Intelligent Keys can be registered and used with one vehicle. The new keys must be registered by a NISSAN dealer or qualified workshop prior to use with the Intelligent Key system and NATS of your vehicle. Since the registration process requires erasing all memory in the Intelligent Key components when registering new keys, be sure to take all Intelligent Keys that you have to the NISSAN dealer or qualified workshop.

*: Immobilizer

CAUTION

- Be sure to carry the Intelligent Key with vou. Do not leave the vehicle with the Intelligent Kev inside.
- Be sure to carry the Intelligent Key with you when driving. The Intelligent Key is a precision device with a built-in transmitter. To avoid damaging it, please note the following.
 - The Intelligent Key is water resistant; however, wetting may damage the Intelligent Key. If the Intelligent Key gets wet, immediately wipe until it is completely dry.
 - Do not allow the Intelligent Key to come into contact with water or salt water this could affect the system function.
 - Do not bend, drop or strike it against another object.
 - Do not place the Intelligent Key for an extended period in a place where temperatures exceed 60°C (140°F).
 - Do not change or modify the Intelligent Key.
 - Do not use a magnetic key holder.

- Do not place the Intelligent Key near equipment that produces a magnetic field such as a TV, audio equipment and personal computers.
- If an Intelligent Key is lost or stolen, NISSAN recommends erasing the ID code of that Intelligent Key. This will prevent the Intelligent Key from unauthorised use to unlock the vehicle. For information regarding the erasing procedure, please contact a NISSAN dealer or qualified workshop.

KEY NUMBER

A key number plate 3 is supplied with your key

Record the key number on the "Security Information" page at the end of this manual and keep it in a safe place, but not in the vehicle. The key can only be duplicated using an original key or the original key number. The key number is required when you have lost all of the keys and do not have the original key to duplicate from. If the key is lost, or you need extra keys, provide an original key or the key number to a NISSAN dealer or qualified workshop.

NISSAN does not record key numbers, so it is very important that you keep a record of your key number

NEW KEYS


As many as four NATS keys can be registered to one vehicle at any one time. New keys must be registered to the NATS components of your vehicle by a NISSAN dealer.

When registering a new key at a NISSAN dealer, you are requested to bring all of your NATS keys with you. This is necessary because the registration process will erase and reprogram the memory of your vehicle's NATS components.

NOTE:

A key number is only required if you have lost all of your keys and do not have one to duplicate from. If you still have a key, this key can be duplicated by a NISSAN dealer.

EMERGENCY/MECHANICAL KEY



Intelligent Key

Intelligent Key and emergency/mechanical key:

The emergency key can be used to unlock the driver's door


- To remove the mechanical key, release the lock knob at the back of the Intelligent Key.
- To install the mechanical key, firmly insert it into the Intelligent Key until the lock knob returns to the lock position.

Use the mechanical key to lock or unlock the doors. (See "Locking/unlocking with the key (vehicle dead battery)" (P.133).)

For further details on accessing and using the emergency key, see "Push-button ignition switch" (P.192).

NOTE:

For the driver's side door, it is normal for the key not to go all the way into the key cylinder.



Intelligent Key

Lock button

→ Unlock button

The remote keyless entry system can operate all door locks (including the tailgate) using the Intelligent Key. The Intelligent Key can operate at a distance of approximately 5 m (15 ft) from the vehicle (the effective distance depends upon the conditions around the vehicle and the state of the key fob battery).

As many as 4 remote controllers can be used with one vehicle. For information about the purchase and use of additional remote controllers, contact a NISSAN dealer or qualified workshop.

The Intelligent Key will not function under the following conditions:

- When the distance between the Intelligent Key and the vehicle is more than approximately 5 m (15 ft).
- When the Intelligent Key battery is discharged.

When the kev is in the ignition switch.

All doors can be locked or unlocked from the outside by pressing the \mathbf{A} (LOCK) or \mathbf{A} (UNLOCK) button on the Intelligent Key.

A WARNING

Super Lock system equipped models:

Failure to follow the precautions below may lead to hazardous situations. Make sure the Super Lock system activation is always conducted safely.

- When the vehicle is occupied, never super lock the doors. Doing so will trap the occupants, since the Super Lock system prevents the doors from being opened from the inside of the vehicle.
- Only super lock by double-pressing the "LOCK" button when there is a clear view of the vehicle. This is to prevent anybody from being trapped inside the vehicle through the Super Lock system activation.

For further details on the Super Lock system, see "Super Lock system (RHD models)" (P.133).

CAUTION

- When locking the doors using the Intelligent Key, be sure not to leave the key in the vehicle.
- Always remove the ignition key or Intelligent Key, close all windows before operating the key fob door lock system.
- Ensure that the driver's door is securely closed before operating the Intelligent Kev

door lock system for correct operation of the system.

- Do not allow the Intelligent Key, which contains electrical components, to come into contact with water or salt water. This could affect the system function.
- Do not drop the Intelligent Key.
- Do not strike the Intelligent Key sharply against another object.
- Do not place the Intelligent Key for an extended period in an area where temperatures exceed 60°C (140°F).

If an Intelligent Key is lost or stolen, NISSAN recommends erasing the ID code of that Intelligent Key from the vehicle. This may prevent the unauthorised use of the Intelligent Key to unlock the vehicle. For information regarding the erasing procedure, contact a NISSAN dealer or qualified workshop.

For information regarding the replacement of a battery, see "Intelligent Key battery replacement" (P.327).

USING THE REMOTE KEYLESS ENTRY SYSTEM

Locking the doors

- 1. Place the ignition in the OFF position and make sure you have the Intelligent Key with you when exiting the vehicle.
- 2. Close all doors (including the backdoor) and windows.

- Push the A button.
 - All the doors and the backdoor will lock.
 - Hazard indicator lights flash once for confirmation.
- 4. Operate the door handles to confirm that the doors have been securely locked.

If the h button is pushed with all the doors locked, the direction indicators will flash once to remind you that the doors are already locked.

Unlocking the doors

Convenience door unlock mode:

As default, the door unlock (convenience) mode is set to unlock all the doors and the tailgate with one push on the 🔒 button.

Push the 🔒 button:

- All doors and the tailgate will be unlocked.
- Hazard indicator lights flash twice.

Selective door unlock mode:

Selective door unlock mode allows the remote unlocking of only the driver's door to prevent an attacker from entering the vehicle via an unlocked passenger door.

- 1. Push the 🔒 button.
 - The driver's door unlocks.
 - Hazard indicator lights flash twice quickly.
- Open the driver's door.
- 3. Push the A button again (if necessary):
 - All doors and the tailgate will be unlocked.

INTELLIGENT KEY SYSTEM

Hazard indicator lights flash twice slowly.

NOTE:

Pushing twice on the a button all doors will be unlocked.

Switching between convenience and selective door lock mode:

For details, see "[Vehicle Settings]" (P.89).

Auto-relock (where fitted):

An auto-relock function will operate a short period after a full or partial unlock, if no further user action is taken. The auto-relock will be cancelled if any door is opened or the key is inserted into the ignition.

KEY FOB OPERATION FAILURE

The key fob may not work properly if:

- The key fob battery is low.
 - See "Intelligent Key battery replacement" (P.327) for key fob battery replacement instructions and the required battery type.
- The locking/unlocking system has been used continuously.
 - An anti lock-abuse system prevents the lock motors from overheating and disables the key fob locking operation for a short period of time if the system is used continuously.
- The door handle is being pulled while the key fob is being operated.
- The vehicle's battery is dead.

NOTE:

See [No key Detected] warning, [Key battery low] indicator, [Key ID Incorrect] warning or Intelligent Key system warning in "Vehicle information display" (P.82) for more information.

A WARNING

- Radio waves could adversely affect electric medical equipment. Those who use a pacemaker should contact the electric medical equipment manufacturer for the possible influences before use.
- The Intelligent Key transmits radio waves when the buttons are pushed. The radio waves may affect aircraft navigation and communication systems. Do not operate the Intelligent Key while on an aeroplane. Make sure the buttons are not operated unintentionally when the unit is stored during a flight.

The Intelligent Key system can operate all the door locks and the tailgate by using the Intelligent Key or pushing a request button on the vehicle without taking the key out from a pocket or purse. The operating environment and/or conditions may affect the Intelligent Key system operation.

Be sure to read the following items before using the Intelligent Key system.

CAUTION

- Be sure to carry the Intelligent Key with you when operating the vehicle.
- Never leave the Intelligent Key in the vehicle when you leave the vehicle.

In such cases, correct the operating conditions before using the Intelligent Key function or use the mechanical key.

Although the life of the Intelligent Key battery

varies depending on the operating conditions, the battery's life is approximately 2 years. If the battery is discharged, replace it with a new one.

For information regarding replacement of a battery, see "Intelligent Key battery replacement" (P.327).

When the Intelligent Key battery is almost discharged, firmly apply the footbrake and touch the power switch with the Intelligent key. Then push the power switch while depressing the brake pedal within 10 seconds after the chime sounds. For details, see "Intelligent Key battery discharge" (P.195).

Pay special attention that the vehicle battery is not completely discharged.


CAUTION

- Do not allow the Intelligent Key, which contains electrical components, to come into contact with water or salt water. This could affect the functioning of the system.
- Do not drop the Intelligent Key.
- Do not strike the Intelligent Key sharply against another object.
- Do not change or modify the Intelligent Key.
- The Intelligent Key may be damaged if it gets wet. If the Intelligent Key gets wet, immediately wipe until it is completely dry.
- Do not place the Intelligent Key for an extended period in an area where temperatures exceed 60°C (140°F).
- If the outside temperature is below -10°C

(14°F), the Intelligent Key may not function properly.

- Do not attach the Intelligent Key to a key holder that contains a magnet.
- Do not place the Intelligent Key near equipment that produces a magnetic field, such as a TV, audio equipment, personal computer or mobile phone.
- Make sure the Intelligent Key battery is in good condition. Note that battery life may vary depending on condition, amount of use, ambient temperature, etc.

INTELLIGENT KEY OPERATING RANGE



The Intelligent Key functions can only be used when the Intelligent Key is within the specified operating range from the request (lock/unlock) button ①.


When the Intelligent Key battery is discharged or strong radio waves are present near the operating location, the Intelligent Key system's operating range becomes narrower, and the Intelligent Key may not function properly.

The operating range is within 80 cm (31.50 in) from each request button \bigcirc .

If the Intelligent Key is too close to the door glass, door handle or rear bumper, the request button may not function.

When the Intelligent Key is within the operating range, it is possible for anyone, even someone who does not carry the Intelligent Key, to push the request button to lock/unlock the doors including the tailgate.

USING INTELLIGENT KEY SYSTEM




The request button will not function under the following conditions:

 When the Intelligent Key is left inside the vehicle. If another intelligent key is outside the vehicle, it can be locked/unlocked.

- When the Intelligent Key is not within the operational range
- When any door is open or not closed securely
- When the Intelligent Key battery is discharged


DOOR LOCKS/UNLOCKS PRECAUTION




- Do not push the door handle request button with the Intelligent Key held in your hand as illustrated. The close distance to the door handle will cause the Intelligent Key system to have difficulty recognising that the Intelligent Key is outside the vehicle.
- After locking with the door handle request button, verify the doors are securely locked by operating the door handles.
- To prevent the Intelligent Key from being left inside the vehicle, make sure you carry the key with you and then lock the doors.
- Do not pull the door handle before pushing the door handle request button. The door will be

unlocked but will not open. Release the door handle once and pull it again to open the door.

DOORS LOCKING/UNLOCKING





Request button

When the Intelligent Key is within the range of operation, the door locks can be locked or unlocked by pushing the door handle request button on the driver's or front passenger's door or the tailgate.

The request button will not function under the following conditions:

- When the Intelligent Key is left inside the vehicle. If another intelligent key is outside the vehicle, it can be locked/unlocked.
- When the Intelligent Key is not within the operational range.
- When the Intelligent Key battery is discharged.
- When the doors are open or not closed securely.
- The hybrid system is running.

Locking the doors

- 1. Make sure you have the Intelligent Key when exiting the vehicle.
- Close all doors.
- 3. Press any of the request button (front doors or tailgate).
 - All doors and the tailgate will be locked.
 - Hazard indicator lights flash once for confirmation
 - Super Lock system equipped models: The Super Lock system will be activated if the request button or the Intelligent Key lock button is double-pressed. Hazard indicator

lights flash longer to indicate Super Lock activation.

4 Pull the door handles to confirm that the doors have been securely locked.

CAUTION

Do not leave the duplicate Intelligent Key inside the vehicle as the locking procedure logic will not work.

NOTE:

If the Intelligent Key is left in the vehicle and the door/tailgate request button is pressed, a buzzer will sound to indicate that the Intelligent Key is still inside the vehicle. If another intelligent key is outside the vehicle, it can be locked/ unlocked.

Unlocking the doors

For details about the selective or convenience door unlock mode settings, see "[Vehicle Settings]" (P.89).

Convenience door unlock mode:

As default, the door unlock (convenience) mode is set to unlock all the doors and the tailgate with one push on the door/tailgate request button.

- All doors and the tailgate will be unlocked.
- Hazard indicator lights flash twice quickly.

Selective door unlock mode:

Selective door unlock mode allows the remote unlocking of only the driver's door to prevent an attacker from entering the vehicle via an unlocked passenger door.

- Push the door/tailgate request button.
 - If the driver's door request button was pressed, only the driver's door unlocks.
 - If the passenger door request button was pressed, only the passenger door unlocks.
 - If the tailgate request button was pressed. only the tailgate unlocks.
 - Hazard indicator lights flash twice quickly.
- 2. Push the request button again within 5 seconds
 - All the doors and the tailgate will be unlocked.
 - Hazard indicator lights flash twice slowly.

NOTE:

- External interference may impair the Intelligent Key's operation. In this case, use the emergency key located in the Intelligent Key. See "Locking/unlocking with the key (vehicle dead battery)" (P.133) for further details.
- If the vehicle is unlocked and no doors are opened for a period of time, the doors will automatically be locked.

Approach unlock function (where fitted)

When you approach the vehicle with the Intelligent Key, the vehicle will be unlocked automatically by the approach unlock function.

This function is disabled by the default setting.

You can enable this function by the vehicle information display. For additional information, see "[Vehicle Settings]" (P.89).

Walk-away lock function (where fitted)

When you walk away from the vehicle with the Intelligent Key, the vehicle will be locked automatically by the walk-away lock function. This function is disabled by the default setting.

You can enable this function by the vehicle information display. For additional information, see "[Vehicle Settings]" (P.89).

NOTE:

- When the doors are locked by the walkaway lock function, the hazard indicator lights flash once (4 seconds). Be sure to confirm the door locks before you leave the vehicle.
- The walk-away lock function may not operate under the following conditions:
 - When the door(s) and/or the tailgate are not closed securely.
 - When the hybrid system is running.
 - When the Intelligent Key is placed inside of the vehicle.
 - When you place the Intelligent Key outside of the vehicle for a period of time. (When a doors is opened and closed, the walk-away lock function will activate.)

STARTING THE HYBRID SYSTEM WITH THE INTELLIGENT KEY See "Push-button ignition switch" (P.192).

CAUTION

- Make sure you carry the Intelligent Key with you when starting and driving the vehicle.
- If the Intelligent Key is too far away from the passenger compartment, the vehicle may not start. See "Intelligent Key operating range" (P.128).

TROUBLESHOOTING GUIDE

Symptom		Possible cause	Action to take
When pushing the ignition switch to start the hybrid system	The [Key battery low] warning appears in the vehicle information display.	The Intelligent Key battery charge is low.	Replace the battery with a new one. See "Intelligent Key battery replacement" (P.327).
	The place the key near the start switch warning appears in the vehicle information display.	The Intelligent Key is not in the vehicle.	Carry the Intelligent Key with you.
When pushing the ignition switch to stop the hybrid system	The [Shift to park] warning appears in the vehicle information display and the inside warning chime sounds continuously	The shift lever is not in the P (Park) position.	Shift the shift lever to the P (Park) position.
	The [No Key Detected] warning appears in the vehicle information display, the outside chime sounds 3 times and the inside warning chime sounds for a few seconds.	The hybrid system is running and the Intelligent Key is not in the vehicle.	Carry the Intelligent Key with you. If you cannot carry the Intelligent Key, push the ignition switch 3 consecutive times or push and hold the ignition switch for more than 2 seconds.
When closing the door after getting out of the vehicle	The [Shift to park] warning appears in the vehicle information display and the outside warning chime sounds continuously.	The ignition switch is in the OFF position and the shift lever is not in the P (Park) position.	Shift the shift lever to the P (Park) position.
When closing the door with the inside lock button (where fitted) in the LOCK position	The outside chime sounds for a few seconds and all the doors unlock.	The Intelligent Key is inside the vehicle or cargo area.	Carry the Intelligent Key with you.
When pushing the request switch or the button on the Intelligent Key to lock the door	The outside chime sounds for a few seconds and all the doors unlock.	A door is not closed securely.	Close the door securely.

SUPER LOCK SYSTEM (RHD models)

A WARNING

Super Lock system equipped models:

Failure to follow the precautions below may lead to hazardous situations. Make sure the Super Lock system activation is always conducted safely.

- When the vehicle is occupied, never super lock the doors. Doing so will trap the occupants, since the Super Lock system prevents the doors from being opened from the inside of the vehicle.
- Only super lock by double-pressing the "LOCK" button when there is a clear view of the vehicle. This is to prevent anybody from being trapped inside the vehicle through the Super Lock system activation.

Double-pressing the "LOCK" button (🔒) on the Intelligent Key, or locking the doors by doublepressing one of the request buttons will activate the Super Lock system. Hazard warning lights flash longer to indicate Super Lock activation.

When the Super Lock system is active, none of the doors can be opened from inside the vehicle. This provides additional security in case of theft or break-in.

The Super Lock system will be released when all the doors are unlocked using the Intelligent Key or a request button.

Emergency situations

If the Super Lock system is activated while you are inside the vehicle, for example by a traffic accident or other unexpected circumstances, follow the instructions below.

To release the Super Lock system:

- Press the Intelligent Key "UNLOCK" button (🔒).
 - All doors can now be opened from inside the vehicle.

To unlock and open the driver's door from inside the vehicle while the Super Lock system is active:

- Open or break the driver's door window.
- Insert the key into the outside door key cylinder and turn it towards the rear of the vehicle.
- 3. The driver's door will unlock and can now be opened from inside the vehicle.


Locking without activating the Super Lock system

A WARNING

Do not leave the key inside the vehicle when leaving the vehicle.

Locking the doors using the door key cylinder, or by a single press of the "LOCK" button on the Intelligent Key, or by a single press of one of the request buttons will not activate the Super Lock system. See "Locking/unlocking with the key (vehicle dead battery)" (P.133) for further information.

LOCKING/UNLOCKING WITH THE KEY (vehicle dead battery)



A WARNING

- When leaving the vehicle, do not leave the key inside the vehicle.
- To help avoid risk of injury or death through unintended operation of the vehicle and/or its systems, do not leave children, people who require the assistance of others or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.

The driver's door can be locked/unlocked from outside using the key/emergency key if the vehicle's battery is dead.

To lock the door, insert the key into the driver's door key cylinder and turn it towards the rear of the vehicle (2).

To unlock the door, turn the key towards the front of the vehicle (1).

See "Emergency/mechanical key" (P.125) for instructions on accessing the Intelligent Key system Emergency key.


CAUTION

The alarm system will be triggered when the door is opened using the key (NISSAN alarm equipped models). To stop the alarm, turn on the hybrid system or press the unlock button on the Intelligent Key.

Initialising the system after vehicle battery loading or replacement

After recharging or replacing the battery, you should release (initialise) the system by unlocking the vehicle using the Intelligent Key.

INSIDE DOOR HANDLE




To unlock and open the door, pull the inside door handle as illustrated.


Models with Super Lock system (where fitted)

The door cannot be opened when the Super Lock system is activated.

POWER DOOR LOCK SWITCH



Power door lock light



- Press to lock
- ② Press to unlock

A WARNING

When leaving the vehicle, do not leave the key inside the vehicle.

The power door lock switch, located on the door trimming, can be used to lock ① or unlock ② all doors simultaneously from inside the vehicle.

The door lock indicator light () in the camera cover (windscreen) comes on when the doors are locked.


NOTE:

Models without the Super Lock system: If a door is manually opened from inside after having pressed the Intelligent Key "LOCK" button (\bigcirc As a result, the door will unlock and the power door lock indicator light (\bigcirc) goes out.

Super Lock equipped models (RHD models)

Locking the doors with the power door lock switch will not activate the Super Lock system.

CHILD SAFETY LOCK — REAR DOORS




The child safety lock helps prevent doors from being opened accidentally, especially when small children are in the vehicle.

When the switch is in the LOCK position, the rear door can only be opened from the outside.

Make sure the child safety lock is working correctly.

TAILGATE LOCK



A WARNING

- Always check that the tailgate has been properly closed to prevent it from opening while driving.
- Do not drive with the tailgate opened. This could allow dangerous exhaust gases to be drawn into the vehicle.
- Closely supervise children when they are around the vehicle to prevent them from playing and being locked in the luggage compartment where they could be seriously injured. Keep the vehicle locked, with the tailgate closed, when not in use, and prevent children's access to the vehicle's keys.


The tailgate can be manually opened from the outside, and it is not locked by the power door lock system, by pushing the button ① located above the rear number plate.

To open the tailgate, unlock it first with one of the following operations, then push the button 1.

- Push the request button (2) of the tailgate. See "Intelligent Key system" (P.127).
- Push the button on the Intelligent Key. See "Intelligent Key system" (P.127).
- Unlock all the doors using the key.
- Push the iside of the power door lock switch.
- Approach the vehicle carrying the Intelligent Key with you and the approach unlock function (where fitted) activated.

To close the tailgate, pull it down until it securely locks and if necessary, lock it with the power door lock system.

Vehicle dead battery - Tailgate lock release lever (where fitted)



The vehicle's tailgate can be unlocked from the inside when the battery is dead. Tilt the seatback down. Slide the release lever (1) as illustrated. See "Rear seats" (P.33) for more information regarding the seat operation.

SECURITY SYSTEM

ALARM SYSTEM (where fitted)

The alarm system provides visual and audible alarm signals if parts of the vehicle are disturbed.

How to arm the alarm system

- 1. Close all doors, windows, tailgate and bonnet.
- Lock the vehicle using the key fob (lock button), for additional information, see "Remote keyless entry system (where fitted)" (P.125).
- The Alarm system will arm 20 seconds after the vehicle has been locked.

Alarm system operation

The system will give the following alarm:

- The siren sounds intermittently and all direction indicators will flash
- The alarm automatically turns off after 28 seconds.

The alarm is activated when:

- The volumetric sensing system (interior movement sensors, where fitted) is triggered.
- Any door / the tailgate is opened.
- The bonnet is opened.
- The ignition circuit is turned on without the owner's key being used.

The alarm system will stop when:

- The vehicle is unlocked using the key fob or intelligent key unlock button.
- The ignition is placed in the ON position with a registered NATS key.

If the system does not operate as described above, have it checked by your NISSAN dealer or qualified workshop.

Interior Movement Sensors (where fitted)

The interior movement sensors (volumetric sensing) detect movements in the passenger's compartment. When the alarm system is set to the armed position, it will automatically switch on the interior movement sensors.

A WARNING

To help avoid risk of injury or death through unintended operation of the vehicle and/or its systems, do not leave children, people who require the assistance of others or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.

NISSAN ANTI-THEFT SYSTEM (NATS) (where fitted)

The NISSAN Anti-Theft System (NATS)* will not allow the hybrid system to start without the use of the registered NATS key.


* Immobilizer

If the hybrid system fails to start using the registered NATS key, it may be due to interference from another NATS key, an automated toll road device or an automated payment device on the key ring. Restart the hybrid system using the following procedure:

- Leave the ignition in the ON position for approximately 5 seconds.
- Place the ignition in the OFF or LOCK position and wait approximately 5 seconds.
- 3. Repeat steps 1 and 2.
- Restart the hybrid system while holding the device (which may have caused the interference) separated from the registered NATS key or NATS Intelligent Key (where fitted).

If this procedure allows the hybrid system to start, NISSAN recommends placing the registered NATS key or NATS Intelligent Key (where fitted) on a separate key-ring to avoid interference from other devices.

FUEL-FILLER LID AND CAP




- 1. Pull the bonnet lock release lever (1), located below the left side of the instrument panel, the bonnet will spring up slightly.
- 2. Push the lever 2, at the front of the bonnet, to the left with your fingertips and raise the bonnet
- 3. Insert the support rod 3 into the slot on the frame behind the headlight unit.
- 4. When closing the bonnet, replace the support rod in its original position, then lower the bonnet to a height of approximately 200 mm (8 inches) above the closed position and drop. Make sure it locks into place.

A WARNING

Always check whether the bonnet is closed and locked securely to prevent it from opening while driving. The vehicle should only be operated with the bonnet securely closed.

FUEL FILLER LID




To open the fuel filler lid, push the rear part of the lid inwards, it will then release the latch and open. To lock, close the fuel filler lid securely.

NOTE:

When the vehicle doors are locked, the fuel filler lid is also locked, and can't be opened until the vehicle doors are unlocked again.

FUEL FILLER CAP



ELECTRIC PARKING BRAKE

The fuel filler cap is a ratcheting type. Tighten the cap clockwise until ratcheting clicks are heard.


Put the fuel filler cap on the cap holder as illustrated while refuelling.

A WARNING


- Fuel is extremely flammable and highly explosive under certain conditions. Always stop the hybrid system and do not smoke or allow open flames or sparks near the vehicle when refuelling.
- Fuel may be under pressure. Turn the cap half a turn and wait for any hissing sound to stop, in order to prevent fuel from spraying out and causing possible personal injury.
- Use only a NISSAN fuel filler cap or exact equivalent as a replacement. It has a builtin safety valve needed for proper operation of the fuel system and emission control system. An incorrect cap can result in a serious malfunction and possible injury.

CAUTION

If fuel is spilled on the vehicle body, flush it away with water to avoid paint damage.



Right hand drive



Left hand drive

The electric parking brake can be applied or released by operating the parking brake switch (A).

To apply: Pull the switch $\mbox{\Large @}$ up $\mbox{\Large 1}$ the indicator light will illuminate.

To release: With the ignition in the **ON** position, depress the brake pedal and push the switch (a) down (2). The indicator light will turn off.

Before driving, check that the brake indicator light

(©) goes out. For additional information, see "Warning lights, indicator lights and audible reminders" (P.72).

The electric parking brake also has an auto apply and auto release function.

The parking brake will automatically release when you drive away using the accelerator with the shift lever in D (Drive) or R (Reverse). For safety reasons, parking brake will not release automatically when the driver door is open. With the vehicle stationary, the electric parking brake is automatically applied when one of the following occurs:

- The hybrid system is turned off.
- The driver's seat belt is unfastened.
- The driver's door is opened.
- The shift lever is moved from D (Drive) or R (Reverse) to P (Park).

To keep the electric parking brake released after turning off the ignition:

 While the hybrid system is running, press the brake pedal and push the parking brake switch (A), before placing the ignition in the OFF position.

A WARNING

- Be sure the electric parking brake is released before driving. Failure to do so could cause brake failure and lead to an accident.
- Do not release the parking brake from outside the vehicle.
- To help avoid risk of injury or death through unintended operation of the ve-

hicle and/or its systems, do not leave children, people who require the assistance of others or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.

Before leaving the vehicle, confirm that the vehicle is held by the parking brake or hybrid gearbox.

NOTE:

- A buzzer will sound if the vehicle is driven without releasing the parking brake. See "Audible reminders" (P.81).
- While the electric parking brake is applied or released, an operating sound is heard from the lower side of the rear seat. This is normal and does not indicate a malfunction.
- When the electric parking brake is frequently applied and released in a short period of time, the parking brake may not operate in order to prevent the parking brake system from overheating. If this occurs, operate the electric parking brake switch again after waiting approximately 1 minute.
- The electric parking brake can only be released with the ignition in the ON position.
- If the electric parking brake must be applied while driving in an emergency, pull up and hold the parking brake switch. When you

release the parking brake switch, the parking brake will be released.

- While pulling up the electric parking brake switch while driving, the parking brake is applied and a chime sounds. The parking brake indicator light in the meter and in the parking brake switch illuminate. This does not indicate a malfunction. The electric parking brake indicator lights in the meter and in the parking brake switch turn off when the parking brake is released.
- When pulling the electric parking brake switch up with the ignition in the OFF or ACC position, the parking brake switch indicator light will continue to illuminate for a short period of time.

CAUTION

To park the vehicle in cold climates place the shift lever in 1st (1) or Reverse (R) (or in Park (P) for automatic (AT) vehicles), and place suitable chocks at both the front and back of a wheel with the electric parking brake released. If the electric parking brake is applied in cold climates, the brake may become frozen and cannot be released.

DRIVING AWAY WHEN TOWING A TRAILER

Please note the following points to prevent the vehicle from rolling back unintentionally on a gradient.

 Pull and hold the parking brake switch and press the accelerator. The parking brake will

remain engaged and prevent any tendency to roll back down the slope.

 You can release the parking brake switch as soon as the hybrid system is delivering enough power to the wheels.

Depending on the weight of the vehicle and trailer and the steepness of the slope, there may be a tendency to roll back downhill when driving away from a standstill. You can prevent this by pulling up the parking brake switch as you press the accelerator (in the same way as with a conventional handbrake).

AUTOMATIC BRAKE HOLD

The automatic brake hold function maintains the braking force without the driver having to depress the brake pedal when the vehicle is stopped (for example, at a traffic light or an intersection). As soon as the driver depresses the accelerator pedal again, the automatic brake hold function is deactivated and the braking force is released. The operating status of the automatic brake hold can be displayed.

A WARNING

- The automatic brake hold function is not designed to hold the vehicle on a steep hill or slippery road. Never use the automatic brake hold function when the vehicle is stopped on a steep hill or slippery road. Failure to do so may cause the vehicle to move.
- The automatic brake hold function warnings may appear to request that the driver retake control by depressing the brake pedal.
- When the automatic brake hold function is activated, but fails to maintain the vehicle at a standstill, depress the brake pedal to stop the vehicle. If the vehicle unexpectedly moves due to the outside conditions, the chime may sound and the warning may appear. In this instance re-apply brake pressure to ensure the vehicle is held.
- Be sure to deactivate the automatic brake hold function when using a drive-thru car wash or towing your vehicle.

Make sure the vehicle is in the P (Park)
position and apply the parking brake when
parking your vehicle, riding on or off the
vehicle, or loading or unloading luggage.
Failure to do so could cause the vehicle to
move or roll away unexpectedly and result
in serious personal injury or property
damage.

CAUTION

- If any of the following conditions occur, the automatic brake hold function may not function. Have the system checked promptly. It is recommended that you visit a NISSAN dealer for this service.
 - A warning message appears.
 - The indicator light of the automatic brake hold switch does not illuminate when the switch is pushed.
- Failure to operate the vehicle in accordance with these conditions could cause the vehicle to move or roll away unexpectedly and result in serious personal injury of property damage.
- The automatic brake hold function will not be activated if the Slip indicator light, electric parking brake indicator light, brake system warning light (yellow) or the master warning light illuminate, and the chassis control system fault warning message appears.
- To maintain the braking force to keep the


vehicle to a standstill, a noise may be heard. This is not a malfunction.

Automatic brake hold function is operated by applying sufficient braking force to hold the vehicle in its place, so there are cases when this hold function is maintained even if the accelerator pedal is depressed.

In this situation, it is advised to depress the brake pedal first, then to turn off Automatic brake hold switch. This will cancel the hold function.

HOW TO ACTIVATE/DEACTIVATE THE AUTOMATIC BRAKE HOLD FUNCTION

Activation of the automatic brake hold function



 With the ignition switch in the ON position, push the automatic brake hold switch ①. The indicator light of the automatic brake hold switch ② illuminates. When the automatic brake hold function goes into standby, the automatic brake hold indicator light (white) illuminates.

To use the automatic brake hold function, the following conditions need to be met:

- The driver's seat belt is fastened.
- The electric parking brake is released.
- The vehicle is not in the P (Park) position.
- The vehicle is not stopped on a steep hill.

NOTE:

The automatic brake hold function retains the last state until the driver changes the option even if the power switch is turned off.

Deactivation of the automatic brake hold function

While the automatic brake hold function is activated, push the automatic brake hold switch to turn off the automatic brake hold indicator light and deactivate the automatic brake hold function. To deactivate the automatic brake hold function while the brake force has been maintained by the automatic brake hold function, depress the brake pedal and push the automatic brake hold switch.

CAUTION

Make sure to firmly depress and hold the brake pedal when turning off the automatic brake hold function while the brake force applied. When the automatic brake hold function is deactivated, the brake force will be released. This could cause the vehicle to move or roll away unexpectedly. Failure to prevent the vehicle from rolling may result in serious personal injury or property damage.

HOW TO USE THE AUTOMATIC BRAKE HOLD FUNCTION

To maintain braking force automatically

With Automatic brake hold function activated and Automatic brake hold indicator light (white) illuminated, depress the braking pedal to stop the vehicle, and the indicator light (green) illuminates.

The braking force is automatically applied without your foot depressed on the brake pedal.

While the braking force is maintained, Automatic brake hold indicator light (green) illuminates.

NOTE:

Automatic brake hold indicator light (green) will not illuminate if the brake pedal is not depressed with sufficient force to hold the vehicle or is released too quickly when the vehicle is stopped.

CAUTION

Confirm Automatic brake hold indicator light (green) is illuminated before removing your foot from the brake pedal.

To start the vehicle from standstill

With the vehicle not in the P (Park) or the N (Neutral) position, depress the accelerator pedal while the brake force is maintained, the braking force will automatically be released to restart the vehicle. Automatic brake hold indicator light (white) illuminates and Automatic brake hold function returns to standby.

Parking

When the vehicle is in the P (Park) position with the braking force maintained by the automatic brake hold function, the parking brake will automatically be applied and the braking force of the automatic brake hold function will be released. The automatic brake hold indicator light turns off. When the parking brake is applied with the braking force maintained by the automatic brake hold function. the braking force of the automatic brake hold function will be released. The automatic brake hold indicator light turns off.

NOTE:

- When the vehicle stops in a slope, depress the brake pedal firmly until Automatic brake hold indicator light (green) illuminates.
- Under the following conditions, the parking brake will automatically be applied and the braking force of the automatic brake hold function will be released. The automatic brake hold indicator light turns off.
 - The braking force is applied by Automatic brake hold function for 3 minutes or longer.
 - The vehicle is in the P (Park) position.
 - Electric Parking Brake is applied manuallv.
 - The driver's seat belt is unfastened.
 - The driver's door is opened.
 - The power switch is placed in the OFF position.


STEERING WHEEL


SUN VISORS

- A malfunction occurs in Automatic brake hold function.
- When the vehicle stops, but the braking force is not automatically applied, depress the brake pedal firmly until the automatic brake hold indicator light (green) illuminates.
- When the vehicle stops on a slope, depress the brake pedal firmly until Automatic brake hold indicator light (green) illuminates.

Automatic brake hold function display

Automatic brake hold function status is shown by color in the [Chassis control] mode in the vehicle information display. Also depending on the driving situations, some warnings or indicators may be displayed in the vehicle information display.






A WARNING

Do not adjust the steering wheel while driving. You could lose control of your vehicle and cause an accident.

Release the lock lever (A) as illustrated and adjust the steering wheel to the desired position (forwards or backwards (1), up or down (2)). Firmly push the lock lever back into position to lock the steering wheel in place.




A WARNING

Do not store the sun visor before returning it to its original position.

- To block out glare from the front, move the main sun visor downwards.
- To block glare from the side, remove the main sun visor from the centre mount and move it to the side.

MIRRORS

INSIDE REAR-VIEW MIRROR



- Night position
- Day position
- Front of the vehicle


The night position (1) will reduce glare from the headlights of vehicles behind you at night.

A WARNING

Only use the night position ① when necessary, as it reduces rear-view clarity.

AUTOMATIC ANTI-DAZZLING INSIDE MIRROR (where fitted)


Automatic anti-dazzling inside mirror (where fitted)



Type A

The inside mirror is designed so that it automatically adjusts the reflection according to the intensity of the following vehicle's headlights.

The automatic anti-dazzling inside mirror will operate when the ignition is ON.



Type B

The inside mirror is designed so that it automatically adjusts the reflection according to the intensity of the following vehicle's headlights on the sensor (C).

The automatic anti-dazzling inside mirror will operate when the ignition switch is in the ACC or ON position. The light (A) shows the system is activated.

The automatic anti-dazzling inside mirror can be deactivated by pressing the power button (B). The (A) light will turn off to show system deactivation.

CAUTION


Do not cover the sensor or hang any object on the mirror or spray glass cleaner directly on the mirror. Doing so will reduce the sensitivity of the sensor, resulting in improper operation.

OUTSIDE REAR-VIEW MIRRORS

A WARNING

- Check the position of all mirrors before driving. Altering their position while driving could distract your attention from the driving operation.
- Objects viewed in the outside mirrors are closer than they appear.
- Never touch the outside rear-view mirrors while they are in motion. Doing so may pinch your fingers or damage the mirror.
- Never drive the vehicle with the outside rear-view mirrors folded. This reduces rear view visibility and may lead to an accident.

Adjusting — Remote control (where fitted)




Slide the control to the left (1) or to the right (2) to select the left or right outside rear-view mirror. then adjust the mirror to the desired position by pushing the control as illustrated 3.

Folding — Manual control

Fold the outside rear-view mirror by pushing it towards the rear of the vehicle.

Folding - Remote control (where fitted)



The outside rear-view mirrors fold when the outside rear-view mirror folding button (1) is pressed. To unfold, push the button again.


NOTE:

If the mirror becomes displaced from its adjusted position, use the following procedure to return it to the correct geared position:

- 1. Fold the mirrors electronically using the outside rear-view mirror folding button.
- 2. Wait until the mirror emits a strong noise, this confirms that the mirror has correctly engaged.

- 3. Fold out the mirrors electronically using the outside rear-view mirror folding button.
- 4. Adjust the mirror to the correct driving angle using the remote control, see "Adjusting — Remote control (where fitted)" (P.144).

Folding — Auto fold (where fitted)




The outside rear-view mirrors automatically unfold when the ignition is switched on or when the vehicle doors are unlocked. Use the [Mirror Fold] menu of the Vehicle Information Display to select the moment that the mirrors are to be automatically folded and unfolded. The Auto fold feature can also be switched off. See "[Vehicle Settings]" (P.89).


NOTE:

The outside rear view mirror folding button can be used to override the auto fold feature.

VANITY MIRROR



Left hand drive



Right hand drive

To use the front vanity mirror, pull down the sun visor and lift up the cover.

MEMO

4 Display screen, heater and air conditioner, and audio system

Safety precautions	148
Rear-view monitor (where fitted)	148
How to read the displayed lines	149
Difference between predictive and	
actual distances	149
How to park with predictive course lines	151
Adjusting the display	152
How to turn on and off predictive course lines	152
Rear-view Monitor system limitations	152
System maintenance	152
Intelligent Around View Monitor (IAVM)	
(where fitted)	153
IAVM system operation	155
Available views	156
Difference between predictive and	
actual distances	158
IAVM system limitations	161
System maintenance	162
Moving object detection (MOD)	163
Vents	166


Heater and air conditioner	166
Operating tips (for automatic air conditioner)	166
Automatic air conditioner	167
Servicing air conditioner	169
Audio system	170
Audio operation precautions	170
Antenna	173
Apple CarPlay and Android Auto (where fitted)	174
NissanConnect (where fitted)	174
SAFETY INFORMATION	174
NAVIGATION (where fitted)	176
AUDIO OPERATION PRECAUTIONS	176
HOW TO UPDATE MAP DATA (where fitted)	176
UPDATING SYSTEM SOFTWARE (where fitted)	177
REGULATORY INFORMATION	177
TRADEMARKS	177
LICENSES	178
Steering wheel switches for audio control	
(where fitted)	179
Control buttons	179

A WARNING

- Do not adjust the heater and air conditioner controls or audio controls while driving so that full attention may be given to vehicle operation.
- If you notice any sparks, smoke, fumes, or fire, immediately stop the vehicle and contact your nearest NISSAN dealer or qualified workshop. Ignoring such conditions may lead to an accident, fire or electric shock.

CAUTION

Do not use the system when the engine is not running for extended periods of time to prevent battery discharge.



- Display
- ② Camera

When the shift lever is moved into the R (Reverse) position, the monitor (NissanConnect display) shows the view from the rear of the vehicle.

The system is designed as an aid to the driver in detecting large stationary objects. It is intended to help avoid damaging the vehicle when reversing. However, the system will not detect small objects below the bumper and may not detect objects close to the bumper or on the ground.

A WARNING

Failure to follow the warnings and instructions for proper use of the rear-view monitor could result in serious injury or death.


 The rear-view camera is a convenience but it is not a substitute for proper reversing.
 Always turn and look out the windows, and check mirrors to be sure that it is safe to move before operating the vehicle. Always reverse slowly.

- The system cannot completely eliminate blind spots.
- Underneath the bumper and the corner areas of the bumper cannot be viewed on the rear-view monitor because of its monitoring range limitation.
- Objects viewed in the rear-view monitor differ from the actual distance because a wide-angle lens is used.
- Do not put anything on the rear-view camera. The rear-view camera is installed above the number plate.
- Objects in the rear-view monitor will appear visually opposite than when viewed in the rear view and outside mirrors.
- Make sure that the tailgate is securely closed when reversing.
- When washing the vehicle with high pressure water, be sure not to spray it around the camera. Otherwise, water may enter the camera unit causing possibly water condensation on the lens, a malfunction, a fire or an electric shock.

CAUTION

There is a transparent cover over the camera lens. Do not scratch the cover when cleaning dirt or snow from it.

HOW TO READ THE DISPLAYED LINES



A WARNING

- Use the displayed lines as a reference. The lines are highly affected by the number of occupants, fuel level, vehicle position, road condition and road grade. Always check with your eyes directly around the vehicle while reversing.
- The distance guide line and the vehicle width line should be used as a reference only when the vehicle is on a level paved surface. The distance viewed on the monitor is for reference only and may be different than the actual distance between the vehicle and displayed objects.
- When reversing the vehicle up a hill, objects viewed in the monitor are further than they appear. When reversing the vehicle down a hill, objects viewed in the monitor are closer than they appear. Use the inside mirror or glance over your shoulder to properly judge distances to other objects.

The lines which are displayed on the monitor, indicate the vehicle's clearance and distance between the obstacle and the bumper (A).

Displayed lines indicate the distances between the obstacle and the bumper as follows:

- (1) 0.5 m (1.5 ft) red
- (2) 1 m (3 ft) blue
- 3 2 m (7 ft) blue
- (4) 3 m (10 ft) blue

Vehicle width guide lines (5):

Indicate the vehicle width when reversing.

Predictive course lines (6):

Indicate the predictive course when reversing. The predictive course lines will be displayed on the monitor when the vehicle is in the R (Reverse) position and if the steering wheel is turned. The predictive course lines will move depending on how much the steering wheel is turned and will not be displayed while the steering wheel is in the straight ahead position.


The vehicle width guide lines and the width of the predictive course lines are wider than the actual width and course

DIFFERENCE BETWEEN PREDICTIVE AND ACTUAL DISTANCES.

The displayed guidelines and their locations on the ground are for approximate reference only. Objects on uphill or downhill surfaces or projecting objects will be actually located at distances different from those displayed in the monitor relative to the guidelines (refer to illustrations). When in doubt, turn around and view the objects

as you are reversing, or park and exit the vehicle to view the positioning of objects behind the vehicle.


Reversing up a steep hill



When reversing a vehicle up a hill, the distance guide lines and the vehicle width guide lines are shown closer than the actual distance. For example, the display shows 1 m (3 ft) to the place (A), but the actual 1 m (3 ft) distance on the hill is the place

(B). Note that any object on the hill is viewed in the monitor further than it appears.


Reversing down a steep hill



When reversing the vehicle down a hill, the distance guide lines and the vehicle width guide lines are shown further than the actual distance. For example, the display shows 1 m (3 ft) to the place (a), but the actual 1 m (3 ft) distance on the hill


is the place (a). Note that any object on the hill is viewed in the monitor closer than it appears.

Reversing near a projecting object



The predictive course lines (a) do not touch the object in the display. However, the vehicle may hit the object if it projects over the actual moving course.

Reversing closer to a projecting object





The position \bigcirc is shown further than the position \bigcirc in the display. However, the position \bigcirc is actually at the same distance as the position \bigcirc . The vehicle may hit the object when moving toward the position \bigcirc if the object projects over the actual moving course.

HOW TO PARK WITH PREDICTIVE COURSE LINES


A WARNING

- If the tyres are replaced with different sized tyres, the predictive course lines may be displayed incorrectly.
- On a snow-covered or slippery road, there may be a difference between the predictive course line and the actual course line.
- If the battery is disconnected or becomes discharged, the predictive course lines may be displayed incorrectly. If this occurs, please perform the following procedures:
 - Turn the steering wheel from lock to lock while the engine is running.
 - Drive the vehicle on a straight road for more than 5 minutes.
- When the steering wheel is turned with the ignition switched ON, the predictive course lines may be displayed incorrectly.





2. The rear view of the vehicle is displayed on the screen (A) when the vehicle is shifted to the R (Reverse) position.



- Slowly reverse the vehicle adjusting the steering wheel so that the predictive course lines (B) enter the parking space (C).
- Manoeuvre the steering wheel to make the vehicle width guide lines (1) parallel to the parking space (C) while referring to the predictive course lines

 When the vehicle is parked in the space completely, push the P position switch and apply the parking brake.

ADJUSTING THE DISPLAY

To adjust the display brightness of the Rear-view Monitor, use the settings described in the separately provided NissanConnect owner's manual.

NOTE:

Do not adjust any of the display settings while the vehicle is moving. Make sure the parking brake is firmly applied.

HOW TO TURN ON AND OFF PREDICTIVE COURSE LINES
Pushing the **<CAMERA>** button while the vehicle is
in the R (Reverse) position can turn on and off the
predictive course lines.

REAR-VIEW MONITOR SYSTEM LIMITATIONS

A WARNING

Listed below are the system limitations for Rear-view Monitor. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.

- The system cannot completely eliminate blind spots and may not show every object.
- Underneath the bumper and the corner areas of the bumper cannot be viewed on the Rear-view Monitor because of its monitoring range limitation. The system will not show small objects below the bumper,


- and may not show objects close to the bumper or on the ground.
- Objects viewed in the Rear-view Monitor differ from actual distance because a wide-angle lens is used.
- Objects in the Rear-view Monitor will appear visually opposite compared to when viewed in the rear view and outside mirrors.
- Use the displayed lines as a reference. The lines are highly affected by the number of occupants, fuel level, vehicle position, road conditions and road grade.
- Make sure that the tailgate is securely closed when reversing.
- Do not put anything on the rear view camera. The rear view camera is installed above the number plate.
- When washing the vehicle with high-pressure water, be sure not to spray it around the camera. Otherwise, water may enter the camera unit causing water condensation on the lens, a malfunction, fire or an electric shock.
- Do not strike the camera. It is a precision instrument. Otherwise, it may malfunction or cause damage resulting in a fire or an electric shock.

The following are operating limitations and do not represent a system malfunction:

 When the temperature is extremely high or low, the screen may not clearly display objects.

- When strong light directly shines on the camera, objects may not be displayed clearly.
- Vertical lines may be seen in objects on the screen. This is due to strong reflected light from the bumper.
- The screen may flicker under fluorescent light.
- The colours of objects on the Rear view Monitor may differ somewhat from the actual colour of objects.
- Objects on the monitor may not be clear in a dark environment.
- There may be a delay when switching between views.
- If dirt, rain or snow accumulates on the camera, the Rear view Monitor may not display objects clearly. Clean the camera.
- Do not use wax on the camera lens. Wipe off any wax with a clean cloth dampened with a diluted mild cleaning agent, then wipe with a dry cloth.

SYSTEM MAINTENANCE




INTELLIGENT AROUND VIEW MONITOR (IAVM) (where fitted)

CAUTION

- Do not use alcohol, benzine or thinner to clean the camera. This will cause discolouration.
- Do not damage the camera as the monitor screen may be adversely affected.

If dirt, rain or snow accumulates on the camera (1). Rear-view Monitor may not display objects clearly. Clean the camera by wiping it with a cloth dampened with a diluted mild cleaning agent and then wiping it with a dry cloth.



Camera button

A WARNING

Failure to follow the warnings and instructions for the proper use of the Intelligent Around View Monitor (IAVM) system could result in serious injury or death.


- The IAVM is a convenient feature but it is not a substitute for proper vehicle operation because it has areas where objects cannot be viewed. The four corners of the vehicle in particular, are areas where objects do not always appear in the bird'seye, front, or rear views. Always check your surroundings to be sure that it is safe to move before operating the vehicle. Always operate the vehicle slowly. Always look out the windows and check mirrors to be sure that it is safe to move.
- The driver is always responsible for safety during parking and other manoeuvres.

CAUTION


Do not scratch the lens when cleaning dirt or snow from the front of the camera.

The IAVM system is designed as an aid to the driver in situations such as slot parking or parallel parking.

The monitor displays various views of the position of the vehicle in a split screen format. All views are not available at all times.



Left Hand Drive



Right Hand Drive

- Message area
- ② [MOD] indicator*
- Bird's-eye view or side view
- Parking sensors
- 5 Front or rear view
- 6 Front or rear view indicator
- * For more information, see "Moving object detection (MOD)" (P.163).

Designs and items displayed on the screen may vary depending on the country and model.

With the ignition in the **ON** position, push the **<CAMERA>** button or move the shift lever to the R (Reverse) position to operate the IAVM. The monitor displays various views around the vehicle.

Available views:

Bird's-eye view
 The surrounding view of the vehicle from above.

Front-side view

The view around and ahead of the front passenger's side wheel.

Front view


The view to the front of the vehicle.

Rear view


The view to the rear of the vehicle.

Full screen rear view

The view to the rear of the vehicle (which is a little wider than the standard rear view).



To display the multiple views, the IAVM system uses cameras ① located in the front grille, on the vehicle's outside mirrors and one just above the vehicle's number plate. Do not put anything on the cameras.




Guiding lines, which indicate the vehicle width and distances to objects with reference to the vehicle body line (a), are displayed on the monitor.

Distance guide lines:

Indicate distances from the vehicle body.

- Red line ①: approx. 0.5 m (1.5 ft)
- Yellow line ②: approx. 1 m (3 ft)
- Green line ③: approx. 2 m (7 ft)
- Green line 4: approx. 3 m (10 ft)

IAVM SYSTEM OPERATION



Example for Left-Hand Drive (LHD) models, for the Right-Hand Drive (RHD) models, the screen layout will be opposite.

The IAVM display consists of the front, left, right and rear screens. You can see a combination of different views on the screens as illustrated.

- A: Audio or navigation screen before the IAVM is operated.
- 1: Front view and bird's-eye view
- 2: Rear view and bird's-eye view
- 3: Front view and front side view
- (4) Rear view and front side view
- (5): Rear view
- : Shift lever into R (Reverse)
- : Shift lever out of R (Reverse)
- : Push the **<CAMERA>** button

The IAVM starts if:

- R (Reverse) gear is selected.
- The **<CAMERA>** button is pushed.
- The front parking sensors (where fitted) detect an object.

Starting with the shift lever operation

- When the shift lever is shifted into the R. (Reverse) position the IAVM starts automatically and the rear view and bird's-eye view are displayed (2)
- When the shift lever is shifted out of the R (Reverse) position (A), the monitor changes from the IAVM screen to the audio or navigation screen.
- In R (Reverse) gear, the rear view and bird's-eye view 2 are shown. The passenger's side view

on the monitor changes to the front side view 4 when the **<CAMERA>** button is pushed.

Push the <CAMERA> button again change to Rear View (5). When the shift lever is shifted out of the R (Reverse), the screen changes to before reversing screen.

Push the <CAMERA> button from (5) to change back to rear view and bird's-eye view (2).

Starting with the <CAMERA> button operation

- When the **<CAMERA>** button is pushed, the IAVM operates and the front view and bird'seve view are displayed (1).
- The front view and bird's-eye view are displayed (1). When the <CAMERA> button is pushed again 3, the view on the screen on the passenger's side changes to the front-side view. Pushing the <CAMERA> button again turns the IAVM off.
- To change the driver's side screen between front view and rear view use the shift lever.

Automatic cancellation

When the shift lever is not in the R (Reverse) position and the vehicle speed increases above approximately 10 km/h (6 MPH), the camera view from the IAVM will be suspended to prohibit the display of video images to the driver during driving. This is not a malfunction


AVAILABLE VIEWS

A WARNING

- The distance guide line and the vehicle width line should be used as a reference only when the vehicle is on a payed, level surface. The distance viewed on the monitor is for reference only and may be different than the actual distance between the vehicle and displayed objects.
- Use the displayed lines and the bird's-eye view as a reference. The lines and the bird's-eve view are greatly affected by the number of occupants, fuel level, vehicle position, road condition and road grade.
- If the tyres are replaced with different sized tyres, the predictive course line and the bird's-eye view may be displayed incorrectly.
- When driving the vehicle up a hill, objects viewed in the monitor are further than they appear. When driving the vehicle down a hill, objects viewed in the monitor are closer than they appear.
- Objects in the monitor will appear visually opposite than when viewed in the rear view and outside mirrors.
- Use the mirrors or actually look to properly judge distances to other objects.
- The distance between objects viewed on the IAVM differs from the actual distance.
- On a snow-covered or slippery road, there

- may be a difference between the predictive course line and the actual course line.
- The vehicle width and predictive course lines are wider than the actual width and course.
- The displayed lines on the rear view will appear slightly off to the right because the rear view camera is not installed in the rear centre of the vehicle.

Front and rearview



Example

Guiding lines, which indicate the vehicle width and distances to objects with reference to the vehicle body line (A), are displayed on the monitor.

Distance guide lines:

Indicate distances from the vehicle body.

- Red line (1): approx. 0.5 m (1.5 ft)
- Yellow line (2): approx. 1 m (3 ft)
- Green line 3: approx. 2 m (7 ft)
- Green line (4): approx. 3 m (10 ft)

Vehicle width guide lines and static predictive course lines (5):

Indicate the vehicle width when reversing.

Dynamic predictive course lines 6:

The dynamic predictive course lines will be displayed on the monitor when the steering wheel is turned. The course lines will move depending on how much the steering wheel is turned and will not be displayed while the steering wheel is in the straight ahead position.

The front view will not be displayed when the vehicle speed is above approximately 10 km/h (6 MPH).

NOTE:


When the monitor displays the front view and the steering wheel turns about 90 degrees or less from the neutral position, both the right and left predictive course lines 6 are displayed. When the steering wheel turns about 90 degrees or more, a line is displayed only on the opposite side of the turn.

Bird's-eye view

A WARNING

- Objects in the bird's-eye view will appear farther than the actual distance because the bird's-eye view is a pseudo views that is processed by combining the views from the cameras on the outside mirrors, the front and the rear of the vehicle.
- Tall objects, such as a kerb or vehicle, may be misaligned or not displayed at the seam of the views.

- Objects that are above the camera cannot be displayed.
- The view for the bird's-eve view may be misaligned when the camera position alters.
- A line on the ground may be misaligned and is not seen as being straight at the seam of the views. The misalignment will increase as the line proceeds away from the vehicle.



The bird's-eye view shows the overhead view of the vehicle which helps confirm the vehicle position and the predictive course to a parking space.

The vehicle icon (1) shows the position of the vehicle. Note that the distance between objects viewed in the bird's-eve view differs from the actual distance

The areas between the camera views (2) (where fitted) are indicated in black.


After the ignition is switched ON, the non-viewable

area (2) (where fitted) is highlighted in yellow for a few seconds after the bird's-eye view is displayed.


The amber markers 3 are displayed when the sonar is turned off or the sonar is not available at the corner.

The predictive course lines (4) indicate the predicted course when operating the vehicle.

Front-side view



Front-side view, Right Hand Drive (RHD) models



Front-side view, Left Hand Drive (LHD) models

Guiding lines:

CAUTION

The actual distance to objects may differ from the distance shown.


Guiding lines that indicate the width and the front end of the vehicle are displayed on the monitor.

The front-of-vehicle line 1 shows the front part of the vehicle.

The side-of-vehicle line ② shows the vehicle width including the outside mirror.

The extensions 3 of both the front 1 and side 2 lines are shown with a green dotted line.

Rear-wide view:



Rear-wide view

While the front view/rear view shows a normal view on the split screens, the rear-wide view shows a wider area on the entire screen and allows checking of the blind corners on the right and left sides

Distance guide lines -:

Indicate distances from the vehicle body.

- Red line : approx. 0.5 m (1.5 ft)
- Yellow line : approx. 1 m (3 ft)
- Green line : approx. 2 m (7 ft)
- Green line : approx. 3 m (10 ft)

Vehicle width guide lines:

Indicate the approximate vehicle width.

Predictive course lines:


Indicate the predictive course when operating the vehicle. The predictive course lines will move depending on how much the steering wheel is turned. The predictive course lines in the rear-wide

view will not be displayed while the steering wheel is in the straight ahead position.

DIFFERENCE BETWEEN PREDICTIVE AND ACTUAL DISTANCES


The displayed guidelines and their locations on the ground are for approximate reference only. Objects on uphill or downhill surfaces or projecting objects will be actually located at distances different from those displayed in the monitor relative to the guidelines (refer to illustrations). When in doubt, turn around and view the objects as you are reversing, or park and exit the vehicle to view the positioning of objects behind the vehicle.

Reversing up a steep hill



When reversing a vehicle up a hill, the distance guide lines and the vehicle width guide lines are shown closer than the actual distance. For example, the display shows 1 m (3 ft) to the place (A), but the actual 1 m (3 ft) distance on the hill is the place (B). Note that any object on the hill is viewed in the monitor further than it appears.

Reversing down a steep hill




When reversing the vehicle down a hill, the distance guide lines and the vehicle width guide lines are shown further than the actual distance. For example, the display shows 1 m (3 ft) to the place (a), but the actual 1 m (3 ft) distance on the hill is the place (B). Note that any object on the hill is viewed in the monitor closer than it appears.


Reversing near a projecting object


The dynamic predictive course lines (A) may show that the vehicle is not touching the object. However, the vehicle may hit the object if it projects over the actual moving course.

A WARNING

The distance viewed on the monitor is for reference only and may be different than the actual distance between the vehicle and displayed objects.








There may be a small visible distance between the vehicle and the object in the bird's-eye view B on the monitor.

Reversing closer to a projecting object



The position \bigcirc is shown further than the position \bigcirc in the display. However, the position \bigcirc is actually at the same distance as the position \bigcirc . The vehicle may hit the object when moving toward the position \bigcirc if the object projects over the actual moving course.

IAVM SYSTEM LIMITATIONS

A WARNING


Listed below are the system limitations for the IAVM. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.

- Do not use the IAVM with the outside mirrors in the stored position, and make sure that the lift gate is securely closed when operating the vehicle using the IAVM.
- The apparent distance between objects viewed on the IAVM differs from the actual distance.
- The cameras are installed on the front grille, the outside mirrors and above the rear license plate. Do not put anything on the vehicle that covers the cameras.
- When washing the vehicle with high-pressure water, be sure not to spray it around the cameras. Otherwise, water may enter the camera unit causing water condensation on the lens, a malfunction, fire or an electric shock.
- Do not strike the cameras. They are precision instruments. Doing so could cause a malfunction or cause damage resulting in a fire or an electric shock.

The following are operating limitations and do not represent a system malfunction:

The screen displayed on the IAVM will automatically return to the previous screen 3 minutes after the <CAMERA> button has been pushed while the shift lever is in a position other than the "R" (Reverse) position.

- There may be a delay when switching between views.
- When the temperature is extremely high or low, the screen may not display objects clearly.
- When strong light shines directly on to the camera, objects may not be displayed clearly.
- The screen may flicker under fluorescent light.
- The colours of objects on the IAVM may differ somewhat from the actual colour of objects.
- Objects on the monitor may not be clear and the colour of the object may differ in a dark environment
- There may be differences in sharpness between each camera view of the bird's-eve view.
- If dirt, rain or snow accumulates on the camera, the IAVM may not display objects clearly. Clean the camera.
- Do not use wax on the camera lens. Wipe off any wax with a clean cloth that has been dampened with a diluted mild cleaning agent, then wipe with a dry cloth.



There are some areas where the system will not show objects and the system does not warn of moving objects.


- 1) When in the front or the rear view display, an object below the bumper or on the ground may not be viewed.
- 2 When in the bird's-eye view, a tall object near the seam (3) of the camera viewing areas will not appear in the monitor.

System temporarily unavailable

When the [!] icon is displayed on the screen, there will be abnormal conditions in the IAVM. This will not hinder normal driving operation but the system should be inspected by a NISSAN dealer or qualified workshop.

When the [\mathbf{X}] icon is displayed on the screen, the camera image may be receiving temporary electronic disturbances from surrounding devices. This will not hinder normal driving operation, but the system should be inspected by a NISSAN dealer or qualified workshop if it occurs frequently.

SYSTEM MAINTENANCE




CAUTION

Do not use alcohol, benzine or thinner to clean the camera. This will cause discolouration. To clean the camera, wipe with a cloth that has been dampened with a diluted mild cleaning agent and then wipe with a dry cloth. Do not damage the camera because the monitor screen may be adversely affected.

If dirt, rain or snow accumulates on any of the cameras ①, the IAVM may not display objects clearly. Clean the camera by wiping with a cloth dampened with a diluted mild cleaning agent and then wiping with a dry cloth.

MOVING OBJECT DETECTION (MOD)



<CAMERA> button

A WARNING

- Failure to follow the warnings and instructions for proper use of the Moving Object Detection system could result in serious injury or death.
- The MOD system is not a substitute for proper vehicle operation and is not designed to prevent contact with objects surrounding the vehicle. When manoeuvring, always use the outside mirror and rearview mirror and turn and check the

surroundings to ensure it is safe to manoeuvre.

- The system is deactivated at speeds above 8 km/h (5 MPH). It is reactivated at lower speeds.
- The MOD system is not designed to detect the surrounding stationary objects.

The MOD system can inform the driver of moving objects near the vehicle when driving out of garages, manoeuvring in parking lots and in other such instances.

The MOD system detects moving objects by using image processing technology on the image shown in the display.

CAUTION

Do not scratch the lens when cleaning dirt or snow from the front of the camera.

MOD system operation

The MOD system will turn on automatically under the following conditions:

- When the transmission is in the R (Reverse). position.
- When the <CAMERA> button is pushed to activate the Intelligent Around View Monitor system on the display.
- When vehicle speed decreases below approximately 8 km/h (5 MPH).

The MOD system operates in the following conditions when the camera view is displayed:


- When the transmission is in the P (Park) or N (Neutral) position and the vehicle is stopped, the MOD system detects the moving objects in the bird's-eye view. The MOD system will not operate if either door is opened. If outside mirrors are folded, MOD may not operate properly.
- When the transmission is in a forward drive position, and the vehicle speed is below approximately 8 km/h (5 MPH), the MOD system detects moving objects in the front view or front-wide view.
- When the transmission is in the R (Reverse) position and the vehicle speed is below approximately 8 km/h (5 MPH), the MOD system detects moving objects in the rear view or rear-wide view. The MOD system will not operate if the tailgate is open.

The MOD system does not detect moving objects in the front-side view. The MOD icon is not displayed on the screen when in this view.


When the MOD system detects a moving object near the vehicle, the yellow frame will be displayed on the view where the object is detected and chime will sound once. While the MOD system continues to detect moving objects, the yellow frame continues to be displayed.

NOTE:


While the RCTA chime (where fitted) is beeping, the MOD system does not chime.




Front and bird's-eye views



Rear and bird's-eye views



Rear and front-side views



Front-wide view / rear-wide view

In the bird's-eye view, the yellow frame ① is displayed on each camera image (front, rear, right, left) depending on where moving objects are detected.

The yellow frame ② is displayed on the front view, rear view, front-wide view and rear-wide view.

A green MOD icon 3 is displayed in the view where the MOD system is operative. A grey MOD icon 3 is

displayed in the view where the MOD system is not operative.

If the MOD system is turned off, the MOD icon 3 is not displayed.

Turning MOD on and off

The MOD system can be turned on and off using the vehicle information display. (See "[Driver Assistancel (where fitted)" (P.87).)

MOD system limitations

A WARNING

Listed below are the system limitations for MOD. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.

- Do not use the MOD system when towing a trailer. The system may not function properlv.
- Excessive noise (for example, audio system volume or open vehicle window) will interfere with the chime sound, and it may not be heard.
- The MOD system performance will be limited according to environmental conditions and surrounding objects such as:
 - When there is low contrast between background and the moving objects.
 - When there is blinking source of light.
 - When strong light such as another vehicle's headlight or sunlight is present.

- When camera orientation is not in its usual position, such as when the outside mirror is folded.
- When there is dirt, water drops or snow on the camera lens.
- When the position of the moving objects in the display is not changed.
- The MOD system might detect flowing water droplets on the camera lens, white smoke from the muffler, moving shadows. etc.
- The MOD system may not function properly depending on the speed, direction, distance or shape of the moving objects.
- If your vehicle sustains damage to the parts where the camera is installed, leaving it misaligned or bent, the sensing zone may be altered and the MOD system may not detect objects properly.
- When the temperature is extremely high or low, the screen may not display objects clearly. This is not a malfunction.


NOTE:

The green MOD icon will change to orange if one of the following has occurred.

- When the system is malfunctioning.
- When the component temperature reaches a high level.
- When the rear view camera has detected a blockage.

If the icon light continues to illuminate in orange, have the MOD system checked. It is recommended that you visit a NISSAN dealer or qualified workshop for this service.

System maintenance




CAUTION


- Do not use alcohol, benzine or thinner to clean the camera. This will cause discolouration.
- Do not damage the camera as the monitor screen may be adversely affected.

If dirt, rain or snow accumulates on any of the cameras ①, the MOD system may not operate properly. Clean the camera by wiping with a cloth dampened with a diluted mild cleaning agent and then wiping with a dry cloth.

HEATER AND AIR CONDITIONER



Air flow direction adjustment



Vents closed - No air flow

Adjust the air flow direction of each vents by moving the centre knob (up/down, left/right) until the desired position is achieved.

Close the vents by sliding the centre knobs towards each other as shown.

The side vents can be used for the side defroster/defogger.

A WARNING

- The heater and air conditioner operate only when the engine is running.
- Never leave children or adults who would normally require the support of others alone in the vehicle. Pets should not be left alone either. They could unknowingly activate switches or controls and inadvertently become involved in a serious accident and injure themselves. On hot, sunny days, temperatures in a closed vehicle could quickly become high enough to cause severe or possibly fatal injuries to people or animals.
- Do not use the recirculation mode for long periods as it may cause the interior air to become stale and the windows to fog up.
- Do not adjust the heating and air conditioning controls while driving so that full attention may be given to vehicle operation.


The heater and air conditioner operate when the engine is running. The air blower will operate when the ignition switch is in the **ON** position even if the engine is turned off.

NOTE:

 Condensation forms inside the air conditioning unit when the air conditioner is running, and is safely discharged underneath your vehicle. Traces of water on the ground are therefore normal.

- Odours from inside and outside the vehicle can build up in the air conditioner unit.
 Odour can enter the passenger compartment through the vents.
- When parking, set the heater and air conditioner controls to turn off air recirculation to allow fresh air into the passenger compartment. This should help reduce odours inside the vehicle.

OPERATING TIPS (for automatic air conditioner)




When the engine coolant temperature and outside air temperature are low, the air flow from the foot outlets may not operate. However, this is not a malfunction. After the coolant temperature warms up, the air flow from the foot outlets will operate normally.

The sensors, located on the instrument panel (a) and beneath the steering wheel, help maintain a constant temperature. Do not put anything on or around the sensors.

AUTOMATIC AIR CONDITIONER

Type A (without seat heater and Thermaclear heated windscreen)



Type A (without seat heater and Thermaclear heated windscreen)

Temperature control dial


Display

<AUTO> button

<A/C> (Air Conditioner) button

- Fan speed control (🐉) dial
- Air recirculation ८९० button
- Rear window defogger www button (See "Defogger switch" (P.108).)
- Air flow control button
- Front defogger 🤬 MAX button
- 10. <ON OFF> button

Type B (with seat heater and Thermaclear heated windscreen)



Type B (with seat heater and Thermaclear heated windscreen)

- 1. Temperature control dial
- 2 <AUTO> button
- Front left seat heater button (see "Seat heating (where fitted)" (P.113).)
- Display
- Front right seat heater button (see "Seat heating (where fitted)" (P.113).)
- 6. Fan speed control (🐉) dial
- 7. <A/C> (Air Conditioner) button
- 8. Air recirculation (\$\sigma\$) button

- Rear window defogger button (see "Defogger switch" (P.108).)
- 10. Air flow control button
- 11. Front defogger 🦙 MAX button
- Thermaclear heated windscreen heater button (see "ThermaClear Heated Windscreen (where fitted)" (P.107).)

Automatic operation (AUTO)

The AUTO mode may be used year-round as the system automatically controls constant temperature, air flow distribution and fan speed after the desired temperature is set manually.

Turning off the heater and air conditioner:

(Models without Thermaclear heated windscreen) To turn off the heater and air conditioner, push the **<ON OFF>** button.

(Models with Thermaclear heated windscreen) The Thermaclear Heated windscreen button (where fitted) replaces the regular **<ON OFF>** button for the heater and air conditioning. To turn off the system turn the Fan speed control dial to the lowest speed position, wait for approximately 1 second and turn the dial further towards the OFF position.

Cooling and dehumidified heating:

- 1. Push the <AUTO> button.
- If the A/C indicator light does not illuminate, push the <A/C> button. (The A/C indicator light will illuminate.)
- Turn the temperature control dial to set the desired temperature.

A visible mist may be seen coming from the vents in hot, humid conditions as the air is cooled rapidly. This does not indicate a malfunction.

Heating (A/C off):

- 1. Push the <AUTO> button.
- If the A/C indicator light illuminates, push the <A/C> button. (The A/C indicator light will turn off.)

- 3. Turn the temperature control dial to set the desired temperature.
- Do not set the temperature lower than the outside air temperature. Doing so may cause the temperature to not be controlled properly.
- If the windows fog up, use dehumidified heating instead of the A/C off heating.

Dehumidified defrosting/defogging:

- 1. Push the front defogger 🐨 button. (The 🐨 indicator light will illuminate.)
- 2. Turn the temperature control dial to set the desired temperature.
- To remove frost from the outside surface of the windscreen quickly, set the temperature to a high temperature and the fan speed to the maximum level.
- After the windscreen is cleared, push the front defogger w button again. (The indicator light will turn off.)
- When the front defogger @ button is pushed, the air conditioner will automatically turn on when the outside air temperature is above -2°C (28°F) to defog the windscreen. The air recirculation mode will automatically turn off. The outside air circulation mode will be selected to improve the defogging performance.

Manual operation

The manual mode can be used to control the heater and air conditioner to your desired settings.

Turning off the heater and air conditioner:

(Models without Thermaclear heated windscreen) To turn off the heater and air conditioner, push the <ON OFF> button

(Models with Thermaclear heated windscreen) The Thermaclear Heated windscreen button (where fitted) replaces the regular **<ON OFF>** button for the heater and air conditioning. To turn off the system turn the Fan speed control dial to the lowest speed position, wait for approximately 1 second and turn the dial further towards the OFF position.

Fan speed control:

Turn the fan speed control dial. Turn the dial clockwise to increase the fan speed. Turn the dial counter clockwise to decrease the fan speed.

Push the <AUTO> button to change the fan speed to the automatic mode.

Air flow control:

Push the Air flow control button to change the air flow mode.

- Air flows from the centre and side vents
- الت Air flows from the centre and side vents and foot outlets
- فيرا Air flows mainly from the foot outlets
- 70 Air flows from the defogger outlets and foot outlets
- w Air flows mainly from the defogger outlets

Temperature control:

Turn the temperature control dial to set the desired temperature. Turn the dial clockwise to increase the temperature. Turn the dial counter clockwise to decrease the temperature.

Air recirculation:

Push the air recirculation so button to circulate the air flow inside the vehicle. (The see indicator light will illuminate.)

Push the air recirculation so button again to draw the air flow from outside the vehicle. (The indicator light goes off.)

Automatic air intake control (where fitted):

If the indicator light on the air recirculation =button is illuminated, push and hold the button with the light illuminated (the indicator light will blink twice). The automatic air intake control mode is set.

SERVICING AIR CONDITIONER

A WARNING

The air conditioner system contains refrigerant under high pressure. To avoid personal injury, any air conditioner service should be done only by an experienced technician with the proper equipment.

The air conditioner system in your vehicle is charged with a refrigerant designed with the environment in mind.

This refrigerant contains fluorinated greenhouse gases (GWP 0,501). It will not harm the

AUDIO SYSTEM

earth's ozone layer. However, it may contribute in a small part to global warming.

Special charging equipment and lubricant are required when servicing your vehicle's air conditioner. Using improper refrigerants or lubricants will cause severe damage to the air conditioner system. (See "Capacities and recommended fluids/lubricants" (P.341).)

A NISSAN dealer or qualified workshop will be able to service your environmentally friendly air conditioner system.

Air conditioner filter

The air conditioner system is equipped with an air conditioner filter which collects pollen. To make sure the air conditioner heats, defogs, and ventilates efficiently, replace the filter according the specified maintenance intervals listed in a separate maintenance booklet. To replace the filter, contact a NISSAN dealer or qualified workshop.

The filter should be replaced if the air flow decreases significantly or if windows fog up easily when operating the heater or air conditioner.

A WARNING

Do not adjust the audio system while driving.

The audio system operates when the ignition is placed in the ACC or ON position. If you want to listen to the radio or connected devices while the engine is not running, place the ignition in the ACC position. Do not use for an extended period of time with the engine stopped.

AUDIO OPERATION PRECAUTIONS


NOTE:

Models with navigation system, see the audio operation precautions in the separately provided navigation system owner's manual.


Radio

- Radio reception is affected by station signal strength, distance from radio transmitter, buildings, bridges, mountains and other external influences. Intermittent changes in reception quality are normally caused by these external influences.
- Using a mobile phone in or near the vehicle may influence radio reception quality.
- Use the antenna for the best reception.

USB (Universal Serial Bus) connection port



Left hand drive



Right hand drive

A WARNING

Do not connect, disconnect or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.

CAUTION

- Do not force the USB device into the USB connection port. Inserting the USB device tilted or up-side-down into the USB connection port may damage the USB connection port. Make sure that the USB device is connected correctly into the USB connection port (some USB devices come with a \dot{v} mark as a guide, make sure that the mark is facing the correct direction before inserting the device).
- Do not grab the USB connection port cover (where fitted) when pulling the USB device out of the USB connection port. This could damage the USB connection port and USB connection port cover (where fitted).
- Do not leave the USB cable in a place where it can be pulled unintentionally. Pulling the cable may damage the USB connection port.

The USB sockets are located in the centre console underneath the heater and air conditioning controls.

The vehicle is not equipped with a USB device, USB devices should be purchased separately as necessary.

This system cannot be used to format USB devices. To format a USB device, use a personal computer.

In some areas, the USB device for the front seats plays only sound without images for regulatory reasons, even when the vehicle is parked.

This system supports various USB connection port

devices. USB hard drives and iPod players. Some USB devices may not be supported by this system.

- Partitioned USB devices may not play correctly.
- Some characters used in other languages (Chinese, Japanese, etc.) may not appear properly in the display. Using English language characters with a USB device is recommended.

General notes for USB use:

Refer to your device manufacturer's owner information regarding the proper use and care of the device.

Notes for iPod use:

"Made for iPod", "Made for iPhone", and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards.


Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance.

iPad, iPhone, iPod, iPod classic, iPod nano, iPod shuffle, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. Lightning is a trademark of Apple Inc.

 NISSAN audio system supports only accessories that Apple has certified and that come with the "Made for iPod/iPhone/iPad" logo.

- Improperly plugging in the iPod may cause a checkmark to be displayed on and off (flickering). Always make sure that the iPod is connected properly.
- An iPod nano (1st Generation) may remain in fast forward or rewind mode if it is connected during a seek operation. In this case, please manually reset the iPod.
- An iPod nano (2nd Generation) will continue to fast-forward or rewind if it is disconnected during a seek operation.
- An incorrect song title may appear when the Play Mode is changed while using an iPod nano (2nd Generation)
- Audiobooks may not play in the same order as they appear on an iPod.
- Large video files cause slow responses in an iPod. The vehicle centre display may momentarily black out, but will soon recover.
- If an iPod automatically selects large video files while in the shuffle mode, the vehicle centre display may momentarily black out, but will soon recover.



- (A) Root folder
- B Folder
- © MP3/WMA


Playback order:

Music playback order of the USB device with MP3/ WMA is as illustrated above.

 The names of folders not containing MP3/ WMA files are not shown in the display.

- If there is a file in the top level of the device, FOLDER is displayed.
- The playback order is the order in which the files were written by the writing software, so the files might not be played in the desired order.

USB (Universal Serial Bus) rear power port (where fitted)



Rear USB power port (where fitted)

A WARNING

Do not connect, disconnect or operate the USB device while driving. Doing so can be a distraction. If distracted you could lose control of your vehicle and cause an accident or serious injury.

CAUTION

Do not force the USB device into the USB connection port. Inserting the USB device tilted or up-side-down into the USB connection port may damage the USB con-

- nection port. Make sure that the USB device is connected correctly into the USB connection port (some USB devices come with a \dot{v} mark as a guide, make sure that the mark is facing the correct direction before inserting the device).
- Do not grab the USB connection port cover (where fitted) when pulling the USB device out of the USB connection port. This could damage the USB connection port and USB connection port cover (where fitted).
- Do not leave the USB cable in a place where it can be pulled unintentionally.
 Pulling the cable may damage the USB connection port.

A USB power point (where fitted) is provided on the rear of the console box/armrest unit.

This port is for power supply only. It does not support data transfer.


The maximum output current for the port is 2.4 A. Please note that actual output current will depend on the device connected to the port. The charger will provide the appropriate current value to the device connected based on the protocol used by the mobile device.

Bluetooth® Audio player (where fitted)

Some Bluetooth® audio devices may not be used with this system. For detailed information about Bluetooth® audio devices that are available for use with this system, contact a NISSAN dealer or qualified workshop.

- Before using a Bluetooth® audio system, the initial registration process for the audio device is necessary.
- Operation of the Bluetooth® audio system may vary depending on the audio device that is connected. Confirm the operation procedure before use.
- The playback of Bluetooth® audio will be paused under the following conditions. The playback will be resumed after the following conditions are completed.
 - while using a hands-free phone
 - while checking a connection with a mobile phone
- The in-vehicle antenna for Bluetooth® communication is built in the system. Do not place the Bluetooth® audio device in an area surrounded by metal, far away from the system or in a narrow space where the device closely contacts the body or the seat. Otherwise, sound degradation or connection interference may occur.
- While a Bluetooth® audio device is connected through the Bluetooth® wireless connection, the battery power of the device may discharge quicker than usual.
- This system is compatible with the Bluetooth® AV profile (A2DP and AVRCP).

ANTENNA



There is a radio antenna on the rear part of the vehicle roof.

CAUTION

- When washing the vehicle, do not apply high pressure water directly to the seal of the antenna. It may damage the seal of the antenna.
- When removing snow from the roof, do not apply excessive force to the antenna. This may cause damage to the antenna and the roof panel.
- A buildup of ice on the antenna can affect radio performance. Remove the ice to restore radio reception.
- The radio performance may be affected if cargo carried on the roof blocks the radio signal. If possible, do not put cargo near the antenna.

NISSANCONNECT (where fitted)

A WARNING


- Stop your vehicle in a safe location and apply the parking brake before connecting your mobile device to the vehicle or operating your connected mobile device for setup.
- If you are unable to devote full attention to vehicle operation while using Apple Car-Play, pull off the road to a safe location and stop your vehicle.
- Laws in some jurisdictions may restrict the use of some of the applications and features, such as social networking and texting. Check local regulations for any requirements.

Apple CarPlay:

With Apple CarPlay, your in-vehicle system can be used as a display and a controller for some of the iPhone functions. Apple CarPlay features Siri which enables operations via voice controls. Refer to the Navigation System Owner's Manual and visit the Apple website for information about the functions that are available and other details.

Android Auto:

With Android Auto, your in-vehicle system can be used as a display and a controller for some of your Android phone functions. Android Auto supports Talk to Google which enables operations via voice controls. Refer to the Navigation System Owner's Manual and visit the Android Auto website for information about the functions that are available and other details.



For details, see the separately provided Nissan-Connect Owner's Manual.

- Online:
 - Go to: https://ugr.to/1mwfs
 - Or scan the QR code



- Online:
 - Go to: https://uar.to/1mwf8
 - Or scan the OR code



Printed version: Please contact your Nissan dealer or qualified workshop.

SAFETY INFORMATION

This system is primarily designed to help you support pleasant driving as outlined in this manual. However, you, the driver, must use the system safely and properly. Information and the availability of services may not always be up to date. The system is not a substitute for safe, proper and legal drivina.

Before using the system, please read the following safety information. Always use the system as outlined in this manual

WARNING

To operate the system, first park the vehicle in a safe location and set the parking brake. Operating the system while driving can distract the driver and may result in a serious accident.

- Exercise extreme caution at all times so full attention may be given to vehicle operation. If the system does not respond immediately, please be patient and keep your eyes on the road. Inattentive driving may lead to a crash resulting in serious injuries or death.
- Do not rely on route guidance (where fitted) alone. Always be sure that all driving manoeuvres are legal and safe in order to avoid accidents.
- Do not disassemble or modify this system. If you do, it may result in accidents, fire or electrical shock.
- If you notice any foreign objects in the system hardware, spill liquid on the system or notice smoke or a smell coming from it, stop using the system immediately and it is recommended you contact a NISSAN dealer or qualified workshop. Ignoring such conditions may lead to accidents, fire or electrical shock.

CAUTION

- Some jurisdictions may have laws limiting the use of video screens while driving. Use this system only where it is legal to do so.
- Extreme temperature conditions (below -20°C (-4°F) and above 70°C (158°F)) could affect the performance of the system.
- The display screen may break if it is hit

with a hard or sharp object. If the display screen breaks, do not touch it. Doing so could result in an injury.

NOTE:

To avoid discharging the battery only use NissanConnect when the hybrid system has been started.

Models with NissanConnect Services:

NissanConnect Services may not be available in some regions. Completing the NissanConnect Services registration is necessary to use Nissan-Connect Services related functions.

Hands-free telephone control

A WARNING

- Use a phone after stopping your vehicle in a safe location. If you have to use a phone while driving, exercise extreme caution at all times so full attention may be given to vehicle operation.
- If you find yourself unable to devote full attention to vehicle operation while talking on the phone, pull off the road to a safe location and stop your vehicle before doing so.

CAUTION

To avoid draining the vehicle battery, use a phone only after starting the hybrid system.

Hands-free text messaging assistant

A WARNING

- Use the text messaging feature after parking your vehicle in a safe location. If you have to use the feature while driving. exercise extreme caution at all times so full attention may be given to vehicle operation.
- Laws in some jurisdictions may restrict the use of "Text-to-Speech." Check local regulations before using this feature.
- Laws in some jurisdictions may restrict the use of some of the applications and features, such as social networking and texting. Check local regulations for any requirements.
- If you are unable to devote full attention to vehicle operation while using the text messaging feature, pull off the road to a safe location and stop your vehicle.

CAUTION

This feature is disabled if the connected device does not support it. See the phone's Owner's Manual for details and instructions.

Liquid crystal display

The display on this unit is a liquid crystal display and should be handled with care

A WARNING

Never disassemble the display. Some parts utilise extremely high voltage. Touching them may result in serious personal injury.

Maintenance of display:

To clean the display screen, use a dry, soft cloth. If additional cleaning is necessary, use a small amount of neutral detergent with a soft cloth. Never spray the screen with water or detergent. Dampen the cloth first, then wipe the screen.

CAUTION

- Clean the display with the ignition switch or power switch in the OFF position. If the display is cleaned while the ignition or power switch is placed in the ON position, unintentional operation may occur.
- To clean the display, never use a rough cloth, alcohol, benzine, thinner or any kind of solvent or paper towel with a chemical cleaning agent. They will scratch or deteriorate the panel.
- Do not splash any liquid, such as water or car fragrance, on the display. Contact with liquid will cause the system to malfunction.

NAVIGATION (where fitted)

The navigation system is primarily designed to help you reach your destination. However, you, the driver, must use the system safely and properly. Information concerning road conditions, traffic signs and the availability of services may not always be up to date. The system is not a substitute for safe, proper, and legal driving.

A WARNING

- Do not rely on route guidance alone. Always be sure that all driving manoeuvres are legal and safe in order to avoid accidents.
- Always stop the vehicle in a safe location before modifying the route conditions.
 Modifying the route conditions while driving may cause an accident.
- The navigation system's visual and voice guidance is for reference purposes only.
 The contents of the guidance may be inappropriate depending on the situation.
- Follow all traffic regulations when driving along the suggested route (e.g. one-way traffic).

AUDIO OPERATION PRECAUTIONS

CAUTION

- To avoid discharging the battery, only use audio system when the hybrid system has been started.
- Do not allow the system to get wet.
 Excessive moisture such as spilled liquids may cause the system to malfunction.
- Park the vehicle in a safe location and apply the parking brake to view movies on the touch screen display.

HOW TO UPDATE MAP DATA (where fitted)

A WARNING

TO AVOID RISK OF DEATH OR SERIOUS PERSONAL INJURY WHEN UPDATING THE MAP SOFTWARE:

If you choose to park the vehicle within range of a Wi-Fi connection (where fitted) or a TCU (Telematics Control Unit) (where fitted), park the vehicle in a secure, safe, well-ventilated location that is open to the air. During the update process, if you choose to park your vehicle, it should be kept in a well ventilated area to avoid exposure to carbon monoxide. Do not breathe exhaust gases; they contain colourless and odourless carbon monoxide. Carbon monoxide is dangerous. It can cause unconsciousness or death.

UPDATING SYSTEM SOFTWARE (where fitted)

A WARNING

TO AVOID RISK OF DEATH OR SERIOUS PERSO-NAL INJURY WHEN UPDATING THE SYSTEM SOFTWARE:

If you choose to park the vehicle within range of a Wi-Fi connection (where fitted), park the vehicle in a secure, safe, well-ventilated location that is open to the air. During the update process, if you choose to park your vehicle, it should be kept in a well ventilated area to avoid exposure to carbon monoxide. Do not breathe exhaust gases; they contain colourless and odourless carbon monoxide. Carbon monoxide is dangerous. It can cause unconsciousness or death.

How to update from the system menu

A WARNING

To operate the system for software update, first park the vehicle in a safe location.

REGULATORY INFORMATION

Radio approval number and information For Europe:

Hereby, Robert Bosch Car Multimedia GmbH declares that the radio equipment type in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:



Any change of the radio equipment or usage with other accessories, components or software as specified will make a re-assessment in accordance with compliance to legal approval necessary.

Frequency Band

2400 MHz - 2480 MHz

Radiated Power (EIRP)

Bluetooth < 10 mW

WLAN < 100 mW

Hints/Restrictions

Internal Antenna

Internal antenna not accessible by user. Any change by the user will violate the legal approval of this product.

TRADEMARKS





Apple, iPhone, iPod, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. Apple CarPlay is a trademark of Apple Inc. Use of the Apple CarPlay logo means that a vehicle user interface meets Apple performance standards. Apple is not responsible for the operation of this vehicle or its compliance with safety and regulatory standards. Please note that the use of this product with iPhone or iPod may affect wireless performance.



Bluetooth® is a trademark owned by Bluetooth SIG, Inc. and licensed to Robert Bosch GmbH and Clarion Co., Ltd.



HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. For patents see http://dts.com/patents. HD Radio, Artist Experience, and the HD, HD Radio. and "ARC" logos are registered trademarks or trademarks of iBiquity Digital Corporation in the United States and/or other countries.

App Store

Apple and the Apple logo are trademarks of Apple

Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Siri

Siri is a trademark of Apple Inc., registered in the U.S. and other countries.

Google/Android/Google Play/Android Auto

Google, Android, Google Play, Android Auto, and other marks are trademarks of Google LLC.

Google

Google is a trademark of Google Inc.

LICENSES

Software licences (Robert Bosch gmbh)

Open Source Software Licences

http://oss.bosch-cm.com/nissan.html

Software licences (Clarion Co., Ltd.)

- This product uses the source code of T-Kernel under T-License granted by the TRON Forum (www.tron.org).
- This software is based in part on the work of the independent JPEG Group.
- This product includes software developed by the OpenSSL project for use in the OpenSSL Toolkit.

(http://www.openssl.org/)

Copyright©1998 - The OpenSSL Project.

All rights reserved.

 Portions of this software are copyright 1996-2002, 2006.

The FreeType Project (www.freetype.org).

All rights reserved.

This unit includes software modules to be licensed under the GNU General Public License (GPL) or GNU Lesser General Public License (LGPL) and other open source software licenses.

You can redistribute and/or modify it under the terms of each open source license.

To get the source code, refer to the following website.


https://www.clarion.com/us/en/opensource/nissan/index.html

Telematics Control unit (TCU)

http://opensourceautomotive.com/IC/tZ7T3eE6AiV4

STEERING WHEEL SWITCHES FOR AUDIO CONTROL (where fitted)

CONTROL BUTTONS



- Volume buttons
- Tuning switch

Play Control (Tuning switch)

Push the tuning switch left or right to select a channel, track, CD or folder when they are listed on the display.

RADIO:

- Pushing Left/Right longer Next or previous preset channel
- Pushing Left/Right shorter Next or previous station/channel

iPod (where fitted), USB device (where fitted) or Bluetooth® Audio (where fitted):

- Pushing Left/Right shorter Next track or the beginning of the current track (the previous track if the button is pushed immediately after the current track starts playing)
- Pushing Left/Right longer Forward or rewind

Volume control switches

Push the volume control switch to increase or decrease the volume.

MEMO

5 Starting and driving

Running-in schedule		184
Before starting the hybrid system		184
Precautions when starting and driving		185
Exhaust gas (Carbon Monoxide)		185
Tyre Pressure Monitoring System (TPMS)		
(where fitted)		186
Meter information		188
Activation		188
New and repositioned TPMS sensors (incl	_	
fitment of alternative wheels)		188
Adjusting TPMS target pressure		189
Tyre pressure units		189
[Check cold tyre] message		189
TPMS temperature calibration		189
On-road and off-road driving precautions		190
Three-way catalyst		190
To help prevent damage		190
Gasoline particulate filter (GPF) (where fitted)		191
Care when driving		192
Engine cold start period		192
Loading luggage		192
Driving on wet roads		192
Driving under winter conditions		192
Push-button ignition switch		192
Precautions on push-button ignition		
switch operation		192

	Intelligent Key system	192
	Ignition switch positions	193
	Emergency hybrid system shut off	194
	Steering lock	194
	Intelligent Key battery discharge	195
S	tarting the hybrid system	195
	riving the vehicle	196
	Driving with Hybrid Gearbox	196
Е	lind Spot Warning (BSW) system/Intelligent Blind Spo	ot
Ir	ntervention system (where fitted)	200
	The BSW and Intelligent Blind Spot	
	Intervention systems:	200
	BSW system operation	202
	Intelligent Blind Spot Intervention	
	system operation	203
	BSW/Intelligent Blind Spot Intervention	
	system precautions	205
	BSW/Intelligent Blind Spot Intervention	
	driving situations	206
	System maintenance	209
	ear Cross Traffic Alert (RCTA) system	
()	where fitted)	210
	RCTA system operation	211
	How to enable/disable the RCTA system	212
	RCTA system limitations	213
	System temporarily unavailable	214

System malfunction214 Intelligent Emergency Braking (IEB) system	m (where
-/	citi (vviicic
System maintenance214 fitted) (for Hong Kong, Tahiti, Palestine, I	New
Lane Assist system215 Caledonia, Morocco)	250
Lane Assist system operation216 System maintenance	260
How to enable/disable the Lane Assist system 217 Intelligent Driver Alertness (where fitted)	26
Lane Assist system limitations	26
System temporarily unavailable	26
System malfunction	26
System maintenance220 Operation	26
Cruise control (where fitted)	268
Precautions on cruise control	268
Cruise control system operations	268
Speed limiter (where fitted)223 Tyre pressure	269
Speed limiter operations223 Safety chains	269
ProPILOT Assist (where fitted)	269
ProPILOT Assist (where fitted)	269
ProPILOT Assist system operation 227 Installation of coupling device	269
ProPILOT Assist System Display Vehicle security	270
and Indicators	
Turning the ProPILOT Assist Conventional (fixed Brake system	
speed) Cruise Control mode on	
Operating the ProPILOT Assist system	
ProPILOT Assist Intelligent Cruise Control Using system	
(ICC) system	
ProPILOT Assist Steering Assist	
ProPILOT Assist Conventional (fixed speed) Cruise Electronic Stability Programme (ESP) system	
Control Mode	
ProPILOT Assist Speed limiter (where fitted) 248 Electronic Stability Programme (ESP)	
ntelligent Emergency Braking (IEB) system Deactivation	27
(where fitted)	27
Intelligent Emergency Braking (IEB) system (where Intelligent Trace Control	270

Intelligent Ride Control	276	
Hill Start Assist (HSA) (where fitted)		
Drive mode	278	
Drive mode	278	
Traffic Sign Assist (where fitted)	279	
System operation	280	
How to enable/disable the Traffic Sign Assist		
(TSA) system	282	
System temporarily unavailable	283	
System Malfunction	283	

Maintenance	284
How to update the map data	284
Cold weather driving	285
Battery	285
Engine coolant	285
Inverter coolant / Battery coolant	285
Tyre equipment	285
Special winter equipment	286
Corrosion protection	286

BEFORE STARTING THE HYBRID SYSTEM

During the first 1,600 km (1,000 miles), follow these recommendations for the future reliability and economy of your new vehicle. Failure to follow the recommendations may result in shortened engine life and reduced engine performance.

- Avoid driving for long periods at a constant speed, either fast or slow.
- Do not accelerate at full throttle in any gear.
- Avoid quick starts.
- Avoid hard braking as much as possible.
- Do not tow a trailer during the first 800 km (500 miles).

A WARNING

The driving characteristics of your vehicle can be changed remarkably by any additional load and its distribution as well as by adding optional equipment (trailer couplings, roof racks, etc.). Your driving style and speed have to be adjusted accordingly. Especially when carrying heavy loads, your speed must be reduced adequately.

- Make sure the area around the vehicle is free of obstacles.
- Check fluid levels such as engine oil, coolant, brake fluid, and window washer fluid as frequently as possible, at least whenever you refuel
- Visually inspect tyres for their appearance and condition. Also check the tyre pressure for proper inflation.
- Maintenance items in the "8. Maintenance and do-it-yourself" section should be checked periodically.
- Check that all windows and light lenses are clean.
- Check that all doors are closed.
- Position the seat and adjust the head restraints.
- Adjust the inside and outside mirrors.
- Fasten your seat belt and ask all passengers to do likewise.
- Check the operation of the warning/indicator lights when the ignition switch is turned to the ON position.

- Do not place hard or heavy objects on the dashboard or rear parcel shelf in order to prevent injury in the event of a sudden stop.
- If the alcohol interlock system is fitted, follow the instructions on the display screen.

A WARNING

- Do not leave children or adults who would normally require the support of others alone in your vehicle. Pets should also not be left alone. They could accidentally injure themselves or others through inadvertent operation of the vehicle. Also, on hot, sunny days, temperatures in a closed vehicle could quickly become high enough to cause severe or possibly fatal injuries to people or animals.
- To prevent luggage or packages from sliding forward during braking, do not stack anything in the cargo area higher than the seatbacks.
- Secure all cargo with ropes or straps to prevent it from sliding or shifting.
- Failure to follow proper seating instructions, see "Seats" (P.32), could result in serious personal injury in an accident or sudden stop.

NOTE:

During the first few months after purchasing a new vehicle, if you smell strong odours of Volatile Organic Compounds (VOCs) inside the vehicle, ventilate the passenger compartment thoroughly. Open all the windows before entering or while in the vehicle. In addition, when the temperature in the passenger compartment rises, or when the vehicle is parked in direct sunlight for a period of time, turn off the air recirculation mode of the air conditioner and/or

open the windows to allow sufficient fresh air into the passenger compartment.


EXHAUST GAS (Carbon Monoxide)

A WARNING


- Do not breathe exhaust gases; they contain colourless and odourless carbon monoxide. Carbon monoxide is a dangerous gas and can cause unconsciousness or death.
- If you suspect that exhaust fumes are entering the vehicle, drive with all windows fully open and have the vehicle inspected immediately.
- Do not run the engine in closed spaces, such as a garage, for any longer than is absolutely necessary.
- Do not park the vehicle with the engine running for any extended length of time.
- Keep the tailgate closed while driving, otherwise exhaust gases could be drawn into the passenger compartment. If you must drive in this way for some reason, take the following steps:
 - Open all the windows.
 - 2) Set the air recirculation mode ('दः') to the "OFF" position.
 - Set the fan speed control to the maximum position to circulate the air.
- If electrical wiring or other cable connections must pass to a trailer through the seal of the body, follow the manufacturer's

- recommendations to prevent carbon monoxide entry into the vehicle.
- When a vehicle has been stopped in an open area with its engine running for any significant length of time, turn the fan on to force outside air into the vehicle.
- If a special body or other equipment is added for recreational or other usage, follow the manufacturer's recommendation to prevent carbon monoxide entry into the vehicle. (Some recreational vehicle appliances such as stoves, refrigerators, heaters, etc. may also generate carbon monoxide.)
- The exhaust system and body should be inspected by a NISSAN dealer or qualified workshop whenever:
 - The vehicle is raised for service.
 - You suspect that exhaust fumes are entering into the passenger compartment.
 - You notice a change in the sound of the exhaust system.
 - You have had an accident involving damage to the exhaust system, underbody, or rear of the vehicle.

TYRE PRESSURE MONITORING SYSTEM (TPMS) (where fitted)



- TPMS indicator light
- TPMS tyre location indicator




A Tyre valve with sensor

The tyre pressure monitoring system monitors the tyre pressure of the four wheels while the vehicle is in motion. Following a loss in pressure, the system will warn the driver using a visual warning. Each TPMS sensor (A) has a registered wheel location


and sends pressure and temperature data via radio to a receiver inside the vehicle.

Each tyre, including the spare (where fitted), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tyre inflation pressure label. (If your vehicle has tyres of a different size than the size indicated on the vehicle placard or tyre inflation pressure label, you should determine the proper tyre inflation pressure for those tyres.)

The Tyre Pressure Monitoring System (TPMS) controls the TPMS indicator light ⓐ, which will illuminate when one or more tyres are significantly under-inflated. A warning and tyre location indicator ⓑ will also appear in the vehicle information display to identify the tyre or tyres with low pressure.



If you now press the **<OK>** switch on the steering wheel, a further screen is displayed to tell you the tyre pressure of all four tyres.



Accordingly, when the TPMS indicator light illuminates, safely stop the vehicle to check the tyres as soon as possible and inflate the tyres to the proper pressure. Driving on a significantly under-inflated tyre causes the tyre to overheat and can lead to tyre failure. Under-inflation also reduces fuel efficiency and tyre tread life which may affect the vehicle's handling and stopping ability.

NOTE:

The TPMS is not a substitute for proper tyre maintenance. It is the driver's responsibility to maintain correct tyre pressure, even if underinflation has not reached the level to trigger the illumination of the TPMS indicator light (a).

The TPMS indicator light flashes for a short period and then turns on continuously if the system is not operating properly. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists (missing or faulty TPMS sensor or TPMS system malfunction). When the malfunction warning light is illuminated, the system may

not be able to detect or signal low tyre pressure as intended. TPMS malfunctions may occur for a variety of reasons including the installation of replacement or alternate tyres or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS indicator light after replacing one or more tyres or wheels on your vehicle to ensure that the replacement or alternate tyres and wheels allow the TPMS to continue to function properly.

- The TPMS does not monitor the tyre pressure of the spare tyre.
- The TPMS will activate only when the vehicle is driven at speeds above 25 km/h (16 MPH). Also, this system may not detect a sudden drop in tyre pressure (for example a flat tyre while driving).
- The TPMS indicator light may not automatically turn off when the tyre pressure is adjusted. After the tyre is inflated to the recommended COLD tyre pressure, drive the vehicle at speeds above 25 km/h (16 MPH) to activate the TPMS. See "New and repositioned TPMS sensors (including fitment of alternative wheels)" (P.188).
- Following a change in the outside temperature, the TPMS indicator light may illuminate even if the tyre pressure has been adjusted properly. Adjust the tyre pressure to the recommended COLD tyre pressure again when the tyres are cold, and reset the TPMS.
 For additional information, see "[Check cold tyre] message" (P.189).

A WARNING

- If the TPMS indicator light illuminates while driving:
 - avoid sudden steering manoeuvres
 - avoid abrupt braking
 - reduce vehicle speed
 - pull off the road to a safe location
 - stop the vehicle as soon as possible
- Driving with under-inflated tyres may permanently damage the tyres and increase the likelihood of tyre failure. Serious vehicle damage could occur which may lead to an accident and could result in serious personal injury.
- Check the tyre pressure for all four tyres. Adjust the tyre pressure to the recommended COLD tyre pressure shown on the tyre placard to turn the TPMS indicator light "OFF". In case of a flat tyre, replace it with a spare tyre as soon as possible. (See "Flat tyre" (P.292) for changing a flat tyre.)
- When a spare tyre is mounted or a wheel is replaced, the TPMS will not function and the TPMS indicator light will flash for approximately 1 minute. The light will remain on after 1 minute. Be sure to follow all instructions for wheel replacement and mount the TPMS system correctly.
- Replacing tyres with those not originally specified by NISSAN could affect the proper operation of the TPMS.
- The Genuine NISSAN Emergency Tyre Re-

- pair Sealant or equivalent can be used for temporarily repairing a tyre. Do not inject any other tyre liquid or aerosol tyre sealant into the tyres, as this may cause a malfunction of the tyre pressure sensors.
- NISSAN recommends using only Genuine NISSAN Emergency Tyre Sealant provided with your vehicle. Other tyre sealants may damage the valve stem seal which can cause the tyre to lose air pressure. Visit a NISSAN dealer or qualified workshop as soon as possible after using tyre repair sealant (for models equipped with the emergency tyre puncture repair kit).

CAUTION

- The TPMS may not function properly when the wheels are equipped with tyre chains or the wheels are buried in snow.
- Do not place metallised film or any metal parts (antenna, etc.) on the windows. This may cause poor reception of the signals from the tyre pressure sensors, and the TPMS will not function properly.

Some devices and transmitters may temporarily interfere with the operation of the TPMS and cause the TPMS indicator light to illuminate. Some examples are:

- Facilities or electric devices using similar radio frequencies are near the vehicle.
- If a transmitter set to similar frequen-

- cies is being used in or near the vehicle.
- If a computer (or similar equipment) or a DC/AC converter is being used in or near the vehicle.
- If devices which transmit electrical noise are connected to the vehicle's 12V power supply.
- When inflating the tyres and checking the tyre pressure, never bend the valves.
- Use Genuine NISSAN valve caps that comply with the factory-fitted valve cap specifications.
- Do not use metal valve caps.
- Fit the valve caps properly. Without the valve caps the valve and tyre pressure monitor sensors could be damaged.
- Do not damage the valves and sensors when storing the wheels or fitting different tyres.
- Replace the TPMS sensor valve stem (including valve core and cap) and screw (where fitted) when the tyres are replaced due to wear or age. The screw (where fitted) must be fitted correctly with a torque setting of 1.4 ± 0.1 N.m. The TPMS sensors can be used again.
- Use caution when using tyre inflation equipment with a rigid air supply tube, as leverage applied by the long nozzle can damage the valve stem.

METER INFORMATION

TPMS indicator light(s)	Possible cause	Recommended action
(!) "	Low tyre pressure	Inflate tyre(s) to the correct pressure
<u>⟨i)</u> → (i)	Genuine NISSAN TPMS sensor is not detected at one or more wheels	Check if the TPMS sensors are present. If no sensor is present add a genuine NISSAN TPMS sensor
	TPMS radio communication interference between TPMS wheel sensor and TPMS receiver due to external sources.	Drive away from the area of interference
	TPMS parts malfunction	If the problem persists contact a NISSAN dealer or qualified workshop

ACTIVATION

At ignition ON. Once the vehicle starts moving the tyre pressure is monitored.

NEW AND REPOSITIONED TPMS SENSORS (including fitment of alternative wheels)

It is recommended that a NISSAN dealer performs the registration of a new TPMS sensor or sensor location.

It is also possible to register the sensor yourself following the procedure below:

Procedure:

Change tyre position or have a new TPMS sensor fitted

- Confirm pressure of COLD tyre and perform Temperature Calibration. See "TPMS temperature calibration" (P.189).
- Drive the vehicle for several minutes between 25 km/h (16 MPH) and 100 km/h (64 MPH). The TPMS sensor ID and position will automatically be detected


NOTE:

The TPMS might not synchronise if one or more of the following conditions apply:


Bad road conditions

- The TPMS unit does not receive correct data from tyre pressure sensors
- Driving below 25 km/h (16 MPH)
- Driving above 100 km/h (64 MPH)
- High acceleration
- High deceleration
- In stop and go traffic or traffic waves

ADJUSTING TPMS TARGET PRESSURE



7 inch display



Full-screen display

- A Tyre pressure
- B Tyre pressure units
- Front target pressure
- Rear target pressure

If you are using your vehicle in a heavily laden condition, the tyre pressures should be inflated to the "Laden Pressure" shown on the tyre placard.

The TPMS system can be adjusted in the vehicle information display to set the target pressure to the "Laden Pressure" shown on the tyre placard. See "Tyre placard" (P.346). To adjust the target pressure use the steering wheel switches to select the [Settings] menu, followed by [Tyre Pressures]. Select [Target front] and [Target rear] and set the desired tyre pressure.

The TPMS target pressures will be displayed in the centre of the front and rear axle on the TPMS screen of the vehicle information display.

TYRE PRESSURE UNITS

The units displayed by the TPMS system can be selected using the vehicle information display. Select the [Settings] menu, followed by [Tyre Pressures]. Select [Tyre pressure unit] and choose the unit that you want.

[CHECK COLD TYRE] MESSAGE

If the tyre pressure becomes higher than the target pressure during a low tyre pressure condition, the [Check Cold Tyre] message will be displayed in the vehicle information display.

See "Settings" (P.86).

NOTE:

Even if the pressure is above the preset target pressure, the yellow colour in the tyre pressure warning means that the tyre pressure is actually too low. Tyre pressure is increasing during driving. Check the tyre pressure when the tyre is cold.

TPMS TEMPERATURE CALIBRATION

The tyre pressure is affected by the temperature of the tyre; the tyre temperature increases when the car is driven. To be able to accurately monitor the tyre air leakage and to prevent false TPMS warnings due to reductions in temperature, the TPMS system uses temperature sensors in the tyres to perform temperature compensation calculations.

On rare occasions it may be necessary to recalibrate the TPMS system reference temperature using the vehicle information display. See "Settings" (P.86). This operation should only be per-

formed when the actual tyre pressure has been adjusted, whilst the current ambient temperature is significantly different to the current calibration temperature.

To initiate TPMS temperature calibration use the steering wheel switches to select the [Settings] menu, followed by [Tyre Pressures]. Select [Calibrate]. While the calibration process is active, the message: [Calibrate] will be displayed in the vehicle information display.

Utility vehicles have a significantly higher rollover rate than other types of vehicles.

They have higher ground clearance than passenger cars to make them capable of performing in a wide variety of on-road and off-road applications. This gives them a higher centre of gravity than ordinary cars. An advantage of higher ground clearance is a better view of the road, allowing you to anticipate problems. However, they are not designed for cornering at the same speeds as conventional two-wheel drive (2WD) vehicles any more than low-slung sports cars are designed to perform satisfactorily under off-road conditions. If possible, avoid sharp turns or abrupt manoeuvres, particularly at high speeds. As with other vehicles of this type, failure to operate this vehicle correctly may result in loss of control or vehicle rollover. In a rollover accident an unbelted person is significantly more likely to be injured than a person who is wearing a seat belt.

The three-way catalyst is an emission control device installed in the exhaust system. In the converter, exhaust gases are burned at high temperatures to help reduce pollutants.

CAUTION

- The exhaust gas and the exhaust system are very hot. While the engine is running, keep people or flammable materials away from the exhaust pipe.
- Do not stop or park the vehicle over flammable materials such as dry grass, waste paper or rags, as they may burn easily.
- When parking, ensure that people or flammable materials are kept away from the exhaust pipe.

TO HELP PREVENT DAMAGE

CAUTION

- Use UNLEADED PETROL ONLY, specifically the recommended type. For details, see "Capacities and recommended fluids/lubricants" (P.341).
- Do not use leaded petrol. Leaded petrol will seriously damage three-way catalyst.
 - Deposits from leaded petrol will seriously reduce the three-way catalyst's ability to help reduce exhaust pollutants.
- Keep your engine tuned up. Malfunctions in the ignition, fuel injection, or electrical systems can cause over-rich fuel flow into the converter, causing it to overheat.

GASOLINE PARTICULATE FILTER (GPF) (where fitted)

- Avoid driving with an extremely low fuel level. Running out of fuel could cause the engine to misfire, damaging the three-way catalyst.
- Do not keep driving if the engine misfires. or if noticeable loss of performance or other unusual operating conditions are detected. Have the vehicle inspected promptly by a NISSAN dealer or qualified workshop.
- Do not race the engine while warming it up.
- Do not push or tow your vehicle to start the engine.

If your vehicle is fitted with a petrol engine, a Gasoline Particulate Filter (GPF) (or Petrol Particulate Filter) may be fitted as part of the emission control system.

The GPF filters carbon particles from the exhaust gas, thus reducing the emission of soot to the environment.

Under normal driving conditions, the accumulated carbon particles in the GPF are burned-off regularly, thus emptying the filter from carbon particles. In this way, the GPF is "regenerated" and again fully operational to filter out the carbon particles from the exhaust gas as intended.

CAUTION

Under certain less-favourable driving conditions, the GPF may become saturated/ clogged because these driving conditions prevent automatic regeneration of the filter. In this case, a message is displayed in the vehicle information display and the Malfunction Indicator Light (MIL - orange) or Malfunction Warning Light (MWL - red) may come on (although there may be other engine management malfunctions that may cause this light to come on). Also, GPF saturation/clogging may result in reduced engine performance and engine speed limitation.



Exhaust filter maintenance

- When the [Exhaust filter maintenance See Owner's Manual] message is displayed, provided that legal and safety conditions allow, the vehicle should be driven at a speed of over 50 km/h (30 MPH), with gentle use of the accelerator pedal, until the message is no longer displayed.
- Should the MIL or MWL come on for any reason, or if the [Exhaust filter maintenance] warning message appears in the vehicle information display, always visit a NISSAN dealer or qualified workshop as soon as possible. Extended driving with the MIL/MWL illuminated may lead to damage to the engine control system.

What you can do yourself to prevent the GPF from becoming saturated/clogged:

- Avoid repeated and frequent short journeys in which the engine does not reach its normal operating temperature.
- Regularly drive the vehicle at speeds over 60 km/h for an extended period of time (more than 30 minutes).

Driving your vehicle to fit the circumstances is essential for your safety and comfort. As a driver, you should be the one who knows best how to drive in the given circumstances.

ENGINE COLD START PERIOD

Due to the higher engine speeds when the engine is cold, extra caution must be exercised when selecting a gear during the engine warm-up period after starting the hybrid system.

LOADING LUGGAGE

Loads, their distribution and the attachment of equipment (coupling devices, roof luggage carriers, etc.) will change the driving characteristics of the vehicle considerably. Driving style and speed must be adjusted accordingly.

DRIVING ON WET ROADS

- Avoid starting off, accelerating and stopping suddenly.
- Avoid sharp turns or lane changes.
- Extra distance should be kept from the vehicle in front.
- When water covers the road surface in puddles, small streams, etc. REDUCE SPEED to prevent aquaplaning which will cause skidding and loss of control. Worn tyres increase this risk

DRIVING UNDER WINTER CONDITIONS

- Drive safely.
- Avoid starting off, accelerating or stopping suddenly.
- Avoid sharp turns or lane changes.
- Avoid sudden steering actions.
- Extra distance should be kept from the vehicle in front.

PRECAUTIONS ON PUSH-BUTTON IGNITION SWITCH OPERATION

A WARNING

Do not operate the push-button ignition switch while driving the vehicle except in an emergency. (The hybrid system will stop when the ignition switch is pushed 3 consecutive times in quick succession or the ignition switch is pushed and held for more than 2 seconds.) If the hybrid system stops while the vehicle is being driven, this could lead to a crash and serious injury.

Before operating the push-button ignition switch:

Move the shift lever to the P (Park) position.

INTELLIGENT KEY SYSTEM


The Intelligent Key system can operate the ignition switch without taking the key out from your pocket or bag. The operating environment and/ or conditions may affect the Intelligent Key system operation.

CAUTION

- Be sure to carry the Intelligent Key with you when operating the vehicle.
- Never leave the Intelligent Key inside the vehicle when you leave the vehicle.
- If the Intelligent Key is too far away from the driver, the vehicle may not start.
- If the vehicle battery is discharged, the ignition switch cannot be switched from the "LOCK" position, and if the steering lock is engaged, the steering wheel cannot be

moved. Charge the battery as soon as possible (See "Jump-starting" (P.300).)

Operating range



The Intelligent Key can only be used for starting the hybrid system when the Intelligent Key is within the specified operating range ① as illustrated.


When the Intelligent Key battery is almost discharged or strong radio waves are present near the operating location, the Intelligent Key system's operating range becomes narrower and may not function properly.

If the Intelligent Key is within the operating range, it is possible for anyone, even someone who does not carry the Intelligent Key, to push the ignition switch to start the hybrid system.


 The luggage room area is not included in the operating range, but the Intelligent Key may function.

- If the Intelligent Key is placed on the instrument panel, inside the glove box, door pocket or the corner of the interior compartment, the Intelligent Key may not function.
- If the Intelligent Key is placed near the door or window outside the vehicle, the Intelligent Key may function.

IGNITION SWITCH POSITIONS



Left hand drive



Right hand drive

When the ignition switch is pushed without depressing the brake pedal, the ignition switch will illuminate:

Push the centre of the ignition switch:

- Once to change it to the "ON" position.
- Two times to change it to the "OFF" position.

The "LOCK" position will automatically be activated when any door is either opened or closed with the switch in the "OFF" position.

Some indicators and warnings for operation are displayed on the vehicle information display. See "Vehicle information display" (P.82).

ON position (normal operating position)

This position turns on the ignition system and electrical accessories.

Battery saver system:

The ignition position "ON" has a battery saver feature. If the vehicle is not running, after a period

of time, the ignition will automatically switch to the "OFF" position.

The battery saver feature will be suspended if the ignition switch position is changed.

CAUTION

Use electrical accessories with the hybrid system running to avoid discharging the vehicle battery. If you must use accessories while the hybrid system is not running, do not use them for extended periods of time and do not use multiple electrical accessories at the same time.

LOCK position (normal parking position)

The ignition switch and steering lock can only be locked at this position.

The ignition switch will lock when any door is opened or closed with the ignition switched off.

When pushing the ignition switch to the "OFF" position, make sure the shift lever is in the P (Park) position.

The shift lever can be moved from the P (Park) position if the ignition switch is in the "ON" position and the brake pedal is depressed.

If the battery of the vehicle is discharged, the pushbutton ignition switch cannot be moved from the "LOCK" position.

OFF position

The ignition switch is in the OFF position when the hybrid system is turned off using the ignition switch. No lights will illuminate on the ignition switch.

ACC position

With the vehicle in the P (Park) position, the Intelligent key with you and the ignition placed from "ON" to "OFF", the radio can still be used for a period of time, or until the driver's door is opened.

After a period of time, functions such as radio, navigation, and Bluetooth® Hands-Free Phone System may be restarted by pressing the POWER ON-OFF button/VOLUME control knob or the key fob unlock button up to a total of 30 minutes.

EMERGENCY HYBRID SYSTEM SHUT OFF

To shut off the hybrid systemin an emergency situation while driving, perform the following procedure:

- Rapidly push the push-button ignition switch 3 consecutive times in less than 1.5 seconds, or
- Push and hold the push-button ignition switch for more than 2 seconds.

STEERING LOCK

The ignition switch is equipped with an anti-theft steering lock device.

To lock steering wheel

- Push the ignition switch to the "OFF" position where the ignition switch position indicator will not illuminate.
- 2. Open or close the door. The ignition switch turns to the "LOCK" position.
- Turn the steering wheel 1/6 of a turn to the right or left from the straight up position.

To unlock steering wheel


Push the ignition switch to "ACC", and the steering wheel will be automatically unlocked.

CAUTION

- If the battery of the vehicle is discharged, the push-button ignition switch cannot be switched from the "LOC" position.
- If the ignition switch position does not change from the "LOCK" position, push the ignition switch again while rotating the steering wheel slightly to the right and left.

STARTING THE HYBRID SYSTEM

INTELLIGENT KEY BATTERY DISCHARGE



If the battery of the Intelligent Key is discharged, or environmental conditions interfere with the Intelligent Key operation, start the hybrid system according to the following procedure:

- Move the shift lever to the P (Park) position.
- Firmly apply the footbrake.
- 3. Touch the ignition switch with the Intelligent Key as illustrated. (A chime will sound.)
- 4. Push the ignition switch while depressing the brake pedal within 10 seconds after the chime sounds. The hybrid system will start.

After step 4 is performed, when the ignition switch is pushed without depressing the brake pedal, the ignition switch position will change to "ON".

NOTE:

When the ignition switch is pushed to the "ACC" or "ON" position or the hybrid system is started by the above procedures, the Intelligent Key system warning light may

blink in yellow (on the meter) even if the Intelligent Key is inside the vehicle. This is not a malfunction.

- If the Intelligent Key system warning light in the meter is blinking in green, replace the battery as soon as possible. (See "Intelligent Key battery replacement" (P.327).)
- Before starting the hybrid system ensure parking brake is applied and vehicle is secure. For additional information, see "Electric parking brake" (P.138).
- 2. Move the shift lever to the P (Park) position, depress and hold brake pedal while starting the hybrid system.

The starter is designed to operate only when the shift lever is in the proper position.

The Intelligent Key must be carried while inside the vehicle when operating the ignition switch.

- 3. To start the hybrid system:
 - Depress the brake pedal then push the ignition switch. If you try to start hybrid system with the shift lever in N (Neutral) without the footbrake depressed, the hybrid system will not start and a [Shift to Park] message will be displayed in the vehicle information display.
- 4. The # indicator is displayed in the vehicle information display.

CAUTION

If it becomes necessary to start the engine with a booster battery and jumper cables, the instructions and cautions contained in the "6. In case of emergency" section should be carefully followed.

5. After starting, allow the engine to idle for at least 30 seconds to warm-up. Drive at moderate speeds for a short distance first, especially in cold weather

DRIVING THE VEHICLE

CAUTION

Do not leave the vehicle unattended while the hybrid system is warming up.

- 6. To stop the hybrid system:
 - Move the shift lever to the P (Park) position, apply the parking brake and push the switch to the "OFF" position.
- 7. The steering wheel lock engages when ignition is off and a door is opened or closed.

DRIVING WITH HYBRID GEARBOX

Driving precautions

A WARNING

Do not downshift abruptly on slippery roads. This may cause a loss of control.

CAUTION

- Never shift to either the P (Park) or R (Reverse) position while the vehicle is moving forward, and P (Park) or D (Drive) position while the vehicle is reversing. This could cause an accident or damage the hybrid gearbox.
- Except in an emergency, do not shift to the N (Neutral) position while driving. Coasting with the hybrid gearbox in the N (Neutral) position may cause serious damage to the hybrid gearbox.
- Start the hybrid system in the P (Park) or N (Neutral) position. The hybrid system will not start in any other shift lever position. If it does, have your vehicle checked by a NISSAN dealer or qualified workshop.
- To avoid possible damage to your vehicle; when stopping the vehicle on an uphill grade, do not hold the vehicle by depressing the accelerator pedal. The footbrake should be used for this purpose.
- Shift into the N (Neutral) position and apply the parking brake when at a standstill for longer than a short waiting period.

- Keep the engine at idling speed while shifting from the N (Neutral) position to any driving position.
- DEPRESS THE FOOTBRAKE PEDAL

When the hybrid system is running, shifting the shift lever into the R (Reverse), D (Drive) or Manual shift mode position without depressing the brake pedal causes the vehicle to move slowly. Be sure the brake pedal is fully depressed and the vehicle is stopped, before shifting the shift lever.

BE AWARE OF THE SHIFT LEVER POSITION

Make sure that the shift lever is in the desired position. Use the D (Drive) mode to move forwards and R (Reverse) to move backwards. Release the parking brake and the footbrake pedal, then depress the accelerator pedal to start the vehicle in motion and merge with traffic (avoid abrupt starting and spinning the wheels).

- Avoid revving up the engine while the vehicle is stopped, this could cause unexpected vehicle movement (if the shift lever is in the R (Reverse) or D (Drive) position) or damage the engine (if the shift lever is in the N (Neutral) or P (Park) position).
- WARM THE ENGINE UP

Due to the higher idle speeds when the engine is cold, extra caution must be taken when shifting the shift lever into the

driving position immediately after starting the hybrid system.

PARKING THE VEHICLE

Depress the footbrake pedal and, once the vehicle stops, move the shift lever into the P (Park) position, apply the parking brake and release the footbrake pedal.

Starting the vehicle

NOTE:

Start the hybrid system in the P (Park) or N (Neutral) position with the footbrake depressed. The hybrid system will not start in any other shift lever position.


If you try to start the hybrid system with the shift lever in N (Neutral) without the footbrake depressed, the hybrid system will not start and a [Shift to Park] message will be displayed in the vehicle information display.


- After starting the hybrid system, fully depress the footbrake pedal before shifting the shift lever from P (Park) to R (Reverse) or D (Drive).
- Keep the footbrake pedal depressed and push the shift lever button to shift into a driving gear.
- Release the parking brake and footbrake, then gradually start the vehicle in motion by pressing the accelerator pedal. If you don't press the accelerator, the vehicle will start to move slowly.

The Hybrid Gearbox is designed so that the footbrake pedal **MUST** be depressed before shift-

ing from P (Park) to any drive position while the ignition is switched \mathbf{ON} .

Shifting





- A LHD models
- RHD models

To move the shift lever:

- Push the button while depressing the brake pedal.
- Push the button to shift.
- Just move the shift lever.

Push the button to shift into P (Park) or R (Reverse). All other positions can be selected without pushing the button.

NOTE:

Never shift to the P (Park) position while the vehicle is moving forward or reversing. This could cause an accident or damage the hybrid gearbox.

P (Park):

Use this position when the vehicle is parked or when starting the hybrid system. Always make sure that the vehicle is completely stopped before moving the shift lever into the P (Park) position. For maximum safety, the footbrake pedal must be depressed before moving the shift lever into the P (Park) position. Use this position together with the parking brake. When parking on a hill, first depress the footbrake pedal, apply the parking brake and then shift into the P (Park) position.

R (Reverse):

CAUTION

Shift into this position only after the vehicle has completely stopped.

Use this position to reverse the vehicle.


When the shift lever is in the R (Reverse) position, either the NissanConnect monitor (where fitted) or the ultrasonic parking sensor (where fitted) will be activated. For details, see "Rear-view monitor (where fitted)" (P.148) or "Intelligent Around View Monitor (IAVM) (where fitted)" (P.153) or "Intelligent Around View Monitor (IAVM) (where fitted)" (P.153).

N (Neutral):

Neither forward nor reverse gear is engaged. The hybrid system can be started in this position. You may shift to N and restart a stalled engine while driving the vehicle.

D (Drive):

Use this position for all normal forward driving.



Shift lever indicator:

The shift lever indicator (A) located in the lower part of the vehicle information display shows the current position of the hybrid gearbox.

It shows the P,R,N,D modes.

Drive mode switch (where fitted):


The Drive Mode switch can be used to change the shifting characteristics of the Hybrid gearbox. ECO Mode will perform upshifts and downshifts at lower engine speeds than standard mode. Sport Mode will perform upshifts and downshifts at higher engine speeds than standard mode.

For more details about the Drive Mode switch, see "Drive mode" (P.278).

Accelerator downshift - In the D (Drive) position

For rapid passing or driving uphill, fully depress the accelerator pedal to the floor. This shifts the hybrid gearbox down into a lower gear, depending on the vehicle speed.

Shift lock release



- Console finisher
- Shift lock release button

If the battery charge is low or discharged, the shift lever may not move from the P (Park) position even with the brake pedal depressed and the shift lever button pushed.

To move the shift lever, perform the following procedure:

- 1. Place the ignition in the **OFF** or **LOCK** position.
- 2. Apply the parking brake.
- Using a suitable tool, unclip and lift up the console finisher ring ①.
- Push down the shift lock release button 2. Use a suitable tool if necessary.
- Push and hold the shift lever button and move the shift lever to the N (Neutral) position while holding down the shift lock release button.

Place the ignition in the **ON** position to unlock the steering wheel. The vehicle may be moved to the desired location.

If the battery is discharged completely, the steering wheel cannot be unlocked. Do not move the vehicle with the steering wheel locked.

If the shift lever cannot be moved out of the P (Park) position, have a NISSAN dealer or qualified workshop check the Hybrid Gearbox system as soon as possible.

A WARNING

If the shift lever cannot be moved from the P (Park) position while the engine is running and the brake pedal is depressed, the brake lights may not work. Malfunctioning brake lights could cause an accident injuring yourself and others.

High fluid temperature protection mode

⚠Warning
Gearbox Hot
Power reduced

This hybrid gearbox has a high fluid temperature protection mode. If the fluid temperature becomes too high (for example, when climbing steep grades in high temperature with heavy loads, such as when towing a trailer), engine power and, under some conditions, vehicle speed will be decreased automatically to reduce the chance of hybrid gearbox damage, and a warning will be displayed on the vehicle information display. Vehicle speed can be controlled with the accelerator pedal, but engine and vehicle speed may be limited.

Fail-safe

⚠Warning
Gearbox Fault

. Warning

Gearbox Fault Stop Safely Call Dealer

MNIC3851

When the fail-safe operation occurs, the vehicle speed will be decreased automatically to reduce the chance of hybrid gearbox damage. Vehicle speed can be controlled with the accelerator pedal, but the engine power may be limited. A [Gearbox Fault] warning message will be displayed on the vehicle information display. Have a NISSAN

BLIND SPOT WARNING (BSW) SYSTEM/INTELLIGENT BLIND SPOT INTERVENTION SYSTEM (where fitted)

dealer or qualified workshop check and repair the hybrid gearbox.

If the vehicle is driven under extreme conditions. such as excessive wheel spinning and subsequent hard braking, the Fail-safe system may be activated. This will occur even if all electrical circuits are functioning properly. In this case, place the ignition in the OFF position and wait for 10 seconds. Then place the ignition back in the ON position. The vehicle should return to its normal operating condition. If it does not return to its normal operating condition have your NISSAN dealer or qualified workshop check the hybrid gearbox and have the hybrid gearbox repaired by a NISSAN dealer or qualified workshop, if necessary.

A WARNING

When the fail safe operation occurs, the vehicle speed may be lower than other traffic, which could increase the chance of a collision. Be especially careful when driving. If necessary, drive to the side of the road at a safe place and away from traffic, to allow the hybrid gearbox to return to normal operation, or have the hybrid gearbox repaired by a NISSAN dealer or qualified workshop, if necessary.

This section contains the information about the following systems:


- Blind Spot Warning (BSW) system
- Intelligent Blind Spot Intervention system


A WARNING

Listed below are the system limitations for the BSW/Intelligent Blind Spot Intervention system. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.

- The BSW/Intelligent Blind Spot Intervention system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When driving, always use the side and rear mirrors and always turn your head and look in the direction you will move to ensure it is safe to change lanes. Never rely solely on the BSW system.
- There is a limitation to the detection capability of the radar. Using the BSW and Intelligent Blind Spot Intervention systems under some road, lane marker or weather conditions could lead to improper system operation. Always rely on your own operation to avoid accidents.
- The BSW system operates at speeds above approximately 32 km/h (20 MPH).
- The Intelligent Blind Spot Intervention system operates at speeds above approximately 60 km/h (37 MPH).

THE BSW AND INTELLIGENT BLIND SPOT INTERVENTION SYSTEMS:






The Blind Spot Warning (BSW) and Intelligent Blind Spot Intervention systems can help alert the driver of other vehicles in adjacent lanes when changing lanes.

The BSW system uses radar sensors (A) installed near the rear bumper to detect other vehicles beside vour vehicle in an adjacent lane. In addition

to the radar sensors, the Intelligent Blind Spot Intervention system uses a camera ① installed behind the windscreen to monitor the lane markers of your travelling lane.



Detection zone


The radar sensors can detect vehicles on either side of your vehicle within the detection zone shown as illustrated. This detection zone starts from the outside mirror of your vehicle and extends approximately 3.0 m (10 ft) behind the rear bumper, and approximately 3.0 m (10 ft) sideways.

The BSW system operates above approximately 32 km/h (20 MPH). If the radar sensors detect vehicles in the detection zone, the BSW LED indicator light illuminates. If the driver then activates the turn signal, the system chimes a sound (twice) and the BSW LED indicator light and the BSW indicator in the meter will flash

The Intelligent Blind Spot Intervention system operates above approximately 60 km/h (37 MPH). If the radar detects a vehicle in the detection zone and your vehicle is approaching the lane marker, the systems chime a sound (three times), flashes the BSW LED indicator light and the BSW indicator in the meter, and slightly applies the brakes on one side for a short period of time to help return the vehicle back to the travelling lane.

The Intelligent Blind Spot Intervention system provides an audible warning and turns on or flashes the BSW LED indicator light even if the BSW system is off.

BSW SYSTEM OPERATION



- BSW LED indicator light
- BSW indicator

The BSW system operates above approximately 32 km/h (20 MPH).

If the radar sensors detect a vehicle in the

detection zone, the BSW LED indicator light illuminates

If the turn signal is then activated, the system chimes (twice) and the BSW LED indicator light and the BSW indicator in the meter flashes. The BSW LED indicator light continues to flash until the detected vehicle leaves the detection zone.

The BSW LED indicator light illuminates for a few seconds when the ignition is placed in the ON position. The brightness of the side indicator light is adjusted automatically depending on the brightness of ambient light.

If a vehicle comes into the detection zone after the driver activates the turn signal, then the BSW LED indicator light, the BSW indicator in the meter flashes and no chime sounds. For additional information, see "Another vehicle approaching from behind" (P.206).

Turning the BSW system on or off

In the [Settings] menu of the vehicle information display, select the [Driver Assistance] key. Select the [Blind Spot] submenu by pressing <OK>. An indicator next to [Warning] indicates that the system is turned on.

For details. see "Vehicle information display" (P.82).

NOTE:

When enabling/disabling the system, the system will retain the current settings even if the engine is restarted.

BSW temporary disabled status

When radar blockage is detected, the BSW system will be turned off automatically. The [Not available Side radar obstructed] warning message will appear in the vehicle information display.

The system is not available until the conditions no longer exist.

The radar sensors may be blocked by temporary ambient conditions such as splashing water, mist, or fog. The blocked condition may also be caused by objects such as ice, frost or dirt obstructing the radar sensors.


System malfunction

If the BSW system malfunctions, it will be turned off automatically. The [System Fault] warning message will appear and BSW indicator (yellow) on in the vehicle information display.

Action to take:

Stop the vehicle in a safe location, turn off and restart the engine. If the message continues to appear, have the BSW system checked by a NISSAN dealer or qualified workshop.

INTELLIGENT BLIND SPOT INTERVENTION SYSTEM OPERATION



- BSW LED indicator on the door mirror glass (where fitted)
- ProPILOT Assist status indicator light (where fitted) in the vehicle information display
- BSW indicator

- (4) Vehicle information Display
 - ProPILOT Assist switch (for models with ProPILOT Assist)

If the radar sensors detect vehicles in the detection zone, the BSW LED indicator light located on the outside mirrors illuminates. If your vehicle is approaching a lane marker, the system chimes a sound (three times), the BSW LED indicator light and the BSW indicator in the meter flashes. Then the system applies the brakes on one side of the vehicle for a moment to help return the vehicle back to the centre of the lane. Intelligent Blind Spot Intervention operates regardless of turn signal usage.

NOTE:

Warning and brake control will only be activated if the BSW LED indicator light is already illuminated when your vehicle approaches a lane marker. If another vehicle comes into the detection zone after your vehicle has crossed a lane marker, no warning or brake control will be activated. For additional information, see "BSW/ Intelligent Blind Spot Intervention driving situations" (P.206). The Intelligent Blind Spot Intervention system is typically activated earlier than the Lane Assist system when your vehicle is approaching a lane marker.

The Intelligent Blind Spot Intervention system turns on when either the ProPILOT Assist switch (for models with ProPILOT Assist) or the speed limiter switch (for models with ProPILOT) on the steering wheel is pushed when the [Intervention] is enabled in the [Driver Assistance] menu in the vehicle information display.

The ProPILOT Assist status indicator light (for models with ProPILOT Assist) on the vehicle information display illuminates.

The Intelligent Blind Spot Intervention system provides a chime and turns on or flashes the

BSW LED indicator light and the BSW indicator in the meter even if the BSW system is off.

Intelligent Blind Spot Intervention system activation and deactivation

Intelligent Blind Spot Intervention is activated when pushing either the ProPILOT Assist switch (for models with ProPILOT Assist) or the Speed Limiter switch on the steering wheel when the [Intervention] setting is enabled in the [Driver Assistance] menu in the vehicle information display.

To deactivate the Intelligent Blind Spot Intervention, push the same switch again or disable the [Intervention] setting in the [Driver Assistance] menu. The system will be automatically deactivated when the ignition switch is placed in the OFF position.

To enable or disable the [Intervention] setting:

- In the [Settings] menu in the vehicle information display, select [Driver Assistance]
- 2. Select the [Blind Spot] submenu.

will be turned off automatically.

Press OK to enable or disable the [Intervention] setting.

For details. see "Vehicle information display" (P.82).

Intelligent Blind Spot Intervention temporarily not available When any of the following messages appear on the vehicle information display, a chime will sound and the Intelligent Blind Spot Intervention system

- [Not Available Road is slippery]: When the ESP system (except traction control system function) or ABS operates.
- [Currently Not Available]: When the ESP system is turned off.
- [Not Available High Camera Temp]: When the camera detects that the interior temperature is high (over approximately 40°C (104°F)).
- [Not Available Side Radar Obstructed]: When side radar blockage is detected.

Turn off the Intelligent Blind Spot Intervention system and turn it on again when the above conditions no longer exist.

Intelligent Blind Spot Intervention malfunction

If the Intelligent Blind Spot Intervention system malfunctions, it will be turned off automatically. The [System fault See Owner's Manual] warning message will appear, the BSW indicator (yellow) in the vehicle information display will illuminate and a chime will sound.

Action to take:

Stop the vehicle in a safe location, turn off and restart the engine. If the message continues to appear, have the Intelligent Blind Spot Intervention system checked by a NISSAN dealer or qualified workshop.

BSW/INTELLIGENT BLIND SPOT INTER-VENTION SYSTEM PRECAUTIONS

A WARNING

- The radar sensors may not be able to detect and activate BSW/Intelligent Blind Spot Intervention when certain objects are present such as:
 - Pedestrians, bicvcles, animals.
 - Vehicles such as motorcycles, low height vehicles, or high ground clearance vehicles.
 - Oncoming vehicles.
 - Vehicles remaining in the detection zone when you accelerate from a stop.
 - A vehicle merging into an adjacent lane at a speed approximately the same as vour vehicle.
 - A vehicle approaching rapidly from behind.
 - A vehicle which your vehicle overtakes rapidly.
 - See "BSW/Intelligent Blind Spot Intervention driving situations" (P.206) for the situations in which the radar sensors may not be able to detect vehicle (s).
- The BSW and Intelligent Blind Spot Intervention systems may not provide a warning or brake control for vehicles that pass the detection zone quickly.
- The radar sensors detection zone is de-

- signed based on a standard lane width. When driving in a wider lane, the radar sensors may not detect vehicles in an adjacent lane. When driving in a narrow lane, the radar sensors may detect vehicles driving two lanes away.
- The radar sensors are designed to ignore most stationary objects, however objects such as guardrails, walls, foliage and parked vehicles may occasionally be detected. This is a normal operating condition.
- Severe weather or road spray conditions may reduce the ability of the radar to detect other vehicles.
- The camera may not detect lane markers in the following situations and the Blind Spot Intervention system may not operate properly.
 - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly: vellow painted lane markers; nonstandard lane markers; lane markers covered with water, dirt, snow, etc.
 - On roads where discontinued lane markers are still detectable.
 - On roads where there are sharp curves.
 - On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs.

- On roads where the travelling lane merges or separates.
- When the vehicle's travelling direction does not align with the lane markers.
- When travelling close to the vehicle in front of you, which obstructs the lane camera unit detection range.
- When rain, snow or dirt adheres to the windscreen in front of a lane camera unit.
- When the headlights are not bright due to dirt on the lens or if aiming is not adjusted properly.
- When strong light enters a lane camera unit. (For example: light directly shines on the front of the vehicle at sunrise or sunset.)
- When a sudden change in brightness occurs. (For example: when the vehicle enters or exits a tunnel or under a bridge.)
- Do not use the Intelligent Blind Spot Intervention system under the following conditions because the system may not function properly.
 - During bad weather (For example: rain, fog, snow, etc.)
 - When driving on slippery roads, such as on ice or snow, etc.
 - When driving on winding or uneven roads.

- When there is a lane closure due to road repairs.
- When driving in a makeshift or temporary lane.
- When driving on roads where the lane width is too narrow.
- When driving with a tire that is not within normal tyre conditions (for example, tyre wear, low tyre pressure, installation of spare tyre, tyre chains, non-standard wheels).
- When the vehicle is equipped with non-original brake parts or suspension parts.
- When towing a trailer or other vehicle.
- Excessive noise (for example, audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.

BSW/INTELLIGENT BLIND SPOT INTER-VENTION DRIVING SITUATIONS

Another vehicle approaching from behind




Illustration 1 Approaching from behind

Illustration 1: The BSW LED indicator light illuminates if a vehicle enters the detection zone from behind in an adiacent lane. However, if the overtaking vehicle is travelling much faster than your vehicle, the BSW LED indicator light may not illuminate before the detected vehicle is beside your vehicle. Always use the side and rear mirrors and turn and look in the direction your vehicle will move to ensure it is safe to change lanes.




Illustration 2 Approaching from behind

Illustration 2: If the driver activates the turn signal, then the system chimes (twice) and the BSW LED indicator light and the BSW indicator in the meter flash.

NOTE:

If the driver activates the turn signal before a vehicle enters the detection zone, the BSW LED indicator light and the BSW indicator in the meter will flash but no chime will sound when the other vehicle is detected.




Illustration 3 Approaching from behind

Illustration 3: If the Intelligent Blind Spot Intervention system is on and your vehicle is approaching a lane marker and a vehicle is in the detection zone, the system chimes (three times), the BSW LED indicator light and the BSW indicator in the meter flash. Then the Intelligent Blind Spot Intervention system slightly applies the brakes on one side to help return the vehicle back to the centre of the driving lane.




Illustration 4 Accelerate from a stop

NOTE:

Illustration 4: If you accelerate from a stop with a vehicle in the detection zone, the other vehicle may not be detected.

Overtaking another vehicle




Illustration 5 Overtaking another vehicle

Illustration 5: BSW LED indicator light illuminates if

you overtake a vehicle and that vehicle stays in the detection zone for approximately 3 seconds.

The radar sensors may not detect slower moving vehicles if they are passed quickly.




Illustration 6 Overtaking another vehicle

Illustration 6: If the driver activates the turn signal while another vehicle is in the detection zone, then the system chimes (twice) and the BSW LED indicator light and the BSW indicator in the meter flash.




Illustration 7 Overtaking another vehicle

Illustration 7: If the Intelligent Blind Spot Intervention system is on and your vehicle approaches a lane marker while another vehicle is in the detection zone, the system chimes (three times) and the BSW LED indicator light and the BSW indicator in the meter flash. Then, the Intelligent Blind Spot Intervention system slightly applies the brakes on the appropriate side to help return the vehicle back to the centre of the driving lane.




Illustration 8 Overtaking several vehicles

Illustration 8: When overtaking several vehicles in a row, the vehicles after the first vehicle may not be detected if they are travelling close together.

Entering from the side




Illustration 9 Entering from the side

Illustration 9: The BSW LED indicator light illuminates if a vehicle enters the detection zone from either side

NOTE:

The radar sensors may not detect a vehicle which is travelling at about the same speed as vour vehicle when it enters the detection zone.




Illustration 10 Entering from the side

Illustration 10: If the driver activates the turn signal while another vehicle is in the detection zone, then the BSW LED indicator light and the BSW indicator in the meter flash and a chime will sound twice

NOTE:

If the driver activates the turn signal before a vehicle enters the detection zone, the BSW LED indicator light and the BSW indicator in the meter will flash but no chime will sound when the other vehicle is detected.




Illustration 11 Entering from the side

Illustration 11: If the Intelligent Blind Spot Intervention system is on and your vehicle approaches the lane marker while another vehicle is in the detection zone, the BSW LED indicator light and the BSW indicator in the meter flash and a chime will sound three times. Then, the Intelligent Blind Spot Intervention system slightly applies the brakes on the appropriate side to help return the vehicle back to the centre of the driving lane.




Illustration 12 Entering from the side

Illustration 12: The Intelligent Blind Spot Intervention system will not operate if your vehicle is on a lane marker when another vehicle enters the detection zone. In this case only the BSW system operates.


NOTE:

Intelligent Blind Spot Intervention braking will not operate or will stop operating and only a warning chime will sound under the following conditions:

- When the brake pedal is depressed or if the vehicle decelerates strongly.
- When the vehicle is accelerated during Intelligent Blind Spot Intervention system operation.
- When steering quickly.
- When the ICC or Intelligent Emergency Braking warnings sound.
- When the hazard warning flashers are operated

When driving on a curve at a high speed.

SYSTEM MAINTENANCE




The two radar sensors (A) for the BSW/Intelligent Blind Spot Intervention system are located near the rear bumper.

To keep the BSW/Intelligent Blind Spot Intervention system operating properly, be sure to observe the following:

- Always keep the area near the radar sensors clean.
- The radar sensors may be blocked by temporary ambient conditions such as splashing water, mist, or fog.
- The blocked condition may also be caused by objects such as ice, frost, or dirt obstructing the radar sensors. Check for and remove objects obstructing the area around the radar sensors.

Do not attach stickers (including transparent material), install accessories, or apply additional paint near the radar sensors

- Do not attach metallic objects near the sensor area (brush guard, etc.). This could cause failure or malfunction.
- Do not strike or damage the area around the radar sensors. If the area around the radar sensors is damaged due to an accident, it is recommended that you visit a NISSAN dealer or qualified workshop.



The lane camera unit ① for the Intelligent Blind Spot Intervention system is located above the Interior rear view mirror. To maintain the proper operation of the Intelligent Blind Spot Intervention system and prevent a system malfunction, be sure to observe the following:

- Always keep the windscreen clean.
- Do not attach a sticker (including transparent material) or install an accessory near the camera unit.

Do not place reflective materials, such as white paper or a mirror, on the instrument panel. The reflection of sunlight may adversely affect

the camera unit's detection capability.

 Do not strike or damage the areas around the camera unit. Do not touch the camera lens or remove the screw located on the camera unit. If the camera unit is damaged due to an accident, contact a NISSAN dealer or qualified workshop.

REAR CROSS TRAFFIC ALERT (RCTA) SYSTEM (where fitted)


A WARNING

Failure to follow the warnings and instructions for proper use of the RCTA system could result in serious injury or death.

The RCTA system is not a replacement for proper driving procedures and is not designed to prevent contact with vehicles or objects. When reversing out of a parking space, always use the side and rear mirrors and turn and look in the direction your vehicle will move. Never rely solely on the RCTA system.

The RCTA system will assist you when reversing out of a parking space. When the vehicle is in reverse, the system is designed to detect other vehicles approaching from the right or left of the vehicle. If the system detects cross traffic, it will alert you.

RCTA SYSTEM OPERATION





- BSW LED indicator light
- Vehicle Information Display
- Steering-wheel-mounted controls (left side)

The RCTA system can help alert the driver of an approaching vehicle when the driver is reversing out of a parking space.

When the shift position is in R (Reverse) and the vehicle speed is less than approximately 8 km/h (5 MPH), the RCTA system is operational.

If the radar detects an approaching vehicle from either side, the system chimes (once) and the BSW LED indicator light flashes on the side the vehicle is approaching from.






The RCTA system uses radar sensors (A) installed on both sides near the rear bumper to detect an approaching vehicle.

The radar sensors (A) can detect an approaching vehicle from up to approximately 20 m (66 ft) away.

HOW TO ENABLE/DISABLE THE RCTA SYSTEM



BSW LED indicator light

the RCTA system.


- Vehicle information display
- Steering-wheel-mounted controls (left side) Perform the following steps to enable or disable
- Press the ◀ or ▶ button until [Settings] displays in the Vehicle Information Display and then press the <OK> button. Use the A and ▼ buttons to select [Driver Assistance]. Then press the **<OK>** button.

2. To set the RCTA system to on or off, use the ▲ and ▼ buttons to navigate the menu and use the <OK> button to select or change an item.

NOTE:

When enabling/disabling the system, the system setting will be retained even if the engine is restarted.

RCTA SYSTEM LIMITATIONS



A WARNING

Listed below are the system limitations for the RCTA system. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.

Always check surroundings and turn to

check what is behind you before reversing. The radar sensors detect approaching (moving) vehicles. The radar sensors cannot detect every object such as:

 Pedestrians, bicycles, motorcycles, animals or child-operated toy vehicles.

- A vehicle that is passing at speeds greater than approximately 30 km/h (19 MPH).
- A vehicle that is passing at speeds lower than approximately 8 km/h (5 MPH).
- The radar sensors may not detect approaching vehicles in certain situations:
 - Illustration

 When a vehicle parked next to you obstructs the beam of the radar sensor.
 - Illustration (b): When the vehicle is parked in an angled parking space.
 - Illustration ©: When the vehicle is parked on inclined ground.
 - Illustration (a): When an approaching vehicle turns into your vehicle's parking lot aisle.
 - Illustration (a): When the angle formed by your vehicle and the approaching vehicle is small
- The following conditions may reduce the ability of the radar to detect other vehicles:
 - Severe weather
 - Road spray
 - Ice/frost/dirt build-up on the vehicle
- Do not attach stickers (including transparent material), install accessories or apply additional paint near the radar sensors.
 These conditions may reduce the ability of the radar to detect other vehicles.

 Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.




Illustration 1





Illustration 2

NOTE:

In the case of several vehicles approaching in a row (Illustration 1) or in the opposite direction (Illustration 2), a chime may not be sounded by

the RCTA system after the first vehicle passes the sensors.

SYSTEM TEMPORARILY UNAVAILABLE



When radar blockage is detected, the system will be deactivated automatically. The [Not available Side Radar Obstructed] warning message will appear in the Vehicle Information Display.

The systems are not available until the conditions no longer exist.

The radar sensors may be blocked by temporary ambient conditions such as splashing water, mist or fog.

The blocked condition may also be caused by objects such as ice, frost or dirt obstructing the radar sensors.

NOTE:

If the BSW system stops working, the RCTA system will also stop working.

Action to take:

When the above conditions no longer exist, the system will resume automatically.

SYSTEM MALFUNCTION

When the RCTA system malfunctions, it will turn off automatically. The [System fault] warning message will appear in the Vehicle Information Display.


NOTE:

If the BSW system stops working, the RCTA system will also stop working.

Action to take:

Stop the vehicle in a safe location, turn the engine off and restart the engine. If the message continues to appear, have the system checked by a NISSAN dealer or qualified workshop.

SYSTEM MAINTENANCE



The two radar sensors (A) for the RCTA systems are located near the rear bumper. Always keep the area near the radar sensors clean.

LANE ASSIST SYSTEM

The radar sensors may be blocked by temporary ambient conditions such as splashing water, mist or fog.

The blocked condition may also be caused by objects such as ice, frost or dirt obstructing the radar sensors.


Check for and remove objects obstructing the area around the radar sensors.

Do not attach stickers (including transparent material), install accessories or apply additional paint near the radar sensors.

Do not attach metallic objects near the sensor area (brush guard, etc.). This could cause failure or malfunction.

Do not strike or damage the area around the radar sensors. It is recommended that you visit a NISSAN dealer or qualified workshop if the area around the radar sensors is damaged due to a collision.

For the radio approval numbers and information, see "Radio frequency approval" (P.355).




A WARNING

Failure to follow the warnings and instructions for proper use of the Lane Assist system could result in serious injury or death.

- The Lane Assist system will not steer the vehicle or prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the travelling lane, and be in control of the vehicle at all times.
- The Lane Assist system is intended to work on all roads with well defined markings or road edges, but it may not detect the road edge or lane markers in certain road, weather or driving conditions.
- There is a limitation to the detection capability of the sensors. Always rely on your own operation to avoid accidents.

The Lane Assist system will be automatically turned on each time the engine is restarted.

The Lane Assist uses a multi-sensing front camera (a) located above the inside mirror to monitors the lane markers on the travelling lane and to detect other vehicles.



- Lane Assist indicator (on the vehicle information display)
- Vehicle information display
- Steering-wheel-mounted controls (left side)
- Shortcut button

LANE ASSIST SYSTEM OPERATION

The Lane Assist system will operate when the vehicle is driven at speeds of approximately 60 km/h (37 MPH) and above. Only when the lane markings or road edge are clearly visible on the road

The Lane Assist system warns the driver when the vehicle approaches the road edge or lane markers


with an indicator on the vehicle information display and steering wheel vibration. The system helps assist the driver to return the vehicle to the travelling lane by applying the brakes to the left or right wheels individually (for a short period of time) in the following circumstances:

- If the [Emergency Lane] is ON in the settings menu of the vehicle information display:
 - the system warns the driver when the vehicle is approaching a lane marker and road edge.
 - the system assists the driver to return the vehicle to the travelling lane when the vehicle is approaching a solid line.
- If the [Advanced Lane] is ON, the system assists the driver to return the vehicle to the travelling lane when the vehicle is approaching a dashed line and road edge.

During brake control of the Lane Assist system, if the system determines that the steering wheel is not being operated, the duration of the warning buzzer increases as the number of assists increases from the second assist.

Even if the system determines that the steering wheel has been operated, the warning buzzer will continue to sound for a certain period of time.

HOW TO ENABLE/DISABLE THE LANE ASSIST SYSTEM



- Lane Assist system OFF indicator (on the vehicle information display)
- Vehicle information display
- Steering-wheel-mounted controls (left side)
- Shortcut button

Perform either of the following steps to enable or disable the Lane Assist system.

Shortcut Menu

The Lane Assist system can be turned ON/OFF using [Driver Assist Custom] and [Custom Mode Setupl.

Refer to "[Shortcut Menul" (P.87) for more details.

Settings

- 1. Push the button until [Settings] appears in the vehicle information display and then push the <OK> button. Use the up and down buttons to select [Driver Assistance]. Then push the <OK> button.
- 2. Select [Lane Assist] and push the <OK> button.
- 3. Select [Emergency Lane] and push the <OK> button to turn the system on or off.

When the [Emergency Lane] is turned off, the Lane Assist system OFF indicator appears.

For details, see "Vehicle information display" (P.82).

[Advanced Lane] setting

You can set the [Advanced Lane] setting using the [Settings] menu in the vehicle information display.

[Advanced Lane] only functions when the [Emergency Lane] setting is ON.

When [Driver Assist Custom] setting is ON, [Lane Assist] cannot be adjusted through the [Settings] menu. To adjust [Lane Assist] setting when [Driver Assist Custom] is ON, go to the [Custom Mode Setup] menu in the [Shortcut Menu].

For details, see "Settings" (P.86).

Push the

button until [Settings] appears in the vehicle information display and then push the <OK> button.

In the [Settings] menu, select the [Driver Assistance] key using the ▲, ▼ then push the <OK> button

- 2. Select the [Lane Assist] submenu by pressing the <OK> button.
- 3. Select [Advanced Lane]
 - ON
 - OFF

NOTE:

- The ON/OFF setting of [Advanced Lane] will be kept even if the engine is restarted.
- The [Emergency Lane] setting will be automatically turned on each time the engine is restarted.
- Even if the Lane Assist system is disabled in the [Settings] menu, the Lane Assist system will automatically be turned on when the Steering Assist system (where fitted) is active.

After that, when the Steering Assist system stops operating, the Lane Assist system state returns to the state before the Steering Assist system operation.

Applied road conditions:

- [Emergency Lane]: Lane assist on the road with solid line
- [Advanced Lane]: Lane assist on the road with dashed line

NOTE:

 Warning function will be automatically turned on each time the engine is restarted.

LANE ASSIST SYSTEM LIMITATIONS

A WARNING

Listed below are the system limitations for the Lane Assist system. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.

- The Lane Assist system may activate if you cross a lane marker and road edge without first activating your turn signal or, for example, if a construction zone directs traffic to cross an existing lane marker. If this occurs you may need to apply corrective steering to complete your lane change.
- Because the Lane Assist system may not activate under the road, weather and lane marker conditions described in this section, it may not activate every time your vehicle begins to leave the travelling lane and you will need to apply corrective steering.
- The Lane Assist system will not operate at speeds below operation speed or if it cannot detect lane markers.
- DO NOT use the Lane Assist system under the following conditions, there could be serious affect on vehicle safety with risk of an accident and injury or death.
 - When driving without normal tyre conditions (for example, tyre wear, low tyre pressure, installation of other tire than Nissan certified standard tyre, tyre chains, non-standard

- wheels). See "Wheels and tyres" (P.334).
- When the vehicle is equipped with non-original brake parts or suspension parts.
- When towing a trailer or another vehicle.
- The Lane Assist system may not function properly in the following conditions
 - During bad weather (rain, fog, snow, etc.).
 - When driving on slippery roads, such as on ice or snow.
 - When driving on winding or uneven roads.
 - When there is a lane closure due to road repairs.
 - When driving in a makeshift or temporary lane.
 - When driving on roads where the lane width is too narrow.
 - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly: vellow painted lane markers; nonstandard lane markers; or lane markers covered with water, dirt, snow, etc.
 - On roads where the edge of the road is not clearly visible.
 - On roads where discontinued lane markers are still detectable.

- On roads where there are sharp curves.
- On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs. (The Lane Assist system could detect these items as lane markers.)
- On roads where the travelling lane merges or separates.
- When the vehicle's travelling direction does not align with the lane marker.
- When travelling close to the vehicle in front of you, which obstructs the lane camera unit detection range.
- When rain, snow, dirt or object adheres to the windscreen in front of the lane camera unit.
- When the headlights are not bright due to dirt on the lens or if the aiming is not adjusted properly.
- When strong light enters the lane camera unit. (For example, the light directly shines on the front of the vehicle at sunrise or sunset.)
- When a sudden change in brightness occurs. (For example, when the vehicle enters or exits a tunnel or under a bridge.)
- Excessive noise will interfere with the warning chime sound, and the chime may not be heard.

NOTE:

While the Lane Assist system is operating, you may hear a sound of brake operation. This is normal and indicates that the Lane Assist system is operating properly.

SYSTEM TEMPORARILY UNAVAILABLE Condition A:

The warning and assist functions of the Lane Assist system are not designed to work under the following conditions:

- When you operate the lane change signal and change the travelling lanes in the direction of the signal. (The Lane Assist system will be deactivated for approximately 2 seconds after the lane change signal is turned off).
- When the vehicle speed lowers to less than the operation speed.

After the above conditions have finished and the necessary operating conditions are satisfied, the warning and assist functions will resume.

Condition B:

The assist function of the Lane Assist system is not designed to work under the following conditions (warning is still functional):

- When the brake pedal is depressed or if the vehicle decelerates strongly.
- When the steering wheel is turned as far as necessary for the vehicle to change lanes.
- When the vehicle is accelerated during the Lane Assist system operation.

- When the Intelligent Cruise Control (ICC) approach warning occurs (where fitted).
- When the hazard warning flashers are operated.
- When driving on a curve at high speed.
- When the vehicle is making a sharp turn.
- When the Intelligent Emergency Brake operates.
- When the Blind Spot Intervention (BSI) operates.
- When the ESP system (except Traction Control System (TCS) function) or ABS operates.

After the above conditions have finished and the necessary operating conditions are satisfied, the Lane Assist system application of the brakes will resume.

Condition C:

If the ESP system is turned OFF, the Lane Assist system will be turned off automatically, the "Currently Unavailable ESP OFF" warning message will appear and the Lane Assist indicator (yellow) will illuminate in the vehicle information display.

When the ESP system turns ON again and the necessary operating conditions are satisfied, the Lane Assist system application of the brakes will resume.

Condition D:


If one of the following messages appears in the vehicle information display and the Lane Assist indicator illuminates in the vehicle information display, the Lane Assist system will be turned off automatically:

- [Temporarily Disabled Camera Blocked See Owner's Manuall: When the front camera is blocked. Always keep the area near the front camera clean.
- [Currently Unavailable Front Camera High Temperature]: If the vehicle is parked in direct sunlight under high temperature conditions (over approximately 40°C (104°F)) and then the Lane Assist system is turned on, the Lane Assist system may be deactivated automatically and the Lane Assist indicator illuminates.
- [Currently Not Available]: When the direction of the front camera is significantly misaligned. Have the system checked. It is recommended vou visit a Nissan dealer for this service.

SYSTEM MALFUNCTION

When the Lane Assist system malfunctions, it will cancel automatically. The Lane Assist system warning light (yellow) will appear in the Vehicle Information Display and a chime will sound. If the warning message appears pull off the road in a safe location, and stop the vehicle. Turn the engine off and restart the engine. If the message continues to appear, have the Lane Assist system checked. It is recommended that you visit a Nissan dealer for this service

SYSTEM MAINTENANCE



The camera (A) is located on the upper side of the windshield. To keep the Lane Assist system operating properly, be sure to observe the following:

- Always keep the sensor area clean.
- Do not strike or damage the areas around the sensors.
- Do not touch the camera lens or remove the screw located on the camera unit. If the camera unit is damaged due to an accident, contact a NISSAN dealer or qualified workshop.
- Do not cover or attach stickers or similar objects on the front of the vehicle near the camera area. This could cause failure or malfunction.
- Do not attach metallic objects near the radar sensor area (brush quard, etc.). This could cause failure or malfunction.
- Do not place reflective materials, such as white paper or a mirror, on the instrument panel.

- The reflection of sunlight may adversely affect the camera unit's detection capability of detecting lane markers.
- Do not alter, remove or paint the front of the vehicle near the sensor area. Before customising or restoring the sensor area, it is recommended that you visit a NISSAN dealer or qualified workshop.

CRUISE CONTROL (where fitted)

NOTE:

If your vehicle is fitted with ProPILOT Assist, refer to the dedicated section later in this manual for information on Cruise Control.

 ProPILOT Assist: See "ProPILOT Assist (where fitted)" (P.225).

The cruise control system allows driving at constant speeds without keeping your foot on the accelerator pedal.

A WARNING

- The cruise control system ONLY maintains a constant vehicle speed, it does not replace the driver.
- Always observe the posted speed limits and do not set the speed above them.
- Do not use the cruise control system when driving under the following conditions.
 Doing so could cause a loss of vehicle control and result in an accident.
 - When it is not possible to keep the vehicle at a constant speed
 - When driving in heavy traffic
 - When driving in traffic that varies speed
 - When driving in windy areas
 - When driving on winding or hilly roads
 - When driving on slippery (rain, snow, ice, etc.) roads

When the cruise control system is on the speed limiter cannot be operated.


The cruise control system operation switches are located on the steering wheel (right side).

The cruise control system operating condition is shown in the vehicle information display.


PRECAUTIONS ON CRUISE CONTROL

- The cruise control system will be automatically cancelled when there is a malfunction. Have the system checked by a NISSAN dealer or qualified workshop.
- To properly set the cruise control system, perform the steps as described in "Setting a cruising speed" (P.222).


CRUISE CONTROL SYSTEM OPERATIONS



- (1) <CANCEL> switch
- (A) <RES/+> (Resume) switch
- (B) <SET/-> switch
- ② Speed limiter main "ON/OFF" switch (For details, see "Speed limiter (where fitted)" (P.223))
- 3 Cruise control main "ON/OFF" switch



Before setting speed



After setting speed

- 4 Cruise control symbol
- 5 Set speed value

Turning the cruise control system on

Push the cruise control main switch (3). The cruise control symbol (4) appears together with a blank set speed value [- - -] ⑤ at the top of the vehicle information display.

Setting a cruising speed

- Accelerate to the desired cruising speed.
- Push the **<SET>** switch (B) and release it.
- 3. The cruise control symbol (4) changes to green with the set speed value (desired cruising speed) (5) in the top of the vehicle information display.
- 4. Take your foot off the accelerator pedal.

The vehicle will maintain the set speed.

If the vehicle speed is less than the minimum set speed, it will not be possible to set the cruise control system.

Changing a cruising speed

Use any one of the following methods to change the cruising speed.

- Slow the vehicle as normal using the footbrake pedal.
 - When the vehicle reaches the desired cruising speed, push and release the **<SET>** switch **(B)**. The new set speed value will be displayed in the top of the vehicle information display.
- Press the accelerator pedal. When the vehicle reaches the desired cruising speed, push and release the **SET** switch (B).

- The new set speed value will be displayed in the top of the vehicle information display.
- Push and release the <RES> (resume) (A) switch to increase or the <SET> switch (B) to decrease the set speed in steps of 1 km/h (1 MPH).

The new set speed value will be displayed in the top of the vehicle information display.

Push and hold the <RES> (resume) (A) switch or the <SET> switch (B). The vehicle speed will increase or decrease to the new set speed. The new set speed value will be displayed in the top of the vehicle information display.

Passing another vehicle

Depress the accelerator pedal to accelerate. After releasing the accelerator pedal, the vehicle will return to the previously set speed.

The set speed value (5) will flash until the vehicle returns to the previously set speed.

Cancelling the cruise control system

To cancel a set speed limit, push the <CANCEL> switch (1).

The cruise control symbol (4) and the set speed value (5) at the top of the vehicle information display turn grey.

The cruise control system will also be cancelled automatically by any of the following:

- Pressing the footbrake pedal.
- Shifting the shift lever to the N (Neutral) position.

 If the vehicle slows down more than approximately 12 km/h (8 MPH) below the set speed.

Resuming a previous cruising speed

If the cruising speed has been cancelled, the last set speed value will be stored in the cruise control system memory and displayed in grey at the top of the vehicle information display. This cruising speed can be reactivated by pressing the <RES> (Resume) switch (A).

If the vehicle speed is less than a minimum set speed, it will not be possible to resume to the cruising speed.

Turn the cruise control system off

The cruise control system will be turned off when one of the following operations is performed:

- Push the cruise control main "ON/OFF" switch. 3. The cruise control symbol 4 and the set speed value (5) will turn off in the combination meter display.
- Push the speed limiter main "ON/OFF" switch (2).
 - The cruise control system information in the combination meter will be replaced with the speed limiter information. For details, see "Speed limiter (where fitted)" (P.223).
- When the vehicle is stopped and the ignition is turned to the off position.

Turning off the cruise control system will erase the cruise control system memory.

SPEED LIMITER (where fitted)

NOTE:

If your vehicle is fitted with ProPILOT Assist or Intelligent Cruise Control (ICC) and Steering Assist, refer to the dedicated ProPILOT Assist Speed Limiter or Intelligent Cruise Control (ICC) and Steering Assist Speed Limiter section later in this manual.

The speed limiter allows you to set the desired vehicle speed limit. While the speed limiter is activated, you can perform normal braking and acceleration, but the vehicle will not exceed the set speed.

When the vehicle reaches the set speed limit or if the set speed limit is lower than the actual vehicle speed, the accelerator pedal will not work (unless fully depressed) until the vehicle speed drops below the set speed limit.

When the actual vehicle speed exceeds the set speed, an audible warning will be heard a short time after the set speed is exceeded and driver intervention is not detected

When the speed limiter is on the cruise control system cannot be operated.

A WARNING


- The speed limiter will not automatically brake the vehicle to the set speed limit.
- Always observe posted speed limits. Do not set the speed above them.
- Always confirm the setting status of the speed limiter in the Vehicle Information Display.
- When the speed limiter is set, avoid hard

- acceleration to reach the set limit to ensure that the system can limit the speed of the vehicle correctly.
- When additional floor mats are used, be sure that they are correctly secured and that they cannot interfere with the accelerator pedal. Mats not adapted to the vehicle may prevent proper operation of the speed limiter.

The speed limiter operation switches are located on the steering wheel (right hand side).


The speed limiter operating condition is shown on the top of Vehicle Information Display. For details, see "Vehicle information display" (P.82).

SPEED LIMITER OPERATIONS




- <CANCEL> switch
- <RES/+> (Resume) switch
- <SET/-> switch

- Speed limiter main "ON/OFF" switch
- Cruise control main "ON/OFF" switch (For details, see "Cruise control (where fitted)" (P.221).)



Before setting speed



After setting speed

- Speed limiter symbol
- Set speed value

Turning the speed limiter on

The speed limiter can be switched on after engine start or when driving.

Push the speed limiter main ON/OFF switch (2).

The speed limiter symbol (4) and the set speed value (5) will illuminate in the Vehicle Information Display.

Setting speed limit

Push the <SET> switch (B).

The speed limit will be set at the current speed.

When driving less than 30 km/h (20 MPH), the speed limiter will be set to the minimum possible set speed of 30 km/h (20 MPH).

When the speed limit is set, the speed limiter symbol (4) and the set speed value (5) will turn green.

Changing a speed limit

Use either of the following operations to change an active speed limit:

- Push and release the <RES> (Resume) switch (A) or <SET> switch (B). Each time you do this, the set speed will increase or decrease by 1 km/h (1 MPH).
- Push and hold the <RES> (Resume) switch (A) or <SET> switch (B). The set speed will increase or decrease to the next multiple of 5 km/h (5 MPH) and then in steps of 5 km/h (5 MPH).

The new set speed limit value (5) will be displayed in the Vehicle Information Display.

When the actual vehicle speed exceeds the set

speed, an audible warning will be heard a short time after the set speed is exceeded and driver intervention is not detected.

Cancelling a speed limit

To cancel a set speed limit, push the <CANCEL> switch (1). The speed limiter symbol (4) and the set speed value (5) in the Vehicle Information Display will turn grey.

It is also possible to override the speed limiter by fully depressing the accelerator pedal beyond the resistance point.

A WARNING

- The vehicle may accelerate when the speed limiter cancels.
- When additional floor mats are used, be sure that they are correctly secured and that they cannot interfere with the accelerator pedal. Mats not adapted to the vehicle may prevent proper operation of the speed limiter.

Fully depress the accelerator pedal beyond the resistance point. The speed limiter will be suspended to allow driving above the set speed. The set speed value (5) will flash and an audible warning will sound. The speed limiter will automatically resume when the vehicle speed drops below the set speed limit.

Resuming a previous set speed

If a set speed limit has been cancelled, the set speed will be stored in the speed limiter memory and displayed in grey at the top of the vehicle information display.

This speed limit can be reactivated by pressing the <RES> (Resume) switch (A).

If the current vehicle speed is higher than the previous set speed, the accelerator pedal will not work and the set speed value (5) will flash until the vehicle speed drops below the set speed limit.

When the actual vehicle speed exceeds the set speed, an audible warning will be heard a short time after the set speed is exceeded and driver intervention is not detected

Turning the speed limiter off

The speed limiter system will be turned off when one of the following operations is performed:

- Push the speed limiter main ON/OFF switch (2). The speed limiter symbol (4) and the set speed value (5) in the Vehicle Information Display will be turned off.
- Push the cruise control main ON/OFF switch 3. The speed limiter information in the Vehicle Information Display will be replaced with the cruise control information. For details see "Cruise control (where fitted)" (P.221), or "Pro-PILOT Assist (where fitted)" (P.225).
- When the vehicle is stopped and the ignition is placed in the OFF position.

Turning off the speed limiter will erase the set speed limit memory.

PROPILOT ASSIST (where fitted)

Speed limiter malfunction

If the speed limiter malfunctions, the speed limiter symbol (4) in the Vehicle Information Display will flash.

Turn the speed limiter off by pushing the speed limiter main "ON/OFF" switch (2) and have the system checked by a NISSAN dealer or qualified workshop.


A WARNING

Failure to follow the warnings and instructions for proper use of the ProPILOT Assist system could result in serious injury or death.

- ProPILOT Assist is not a self-driving system. Within the limits of its capabilities, as described in this manual, it helps the driver with certain driving activities.
- The ProPILOT Assist system is not a replacement for proper driving procedure and is not designed to correct careless, inattentive or absent-minded-driving. ProPILOT Assist will not always steer the vehicle to keep it in the lane. The ProPILOT Assist system is not designed to prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the travelling lane, and be in control of the vehicle at all times.
- There are limitations to the ProPILOT Assist system capability. The ProPILOT Assist system does not function in all driving, traffic, weather, and road conditions. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the travelling lane, and be in control of the vehicle at all times.
- The ProPILOT Assist system is only an aid to assist the driver and is not a collision warning or avoidance device.
- The ProPILOT Assist system is for use on motorways with opposing traffic sepa-

rated by a barrier only, and is not intended for city driving.

- Always observe the posted speed limits and do not set the speed over them.
- Never take your hands off the steering wheel when driving. Always keep your hands on the steering wheel and drive vour vehicle safely.
- The ProPILOT Assist system does not react to stationary or slow moving vehicles.
- Always drive carefully and attentively when using the ProPILOT Assist system. Read and understand the Owner's Manual thoroughly before using the ProPILOT Assist system. To avoid serious injury or death, do not rely on the system to prevent accidents or to control the vehicle's speed in emergency situations. Do not use the ProPILOT Assist system except in appropriate road and traffic conditions.



- Radar sensor
- Multi-sensing front camera

The ProPILOT Assist system is intended to enhance the operation of the vehicle when following a vehicle travelling in the same lane and direction.

The ProPILOT Assist system uses a multi-sensing front camera (B) installed behind the windscreen and a radar sensor located on the front of the vehicle (A) to measure the distance to the vehicle ahead in the same lane and to monitor the lane markers. If the vehicle detects a slower moving vehicle ahead, the system will reduce the vehicle speed so that your vehicle follows the vehicle in front at the selected distance. The system will also help keep the vehicle centred in the travelling lane when clear lane markings are detected.

PROPILOT ASSIST SYSTEM OPERATION

The ProPILOT Assist system has the following functions:

- Intelligent Cruise Control (ICC)
- Steering Assist

Intelligent Cruise Control (ICC) (vehicles with ProPILOT Assist) The ICC system can be set to one of two cruise control modes:

 Conventional (fixed speed) cruise control mode:

Used for cruising at a preset speed.

NOTE:

Steering assist is not available in the conventional (fixed speed) cruise control mode.

Vehicle-to-vehicle distance control mode:

The ICC system maintains a selected distance from the vehicle in front of you within the speed range of 0 km/h (0 MPH) up to the set speed. The set speed can be selected by the driver above approximately 30 km/h (20 MPH). When the vehicle ahead slows to a stop, your vehicle gradually decelerates to a standstill. When the vehicle is stopped, the ICC system maintains braking force to keep your vehicle stationary.

NOTE:

When your vehicle is stopped for less than approximately 3 seconds and the vehicle ahead begins to move, your vehicle will start moving again automatically. If your vehicle is stationary for more than approximately 3 minutes, the ICC system will be switched off and the electric parking brake will be applied.

- When the vehicle ahead begins to move forward, push the <RES+> button on the steering wheel or lightly depress the accelerator pedal to release the brake. The ICC system will restart to maintain a selected distance from the vehicle in front of you.
- When stationary and no vehicle is detected ahead the ICC will not function. The accelerator should be used to control the vehicle speed.

NOTE:


Even if the Intelligent Emergency Braking (IEB) setting is turned off by the driver using the [Settings] menu in the Vehicle Information Display, IEB will be turned on automatically when the ProPILOT Assist is used.

Steering Assist (vehicles with ProPILOT Assist)


The Steering Assist function controls the steering system to help keep your vehicle within the travelling lane.

Steering Assist is not available at speeds under 60 km/h (37 MPH) unless a vehicle is detected ahead.

PROPILOT ASSIST SWITCHES



- Steering wheel mounted controls (left)
- Vehicle Information Display
- Steering Assist switch
- Steering wheel mounted controls (right)
- ProPILOT Assist switch



- Distance switch
 - Long
 - Middle
 - Short
- <RES+> switch

Resumes set speed or increases speed incrementally

<CANCEL> switch

Deactivates the ProPILOT Assist system without the set speed


<SET-> switch

Sets desired cruise speed or reduces speed incrementally

ProPILOT Assist switch

Turns the ProPILOT Assist system on or off

PROPILOT ASSIST SYSTEM DISPLAY AND INDICATORS



1) Lane marker indicator

Indicates whether the system detects lane markers

- No lane markers displayed: Steering Assist is turned off
- Lane marker indicator (grey): No lane

markers detected

- Lane marker indicator (green): Lane markers detected
- Lane marker indicator (yellow): Lane departure is detected

2) Set distance indicator

Displays the selected distance.

Vehicle ahead detection indicator

When the ICC is ON and active this indicates whether the system detects a vehicle in front of you.

4) Steering Assist status indicator

Displays the status of the Steering Assist by the colour of the indicator

- Grey: Steering Assist standby.
- Green: Steering Assist active.

ProPILOT Assist activation

Displays once the ProPILOT Assist system is activated

6) ProPILOT Assist status indicator

Displays the status of ProPILOT Assist Intelligent Blind Spot Intervention, Steering Assist and ICC systems.

- White: systems are on (only if they are turned on in the [Settings] menu), ICC is in standby mode.
- Blue: ICC is active

7) Steering Assist status indicator/warning

Displays the status of the Steering Assist by the colour of the indicator/warning

- No Steering Assist status indicator displayed: Steering Assist is turned off.
- Grey: Steering Assist standby.
- Green: Steering Assist active.

228 Starting and driving

- Yellow: Steering Assist malfunction.
- Red: Hands off detected

Lane marker indicator/speed control status indicator/set distance indicator

Displays the status of speed control by the colour and shape of the indicator/warning Speed control status indicator (white): ICC standby

Speed control status indicator (green): ICC (distance control mode) is active

- Green vehicle icon displayed: Vehicle detected ahead
- No vehicle icon shown: No vehicle detected ahead (Your vehicle maintains the driverselected set speed.)

Speed control status indicator (yellow): Indicates an ICC malfunction

Lane marker indicator: Indicates whether the system detects lane markers

- No lane markers displayed: Steering Assist is turned off
- Lane marker indicator (grev): No lane markers detected
- Lane marker indicator (green): Lane markers detected

Set vehicle speed indicator

Indicates the set vehicle speed.

- Grey numbers: ICC standby.
- Green numbers: ICC active


TURNING THE PROPILOT ASSIST CONVENTIONAL (fixed speed) CRUISE CONTROL MODE ON

NOTE:

ProPILOT Assist provides no approach warnings, automatic braking, or steering assist in the conventional (fixed speed) cruise control mode.

To select the conventional (fixed speed) cruise control mode, push and hold the ProPILOT Assist switch for longer than approximately 1.5 seconds. For additional information, refer to "ProPILOT Assist Conventional (fixed speed) Cruise Control Mode" (P.246).

OPERATING THE PROPILOT ASSIST SYSTEM



- Push the ProPILOT Assist switch (5). This turns on the ProPILOT Assist system and displays the status of the ProPILOT Assist system on the Vehicle Information Display.
- 2. Accelerate or decelerate your vehicle to the desired speed.

- 3. Push the <SET-> switch. The ProPILOT Assist system begins to automatically maintain the set speed. The ProPILOT Assist activation indicator and ProPILOT Assist status indicators illuminate (blue), ICC status indicator and set speed illuminate green.
- When a vehicle ahead is travelling at a speed of 30 km/h (20 MPH) or below and the <SET> switch is pushed, the set speed of your vehicle is 30 km/h (20 MPH).

NOTE:

Turning the ProPILOT Assist system on will turn on the Intelligent Blind Spot Intervention system at the same time, providing that system is enabled in the [Driver Assistance] menu in the vehicle information display. For additional information, refer to "Blind Spot Warning (BSW) system/Intelligent Blind Spot Intervention system (where fitted)" (P.200).

When the <SET-> switch is pushed under the following conditions, the ProPILOT Assist system cannot be set and the set vehicle speed indicators blinks for approximately 2 seconds:

- When travelling below 30 km/h (20 MPH) and the vehicle ahead is not detected
- When the shift lever is not in the D (Drive) position or Manual mode
- When the parking brake is applied
- When the brakes are operated by the driver
- When the ESP system is off. For additional information, refer to "Electronic Stability Programme (ESP) system (where fitted)" (P.274).

- When the ESP system (including the traction control system) is operating
- When a wheel is slipping
- When any door is open
- When the driver's seat belt is not fastened

How to change the set vehicle speed

The set vehicle speed can be adjusted.

To change to a faster cruising speed:

- Push and hold the <RES+> switch. The set vehicle speed increases by 10 km/h (5 MPH) increments
- Push, then quickly release, the <RES+> switch. Each time you do this, the set speed increases by 1 km/h (1 MPH).

To change to a slower cruising speed:

- Push and hold the <SFT-> switch. The set vehicle speed decreases by 10 km/h (5 MPH) increments.
- Push, then quickly release, the <SET-> switch. Each time you do this, the set speed decreases by 1 km/h (1 MPH).

How to momentarily accelerate or decelerate

- Depress the accelerator pedal when acceleration is required. Release the accelerator pedal to resume the previously set vehicle speed.
- Depress the brake pedal when deceleration is required. Control by the ProPILOT Assist system is cancelled. Push the <RES+> switch to resume the previously set vehicle speed.

A WARNING

When the accelerator pedal is depressed and you are approaching the vehicle ahead, the ICC system will neither control the brake nor warn the driver with the chime and display. The driver must manually control the vehicle speed to maintain a safe distance to the vehicle ahead. Failure to do so could result in severe personal injury or death.

NOTE:

When you accelerate by depressing the accelerator pedal or decelerate by pushing the <SET-> switch and the vehicle travels faster than the speed set by the driver, the set speed vehicle indicator will blink.

How to change the set distance to the vehicle ahead


The distance to the vehicle ahead can be selected when the ICC is in standby mode or the ICC is active.

Each time the DISTANCE switch 💄 is pushed, the set distance will change from long to middle, short and back to long again in that sequence.

Distance	Display	Approximate distance at 100 km/h (60 MPH) (m (ft))
Long	=	60 (200)
Middle	=	45 (150)
Short	_	30 (100)

The distance to the vehicle ahead changes automatically according to the vehicle speed. As the vehicle speed increases so does the distance.

The distance setting will remain at the current setting even if the hybrid system is restarted.



Each time the ICC system is turned on using the blue ProPILOT Assist switch (5), the distance setting reverts to Lona.

Steering Assist Activation/Deactivation

Use the following methods to enable or disable the Steering Assist.

Steering Assist switch:

To turn the Steering Assist ON or OFF, push the Steering Assist switch on the instrument panel.

NOTE:

 When the Steering Assist switch is used to turn the system ON or OFF, the system remembers the setting between power cycles. The switch must be pushed again to change the setting to ON or OFF.

 The Steering Assist switch changes the status of the [Steering Assist] selection made in the [Settings] screen in the Vehicle Information Display.

Setting in the Vehicle Information Display:

- Use the ▲ and ▼ buttons on the steering wheel to highlight [Driver Assistance] and press the <OK> button.
- With [Steering Assist] highlighted press the
 button to toggle the Steering Assist system status.

If the indicator is displayed, the system is ON.

NOTE:

- When the ProPILOT Assist screen is displayed on the Vehicle Information Display, press the <OK> button on the steering wheel to show the [Driver Assistance] setting menu.
- When enabling/disabling the system through the Vehicle Information Display or when pressing the Steering Assist switch, the system retains the current settings even if the system is restarted.

Cancelling the ProPILOT Assist system

To cancel the ProPILOT Assist system, use one of the following methods:

- Press the <CANCEL> switch on the steering wheel.
- Tap or depress the brake pedal (except when the vehicle is stationary).
- To turn the ProPILOT Assist system off completely, press the ProPILOT Assist switch on the steering wheel, the ProPILOT Assist indicator will turn OFF.

When the ProPILOT Assist system is switched off while the vehicle is stopped, the electronic parking brake is automatically activated.

A WARNING

When you leave the vehicle, make sure to push the ProPILOT Assist switch to turn the system off, place the shift lever in the P (Park) position, and turn the hybrid system OFF.

PROPILOT ASSIST INTELLIGENT CRUISE CONTROL (ICC) SYSTEM

A WARNING

Failure to follow the warnings and instructions for proper use of the ICC system could result in serious injury or death.

- The ICC system is only an aid to assist the driver and is not a collision warning or avoidance device. It is for highway use only and it is not intended for congested areas or city driving. It is the driver's responsibility to stay alert, drive safely, and be in control of the vehicle at all times.
- There are limitations to the ICC system capability. The ICC system does not function in all driving, traffic, weather, and road

conditions. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the travelling lane, and be in control of the vehicle at all times.

- Always observe posted speed limits and do not set the speed over them.
- The ICC system does not react to stationary or slow moving vehicles.
- Always drive carefully and attentively when using the ICC system. Read and understand the Owner's Manual thoroughly before using the ICC system. To avoid serious injury or death, do not rely on the system to prevent accidents or to control the vehicle's speed in emergency situations. Do not use the ICC system except in appropriate road and traffic conditions.
- In the conventional (fixed speed) cruise control mode, a warning chime will not sound to warn you if you are too close to the vehicle ahead. Pay special attention to the distance between your vehicle and the vehicle ahead of you or a collision could occur.

ProPILOT Assist ICC system operation

The vehicle-to-vehicle distance control mode is designed to maintain a selected distance and reduce the speed to match the slower vehicle ahead; the system will decelerate the vehicle as necessary and if the vehicle ahead comes to a stop, the vehicle decelerates to a standstill. How-


ever, the ICC system can only apply up to approximately 40% of the vehicle's total braking power. This system should only be used when traffic conditions allow vehicle speeds to remain fairly constant or when vehicle speeds change gradually. If a vehicle moves into the travelling lane ahead or if a vehicle travelling ahead rapidly decelerates, the distance between vehicles may become closer because the ICC system cannot decelerate the vehicle quickly enough. If this occurs, the ICC system will sound a warning chime and blink the system display to notify the driver to take necessary action.

The ICC system cancels and a warning chime sounds if the speed is below approximately 25 km/h (15 MPH) and no vehicle is detected ahead.

The ICC system operates as follows:

- When there are no vehicles travelling ahead, the ICC system maintains the speed set by the driver. The set speed range is above approximately 30 km/h (20 MPH).
- When there is a vehicle travelling ahead, the ICC system adjusts the speed to maintain the distance, selected by the driver, from the vehicle ahead. If the vehicle ahead comes to a stop, the vehicle decelerates to a standstill. Once your vehicle stops, the ICC system keeps the vehicle stopped.
- When your vehicle is at a standstill for more than 3 seconds and the vehicle ahead begins to accelerate, push the <RES+> switch or lightly depress the accelerator pedal. The ICC system starts to follow the vehicle ahead. If your vehicle is stationary for more than

- approximately 3 minutes, the ICC system will be switched off and the electronic parking brake will be applied.
- When the vehicle travelling ahead moves to a different travelling lane, while the vehicle speed is above 30 km/h (20 MPH), the ICC system accelerates and maintains vehicle speed up to the set speed.
- When the vehicle travelling ahead moves to a different travelling lane, while the vehicle speed is below 30 km/h (20 MPH), the ICC system cancels and a warning chime sounds.



NOTE:


The ICC system does not control vehicle speed or warn you when you approach stationary and slow moving vehicles. You must pay attention to vehicle operation to maintain proper distance from vehicles ahead when approaching toll gates or traffic congestion.

When driving on the motorway at a set speed and approaching a slower travelling vehicle ahead, the ICC system adjusts the speed to maintain the distance, selected by the driver, from the vehicle ahead. If the vehicle ahead changes lanes or exits the motorway, the ICC system accelerates and maintains the speed up to the set speed. Pay attention to the driving operation to maintain control of the vehicle as it accelerates to the set speed.

The vehicle may not maintain the set speed on winding or hilly roads. If this occurs, you will have to manually control the vehicle speed.

Normally when controlling the distance to a vehicle ahead, the system automatically accelerates or decelerates your vehicle according to the speed of the vehicle ahead.

Depress the accelerator to properly accelerate your vehicle when acceleration is required for a lane change. Depress the brake pedal when deceleration is required to maintain a safe distance to the vehicle ahead due to sudden braking or if a vehicle cuts in. Always stay alert when using the ICC system.



- System set display with vehicle ahead
- System set display without vehicle ahead

No vehicle detected ahead:

The driver sets the desired vehicle speed based on the road conditions. The ICC system maintains the set vehicle speed, similar to standard cruise control, as long as no vehicle is detected in the lane ahead. The ICC system displays the set speed.

Vehicle detected ahead:

When a vehicle is detected in the lane ahead, the ICC system decelerates the vehicle by controlling the throttle and applying the brakes to match the speed of a slower vehicle ahead. The ICC system then controls the vehicle speed based on the speed of the vehicle ahead to maintain the driver selected distance.

NOTE:

The brake lights of the vehicle come on when braking is performed by the ICC system.

When the brake is applied by the system, a noise may be heard. This is not a malfunction.

When the ICC system detects a vehicle ahead, the vehicle ahead detection indicator is displayed and the speed control status indicator illuminates in green.

Vehicle ahead stops:

When the vehicle ahead decelerates to stop, your vehicle decelerates to a standstill. Once your vehicle stops, the ICC system automatically applies the brakes to keep the vehicle stopped. When your vehicle is at a standstill, the [Press to start] message is displayed on the Vehicle Information Display.

NOTE:

When your vehicle stops for less than 3 seconds, your vehicle will automatically follow the vehicle ahead as it accelerates from a stop. If your vehicle is stationary for more than approximately 3 minutes, the ICC system will be

switched off and the electronic parking brake will be applied.

Vehicle ahead accelerates:

When your vehicle is stopped and the vehicle ahead begins to accelerate, push the <RES+> switch or lightly depress the accelerator pedal. The ICC system starts to follow the vehicle ahead.

Vehicle ahead not detected:

When a vehicle is no longer detected ahead, the ICC system gradually accelerates your vehicle to resume the previously set vehicle speed. The ICC system then maintains the set speed.

When a vehicle is no longer detected, the vehicle ahead detection indicator turns off.

The ICC system gradually accelerates to the set speed, but you can depress the accelerator pedal to guickly accelerate. When a vehicle is no longer detected and your vehicle is travelling under approximately 25 km/h (15 MPH), the ICC system automatically cancels.

When passing another vehicle, the set speed indicator flashes when you override ICC by pressing the accelerator and the vehicle speed exceeds the set speed. When the pedal is released, the vehicle returns to the previously set speed. Even though your vehicle speed is set in the ICC system, you can depress the accelerator pedal when it is necessary to accelerate your vehicle rapidly.

Approach warning:

If your vehicle comes closer to the vehicle ahead due to rapid deceleration of that vehicle or if another vehicle cuts in, the system warns the driver with the chime and ICC system display. Decelerate by depressing the brake pedal to maintain a safe vehicle distance if:

- The chime sounds
- The vehicle ahead detection indicator blinks.
- You judge it necessary to maintain a safe distance

The warning chime may not sound in some cases when there is a short distance between vehicles Some examples are:

- When the vehicles are travelling at the same speed and the distance between vehicles is not changing.
- When the vehicle ahead is travelling faster and the distance between vehicles is increasing.
- When a vehicle cuts in near your vehicle. The warning chime will not sound when:
- Your vehicle approaches other vehicles that are parked or moving slowly.
- The accelerator pedal is depressed, overriding the system.

NOTE:

The approach warning chime may sound and the system display may flash when the radar sensor detects objects on the side of the vehicle or on the side of the road. This may cause the ICC system to decelerate or accelerate the vehicle. The radar sensor may detect these objects when the vehicle is driven on winding, narrow, or hilly roads or when the vehicle is entering or exiting a curve. In these cases, you will have to manually control the proper distance ahead of your vehicle.

Also, the sensor sensitivity can be affected by vehicle operation (steering manoeuvre or driving position in the lane) or traffic or vehicle conditions (for example, if a vehicle is being driven with some damage).

Acceleration when passing:

Passing on the left-hand side:

When the ICC system is engaged above 60 km/h (37 MPH) and following a slower vehicle (below ICC set speed), and the turn signal is activated to the left, the ICC system will automatically start to accelerate the vehicle to help initiate passing on the left and will begin to reduce the distance to vehicle directly ahead. Only the left side turn signal operates this feature. As the driver steers the vehicle and moves into the passing lane, if no vehicle is detected ahead the ICC system will continue to accelerate to the ICC system set speed.

If another vehicle is detected ahead, then the vehicle will accelerate up to the following speed of that vehicle. If the vehicle is not steered into the left lane to pass, the acceleration will stop after a short time and regain the set following distance.

Acceleration can be stopped at any point by depressing the brake pedal or the <CANCEL> switch on the steering wheel.

Passing on the right-hand side:

When the ICC system is engaged above 60 km/h (37 MPH) and following a slower vehicle (below ICC set speed), and the turn signal is activated to the right, the ICC system will automatically start to accelerate the vehicle to help initiate passing on the right and will begin to reduce the distance to vehicle directly ahead. Only the right side turn signal operates this feature. As the driver steers the vehicle and moves into the passing lane, if no vehicle is detected ahead the ICC system will continue to accelerate to the ICC system set speed.

If another vehicle is detected ahead, then the vehicle will accelerate up to the following speed of that vehicle. If the vehicle is not steered into the right lane to pass, the acceleration will stop after a short time and regain the set following distance.

Acceleration can be stopped at any point by depressing the brake pedal or the <CANCEL> switch on the steering wheel.

A WARNING

In order to reduce the risk of a collision that may result in serious injury or death, please be aware of the following:

- This function is only activated with the left or right turn signal and will briefly accelerate the vehicle even if a lane change is not initiated. This can include non-passing situations such as left or right side exits.
- Ensure that when passing another vehicle, the adjacent lane is clear before initiating the pass. Sudden changes in traffic may occur while passing always manually steer or brake as needed never solely rely on the system.

ICC system limitations

A WARNING

Listed below are the system limitations for the ICC system. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death:

- The ICC system is primarily intended for use on straight, dry, open roads with light traffic. It is not advisable to use the ICC system in city traffic or congested areas.
- The ICC system will not adapt automatically to road conditions. This system should be used in evenly flowing traffic. Do not use the system on roads with sharp curves or on icy roads, in heavy rain or in fog.
- As there is a performance limit to the distance control function, never rely solely on the ICC system. This system does not correct careless, inattentive or absent minded driving or overcome poor visibility in rain, fog, or other bad weather. Decelerate the vehicle speed by depressing the brake pedal, depending on the distance to the vehicle ahead and the surrounding circumstances in order to maintain a safe distance between vehicles.
- When the ICC system automatically brings the car to a stop, your vehicle can automatically accelerate if the vehicle is stopped for less than approximately 3 seconds and a vehicle ahead is detected

- moving away. Be prepared to stop your vehicle if necessary.
- Always pay attention to the operation of the vehicle and be ready to manually control the proper following distance. The ICC system may not be able to maintain the selected distance between vehicles (following distance) or selected vehicle speed under some circumstances.
- The system may not detect the vehicle in front of you in certain road or weather conditions. To avoid accidents, never use the ICC system under the following conditions:
 - On roads with heavy, high-speed traffic or sharp curves
 - On slippery road surfaces such as on ice or snow, etc.
 - During bad weather (rain, fog, snow, etc.)
 - When rain, snow or dirt adhere to the bumper around the distance sensor
 - On steep downhill roads (the vehicle may go beyond the set vehicle speed and frequent braking may result in overheating the brakes)
 - On repeated uphill and downhill roads
 - When traffic conditions make it difficult to keep a proper distance between vehicles because of frequent acceleration or deceleration
 - Interference by other radar sources.


- Do not use the ICC system if you are towing a trailer or another vehicle.
- In some road or traffic conditions, a vehicle or object can unexpectedly come into the sensor detection zone and cause automatic braking. Always stay alert and avoid using the ICC system where not recommended in this warning section.

The ICC system will not detect the following objects:

- Stationary or slow moving vehicles
- Pedestrians or objects in the roadway
- Oncoming vehicles in the same lane
- Motorcycles travelling offset in the travel lane The following are some conditions in which the radar sensor cannot properly detect a vehicle
- ahead and the system may not operate properly: When the sensor detection is reduced (condi-
- tions such as rain, snow, fog, dust storms, sandstorms, and road spray from other vehicles).
- Driving on a steep downhill slope or roads with sharp curves.
- Driving on a bumpy road surface, such as an uneven dirt road
- If dirt, ice, snow or other material is covering. the radar sensor area
- A complicated-shaped vehicle such as a car carrier trailer or flatbed truck/trailer is near the vehicle ahead.
- Interference by other radar sources.


- When your vehicle is towing a trailer, etc.
- When excessively heavy baggage is loaded in the rear seat or cargo area of your vehicle.

The ICC system is designed to automatically check the radar sensor's operation within the limitations of the system.



The detection zone of the radar sensor is limited. A vehicle ahead must be in the detection zone for the ICC system to maintain the selected distance from the vehicle ahead. A vehicle ahead may move outside of the detection zone due to its position within the same lane of travel. Motorcycles may not be detected in the same lane ahead if they are travelling offset from the centre line of the lane. A vehicle that is entering the lane ahead may not be detected until the vehicle has completely moved into the lane

If this occurs, the ICC system may warn you by blinking the system indicator and sounding the chime. The driver may have to manually control the proper distance away from the vehicle travelling ahead.



When driving on some roads, such as winding, hilly, curved, narrow roads, or roads which are under construction, the radar sensor may detect vehicles in a different lane, or may temporarily not detect a vehicle travelling ahead. This may cause the radar system to decelerate or accelerate the vehicle.

The detection of vehicles may also be affected by vehicle operation (steering manoeuvre or travelling position in the lane, etc.) or vehicle condition.

If this occurs, the ICC system may warn you by blinking the system indicator and sounding the chime unexpectedly. You will have to manually control the proper distance away from the vehicle travelling ahead.

The ICC system (with ProPILOT Assist) uses a multisensing front camera. The following are some conditions in which the camera may not properly detect a vehicle and detection of a vehicle ahead may be delayed:

 Poor visibility (conditions such as rain, snow, fog, dust storms, sandstorms, and road spray from other vehicles).

- The camera area of the windscreen is fogged up or covered with dirt, water drops, ice, snow, etc.
- Strong light (for example, sunlight or high beams from oncoming vehicles) enters the front camera
- Strong light causes the area around the pedestrian to be cast in a shadow, making it difficult to see.
- A sudden change in brightness occurs (for example, when the vehicle enters or exits a tunnel or shaded area or lightning flashes).

Automatic cancellation

The following are conditions in which the ICC system may be temporarily unavailable. In these instances, the ICC system may not cancel and may not be able to maintain the selected following distance from the vehicle ahead.

Condition A:

Under the following conditions, the ICC system is automatically cancelled. A chime will sound and the system will not be able to be set:

- Any door is open
- The driver's seat belt is not fastened.
- The vehicle ahead is not detected and your vehicle is travelling below the speed of 25 km/h (15 MPH).
- Your vehicle has been stopped by the ICC system for approximately 3 minutes or longer.
- When the shift lever is not in the D (Drive) or Manual mode.
- The electronic parking brake is applied.
- The ESP system is turned off.
- The IEB applies harder braking
- ESP (including the traction control system) operates.
- A wheel slips.
- When distance measurement becomes impaired due to adhesion of dirt or obstruction to the sensor.
- When the radar signal is temporarily interrupted.

Action to take:

When the conditions listed above are no longer present, turn the system off using the ProPILOT Assist switch. Turn the ProPILOT Assist system back on to use the system.

NOTE:

When the ICC system is cancelled under the following conditions at a standstill, the electronic parking brake is automatically activated:

- Any door is opened.
- The driver's seat belt is not fastened.
- Your vehicle has been stopped by the ICC system for approximately 3 minutes or longer.
- When the shift lever is not in the D (Drive) or Manual mode.
- The ESP system is turned off.
- When distance measurement becomes impaired due to adhesion of dirt or obstruction to the sensor.
- When the radar signal is temporarily interrupted.

Condition B:

The Radar sensor is positioned behind the front bumper. When this area is covered with dirt or is obstructed, the ICC system will automatically be cancelled.

The chime will sound and the [Temporarily Disabled Front Radar Blocked] warning message will appear in the Vehicle Information Display.

Action to take:

If the warning message appears, stop the vehicle in a safe place, place the shift lever in the P (Park) position, and turn the hybrid system off. When the radar signal is temporarily interrupted, clean the sensor area and restart the hybrid system. Note that the system will require some time to detect that the area is now clean and to reset itself. If the [Temporarily Disabled Front Radar Blocked] warning message continues to be displayed, have the system checked by a NISSAN dealer or qualified workshop.

Condition C:

When driving on roads with limited road structures or buildings (for example, long bridges, deserts, snow fields, driving next to long walls), the system may illuminate the system warning light and display the [Temporarily Disabled Front Radar Blocked] message.

Action to take:

When the above driving conditions no longer exist, turn the system back on.


ICC system malfunction

If the ICC system malfunctions, it will be turned off automatically, a chime will sound, and the speed control status warning (yellow) will illuminate.


Action to take:

If the warning light comes on, stop the vehicle in a safe place. Turn the hybrid system off, restart the hybrid system and set the ICC system again. If it is not possible to set the ICC system or the indicator stays on, it may be a malfunction. Although the normal driving can be continued, the ICC system should be checked by a NISSAN dealer or qualified workshop.


ICC sensor maintenance



The radar sensor is located on the front of the vehicle (A).



No frame/frameless



Frame type

A WARNING

- NISSAN recommends only to use frameless type number plate holders.
- The ICC system may not function properly if the number plate is placed in a frame as illustrated.

Please contact a NISSAN dealer or qualified workshop for advice.

The sensor for the ICC system A is located behind the lower grille of the front bumper.

- Always keep the sensor area of the front bumper clean.
- Do not strike or damage the areas around the sensor.
- Do not cover or attach stickers or similar objects on the front bumper near the sensor area. This could cause failure or malfunction.
- Do not attach metallic objects near the sensor area (brush guard, etc.) This could cause failure or malfunction.
- Do not alter, remove, or paint the front bumper. Before customising or restoring the front bumper, please contact a NISSAN dealer or qualified workshop.
- Do not place the number plate in a frame.

Before customizing or restoring the front bumper, it is recommended that you visit a NISSAN dealer or qualified workshop.

For the radio approval numbers and information, see "Radio frequency approval" (P.355).

The camera sensor is located above the inside mirror.

To keep the proper operation of the systems and prevent a system malfunction, be sure to observe the following:

- Always keep the windscreen clean.
- Do not attach a sticker (including transparent material) or install an accessory near the camera unit.
- Do not place reflective materials, such as white paper or a mirror, on the instrument panel.
 The reflection of sunlight may adversely affect

the camera unit's capability of detecting the lane markers.

 Do not strike or damage the areas around the camera unit. Do not touch the camera lens or remove the screw located on the camera unit.

If the camera unit is damaged due to an accident, have it checked by a NISSAN dealer or qualified workshop.

PROPILOT ASSIST STEERING ASSIST

A WARNING

Failure to follow the warnings and instructions for proper use of the Steering Assist could result in serious injury or death.

- The Steering Assist is not a replacement for proper driving procedures and is not designed to correct careless, inattentive or absent-minded driving. The Steering Assist will not always steer the vehicle to keep it in the lane. It is not designed to prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the travelling lane, and be in control of the vehicle at all times.
- As there is a performance limit to the Steering Assist's capability, never rely solely on the system. The Steering Assist does not function in all driving, traffic, weather, and road conditions. Always drive safely, pay attention to the operation of the vehicle, and manually control your vehicle appropriately.
- The Steering Assist is intended for use on

well-developed motorways or highways with gentle (moderate) curves, where traffic travelling in opposing directions is separated with a barrier. To avoid risk of an accident, do not use this system on local or non-highway roads.

- The Steering Assist only steers the vehicle to maintain its position in the centre of a lane. The vehicle will not steer to avoid objects in the road in front of the vehicle or to avoid a vehicle moving into your lane.
- It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the travelling lane, and be in control of the vehicle at all times. Never take your hands off the steering wheel when driving. Always keep your hands on the steering wheel and drive your vehicle safely.
- Always drive carefully and attentively when using the Steering Assist. Read and understand the Owner's Manual thoroughly before using the Steering Assist. To avoid serious injury or death, do not rely on the system to prevent accidents or to control the vehicle's speed in emergency situations. Do not use the Steering Assist except in appropriate road and traffic conditions.


ProPILOT Assist Steering Assist operation

The Steering Assist controls the steering system to help keep your vehicle near the centre of the lane when driving. The Steering Assist is combined with the Intelligent Cruise Control (ICC) system.

The Steering Assist can be activated when the following conditions are met:

- The ICC system is activated and the speed set.
- Lane markers on both sides are clearly detected
- A vehicle ahead is detected (when the vehicle is driven at speeds under 60 km/h (37 MPH)).
- The driver grips the steering wheel.
- The vehicle is driven at the centre of the lane.
- The turn signals are not operated.
- The windscreen wiper is not operated in the high (HI) speed operation (the steering assist function is disabled after the wiper operates for approximately 10 seconds).

ProPILOT Assist Steering Assist switches




- Steering wheel mounted controls (left)
- ② Vehicle Information Display
- Steering Assist switch

To turn the Steering Assist ON or OFF, push the Steering Assist switch on the instrument panel. When the Steering Assist switch is used to turn the

system On or OFF, the system remembers the setting when the hybrid system is restarted. The switch must be pushed again to change the setting to ON or OFF.

The Steering Assist switch changes the status of the [Steering Assist] selection made in the [Settings] screen in the Vehicle Information Display.

ProPILOT Assist Steering Assist display and indicators



1. Steering Assist status indicator/warning

Displays the status of the Steering Assist by the colour of the indicator/warning

- Grey: Steering Assist standby
- Green: Steering Assist active
- Yellow: Steering Assist malfunction
- · Red: Hands off detected

2. Lane marker indicator

Indicates whether the system detects the lane marker

- Grey: Lane markers not detected
- Green: Lane markers detected
- Yellow: Lane departure is detected

3. Steering Assist status indicator

Displays the status of the Steering Assist by the colour of the indicator/warning

- Grey: Steering Assist standby
- · Green: Steering Assist active


When the Steering Assist is in operation, the Steering Assist status indicator (1) and (3), and the lane marker indicator (2) and (4) on the Vehicle Information Display turn green. A chime sounds when the Steering Assist initially activates.

When the Steering Assist enters standby mode, the Steering Assist status indicator (1) and (3), and the lane marker indicator (2) and (4) on the Vehicle Information Display turn grey. If Steering Assist has been deactivated automatically as the conditions for activation are no longer met, a double chime will sound.

ProPILOT Assist Lane Assist

When a curve or strong cross wind exceeds the capabilities of the Steering Assist and your vehicle approaches either the left or the right side of the travelling lane, the steering wheel vibrates, a warning chime sounds and the Lane Assist indicator light (yellow) on the instrument panel flashes to alert the driver. Then, the Lane Assist system automatically applies the brakes for a short period of time to help assist the driver to avoid departing the lane and to return the vehicle to the centre of the travelling lane. This action is in addition to any Steering Assist actions. For additional information, refer to "Lane Assist system" (P.215).

Hands on detection



When the Steering Assist is activated, it monitors the driver's steering wheel operation.

If the steering wheel is not operated or the driver takes his/her hands off the steering wheel for a period of time, the warning (1) appears in the Vehicle Information Display and the hands OFF warning light illuminates.

If the driver does not operate the steering wheel after the warning has been displayed, an audible alert sounds and the warning flashes in the Vehicle Information Display. If the driver still does not operate the steering wheel, the system applies Emergency Assist, followed by a momentary brake application to request the driver to take control of the vehicle again.

If the driver still does not respond, the ProPILOT Assist turns on the hazard flasher and slows the vehicle to a complete stop.

The driver can cancel the deceleration at any time

by steering, braking, accelerating, or operating the ProPILOT Assist switch.

A WARNING

Steering Assist is not a system for hands-free driving. Always keep your hands on the steering wheel and drive your vehicle safely. Failure to do so could cause a collision resulting in serious personal injury or death.

NOTE:

If the driver softly touches (instead of firmly arips) the steering wheel, the Steering Assist may not detect the steering wheel operation and the warning may be displayed. When the driver holds and operates the steering wheel again, the warning turns off and the Steering Assist resumes automatically.

Steering Assist Activation/Deactivation

Use the following methods to enable or disable the Steering Assist.

ProPILOT Assist switch on steering wheel:

Press the ProPILOT Assist switch. This will turn ICC on in standby mode. Note that Steering Assist may already be switched on, depending on the settings in the [Settings] menu. These settings are retained if the hybrid system is restarted.

Then press <SET> on the right-hand steering wheel switch to set cruise control speed. When the system detects clear lane markings the Steering Assist icons will turn green and the Steering Assist system will become active.

The Steering Assist icon will remain grey if the

vehicle is driven at speeds under 60 km/h (37 MPH) and no vehicle ahead is detected

Steering Assist switch:

To turn the Steering Assist ON or OFF, push the Steering Assist switch on the instrument panel.

NOTE:

- When the Steering Assist switch is used to turn the system ON or OFF, the system remembers the setting when the hybrid system is restarted. The switch must be pushed again to change the setting to ON or OFF.
- The Steering Assist switch changes the status of the [Steering Assist] selection made in the [Settings] screen in the Vehicle Information Display.

Setting in the Vehicle Information Display:

- Press the
 or
 buttons on the left hand side of the steering wheel until the [Settings] menu is displayed in the Vehicle Information Display and press the **<OK>** button.
- Use the ▲ and ▼ buttons on the steering wheel to highlight [Driver Assistance] and press the <OK> button.
- 3. With [Steering Assist] highlighted press the **<OK>** button to toggle the Steering Assist system status.
 - An indicator indicates that Steering Assist is selected

NOTE:

- When the Steering Assist screen is displayed on the Vehicle Information Display, press the <OK> button on the steering wheel to show the [Driver Assistance] setting menu.
- When enabling/disabling the system through the Vehicle Information Display or when pressing the Steering Assist switch, the system retains the current setting even if the hybrid system is restarted.

Steering Assist limitations

A WARNING

- In the following situations, the camera may not detect lane markers correctly or may detect lane markers incorrectly and the Steering Assist may not operate properly:
 - When driving on roads where there are multiple parallel lane markers, lane markers that are faded or not painted clearly, nonstandard lane markers, or lane markers covered with water, dirt, snow, etc.
 - When driving on roads with discontinued lane markers
 - When driving on roads with a widening or narrowing lane width
 - When driving on roads where there are multiple lanes or unclear lane markers due to road construction
 - When driving on roads where there are sharply contrasting objects, such as

- shadows, snow, water, wheel ruts, seams, or lines remaining after road repairs (the Steering Assist could detect these items as lane markers)
- When driving on roads where the travelling lane merges or separates
- Where the lanes are too narrow or too wide
- Do not use the Steering Assist under the following conditions because the system may not properly detect lane markers. Doing so could cause a loss of vehicle control and result in an accident.
 - During bad weather (rain, fog, snow, dust. etc.)
 - When rain, snow, sand, etc., is thrown up by the wheels of other vehicles
 - When dirt, oil, ice, snow, water, or another object adheres to the camera unit
 - When the glass in front of the camera is foggy
 - When strong light (for example, sunlight or high beams from oncoming vehicles) shines on the camera
 - When the headlights are not bright due to dirt on the lens or the headlights are off in tunnels or darkness
 - When a sudden change in brightness occurs (for example, when the vehicle enters or exits a tunnel or is under a bridge)

- When driving on roads where the travelling lane merges or separates or where there are temporary lane markers because of road construction
- When there is a lane closure due to road repairs
- When driving on a bumpy road surface, such as an uneven dirt road
- When driving on sharp curves or winding roads
- When driving on repeated uphill and downhill roads
- Do not use the Steering Assist under the following conditions because the system will not operate properly:
 - When driving with a tyre that is not within normal tyre conditions (for example, tyre wear, abnormal tyre pressure, installation of a spare tyre, tyre chains, nonstandard wheels)
 - When the vehicle is equipped with non-original brake or suspension parts
 - When an object such as a sticker or cargo obstructs the camera
 - When excessively heavy baggage is loaded in the rear seat or luggage area of your vehicle
 - When the vehicle load capacity is exceeded
 - When towing a trailer or other vehicle
- Excessive noise will interfere with the

warning chime sound, and the beep may not be heard.

For the ProPILOT Assist system to operate properly, the windscreen in front of the camera must be clean. Replace worn wiper blades. The correct size wiper blades must be used to help make sure the windscreen is kept clean. Only use Genuine NISSAN wiper blades, or equivalent wiper blades, that are specifically designed for use on your vehicle model and model year. It is recommended that you visit a NISSAN dealer or qualified workshop for the correct parts for your vehicle.

Steering Assist temporary standby

Automatic standby due to driving operation:

When the driver activates the turn signal, the Steering Assist is temporarily placed in a standby mode. (The Steering Assist restarts automatically when the operating conditions are met again.)

Automatic standby:

In the following cases, a double chime sounds, and the Steering Assist is placed in a temporary standby mode. (The Steering Assist restarts automatically when the operating conditions are met again.)

- When the current travelling lane is too narrow to operate.
- When a corner is too tight and the vehicle cannot stay in the travelling lane.

- When lane markers on both sides are no longer detected.
- When a vehicle ahead is no longer detected under approximately 60 km/h (37 MPH).
- When strong light enters the camera unit (For example, the light directly shines on the front of the vehicle at sunrise or sunset)
- When the temperature of the camera is too high.


Steering Assist cancel

Under the following conditions, the Steering Assist cancels a warning message is displayed, a doublechime sounds, and the Steering Assist indicators turn off.

- When unusual lane markers appear in the travelling lane or when the lane marker cannot be correctly detected for some time due to certain conditions (for example, a snow rut, the reflection of light on a rainy day, the presence of several unclear lane markers).
- When the windscreen wiper operates in the high (HI) speed operation (the Steering Assist is disabled when the wiper operates for more than approximately 10 seconds).

Action to take:

When the conditions listed above are no longer present, turn the Steering Assist system on again using the Steering Assist button on the instrument panel.



Steering Assist malfunction

When the system malfunctions, it turns off automatically. The Steering Assist status warning illuminates (yellow) and a warning message is displayed in the vehicle information display. A chime may sound depending on the situation.

Action to take:

Stop the vehicle in a safe location, place the vehicle in the P (Park) position, turn the hybrid system off, restart the hybrid system, resume driving, ensure that the Steering Assist is switched on using the Steering Assist button on the instrument panel or the [Settings] menu and set the Intelligent Cruise Control system again. If the warning (yellow) continues to illuminate, the Steering Assist may be malfunctioning. Although the vehicle is still drivable under normal conditions, have the system checked by a NISSAN dealer or qualified workshop.

Steering Assist maintenance

The camera sensor is located above the inside mirror.

To keep the proper operation of the system and prevent a system malfunction, be sure to observe the following:

- Always keep the windscreen clean.
- Do not attach a sticker (including transparent material) or install an accessory near the camera unit.
- Do not place reflective materials, such as white paper or a mirror, on the instrument panel. The reflection of sunlight may adversely affect the camera unit's capability of detecting the lane markers
- Do not strike or damage the areas around the camera unit. Do not touch the camera lens or remove the screw located on the camera unit

If the camera unit is damaged due to an accident, it is recommended that you visit a NISSAN dealer or qualified workshop.

PROPILOT ASSIST CONVENTIONAL (fixed speed) CRUISE CONTROL MODE

NOTE:


ProPILOT Assist provides no approach warnings, automatic braking, or steering assist in the conventional (fixed speed) cruise control mode.

This mode allows driving at a speed above approximately 30 km/h (20 MPH) without keeping your foot on the accelerator pedal.

A WARNING


- In the conventional (fixed speed) cruise control mode, a warning chime does not sound to warn you if you are too close to the vehicle ahead, as neither the presence of the vehicle ahead nor the vehicle-tovehicle distance is detected.
- Pay special attention to the distance between your vehicle and the vehicle ahead of you or a collision could occur.
- Always confirm the setting in the ICC system display.
- Do not use the conventional (fixed speed) cruise control mode when driving under the following conditions:
 - When it is not possible to keep the vehicle at a set speed
 - In heavy traffic or in traffic that varies in speed
 - On winding or hilly roads
 - On slippery roads (rain, snow, ice, etc.)
 - In verv windv areas
- Doing so could cause a loss of vehicle control and result in an accident.

ProPILOT Assist Conventional (fixed speed) cruise control switches



- <RES/+> switch:
 - Resumes set speed or increases speed incrementally.
- <CANCEL > switch:
 - Deactivates the system without erasing the set speed.
- <SET/-> switch:
 - Sets desired cruise speed, reduces speed incrementally.
- ProPILOT Assist switch:
 - Master switch to activate the system.

ProPILOT Assist Conventional (fixed speed) cruise control mode display and indicators



The display is located in the vehicle information display.

- 1 Cruise indicator
 - This indicator indicates the condition of the Conventional (fixed speed) cruise control mode of the ICC system depending on a colour
 - Cruise control ON indicator (grey): Indicates that the ICC switch is on.
 - Cruise control SET indicator (green): Indicates that the cruising speed is set.
 - Cruise control warning (yellow): Indicates that there is a malfunction in the Conventional (fixed speed) cruise control mode of the ICC system.
- 2. Set vehicle speed indicator:

This indicator indicates the set vehicle speed.

- Grey: cruise control standby
- Green: cruise control active

Operating ProPILOT Assist conventional (fixed speed) cruise control mode

To turn on the conventional (fixed speed) cruise control mode, push and hold the blue ProPILOT Assist switch for longer than about 1.5 seconds.

When pushing the blue ProPILOT Assist switch on, the ICC system display and indicators are displayed in the Vehicle Information Display, After you hold ProPILOT Assist switch on for longer than about 1.5 seconds, the ProPILOT Assist system display turns off. The cruise indicator appears. You can now set your desired cruising speed. Pushing the ProPILOT Assist switch again will turn the system completely off. When the ignition switch is placed in the OFF position, the system is also automatically turned off.

To use the ICC system again, guickly push and release the ProPILOT Assist switch (vehicle-tovehicle distance control mode) or push and hold it (conventional cruise control mode) again to turn it on.

CAUTION

To avoid accidentally engaging cruise control, make sure to turn the ProPILOT Assist switch off when not using the cruise control system.

To set cruising speed, accelerate your vehicle to the desired speed, push the <SET-> switch and release it. (The colour of the cruise indicator changes to green and set vehicle speed indicator comes on.) Take your foot off the accelerator pedal. Your vehicle will maintain the set speed.

- To pass another vehicle, depress the accelerator pedal. When you release the pedal, the vehicle will return to the previously set speed.
- The vehicle may not maintain the set speed when going up or down steep hills. If this happens, manually maintain vehicle speed.

To cancel the preset speed, use any of the following methods:

- Push the <CANCEL> switch. The vehicle set. speed indicator will turn grey.
- Tap the brake pedal. The vehicle set speed indicator will turn grey.
- You can also Turn ProPILOT Assist off completely. Turn the blue ProPILOT Assist switch off. Both the cruise indicator and vehicle set speed indicator will turn off.

To reset at a faster cruising speed, use one of the following three methods:

- Depress the accelerator pedal. When the vehicle attains the desired speed, push and release the <SET-> switch.
- Push and hold the <RES+> switch When the vehicle attains the desired speed, release the switch.
- Push, then guickly release the <RES+> switch. Each time you do this, the set speed will increase by about 1 km/h (1 MPH).

To reset at a slower cruising speed, use one of the following three methods:

Lightly tap the brake pedal. When the vehicle

- attains the desired speed, push the <SET-> switch and release it.
- Push and hold the <SET-> switch Release the switch when the vehicle slows down to the desired speed.
- Push, then guickly release the <SET-> switch. Each time you do this, the set speed will decrease by about 1 km/h (1 MPH).

To resume the preset speed after ICC cancel, push and release the <RES+> switch. The vehicle will resume the last set cruising speed when the vehicle speed is over 30 km/h (20 MPH).

PROPILOT ASSIST SPEED LIMITER (where fitted)

The speed limiter allows you to set the desired vehicle speed limit. While the speed limiter is activated, you can perform normal braking and acceleration, but the vehicle will not exceed the set speed.

When the vehicle reaches the set speed limit or if the set speed limit is lower than the actual vehicle speed, the accelerator pedal will not work until the vehicle speed drops below the set speed limit.

When the actual vehicle speed exceeds the set speed, an audible warning will be heard a short time after the set speed is exceeded and driver intervention is not detected.

When the speed limiter is on the cruise control system cannot be operated.

A WARNING


The speed limiter will not automatically brake the vehicle to the set speed limit.

- Always observe posted speed limits. Do not set the speed above them.
- Always confirm the setting status of the speed limiter in the Vehicle Information Display.
- When the speed limiter is set, avoid hard acceleration to reach the set limit to ensure that the system can limit the speed of the vehicle correctly.
- When additional floor mats are used, be sure that they are correctly secured and that they cannot interfere with the accelerator pedal. Mats not adapted to the vehicle may prevent proper operation of the speed limiter.


The speed limiter operation switches are located on the steering wheel (right hand side).

The speed limiter operating condition is shown on the top of Vehicle Information Display. For details. see "Vehicle information display" (P.82).


ProPILOT Assist Speed limiter operations



- <CANCFL > switch
- <RES +> (Resume) switch
- <SET -> (Set) switch
- Speed limiter main "ON/OFF" switch
- ProPII OT Assist switch



Before setting speed



After setting speed

Speed limiter symbol

Set speed value

Turning the speed limiter on:

The speed limiter can be switched on after hybrid system start or when driving.

Push the speed limiter main "ON/OFF" switch 2.

The speed limiter symbol (4) and the set speed value (5) will illuminate in the Vehicle Information Display.

NOTE:

Turning the Speed limiter system on will turn on the Intelligent Blind Spot Intervention systems at the same time, providing those systems are enabled in the [Driver Assistance] menu in the vehicle information display. For additional information, see "Lane Assist system" (P.215) and "Blind Spot Warning (BSW) system/Intelligent Blind Spot Intervention system (where fitted)" (P.200).

Setting speed limit:

Push the <SET> switch.

The speed limit will be set at the current speed.

When driving less than 30 km/h (20 MPH), the speed limiter will be set to the minimum possible set speed of 30 km/h (20 MPH).

When the speed limit is set, the speed limiter symbol 4 and the set speed value 5 will turn areen.

Changing a speed limit:

Use either of the following operations to change an active speed limit:

- Push and release the <RES> (Resume) switch or <SET> switch. Each time you do this, the set speed will increase or decrease by 1 km/h (1 MPH).
- Push and hold the <RES> (Resume) switch or <SET> switch . The set speed will increase or decrease to the next multiple of 5 km/h (5 MPH) and then in steps of 5 km/h (5 MPH).

The new set speed limit value (5) will be displayed in the Vehicle Information Display.

When the actual vehicle speed exceeds the set speed, an audible warning will be heard a short time after the set speed is exceeded and driver intervention is not detected.

Cancelling a speed limit:

To cancel a set speed limit, push the <CANCEL> switch. The speed limiter symbol (4) and the set speed value (5) in the Vehicle Information Display will turn arev.

It is also possible to override the speed limiter by fully depressing the accelerator pedal beyond the resistance point.

WARNING

- The vehicle may accelerate when the speed limiter cancels.
- When additional floor mats are used, be sure that they are correctly secured and that they cannot interfere with the accelerator pedal. Mats not adapted to the vehicle may prevent proper operation of the speed limiter.

Fully depress the accelerator pedal beyond the resistance point. The speed limiter will be suspended to allow driving above the set speed. The set speed value (5) will flash and an audible warning will sound. The speed limiter will automatically resume when the vehicle speed drops below the set speed limit.

Resuming a previous set speed:

If a set speed limit has been cancelled, the set speed will be stored in the speed limiter memory.

This speed limit can be reactivated by pressing the <RES> (Resume) switch (A).

If the current vehicle speed is higher than the previous set speed, the accelerator pedal will not work and the set speed value (5) will flash until the vehicle speed drops below the set speed limit.

When the actual vehicle speed exceeds the set speed, an audible warning will be heard a short time after the set speed is exceeded and driver intervention is not detected.

Turning the speed limiter off:

The speed limiter system will be turned off when one of the following operations is performed:

- Push the speed limiter main "ON/OFF" switch. The speed limiter symbol (4) and the set speed value (5) in the Vehicle Information Display will be turned off
- Push the blue ProPILOT Assist "ON/OFF" switch. The speed limiter information in the vehicle information will be replaced with the ProPILOT Assist display. For details, see "Pro-PILOT Assist (where fitted)" (P.225).

 When the vehicle is stopped and the ignition is placed in the **OFF** position.

Turning off the speed limiter will erase the set speed limit memory.

Speed limiter malfunction:

If the speed limiter malfunctions, the speed limiter symbol 4 in the Vehicle Information Display will flash.

Turn the speed limiter off by pushing the speed limiter main "ON/OFF" switch 3 and have the system checked by a NISSAN dealer or qualified workshop.

INTELLIGENT EMERGENCY BRAK-ING (IEB) SYSTEM (where fitted)

INTELLIGENT EMERGENCY BRAKING (IEB) SYSTEM (where fitted) (for EUROPE)


A WARNING

Failure to follow the warnings and instructions for proper use of the IEB system could result in serious injury or death.

- The IEB system is a supplemental aid to the driver. It is not a replacement for the driver's attention to traffic conditions or responsibility to drive safely. It cannot prevent accidents due to carelessness or dangerous driving techniques.
- The IEB system does not function in all driving, traffic, weather and road conditions.

The IEB system can assist the driver when there is a risk of a forward collision with:

- a vehicle ahead in the travelling lane
- a pedestrian ahead in the travelling lane
- a cyclist ahead in the travelling lane



The IEB system uses a radar sensor (a) to measure the distance to the vehicle ahead in the same lane. For pedestrians and cyclists, the IEB system uses a camera (a) installed behind the windscreen in addition to the radar sensor.

Overview of warnings

Warning	Visual	Audible
First		Chime
Second	A	High pitched chime

Overview of warnings


IEB system operation

The IEB system will function when your vehicle is driven at speeds above approximately 5 km/h (3 MPH). For the pedestrian and cyclist detection function, the IEB system operates at speeds between 10 and 80 km/h (6 and 50 MPH).

If a risk of a forward collision is detected, the IEB system will first provide a warning to the driver by flashing the warning (yellow) in the vehicle information display and providing an audible alert. In addition, the IEB system applies partial braking. If the driver applies the brakes quickly and forcefully, but the IEB system detects that there is still the possibility of a forward collision, the system will automatically increase the braking force.

If the driver does not take action, the IEB system

issues the second visual warning (flashing red and white) and audible warning, then the system applies partial braking. If the risk of a collision becomes imminent, the IEB system applies harder braking automatically.



- D IEB emergency warning indicator
- Vehicle ahead detection indicator (on the vehicle information display)
- IEB system OFF warning light (on the meter panel)
- Steering-wheel-mounted controls (left side)

NOTE:

- The vehicle's brake lights come on when braking is performed by the IEB system.
- When the IEB system detects an obstacle in the path of the vehicle and displays the IEB warning, a noise may be heard from the engine bay as the vehicle primes the brakes to improve response time.

Depending on vehicle speed and distance to the vehicle or pedestrian or cyclist ahead, as well as driving and roadway conditions, the system may help the driver avoid a forward collision or may help mitigate the consequences of a collision, should one be unavoidable. If the driver is handling the steering wheel, accelerating or braking, the IEB system will function later or will not function.

The automatic braking will cease under the following conditions:

- When the steering wheel is turned as far as necessary to avoid a collision.
- When there is no longer a vehicle or pedestrian or cyclist detected ahead.

If the IEB system has stopped the vehicle, the vehicle will remain at a standstill for approximately 2 seconds before the brakes are released.

Turning the Intelligent Emergency Braking (IEB) system ON/OFF Perform the following steps to turn the IEB system ON or OFF.

Using the

or

switches and the <OK>
button on the left side of the steering wheel,
select the [Settings] menu in the Vehicle
Information Display.

For details, see "Settings" (P.86).

- Using the ▲ or ▼ switches and the <OK> button, navigate to the [Driver Assistance] menu.
- In the [Driver Assistance] menu, highlight the [Emergency Brake] item and use the <OK> button to toggle between ON (enabled) or OFF (disabled).

When the IEB system is turned off, the IEB system warning light will illuminate.

NOTE:

- Disabling the ESP system causes the Intelligent Emergency Braking system to become unavailable regardless of settings selected in the Vehicle Information Display.
- The IEB system will be automatically turned ON when the hybrid system is restarted.
- IEB system cannot be turned OFF while driving.

IEB system limitations

A WARNING

Listed below are the system limitations for the IEB system. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.

- The IEB system cannot detect all vehicles, pedestrians or cyclists under all conditions.
- The IEB system does not detect the following objects:

- Small pedestrians (including small children) and animals.
- Pedestrians in wheelchairs or using mobile transport such as scooters, child-operated toys, or skateboards.
- Pedestrians who are seated or otherwise not in a full upright standing or walking position.
- Oncoming vehicles.
- Crossing vehicles.
- Obstacles on the roadside.
- The IEB system has some performance limitations.
 - If a stationary vehicle is in the vehicle's path, the IEB system will not function when the vehicle is driven at speeds over approximately 80 km/h (50 MPH).
 - For pedestrian and cyclist detection, the IEB system will not function when the vehicle is driven at speeds over approximately 80 km/h (50 MPH) or below approximately 10 km/h (6 MPH).
- The IEB system may not function for pedestrians and cyclists in darkness or in tunnels, even if there is street lighting in the area.
- The IEB system may not function if the vehicle ahead is narrow (e.g. a motorcycle).
- The IEB system may not function if the speed difference between the two vehicles is too small.
- The IEB system may not function properly

or detect a vehicle, pedestrian or cyclist ahead in the following conditions:


- Poor visibility (conditions such as rain, snow, fog, dust storms, sand storms, and road spray from other vehicles).
- Driving on a steep downhill slope or roads with sharp curves.
- Driving on a bumpy road surface, such as an uneven dirt road.
- If dirt, ice, snow or other material is covering the radar sensor area.
- Interference by other radar sources.
- The camera area of the windscreen is fogged up, covered with dirt, water drops, ice, snow, etc.
- Strong light (e.g. sunlight or high beams from oncoming vehicles) enters the front camera. Strong light causes the area around the pedestrian or cyclist to be cast in shadow, making it difficult to see.
- A sudden change in brightness occurs. For example, when the vehicle enters or exits a tunnel or a shaded area or lightning flashes.
- The poor contrast of a person to the background, such as having clothing coloured or patterned similar to the background.
- The pedestrian's profile is partially obscured or unidentifiable due to the pedestrian transporting luggage,


- wearing bulky or very loose-fitting clothing or accessories.
- When the system has never detected an obstacle since the vehicle was driven after the hybrid system was started.
- The system performance may degrade in the following conditions:
 - The vehicle is driven on a slipperv road.
 - The vehicle is driven on a slope.
 - Excessively heavy luggage is loaded in the rear seat or the luggage area of vour vehicle.
- The system is designed to automatically check the sensor (radar and camera) functionality, within certain limitations. The system may not detect some forms of obstruction of the sensor area such as ice, snow, stickers, etc. In these cases, the system may not be able to warn the driver properly. Be sure that you check, clean and clear sensor areas regularly.
- In some road or traffic conditions, the IEB system may unexpectedly apply partial braking. When acceleration is necessary, continue to depress the accelerator pedal to override the system.
- Excessive noise will interfere with the warning chime sound, and the chime may not be heard.
- Braking distances increase on slipperv surfaces.

- The Intelligent Emergency Braking system may operate when the following are similar to the outlines of pedestrians or cvclists, or if they are the same size and position as a vehicle's and motorcycle's tail lights.
 - Paint, a shadow or a pattern on the road, roadside or wall (including faded and unusual road markings).
 - A shape formed by road structures ahead (such as tunnels, viaducts, traffic sign, reflectors installed on the side of vehicles, reflection sheets, and quardrails), road side objects (trees, buildings) and light sources.
 - A shape formed by road side objects, such as trees, lighting, shadows, or buildings.
- The Intelligent Emergency Braking system may react to:
 - objects on the roadside (traffic sign, quard rail, pedestrian, cyclist, motorcycle, vehicle, etc.)
 - objects above the road (low bridge, traffic sign, etc.)
 - objects on the road surface (railroad track, grate, steel plate, etc.)
 - objects in a parking garage (beam, pillar, etc.)
 - pedestrians or cyclists or motorcycles approaching the travelling lane
 - vehicles, pedestrians, cyclists, motor-

cycles or objects in adjacent lane or close to the vehicle

- oncoming pedestrians, cyclists





When driving on some roads, such as winding, hilly, curved, narrow roads, or roads which are under construction or on a slope, the sensor may detect vehicles in a different lane, or may temporarily not detect a vehicle travelling ahead. This may cause the system to work inappropriately.

The detection of vehicles may also be affected by vehicle operation (steering manoeuvre or travelling position in the lane, etc.) or vehicle condition. If this occurs, the system may warn you by blinking the system indicator and sounding the chime unexpectedly. You will have to manually control the proper distance to the vehicle travelling ahead.

System temporarily unavailable

Condition A:

In the following conditions, the IEB system warning light illuminates, a [Temporarily Disabled Camera Blocked See Owner's Manual] message will appear in the vehicle information display and the system will be turned off automatically.

- The camera area of the windscreen is misted or frozen.
- The camera area of the windscreen is continuously covered with dirt, etc.

Action to take:

Check that the windscreen is clean and free from ice/mist in front of the camera. If necessary, operate the Max Demist function or heated front screen to clear. This may take several minutes.

Condition B:

In the following condition, the IEB system OFF warning light illuminates and the [Currently Unavailable Poor Visibility] warning message will appear in the Vehicle Information Display.

When strong light is shining onto the front of the vehicle or in poor visibility conditions (such as rain, snow, fog)

Action to take:

None. When the above condition no longer exists, the IEB system will resume automatically.

Condition C:

In the following condition, the IEB system OFF warning light illuminates and the [Currently Unavailable Front Camera High Temperature] warning message will appear in the Vehicle Information Display.

 The cabin temperature is over approximately 40 °C (104 °F) in direct sunlight.

Action to take:

None. When the above condition no longer exists, the IEB system will resume automatically.

Condition D:

In the following condition, the IEB system OFF warning light illuminates and the [Currently Unavailable Radar Inhibited] warning message will appear in the Vehicle Information Display.

 When the radar sensor receives interference from other radar sources

Action to take:

None. When the above condition no longer exists, the IEB system will resume automatically.

Condition E:

In the following condition, the IEB system warning light (yellow) will illuminate and the [Temporarily Disabled Front Radar Blocked] warning message will appear in the Vehicle Information Display.

 The sensor area on the front of the vehicle is covered with dirt or is obstructed.

Action to take:

If the warning light (yellow) comes on, stop the vehicle in a safe place and turn the hybrid system off. Check if the sensor area of the front bumper is blocked, and remove the blocking material. Restart the hybrid system. If the warning light continues to illuminate after driving for a few minutes, have the Intelligent Emergency Braking system checked by a NISSAN dealer or qualified workshop.

Condition F:

In the following condition, the Intelligent Emergency Braking warning light (yellow) will illuminate and the [Temporarily Disabled Front Radar Blocked] warning message will appear in the Vehicle Information Display.

When driving on roads with limited road structures or buildings (for example, long bridges, deserts, snow fields, driving next to long walls).

Action to take:

When the above conditions no longer exist, the Intelligent Emergency Braking system will resume automatically.

Condition G:

When the Electronic Stability Program (ESP) system is turned OFF, the IEB system braking will not operate. In this case only the visible and audible warning operates. The IEB system OFF warning light illuminates and the [Currently Unavailable ESP OFF] warning will be displayed.

Action to take:

When the ESP system is ON, the Intelligent Emergency Braking system will resume automaticallv.

System malfunction


If the IEB system malfunctions, it will be turned off automatically, a chime will sound, the IEB system warning light (yellow) will illuminate and the warning message [System Fault] will appear in the Vehicle Information Display.

Action to take:

If the warning light (yellow) comes on, park the vehicle in a safe location, turn the hybrid system off and restart the hybrid system. If the warning light continues to illuminate, have the IEB system checked by a NISSAN dealer or qualified workshop.

INTELLIGENT EMERGENCY BRAKING (IEB) SYSTEM (where fitted) (for Hong Kong, Tahiti, Palestine, New Caledonia, Morocco)

The Intelligent Emergency Braking (IEB) system can assist the driver when there is a risk of a forward collision with the vehicle ahead in the travelling lane.



The IEB system uses a radar sensor (A) located at the front of the vehicle and a camera installed behind the windscreen (B) to measure the distance to the vehicle ahead in the travelling lane.

A WARNING

- The IEB system is a supplemental aid to the driver. It is not a replacement for the driver's attention to traffic conditions or responsibility to drive safely. It cannot prevent accidents due to carelessness or dangerous driving techniques.
- The IEB system does not function in all driving, traffic, weather and road conditions.

System Operation

The IEB system will function when your vehicle is driven at speeds above approximately 5 km/h (3 MPH).

If a risk of a forward collision is detected, the IEB system will first provide a warning to the driver by flashing the warning (yellow) in the Vehicle Information Display and providing an audible alert.

If the driver applies the brakes quickly and forcefully after the warning, and the IEB system detects that there is still the possibility of a forward collision, the system will automatically increase the braking force.

If the driver does not take action, the IEB system issues the second visual warning (red) and audible warning, then the system applies partial braking.

If the risk of a collision becomes imminent, the IEB system applies harder braking automatically.

Overview of warnings

Warning	Visual	Audible
First		Chime
Second	A	High pitched chime

NOTE:

- The vehicle's brake lights come on when braking is performed by the IEB system.
- When the IEB system detects an obstacle in the path of the vehicle and displays the IEB warning, a noise may be heard from the engine bay as the vehicle primes the brakes to improve response time.

Depending on vehicle speed and distance to the vehicle ahead, as well as driving and roadway conditions, the system may help the driver avoid a forward collision or may help mitigate the consequences of a collision should one be unavoidable

If the driver is handling the steering wheel, accelerating or braking, the IEB system will function later or will not function

The automatic braking will cease under the following conditions:

 When the steering wheel is turned as far as necessary to avoid a collision.

- When the accelerator pedal is depressed.
- When there is no longer a vehicle detected ahead

If the IEB system has stopped the vehicle, the vehicle will remain at a standstill for approximately 2 seconds before the brakes are released.


A WARNING


Listed below are the system limitations for the Intelligent Emergency Braking system. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.

- The IEB system cannot detect all vehicles under all conditions.
- The radar sensor does not detect the following objects:
 - Pedestrians, animals or obstacles in the roadway
 - Oncoming vehicles
 - Crossing vehicles
- The radar sensor has some performance limitations. If a stationary vehicle is in the vehicle's path, the IEB system will not function when the vehicle is driven at speeds over approximately 80 km/h (50 MPH).
- The radar sensor may not detect a vehicle ahead in the following conditions:
 - Dirt, ice, snow or other material covering the radar sensor.
 - Interference by other radar sources.

- Snow or road spray from travelling vehicles.
- If the vehicle ahead is narrow (e.g. motorcycle).
- When driving on a steep downhill slope or roads with sharp curves.
- When towing a trailer.
- In some road or traffic conditions, the IEB system may unexpectedly apply partial braking. When acceleration is necessary. continue to depress the accelerator pedal to override the system.
- The IEB system may react to a roadside object (traffic sign, guard rail etc.).
- Braking distances increase on slippery surfaces.
- Excessive noise will interfere with the warning chime sound, and the chime may not be heard.
- The system is designed to automatically check the sensor's functionality, within certain limitations. The system may not always properly warn the driver about functional issues during the first few minutes after starting the hybrid system. The system may not detect some forms of obstruction of the sensor area such as ice, snow, mud, stickers, for example. In these cases, the system may not be able to warn the driver properly. Be sure that you check, clean and clear the sensor area regularly.

- The Intelligent Emergency Braking system may react to
 - objects on the roadside (traffic sign, guard rail, pedestrian, vehicle, etc.)
 - objects above the road (low bridge, traffic sign, etc.)
 - objects on the road surface (railroad track, grate, steel plate, etc.)
 - objects in a parking garage (beam, pillar, etc.)





When driving on some roads, such as winding, hilly, curved, narrow roads, or roads which are under construction, the sensor may detect vehicles in a different lane, or may temporarily not detect a vehicle travelling ahead. This may cause the system to work inappropriately.

The detection of vehicles may also be affected by vehicle operation (steering manoeuvre or travelling position in the lane, etc.) or vehicle condition, if this occurs, the system may warn you by blinking the system indicator and sounding the chime unexpectedly. You will have to manually control the proper distance to the vehicle travelling ahead.

Turning the Intelligent Emergency Braking (IEB) system ON/OFF Perform the following steps to turn the IEB system ON or OFF.

 Using the ◀ or ▶ switches and the <OK> button on the left side of the steering wheel, select the [Settings] menu in the vehicle information display.

For details, see "Settings" (P.86).

- Using the ▲ or ▼ switches and the <OK> button, navigate to the [Driver Assistance] menu.
- In the [Driver Assistance] menu, highlight the [Emergency Brake] item and use the <OK> button to toggle between ON (enabled) or OFF (disabled).

When the IEB system is turned off, the IEB system warning light will illuminate.

NOTE:

- Disabling the ESP system causes the Intelligent Emergency Braking system to become unavailable regardless of settings selected in the Vehicle Information Display.
- The IEB system will be automatically turned ON when the hybrid system is restarted.

System temporarily unavailable

Condition A:

In the following conditions, the IEB system warning light blinks, a [Temporarily Disabled Camera Blocked See Owner's Manual] message will appear in the vehicle information display and the system will be turned off automatically.

- The camera area of the windscreen is misted or frozen.
- The camera area of the windscreen is continuously covered with dirt, etc.

Action to take:

Check that the windscreen is clean and free from ice/mist in front of the camera. If necessary, operate the Max Demist function or heated front screen to clear. This may take several minutes.

Condition B:

In the following condition, the IEB system OFF warning light illuminates and the [Currently Unavailable Poor Visibility] warning message will appear in the Vehicle Information Display.

 When strong light is shining onto the front of the vehicle or in poor visibility conditions (such as rain, snow, fog)

Action to take:

None. When the above condition no longer exists. the IEB system will resume automatically.

Condition C:

In the following condition, the IEB system OFF warning light illuminates and the [Currently Unavailable Front Camera High Temperaturel warning message will appear in the Vehicle Information Display.

 The cabin temperature is over approximately 40 °C (104 °F) in direct sunlight.

Action to take:

None. When the above condition no longer exists. the IEB system will resume automatically.

Condition D:

In the following condition, the IEB system OFF warning light illuminates and the [Currently Unavailable Radar Inhibited) warning message will appear in the Vehicle Information Display.

 When the radar sensor receives interference from other radar sources

Action to take:

None. When the above condition no longer exists. the IEB system will resume automatically.

Condition E:

In the following condition, the Intelligent Emergency Braking warning light (vellow) will illuminate and the [Temporarily Disabled Front Radar Blocked warning message will appear in the Vehicle Information Display.

 The sensor area on the front of the vehicle is covered with dirt or is obstructed

Action to take:

If the warning light (yellow) comes on, stop the vehicle in a safe place and turn the hybrid system off. Check if the sensor area of the front bumper is blocked, and remove the blocking material. Restart the hybrid system. If the warning light continues to illuminate after driving for a few minutes, have the Intelligent Emergency Braking system checked by a NISSAN dealer or qualified workshop.

Condition F:

In the following condition, the Intelligent Emergency Braking warning light (yellow) will illuminate and the [Temporarily Disabled Front Radar Blocked] warning message will appear in the Vehicle Information Display.

When driving on roads with limited road structures or buildings (for example, long bridges, deserts, snow fields, driving next to long walls).

Action to take:

When the above conditions no longer exist, the Intelligent Emergency Braking system will resume automatically.

Condition G:

When the Electronic Stability Program (ESP) system is turned OFF, the IEB system braking will not operate. In this case only the visible and audible warning operates. The IEB system OFF warning light illuminates and the [Currently Unavailable ESP OFF] warning will be displayed.

Action to take:

When the ESP system is ON, the Intelligent Emergency Braking system will resume automatically.


System malfunction

If the IEB system malfunctions, it will be turned off automatically, a chime will sound, the IEB system warning light (yellow) will illuminate and the warning message [System fault] will appear in the Vehicle Information Display.


Action to take:

If the warning light (yellow) comes on, park the vehicle in a safe location, turn the hybrid system off and restart the hybrid system. If the warning light continues to illuminate, have the IEB system checked by a NISSAN dealer or qualified workshop.


SYSTEM MAINTENANCE



The sensor (A) is located behind the front bumper. The camera (B) is located on the upper side of the windscreen.



No frame/frameless



Frame type

A WARNING

- NISSAN recommends only to use frameless type number plate holders.
- The Intelligent Emergency Braking system may not function properly if the number plate is placed in a frame as illustrated.

Please contact a NISSAN dealer or qualified workshop for advice.

The sensor for the Intelligent Emergency Braking system (a) is located behind the lower grille of the front bumper.

To keep the Intelligent Emergency Braking system operating properly, be sure to observe the following:

- Always keep the sensor area of the front bumper clean.
- Do not strike or damage the areas around the sensor.
- Do not cover or attach stickers or similar objects on the front bumper near the sensor area. This could cause failure or malfunction.
- Do not attach metallic objects near the sensor area (brush guard, etc.) This could cause failure or malfunction.
- Do not alter, remove, or paint the front bumper. Before customising or restoring the front bumper, please contact a NISSAN dealer or qualified workshop.
- Do not place the number plate in a frame.

For the radio approval numbers and information, see "Radio frequency approval" (P.355).

A WARNING


Failure to follow the warnings and instructions for proper use of the Intelligent Driver Alertness system could result in serious injury or death.

- The Intelligent Driver Alertness system is only a warning to inform the driver of a potential lack of driver attention or drowsiness. It will not steer the vehicle or prevent loss of control.
- The Intelligent Driver Alertness system does not detect and provide an alert of the driver's lack of attention or fatigue in every situation.
- It is the driver's responsibility to:
 - stay alert,
 - drive safely.
 - keep the vehicle in the travelling lane,
 - be in control of the vehicle at all times,
 - avoid driving when tired,
 - avoid distractions (texting, etc.).

The Intelligent Driver Alertness system helps alert the driver if the system detects a lack of attention or driving fatigue.

The system monitors driving style and steering behaviour over a period of time, and it detects changes from the normal pattern. If the system detects that driver attention is decreasing over a period of time, the system uses an audible and visual warning to suggest that the driver take a break.

SYSTEM OPERATION



The Intelligent Driver Alertness indicator illuminates in white when a warning is issued and in yellow when a malfunction occurs (where fitted).

If the system detects that driver fatigue increases or that driver attention is decreasing, the message [Take a break?] appears in the Vehicle Information Display and a chime sounds when the vehicle is driven at speeds above 60 km/h (37 MPH).


- When the system alerts the driver, the Intelligent Driver Alertness indicator light (white) will also illuminate
- The chime will sound continuously. To stop the chime and turn off the message, push the <OK> button

The system continuously monitors driver attention and can provide multiple warnings per trip.

The system resets and starts reassessing driving style and steering behaviour when the ignition switch is cycled from the ON to the OFF position and back to the ON position.

The system will not operate when the Steering Assist or ProPILOT Assist system is switched on.

How to enable/disable the Intelligent Driver Alertness system warning



- Steering-wheel-mounted control (left side)
- Vehicle information display

Perform either of the following steps to enable or disable the Intelligent Driver Alertness system.

Shortcut Menu

The Intelligent Driver Alertness system can be

turned ON/OFF using [Driver Assist Custom] and [Custom Mode Setup].

Refer to "[Shortcut Menu]" (P.87) for more details. Settings

When [Driver Assist Custom] setting is ON, Driver Attention Alert cannot be adjusted through the

[Settings] menu. To adjust Driver Attention Alert setting when [Driver Assist Custom] is ON, go to the [Custom Mode Setup] menu in the [Shortcut Menul.

- Use the ◀ or ▶ button on the steering wheel until [Settings] is shown on the Vehicle Information Display.
- Use the ▲ or ▼ button to select [Driver] Assistance]. Then push <OK>.
- 3. Select [Driver Attention Alert] and push <OK>.

NOTE:

- Intelligent Driver Alertness system will automatically be turned on when the engine is restarted.
- Intelligent Driver Alertness system will automatically be turned on when the hybrid system is restarted.
- The setting will be retained even if the engine is restarted.
- As long as the Steering Assist system (where fitted) or ProPILOT Assist system (where fitted) is activated the Intelligent Driver Alertness system will be deactivated. Turning off the Steering Assist or ProPILOT system reactivates the Intelligent Driver Alertness system.

Intelligent Driver Alertness Limitations

A WARNING

Listed below are the system limitations for the Intelligent Driver Alertness system. Failure to operate the vehicle in accordance with these

PARKING

system limitations could result in serious injury or death.

- The Intelligent Driver Alertness system may not operate properly and may not provide an alert in the following conditions:
 - Poor road conditions such as an uneven road surface or pot holes.
 - Strong side wind.
 - If you have adopted a sporty driving style with higher cornering speeds or higher rates of acceleration.
 - Frequent lane changes or changes to vehicle speed.
- The Intelligent Driver Alertness system may not provide an alert in the following conditions:
 - Vehicle speeds lower than 60 km/h (37 MPH).
 - Short lapses of attention.
 - Instantaneous distractions such as dropping an object.
 - While the Steering Assist or ProPILOT Assist system (where fitted) is activated.

System malfunction

If the Intelligent Driver Alertness system malfunctions, it will be turned off automatically, the Intelligent Driver Alertness indicator light (yellow) will illuminate and the [System fault See Owner's Manual] warning message will appear in the vehicle information display.

Action to take:

If the indicator light (yellow) illuminates, pull off the road to a safe location and stop the vehicle. Turn the hybrid system off and restart the hybrid system. If the indicator light (yellow) continues to illuminate, have the system checked. It is recommended that you visit a NISSAN dealer for this service.

A WARNING

- Do not park the vehicle over flammable materials, such as dry grass, waste paper, or rags. They may ignite and cause a fire.
- Safe parking procedures require that:
 - The parking brake is applied.
 - The shift lever is placed in the P (Park) position.


Failure to follow the above recommendations could cause the vehicle to move unexpectedly or roll away and result in an accident.

- Never leave the hybrid system running while the vehicle is unattended.
- Do not leave children unattended inside the vehicle. They could unknowingly activate switches or controls, or move the vehicle. Unattended children could become involved in serious accidents.
- To help avoid risk of injury or death through unintended operation of the vehicle and/or its systems, do not leave children, people who require the assistance of others or pets unattended in your vehicle. Additionally, the temperature inside a closed vehicle on a warm day can quickly become high enough to cause a significant risk of injury or death to people and pets.


Fully depress the brake pedal and move the shift lever to the P (Park) position.

A WARNING

Make sure that the shift lever has been pushed as far forward as it can go and cannot be moved without depressing the button on the shift lever handle.



LHD models



RHD models

When parked on a sloping driveway, turn the wheels so the vehicle will not roll into the street in case it moves.

ULTRASONIC PARKING SENSORS (where fitted)

FACING DOWNHILL: (1)

Turn the wheels into the kerb, allow the vehicle to move forward until the kerb side wheel gently touches the kerb. Then set the parking brake.

FACING UPHILL: (2)


Turn the wheels away from the kerb and allow the vehicle to move back until the kerb side wheel gently touches the kerb. Then set the parking brake.

NO KERB - FACING DOWNHILL OR UPHILL: (3)


Turn the wheels toward the side of the road so the vehicle will move away from the centre of the road if it moves. Then set the parking brake.

Turn the ignition switch to the LOCK position and remove the kev.

Turn the ignition switch to the LOCK position and remove the key/Intelligent Key (where fitted).



Where fitted



Where fitted

Ultrasonic sensors (1) (where fitted) in the vehicle's front and rear bumpers (or rear bumper only). measure the distances between the vehicle and an obstacle when reversing. When reverse gear is engaged, a top view of the vehicle is shown in the vehicle information display. On the display the distances (1 meter and less) to objects are shown. If the object(s) get(s) closer to the vehicle, colours change from green over yellow to red. If the text

[STOP] is shown, stop the vehicle before actually touching the object.

A WARNING

- If there is any doubt the surroundings in the path of the parking area and/or the parking area itself are not free from obstacles immediately stop the vehicle and check.
- The parking sensor system is a convenience but it is not a substitute for proper parking. The driver is always responsible for safety during parking and other manoeuvres. Always look around and check that it is safe to do so before parking.
- Read and understand the limitations of the parking sensor system as contained in this section. The colours of the corner sensor indicator and the distance guide lines in the front (where fitted)/rear view indicate different distances to the object. Inclement weather or ultrasonic sources such as an automatic car wash, a truck's compressedair brakes, horn sound, or a pneumatic drill may affect the function of the system; this may include reduced performance or a false activation.
- Some types of kerb may also be detected.
- This function is designed as an aid to the driver in detecting large stationary objects to help avoid damaging the vehicle. The system is not designed to prevent contact with small or moving objects. Always move slowly.

- The system will not detect small objects below the bumper, and may not detect objects close to the bumper or on the around.
- The system is deactivated at speeds above 10 km/h (6 MPH). It is reactivated at lower speeds.
- This system is intended as an aid to parking, to be used in conjunction with your rear view mirrors.
- Do not attach stickers (including transparent material), install accessories, or apply anything blocking the sensors. These conditions may reduce the ability of the system.
- The system may not detect the following objects.
 - Fluffy objects such as snow, cloth, cotton, glass-wool, etc.
 - Thin objects such as rope, wire and chain, etc.
 - Wedge-shaped objects.
- If your vehicle sustains damage to the bumper fascia, leaving it misaligned or bent, the sensing zone may be altered causing inaccurate measurement of obstacles or false alarms.

CAUTION


Excessive noise (such as audio system volume or an open vehicle window) will interfere with the tone and it may not be heard.

- In some conditions (i.e. after car wash, or rain) water can accumulate around the sonar sensors reducing performance or cause false activation of the system. This water will drain away automatically while driving, bringing system performance back to normal.
- Keep the surface of the sonar sensors (located on the front and rear bumper fascia) free from accumulations of snow, ice and dirt. Do not scratch the surface of the sonar sensors when cleaning. If the sensors are covered, the accuracy of the sonar function will be diminished.

OPERATION

Using the [Settings] menu

The settings of the parking sensor system can be changed.



At ignition **ON** when the [Settings] menu is shown in the display, select

[Driver Assistance] → [Parking Aids]

or when the parking sensor screen is displayed, press the **<OK>** switch (B) on the steering wheel. Press the BACK switch (A) to return to the previous item

The [Settings] menu is shown.

Set the following items on or off by selecting (highlighted) and pressing the **<OK>** (B) switch on the steering wheel. When selected, a green marker is shown.

- [Front] *: Switch the front sensors on or off
- [Rear]: Switch the rear sensors on or off
- Displayl: Switch the parking sensor system automatically on or off when selecting R (Reverse) gear.

* Where fitted

By highlighting the colour of the to be set item:

- Set the volume of the parking sensor system Select [Volume] and press <OK>
 - [High]
 - [Medium]
 - Lowl
- Set the range sensitivity Select [Distance] and press <OK>
 - [Far]

TRAILER TOWING

- [Medium]
- [Near]

MAINTENANCE

Blockages like dirt, ice, and objects such as stickers and accessories installed within the detection range of the parking sensor may cause incorrect function of the parking sensor system. Clean the sensors regularly with care, and do not scratch or damage them.

OPERATING PRECAUTIONS

Your new vehicle was designed to be used primarily to carry passengers and luggage.

Remember that towing a trailer will place additional loads on your vehicle's hybrid system, drivetrain, steering, braking and other systems. Towing a trailer will also exaggerate other conditions, such as sway caused by crosswinds, rough road surfaces or passing trucks. Driving style and speed must be adjusted according to the circumstances. Before towing a trailer, see a NISSAN dealer or qualified workshop for an explanation of towing equipment and its proper use.

- Avoid towing a trailer during the running-in schedule
- Choose proper coupling devices (trailer hitch. safety chain, roof carrier, etc.) for your vehicle and trailer. These devices are available from a NISSAN dealer or qualified workshop where you can also obtain more detailed information about trailer towing.
- It is advisable to contact a NISSAN dealer or qualified workshop for towing details, before towing a trailer up steep slopes for long distances.
- Never allow the total trailer load (trailer weight plus its cargo weight) to exceed the maximum set for the coupling device.
 - Contact a NISSAN dealer or qualified workshop for more information on this matter.
- The trailer must be loaded so that heavy goods are distributed over the axle and as low in the trailer as possible. Poor load

- distribution can seriously affect the stability of the trailer and tow vehicle.
- Do not exceed the maximum permitted vertical load on the trailer hitch.
- Do not exceed the maximum gross vehicle weight. This is the combined weight of the vehicle, driver, passengers, cargo, and load on the towing coupling device (where fitted). You can find the maximum gross vehicle weight on the vehicle identification label (see "Vehicle identification" (P.345)).
- Before driving, make sure that the lighting system of the trailer works properly.
- Avoid abrupt starts, acceleration and stops.
- Avoid sharp turns and lane changes.
- Always drive your vehicle at a moderate speed.
- Always block the wheels on both vehicle and trailer when parking. Apply the handbrake (where fitted) on the trailer. Parking on a steep slope is not recommended.
 - If parking on a steep slope is unavoidable it is also advisable to put the vehicle into gear, or select P (Park), and turn the front wheels into the kerb (in addition to the other precautions described). Before parking on a steep slope consider the incline (the towing weights quoted are for a 12% slope).
- Follow the trailer manufacturer's instructions.
- Have your vehicle serviced more often than at the intervals specified in the separately provided Warranty Information and Maintenance booklet

- Trailer towing requires more fuel than under normal circumstances because of a considerable increase in traction power required and resistance.
- When towing a trailer, observe the following restricted towing speed:

Speed: below 100 km/h (62 MPH)

CAUTION

While towing a trailer, check the warning message "High Coolant Temp" regularly to prevent engine overheating.

TYRE PRESSURE

When towing a trailer, inflate the vehicle tyres to the maximum recommended COLD tyre pressure, as indicated on the tyre placard (for full loading). Make sure the trailer tyre pressures are correct.

CAUTION

Do not tow a trailer when the vehicle is installed with a temporary-use spare tyre.

SAFETY CHAINS

Always use a suitable chain between the vehicle and trailer. The chain should be attached to the hitch and not to the vehicle bumper or axle. Be sure to leave enough slack in the chain to permit turning corners. The chain should not drag on the ground: passing the chain across the trailer hitch may be the best practice depending on your trailer.

TRAILER BRAKES

Ensure that trailer brakes are installed as required by local regulations. Also check that all other trailer equipment conforms to local regulations.

TRAILER DETECTION (where fitted)

When towing a trailer and the turn signal switch is used, the electrical system of the vehicle will detect an additional electrical load of the trailer lighting. As a result, the trailer direction indicator light comes on.


INSTALLATION OF COUPLING DEVICE

NISSAN recommends that the coupling device for trailer towing be installed under the following conditions:

- Maximum permissible vertical load on the coupling device: 736 N (75 kg, 165 lb)
- The coupling device, mounting points and installation parts on your vehicle: as shown as an example in the illustration.

Follow all of the coupling device manufacturer's instructions for installation and use.

VEHICLE SECURITY



Rear overhang of coupling device:

A 744 mm (29.3 in)

I Detachable towbar

II Fixed towbar

When leaving your vehicle unoccupied:

- Always remove the ignition key and take it with you — even in your own garage.
- Always remove the ignition key or Intelligent Key (where fitted) and take it with you — even in your own garage.
- Close all windows completely and lock all doors.
- Always park your vehicle where it can be seen.
 At night, park in a well lit area.
- If the vehicle is equipped with an alarm or immobilization device, use it – even for short periods.
- Do not leave children and pets in the vehicle unattended.
- Do not leave valuables on view to tempt a thief. Always take your valuables with you. If you must leave something in your vehicle, lock it in the luggage compartment or hide it out of sight.
- Do not leave the vehicle documents in your vehicle. In the unfortunate event of your vehicle being stolen, the documents will only help a thief to sell the vehicle.
- Do not leave articles on a roof rack as they are particularly vulnerable. If possible, remove them from the rack and lock them inside the vehicle.
- Do not leave the spare key in the vehicle keep it in a safe place at home.
- Do not leave the spare key or Intelligent Key in the vehicle — keep it in a safe place at home.

POWER STEERING

Do not leave a note of your vehicle's key number in the vehicle. A thief may break into the vehicle, note the key number and return with a new key and drive the vehicle.

A WARNING

- If the hybrid system is not running or is turned off while driving, the power assistance for the steering will not work. The steering will be harder to operate.
- When the electric power steering warning light illuminates with the hybrid system running, the power assistance for the steering will cease operation. You will still have control of the vehicle but the steering will be harder to operate.


The electric power steering system is designed to provide power assistance while driving to allow you to operate the steering wheel with light force.

NOTE:

When the steering wheel is operated repeatedly or continuously while parking or driving at a very low speed, the power assistance for the steering wheel will be reduced. This is to prevent overheating of the electric power steering system and protect it from becoming damaged. While the power assistance is reduced, steering wheel operation will become heavy. When the temperature of the electric power steering system decreases, the power assistance level will return to normal. Avoid repeating such steering wheel operations that could cause the electric power steering system to overheat.

You may hear a noise when the steering wheel is operated quickly. However, this is not a malfunction.

If the electric power steering warning light



When the electric power steering warning light illuminates with the hybrid system running, the power assistance for the steering will cease operation. You will still have control of the vehicle. However, greater steering effort is needed, especially in sharp turns and at low speeds.

BRAKE SYSTEM

BRAKING PRECAUTIONS

This vehicle is equipped with two braking systems:

- Hydraulic brake system
- Regenerative brake system

Hydraulic brake system

The hydraulic brake system is similar to the brakes used on conventional vehicles.

The brake system has two separate hydraulic circuits.

If one circuit malfunctions, you will still have braking at two wheels.

Regenerative brake system

The primary purpose of regenerative brake system is to provide some power to help recharge the Liion battery and extend driving range. A secondary benefit is "engine braking" that operates based on battery conditions.

In the D (Drive) position, when the accelerator is released, the regenerative brake system provides some deceleration and generates power for the Liion battery. Power is also generated when the brake pedal is applied.

However, during high-speed driving you may feel that regenerative brake provides less deceleration than the engine braking in an ordinary vehicle.

This is normal

Less deceleration is provided by the regenerative brake system when the Li-ion battery is fully charged. Regenerative brake is automatically reduced when the Li-ion battery is fully charged to

prevent the Li-ion battery from becoming overcharged.

Regenerative brake is also automatically reduced when the battery temperature is high/low to prevent Li-ion battery damage.

The brake pedal should be used to slow or stop the vehicle depending on traffic or road conditions. The vehicle brakes are not affected by regenerative brake system operation.

NOTE:

The amount of regenerated charge varies depending on the drive mode and e-Pedal usage.

Wet brakes

When the vehicle is washed or driven through water, the brakes may get wet. As a result, your braking distance will be longer and the vehicle may pull to one side during braking.

To dry brakes, drive the vehicle at a safe speed while lightly pressing the brake pedal to heat up the brakes. Do this until the brakes return to normal. Avoid driving the vehicle at high speeds until the brakes function correctly.

Using the brakes

Avoid resting your foot on the brake pedal while driving. This will overheat the brakes, wear out the brake linings and pads faster and reduce fuel economy performance.

To help reduce brake wear and to prevent the brakes from overheating, reduce speed and shift to a lower gear before going down a slope or long downhill gradient. Overheated brakes may reduce

braking performance and could result in loss of vehicle control.

CAUTION

- While driving on a slippery surface, be careful when braking or accelerating. Abrupt braking actions or sudden acceleration could cause the wheels to skid and result in an accident.
- If the brake pedal is depressed with the hybrid system OFF, you may feel an increased brake pedal effort and a decreased pedal stroke. If the brake warning light (red) does not illuminate and the brake pedal feels like it has returned to its normal state after the hybrid system is started, this indicates that there is no malfunction and the vehicle can be operated normally.

Be aware that brakes will fade if repeated heavy brake applications are made.

Driving uphill

Use the parking brake to hold the vehicle. Make sure that the shift lever is in an appropriate forward or reverse driving position, slowly release the parking brake while depressing the accelerator pedal. If your vehicle has an electric parking brake, this will automatically release when you depress the accelerator pedal.

ANTI-LOCK BRAKING SYSTEM (ABS)

Driving downhill

The engine braking action is effective for controlling the vehicle while descending hills.

A WARNING

- The Anti-lock Braking System (ABS) is a sophisticated device, but it cannot prevent accidents resulting from careless or dangerous driving techniques. It can help maintain vehicle control during braking on slippery surfaces. Remember that stopping distances on slippery surfaces will be longer than on normal surfaces even with ABS. Stopping distances may also be longer on rough, gravel or snow covered roads, or if you are using snow chains. Always maintain a safe distance from the vehicle in front of you. Ultimately, the driver is responsible for safety.
- Tyre type and condition may also affect braking effectiveness.
 - When replacing tyres, install the specified size of tyres on all four wheels.
 - When installing a spare tyre, make sure that it is the proper size and type as specified on the tyre placard. (See "Vehicle identification" (P.345).)
 - For detailed information, see "Wheels and tyres" (P.334).

The Anti-lock Braking System (ABS) controls the brakes so the wheels do not lock during hard braking or when braking on slippery surfaces. The system detects the rotation speed at each wheel and varies the brake fluid pressure to prevent each wheel from locking and sliding. By preventing each wheel from locking, the system helps the driver

maintain steering control and helps to minimise swerving and spinning on slippery surfaces.

USING SYSTEM

Depress the brake pedal and hold it down. Depress the brake pedal with firm steady pressure, but do not pump the brakes. The ABS will operate to prevent the wheels from locking up. Steer the vehicle to avoid obstacles.

A WARNING

Do not pump the brake pedal. Doing so may result in increased stopping distances.

SELF-TEST FEATURE

The ABS includes electronic sensors, electric pumps, hydraulic solenoids and a computer. The computer has a built-in diagnostic feature that tests the system each time you start the hybrid system and move the vehicle at a low speed in forward or reverse. When the self-test occurs, you may hear a "clunk" noise and/or feel a pulsation in the brake pedal. This is normal and does not indicate a malfunction. If the computer senses a malfunction, it switches the ABS off and illuminates the ABS warning light on the instrument panel. The brake system then operates normally, but without anti-lock assistance.

If the ABS warning light illuminates during the selftest or while driving, have the vehicle checked by a NISSAN dealer or qualified workshop.

ELECTRONIC STABILITY PROGRAMME (ESP) SYSTEM (where fitted)

NORMAL OPERATION

The ABS operates at speeds above 5 to 10 km/h (3 to 6 MPH). The speed varies according to road conditions.

When the ABS senses that one or more wheels are close to locking up, the actuator rapidly applies and releases hydraulic pressure. This action is similar to pumping the brakes very quickly. You may feel a pulsation in the brake pedal and hear a noise from under the bonnet or feel a vibration from the actuator when it is operating. This is normal and indicates that the ABS is operating properly. However, the pulsation may indicate that road conditions are hazardous and extra care is required while driving.

When accelerating, driving on slippery surfaces or suddenly avoiding obstacles on roads, the vehicle might swerve or slip. The Electronic Stability Programme (ESP) system continuously monitors and compares the driver's intended speed and the travel direction. The system adjusts wheel brake pressure and engine torque to assist in improving vehicle stability.

- When the ESP system is operating, the "SLIP" indicator light 🕏 in the combination meter blinks
- When only the traction control (TCS) system in the ESP system is operating, the "SLIP" indicator light 🕏 in the combination meter will also blink.
- If the "SLIP" indicator light 🏂 blinks, the road conditions are slippery. Be sure to drive carefully. See "Warning lights, indicator lights and audible reminders" (P.72).
- Indicator light

If a malfunction occurs in the system, the "SLIP" indicator light 🕏 will come on in the combination meter.

As long as these indicator lights are on, the traction control function is cancelled.

The ESP system uses Active Brake Limited Slip (ABLS) system to improve vehicle traction. The Active Brake Limited Slip (ABLS) system works when one of the driving wheels is spinning on a slippery surface. The Active Brake Limited Slip (ABLS) system, brakes the spinning wheel to distribute the driving power to the other driving wheel.

If the vehicle is operated with the ESP system

turned off, all ESP and TCS functions will be turned off. The Active Brake Limited Slip (ABLS) system and ABS will still operate with the ESP system off. If the Active Brake Limited Slip (ABLS) system is activated, the "SLIP" indicator light 🕏 will blink and you may hear a clunk noise and/or feel a pulsation in the brake pedal. This is normal and does not indicate a malfunction.

Fade Brake Support (FBS) (where fitted) is an additional aid to the ESP system, it minimises the stopping distance during braking when the brakes become hot and in addition, it provides a safety benefit for driving on a downhill descent where frequent braking is necessary.

While the ESP system is operating, you may feel a pulsation in the brake pedal and hear a noise or vibration from under the bonnet. This is normal and indicates that the ESP system is working properly.

The ESP computer has a built in diagnostic feature that tests the system each time the engine is started and the vehicle moves forwards or reverses at a slow speed. When the self-test occurs, you may hear a clunk noise and/or feel a pulsation in the brake pedal. This is normal and is not an indication of a malfunction.

WARNING

The ESP system is designed to help improve driving stability but does not prevent accidents caused by abrupt steering operation at high speeds, or careless or dangerous driving techniques. Reduce vehicle speed and be especially careful when driving and cornering on slipperv surfaces. Always drive carefully.

- If engine related parts, such as a muffler, are not standard equipment or are extremely deteriorated, the "SLIP" indicator light 🕏 may illuminate.
- If brake related parts, such as brake pads, rotors and callipers, are not standard equipment or are extremely deteriorated, the ESP system may not operate properly and the "SLIP" indicator light 🕏 may illuminate.
- If the hybrid system control related parts are not NISSAN recommended or are extremely deteriorated, the "SLIP" indicator light 🏂 may illuminate.
- Do not modify the vehicle's suspension. If suspension parts, such as shock absorbers, struts, springs, stabiliser bars and bushings, are not NISSAN-approved or are extremely deteriorated, the ESP system may not operate properly. This could adversely affect vehicle handling performance and the "SLIP" indicator light 🕏 may illuminate.
- When driving on extremely inclined surfaces, such as higher banked corners, the ESP system may not operate properly and the "SLIP" indicator light 🕏 may illuminate. Do not drive on these types of roads. If ESP OFF indicator light 🐉 does illuminate after driving on extreme surfaces, restart the engine to reset the ESP system.
- If wheels or tyres other than the recom-

mended ones are used, the ESP system may not operate properly and the "SLIP" indicator light 🕏 may illuminate.

 The ESP system is not a substitute for winter tyres or snow chains on a snow covered road.

NOTE:

- The ESP system should be switched on under normal circumstances although it may be advantageous to switch off the ESP system to allow wheel spin under the following conditions:
 - When driving in deep snow or mud.
 - When trying to rock a vehicle free that is stuck in snow.
 - When driving with snow chains.
- If the ESP system has been switched off, drive carefully with reduced speed. When road conditions allow, ESP should be switched back on.

ELECTRONIC STABILITY PROGRAMME (ESP) DEACTIVATION

The vehicle should be driven with the Electronic Stability Programme (ESP) system ON for most driving conditions.

If the vehicle is stuck in mud or snow, the ESP system reduces the engine output to decrease wheel spin. The engine speed will be reduced even if the accelerator is depressed to the floor. If maximum engine power is needed to free a stuck vehicle, turn the ESP system off.

To turn off the ESP system, Use the Vehicle Information Display, see "Vehicle information dis-

play" (P.82) for operational details. The ESP OFF indicator light 👼 will come on.

NOTE:

The ESP system cannot be switched off when the ESP system is operating and the "SLIP" indicator light 🕏 is blinking.

Disabling the ESP system causes the Intelligent Emergency Braking (IEB) system (where fitted) to become unavailable. The IEB warning light will illuminate. See "Intelligent Emergency Braking (IEB) system (where fitted)" (P.250) for operational details.

Use the Vehicle Information Display, or restart the engine, to turn the system ON. See "Vehicle information display" (P.82) for operational details.

CHASSIS CONTROL

The chassis control is an electric control module that includes the following functions:

- Intelligent Trace Control
- Intelligent Ride Control

INTELLIGENT TRACE CONTROL


A WARNING

The Intelligent Trace Control may not be effective depending on the driving condition. Always drive carefully and attentively.

This Intelligent Trace Control senses driving based on the driver's steering and acceleration/braking patterns, and controls brake pressure at individual wheels to aid tracing at corners and help smooth vehicle response.

The Intelligent Trace Control can be set to ON (enabled) or OFF (disabled) using the [Driver Assistance] settings in the vehicle information display.

When the Electronic Stability Programme (ESP) system is turned OFF, the Intelligent Trace Control is also turned OFF.



Chassis control

When the Intelligent Trace Control is operated and the [Chassis Control] is selected in the vehicle information display, the Intelligent Trace Control graphics are shown in the vehicle information display. See "[Driver Assistance] (where fitted)" (P.87) for more information.

If the [Chassis Control] warning message appears in the vehicle information display, it may indicate that the Intelligent Trace Control is not functioning properly. Have the system checked by a NISSAN dealer or qualified workshop.

When the Intelligent Trace Control is operating, you may feel a pulsation in the brake pedal and hear a noise. This is normal and indicates that the Intelligent Trace Control is operating properly.

You may also feel deceleration when the Intelligent Trace Control is operating. However, this is not a malfunction.

Even if the Intelligent Trace Control is set to OFF, some functions will remain on to assist the driver (for example, avoidance scenes).

INTELLIGENT RIDE CONTROL

This system senses upper body motion (based on wheel speed information) and controls four wheel brake pressure. This will enhance ride comfort in effort to restrain uncomfortable upper body movement when passing over undulated road surfaces.

When the Electronic Stability Programme (ESP) system is turned OFF, the Intelligent Ride Control is also turned OFF.

When the Intelligent Ride Control is operated and the [Chassis Control] is selected in the vehicle information display, the Intelligent Ride Control graphics are shown in the vehicle information display. See "[Driver Assistance] (where fitted)" (P.87) for more information.

If the chassis control warning message appears in the vehicle information display, it may indicate that the Intelligent Ride Control is not functioning properly. Have the system checked by a NISSAN dealer or qualified workshop.

When the Intelligent Ride Control is operating, you

may hear noise and sense slight deceleration. This is normal and indicates that the Intelligent Ride Control is operating properly.

A WARNING

- Never rely solely on the Hill Start Assist (HSA) system to prevent the vehicle from moving backward on a hill. Always drive carefully and attentively. Depress the brake pedal when the vehicle is stopped on a steep hill. Be especially careful when stopped on a hill on frozen or muddy roads. Failure to prevent the vehicle from rolling backwards may result in a loss of control of the vehicle and possible serious injury or death.
- The Hill Start Assist system is not designed to hold the vehicle at a standstill on a hill.
 Depress the brake pedal when the vehicle is stopped on a steep hill. Failure to do so may cause the vehicle to roll backwards and may result in a collision or serious personal injury.
- The Hill Start Assist system may not prevent the vehicle from rolling backwards on a hill under all load or road conditions. Always be prepared to depress the brake pedal to prevent the vehicle from rolling backwards. Failure to do so may result in a collision or serious personal injury.

The Hill Start Assist system automatically keeps the brakes applied to help prevent the vehicle from rolling backwards in the time it takes the driver to release the brake pedal and apply the accelerator when the vehicle is stopped on a hill.

The Hill Start Assist system will operate automatically under the following conditions:

- The shift lever is shifted into a forward (vehicle facing uphill) or reverse gear (vehicle facing downhill).
- The vehicle is stopped completely on a hill by applying the footbrake.
- The slope is greater than 3 degrees.


The maximum holding time is 2 seconds. After 2 seconds the vehicle will begin to roll back and the Hill Start Assist system will stop operating completely.

The Hill Start Assist system will not operate when the shift lever is shifted to the N (Neutral) or P (Park) position or on a flat and level road.


When the Electronic Stability Programme (ESP) OFF indicator light illuminates in the meter, the Hill Start Assist system will not operate. (See "Electronic Stability Programme (ESP) OFF indicator light (where fitted)" (P.80).)

The Hill Start Assist function status can be checked in the [Chassis Control] mode in the Vehicle Information Display. If the [Chassis Control] screen is selected, the vehicle is displayed on a slope. The wheels flash to show that the car is being held.


DRIVE MODE



DRIVE MODE



Left hand drive



Right hand drive

The Drive mode switch is located behind the shift lever on the centre console.

Three drive modes (<STANDARD>, <SPORT> and <ECO>) can be selected depending on the driving condition. If <SPORT> or <ECO> mode is currently selected, a <SPORT> or <ECO> icon is displayed in the vehicle information display.

Each of the modes changes the driving characteristics of the car by altering the feeling given from the steering, accelerator pedal and engine response.

STANDARD drive mode

The <STANDARD> drive mode is recommended for normal driving. This is the default drive mode.

From the <STANDARD> drive mode switch position (default mode):

- Press the switch UP to select <SPORT> mode
- Press the switch DOWN to select <ECO> mode

SPORT drive mode

The <SPORT> drive mode is recommended for an enhanced performance feel. In sport mode, steering weight will increase, and engine control and acceleration response will be enhanced. This will give the vehicle a sportier feel.

Sport mode will run the engine more and will keep the hybrid battery at a higher charge to allow for optimum response.

NOTE:

In the <SPORT> mode, it will increase regenerative braking level and the fuel economy may be reduced.

From the <SPORT> drive mode switch position:

- Press the switch UP to select <STANDARD> mode
- Press the switch DOWN to select <ECO> mode

TRAFFIC SIGN ASSIST (where fitted)

ECO drive mode


The <ECO> drive mode is recommended for maximum fuel economy. In the <ECO> drive mode, the control state of the engine and hybrid gearbox are adjusted to enhance fuel economy.

NOTE:

- Many driving factors influence fuel economy. Selecting the <ECO> drive mode does not necessarily improve fuel economy.
- In the <ECO> drive mode, performance may be reduced.
- Eco mode decrease regenerative braking level to allow to coast to conserve vehicle momentum and economy.

From the <ECO> drive mode switch position:

- Press the switch UP to select <SPORT> mode
- Press the switch DOWN to select <STANDARD> mode



The Traffic Sign Assist (TSA) system provides the driver with information about the most recently detected speed limit. The system captures the road sign information with the multi-sensing front camera unit (1) located on the windshield in front of the interior rear-view mirror and displays the detected signs in the Vehicle Information Display.

The speed limit displayed is based on a combination of map data and live camera recognition. When a change of the speed limit is detected, the system notifies the driver with a speed display icon and a warning chime (once). If the vehicle exceeds the speed limit, the system warns the driver by flashing the speed display icon and issues warning chime (four times). The overspeed warning can be cancelled if the driver takes action to slow down or by pushing the <OK> button on the steeringwheel-mounted controls.

A WARNING

- The TSA system is only intended to be a support device to provide the driver with information. It is not a replacement for the driver's attention to traffic conditions or responsibility to drive safely. It cannot prevent accidents due to carelessness. It is the driver's responsibility to stay alert and drive safely at all times.
- Any indications and warnings provided by the TSA system will not override the actual speed limit applicable in a particular situation. It is the driver's responsibility to observe and comply with the speed limits at all times.


The TSA system operates as follows:

- The function will be automatically turned ON when the ignition switch is placed in the ON position.
- If the license of the map data has expired, the map data cannot be used, which means that in some cases the speed limit display cannot be used.

To maintain the road sign display performance of the system, periodic updates of the map data are required. See "How to update the map data" (P.284).


The map data may be automatically updated to the latest version depending on the environment and some conditions

SYSTEM OPERATION



Example

The Traffic Sign Assist system displays the following types of road sign:



TSA: available road signs

A Latest detected speed limit.

- B National speed limit.
- No speed limit information.
- No-overtaking zone.
- End of no-overtaking zone.
- © Conditional speed limit, with the following available conditions:
- (9) Snow
- Towing
- (i) Goods vehicles
- (j) Generic
- k Left turn allowed
- ① Right turn allowed

CAUTION

- The Traffic Sign Assist (TSA) system is intended as an aid to careful driving. It is the driver's responsibility to stay alert, drive safely, and observe all road regulations that currently apply, including looking out for road signs.
- The Traffic Sign Assist (TSA) system may not function properly under all conditions.
 Below are some examples:
 - When the road sign is not clearly visible, for example, due to damage or weather conditions.
 - When rain, snow or dirt adheres to the windscreen in front of the multi-sensing camera unit.
 - When the headlights are not bright due to dirt on the lens or if the aiming is not adjusted properly.


- When strong light enters the camera unit. (For example, the light directly shines on the front of the vehicle at sunrise or sunset.)
- When a sudden change in brightness occurs. (For example, when the vehicle enters or exits a tunnel or under a bridge.)
- When there is poor visibility. (For example, insufficient illumination of the road, bad weather conditions in rain, snow, fog or heavy spray.)
- When the traffic signs are damaged or not standard. (For example, incorrect size, height, direction or brightness, broken or bent.)
- When the traffic signs are hard to detect. (For example, they are covered by dirt or snow, or insufficient lighting.)
- When the traffic signs are ambiguous. (For example, traffic signs on construction sites, in adjacent lanes or exit lane.)
- When there is an object similar to traffic signs. (For example, similar signs, board or structure.)
- When passing traffic signs are outside the camera's field of vision. (For example, after a sharp turn or located too far away.)
- When electric traffic signs are hard to

- detect. (For example, low contrast, located too far away or 3 digits.)
- When overtaking buses or trucks with speed stickers.
- The Traffic Sign Assist (TSA) system may display a traffic sign, even though there is no traffic sign in front of the vehicle. It may display a different speed limit from that for a passenger vehicle. (The maximum speed limit sign may show a higher or lower number than the actual maximum speed, for example, when detecting a speed limit sign for trucks, different speed limit with the time of day or day of the week, or speed limit sign using different units near a border, when detecting an electric traffic sign with or without speed limit indication, when detecting an irrelevant speed limit passing by a freeway exit or junction, etc.)

NOTE:

The TSA system may not work properly after replacing the battery in the area/environment where the reception of the GNSS (Global Navigation Satellite System) signals is weak, such as in a garage. Restart the engine where GNSS signal is available.

HOW TO ENABLE/DISABLE THE TRAFFIC SIGN ASSIST (TSA) SYSTEM



- (1) Steering-wheel mounted controls (left side)
- (2) Vehicle Information Display
- (3) Shortcut button

Perform either of the following steps to enable or disable the TSA system, or customize the settings:

Push the \blacktriangleleft , \blacktriangleright buttons until [Settings] appears

Select [Traffic Sign] and push the <OK> button to turn the system on or off.

Shortcut Menu

- Push the shortcut button (3) on the steering wheel to display [Shortcut Menu].
- Select [Driver Assist Custom] and push the <OK> button to enable the system settings.
- Select [Custom Mode Setup] and push the <OK> button to customize the settings.

[Speed Limit]

- [Warning]: both the speed limit display and overspeed warning function (display and chime) are enabled.
- [Info Only]: only the speed limit display is enabled (overspeed alarm sound and flashing display are disabled).
- [OFF]: the Traffic Sign Assist (TSA) is disabled.

[New Limit Alert]

Notification (chime) when the speed limit changes is enabled or disabled.

Settings

- Push the ' ◀ ' and ' ▶ ' button until [Settings] appears in the Vehicle Information Display and then push the <OK> button. Use the ' ▲ ' and ' ▼ ' to select [Driver Assistance]. Then push the <OK> button.
- Select [Traffic Sign Assist]. Then push the <OK> button.

The following items are available:

[Speed Limit]

The Traffic Sign Assist (TSA) can be customized or turned off.

- [Warning]: both the speed limit display and overspeed warning function (display and chime) are enabled.
- [Info Only]: only the speed limit display is enabled (overspeed alarm sound and flashing display are disabled).
- [OFF]: the Traffic Sign Assist System (TSA) is disabled.

[New Limit Alert]

Notification (chime) when the speed limit changes is enabled or disabled.

[Database Version]

The version of the map data can be confirmed.

[Update by USB]

This is used to update the map data. (See "How to update the map data" (P.284).)

[License Information]

The map license information can be confirmed.

- [License Expiration]: The expiry date of the map license.
- [License State]: The state (active/inactive) of the current map license.

When the overspeed warning function is disabled, the M mark is shown in the vehicle information display. (The indicator will turn off after a period of time.)

When both the speed limit display and overspeed warning function are disabled, the R mark is shown in the Vehicle Information Display.

SYSTEM TEMPORARILY UNAVAILABLE

Condition A

If the vehicle is parked in direct sunlight under high temperature conditions (over approximately 40°C (104°F)) and then started, the TSA system may be deactivated automatically. The [Unavailable Camera Temperature High] warning message will appear in the vehicle information display.

Action to take:

When the interior temperature is reduced, the TSA system will resume operating automatically.

Condition B

In the following conditions, the [Temporarily Disabled Camera Blocked See Owner's Manual] warning message will appear in the vehicle information display and the system will be turned off automatically.

- The camera area of the windshield is covered with moisture, snow, ice, dirt or some other object.
- The camera area of the windshield is continuously covered with dirt, etc.

Action to take:

Check that the windshield is clean and free from ice/mist in front of the camera. If necessary, operate the Max defogging/defrosting function or heated windshield (where fitted) to clear. This may take several minutes.

When the above conditions no longer exist, the TSA system will resume automatically.

Condition C

If the data communication between systems is temporarily interrupted for some reason, the indicator (yellow) and the [Currently Unavailable] warning message will appear in the vehicle information display.

Action to take:

If the warning message appears, pull off the road to a safe location and stop the vehicle. Turn the engine off and restart the engine. If the warning message continues to appear, have the TSA system checked. It is recommended you visit a NISSAN dealer for this service.

If the vehicle is parked in direct sunlight under high temperature conditions (over approximately 40°C (104° F) and then started, the TSA system may be deactivated automatically. The TSA warning message will appear in the Vehicle Information Display.

When the interior temperature is reduced, the TSA system will resume operating automatically.

SYSTEM MALFUNCTION

If the TSA system malfunctions it will be turned off automatically and the 🦃 (yellow) and the [System fault See Owner's Manual] warning message appears in the Vehicle Information Display.

Action to take:

If the warning message appears, pull off the road at a safe location and stop the vehicle. Turn the engine off and restart the engine. If the warning message continues to appear, it is recommended you visit a NISSAN dealer for this service.

MAINTENANCE


The TSA system uses the same camera unit that is used by the Lane Assist system, located in front of the interior rear view mirror. For maintenance of the camera, see "System malfunction" (P.220).

HOW TO UPDATE THE MAP DATA


The map data used for the TSA system can be updated by downloading a new map data to a USB memory device and installing it in the vehicle.

For map data update, some equipment is necessary depending on the model. Please visit https:// nissan.navigation.com/nissan-road-database-update.

For detailed specification and recommended products, please contact a NISSAN dealer or qualified workshop.



Left hand drive



Right hand drive

COLD WEATHER DRIVING

NOTE:

- The vehicle information display cannot be operated while the map is being updated.
- The map data should be updated while the engine is running to prevent discharge of the 12-volt battery.
- This USB port (for TSR map update) cannot be used for charging an external device.

A WARNING

- Whatever the conditions, drive with caution. Accelerate and decelerate with great care. If accelerating or decelerating too fast, the drive wheels will lose even more traction.
- Allow more stopping distance in cold weather driving. Braking should be started sooner than on dry surfaces.
- Keep at a greater distance from the vehicle in front of you on slippery roads.
- Wet ice (0°C, 32°F and freezing rain), very cold snow and ice can be slick and very difficult to drive on. The vehicle will have a lot less traction or grip under these conditions. Try to avoid driving on wet ice until the road is salted or sanded.
- Watch for slippery spots (black ice). These may appear on an otherwise clear road in shaded areas. If a patch of ice is seen ahead, brake before driving on it. Try not to brake while actually on the ice and avoid any sudden steering manoeuvres.
- Do not use cruise control (where fitted) on slipperv roads.
- Snow can trap dangerous exhaust gas under your vehicle. Keep snow clear of the exhaust pipe and from around your vehicle.

BATTERY

If the battery is not fully charged during extremely cold weather conditions, the battery fluid may freeze and damage the battery. To maintain maximum efficiency, the battery should be checked regularly. For details, see "Battery" (P.324).

ENGINE COOLANT

If the vehicle is to be left outside without antifreeze, drain the cooling system. Refill before operating the vehicle. For details, see "Engine cooling system" (P.317).

INVERTER COOLANT / BATTERY COOLANT

If the vehicle is to be left outside without antifreeze, drain the cooling system. Refill before operating the vehicle. For details, see "Inverter coolingBattery cooling system" (P.318).

TYRE EQUIPMENT

- 1. The SUMMER tyres are of a tread design to provide superior performance on dry surfaces. However, the performance of these tyres will be substantially reduced in snowy and icy conditions. If you operate your vehicle on snowy or icy roads, NISSAN recommends the use of MUD & amp: SNOW or ALL SEASON tyres on all four wheels. Please consult a NISSAN dealer or qualified workshop for tyre type, size, speed rating and availability information.
- 2. For additional traction on icy roads, studded tyres may be used. However, some countries, provinces and states prohibit their use. Check applicable laws before installing studded tyres.

CAUTION

Skid and traction capabilities of studded snow tyres on wet or dry surfaces may be poorer than that of non-studded snow tyres.

Snow chains may be used, if desired. But the use of snow chains may be prohibited in some areas. Therefore, check the local laws before installing snow chains. When installing snow chains, make sure they are of proper size for the tyres on your vehicle and are installed according to the snow chain manufacturer's instructions. Use chain tensioners when recommended by the snow chain manufacturer to ensure a tight fit. Loose end links of the snow chain must be secured or removed to prevent the possibility of whipping action damage to the wings or undercarriage. In addition, drive at a reduced speed, otherwise, your vehicle may be damaged and/or vehicle handling and performance may be adversely affected

SPECIAL WINTER EQUIPMENT

It is recommended to carry the following items in the vehicle during winter:

- A scraper and stiff-bristled brush to remove ice and snow from the windows.
- A sturdy, flat board to be placed under the jack to give it firm support.
- A shovel to dig the vehicle out of snowdrifts.

Extra windscreen washer fluid to refill the reservoir tank.

CORROSION PROTECTION

Chemicals used for road surface de-icing are extremely corrosive and will accelerate corrosion and the deterioration of underbody components such as the exhaust system, fuel and brake lines, brake cables, floor pan, and wings.

In the winter, the underbody must be cleaned periodically. For additional information, see "Corrosion protection" (P.310).


For additional protection against rust and corrosion, which may be required in some areas, consult a NISSAN dealer or qualified workshop.

6 In case of emergency

Hazard warning flasher switch	288
Emergency services call eCall/SOS system	
(where fitted)	288
Automatic eCall	288
Manual eCall (SOS button)	290
System status indicator	290
Modalities for exercising data subject's rights	291
Event Data Recorder (EDR) (where fitted)	291
Spare tyre	292
Temporary-use spare tyre (where fitted)	292
Flat tyre	292
Stopping the vehicle	292
Changing flat tyre (Models with spare wheel, whe	ere
fitted)	293

Tyre Pressure Monitoring System (TPMS) (where fitted)	296
Repairing flat tyre (Models with emergency tyre puncture repair kit)	298
Jump-starting	300
Push starting	30
f your vehicle overheats	302
Fowing your vehicle	303
Towing precautions	303
Recommended towing	303
Towing eye	303
Freeing the vehicle from sand, snow or mud	304

HAZARD WARNING FLASHER SWITCH



blink automatically depending on the force of impact.

The hazard warning flasher switch operates regardless of the ignition position except when the battery is discharged.

The hazard warning flasher is used to warn other drivers when you have to stop or park under emergency conditions.

When the hazard warning flasher switch is pushed, all turn signal lights will flash. To turn off the hazard warning flasher, push the hazard warning flasher switch again.

When an impact that could activate the supplemental air bags is detected, the hazard warning flasher lights blink automatically. If the hazard warning flasher switch is pushed, the hazard warning flashers will turn off.

A WARNING

Do not turn the hazard warning flasher switch off until you can make sure that it is safe to do so. Also, the hazard warning flasher may not

EMERGENCY SERVICES CALL ECALL/SOS SYSTEM (where fitted)

Your vehicle is equipped with the 112-based invehicle emergency services call system (eCall). In the event of a serious road accident emergency an automatic call can be made to the emergency services operator. The system can also be used manually to call the emergency services operator.

The 112-based eCall service is a public service of general interest and is accessible free of charge.

NISSAN is responsible only for the emergency communication system technical performance in the event of an accident within the warranty period.

AUTOMATIC ECALL

If the air bag control unit detects a frontal collision, side collision or rear collision (where fitted) the system automatically places an emergency call to the emergency call centre. At the same time, the vehicle information is also transferred. Once an emergency call is received by the emergency call centre, the operator tries to talk to the vehicle's occupant.

NOTE:

- During the emergency call, the volume of the voice of the operator cannot be adjusted.
- During the emergency call, the volume of the vehicle audio will be muted.

The eCall system is always enabled by default. It is activated automatically by means of in-vehicle sensors in the event of a severe accident.

The eCall system is not traceable and is not subject to any constant tracking in its normal operational status. Data in the internal memory of the system

is not available outside the in-vehicle system to any entities before the eCall is triggered.

Any processing of personal data through the 112-based eCall in-vehicle system shall comply with the personal data protection rules provided for in Directives 95/46/EC and 2002/58/EC of the European Parliament and of the Council, and in particular, shall be based on the necessity to protect the vital interests of the individuals in accordance with Article 7(d) of Directive 95/46/EC.

Processing of such data is strictly limited to the purpose of handling the emergency eCall to the single European emergency number 112.

Recipients of data processed by the 112-based eCall in-vehicle system are the relevant public safety answering points designated by the respective public authorities of the country on which territory they are located, to first receive and handle eCalls to the single European emergency number 112

The following information will be sent to the emergency call centre by the vehicle emergency call system if a collision occurs:

- Vehicle Identification Number (VIN)
- Vehicle type
- Fuel type
- Activation type (Automatic/Manual)
- Call type (Test/Emergency)
- Position (Trusted/Low confidence)
- Time stamp (when the collision or event occurred)

- Last three vehicle locations, and vehicle direction
- Vehicle speed
- (where fitted) Number of passengers

The 112-based eCall in-vehicle system is designed in such a way as to ensure that data in the system internal memory is automatically and continuously removed.

The vehicle location data is constantly overwritten in the internal memory of the system so as always to keep maximum of the last three up-to-date locations of the vehicle necessary for the normal functioning of the system.

The log of activity data in the 112-based eCall invehicle system is kept for no longer than necessary for attaining the purpose of handling the emergency eCall and in any case not beyond 13 hours from the moment an emergency eCall was initiated

CAUTION

- The automatic emergency call will only be triggered if the vehicle air bag system is activated during the collision.
- If the automatic emergency call has been triggered, please bring your vehicle to a NISSAN dealer or qualified workshop. This is necessary because the automatic emergency call system needs to be reset to avoid any unintended eCall being made.
- The mobile network provider that manages the connection from the vehicle to the emergency call centre is specified and

controlled outside of the vehicle emergency call system.

• Within the first minute of any emergency call the operator will determine if the call is genuine. Should the operator determine it is a non-genuine call they will stop the call, making no further attempts to call the vehicle back. This action does not prevent the occupant(s) of the vehicle from making a further manual emergency call.

The emergency call function cannot be used in the following conditions:

- The vehicle is outside the area where mobile network service is receivable.
- The vehicle is in a location with poor signal reception such as tunnels, underground parking garages, between buildings or in mountainous areas.
- The TCU (Telematics Control Unit) or other systems of your vehicle are not working properly.
- The available mobile network provider at the location of the vehicle is not specified for emergency call usage.
- The communication line of the emergency call centre is busy.


MANUAL ECALL (SOS button)

The manual eCall can be performed with the ignition switch placed in the ON position, by pushing the <SOS> call button (3) located on the overhead control panel.

After the ignition switch is placed in the OFF position, if an emergency call was not made, the eCall system is turned off.

CAUTION

- Park the vehicle in a safe location and apply the parking brake before operating the <SOS> button.
- Use this service only in case of an emergency. There may be a penalty for inappropriate use of the service.



- Place the ignition switch in the **ON** position.
- Push 1 to open the <SOS> cover 2. 2


- Push the **<SOS>** button 3. An emergency call is sent to the emergency call centre. At the same time, the vehicle information is also transferred.
- When the call is connected, you can speak to the emergency support staff.

If you want to cancel the emergency call, push and hold the <SOS> button for a few seconds. The call cannot be cancelled after connection.

NOTE:

- During the emergency call, the volume of the voice of the operator cannot be adjusted.
- During the emergency call, the volume of the vehicle audio will be muted.
- After the <SOS> button is pushed, it may take some time until the system initiates connection, depending on the technical environment and whether the TCU is being used by other services.
- To avoid disconnecting the call, do not turn the hybrid system off.
- During the emergency call Bluetooth® Hands-Free Phone connection will be disabled and phone operation will only be available by mobile phone.
- If the emergency call is disconnected for some reason the emergency call centre may call back. This action does not prevent the occupant(s) of the vehicle from making another manual emergency call.

SYSTEM STATUS INDICATOR



The indicator lights (4) and (5) above the <SOS> button indicate the status of the vehicle emergency call system. If the indicator light is illuminated red or no indicator light is illuminated the emergency call may not connect to the emergency call centre when the <SOS> button is pressed. Also an automatic emergency call may not be sent when a collision occurs

- During vehicle start up the system operates self diagnostics and the red indicator light is illuminated for up to 15 seconds.
- At any other time if the red indicator light is illuminated contact a NISSAN dealer or qualified workshop for assistance. In the event of a critical system failure that would disable the 112-based eCall in-vehicle system, the red indicator light is illuminated as a warning.

EVENT DATA RECORDER (EDR) (where fitted)

NOTE:

If the indicator light is illuminated red or no indicator light is illuminated, emergency services (such as the police or other agencies) should be contacted using other normal communication devices (for example a phone) in the event of an accident.

MODALITIES FOR EXERCISING DATA SUBJECT'S RIGHTS.

The data subject (the vehicle's owner) has a right of access to data and as appropriate to request the rectification, erasure or blocking of data, concerning him or her, the processing of which does not comply with the provisions of Directive 95/46/EC. Any third parties to whom the data have been disclosed have to be notified of such rectification, erasure or blocking carried out in compliance with this Directive, unless it proves impossible or involves a disproportionate effort.

The data subject has a right to complain to the competent data protection authority if he or she considers that his or her rights have been infringed as a result of the processing of his or her personal data

This vehicle is equipped with an Event Data Recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dvnamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating:
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.
- Sounds are not recorded.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.


NOTE:

EDR data are recorded by your vehicle only if a nontrivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g. name, gender, age and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special

equipment is required and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer and NISSAN certified dealer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR. EDR data will only be accessed with the consent of the vehicle owner or lessee or as otherwise required or permitted by law.

FI AT TYRE



Temporary use spare tyre label

TEMPORARY-USE SPARE TYRE (where fitted)

The temporary-use spare tyre is designed for emergency use only. This spare tyre should be used ONLY for very short periods and NEVER be used for long drives or extended periods.

Observe the following precautions if the temporary-use spare tyre must be used, otherwise your vehicle could be damaged or involved in an accident.

A WARNING

Any continuous road use of this tyre could result in tyre failure, loss of vehicle control, and possible personal injury.

CAUTION

The temporary-use spare tyre should be used only in emergencies. It should be replaced by the standard tyre at the first opportunity.

- Drive carefully and do not drive your vehicle faster than 80 km/h (50 MPH).
- Avoid driving over obstacles, Also, do not take the vehicle through an automatic car wash.
- Avoid driving sharp turns and abrupt braking.
- Do not exceed the vehicle's maximum load rating or the load-carrying capacity molded on the sidewall of the temporaryuse spare tyre.
- Do not use a snow chain on this tyre because it will not fit properly. This could cause damage to the vehicle and result in loss of the chain.
- Do not use the temporary-use spare tyre on any other vehicle because this tyre has been designed specifically for your vehicle.
- The vehicle must not be driven with more than one temporary-use spare tyre at the same time.
- Do not tow a trailer.
- As with all tyres, the temporary-use spare tyre must be checked regularly to ensure pressure is maintained.

For pressure details, see the tyre placard located on the driver's side centre pillar.

In case of a flat tyre, follow the instructions as described below:

STOPPING THE VEHICLE

A WARNING


- Make sure that the parking brake is securely applied.
- For Manual Transmission (MT) models: Make sure the shift lever is in the R (Reverse) position.

For Automatic (DCT) models: Make sure that the shift lever is in the P (Park) position.

- Never change tyres when the vehicle is on a slope, ice or a slipperv area. This is hazardous.
- Never change tyres if oncoming traffic is close to your vehicle. Wait for professional road assistance.
- Safely move the vehicle off the road, away from traffic.
- Switch on the hazard warning flashers.
- Park on a level surface.
- Apply the parking brake.
- Shift the shift lever (MT models) into the R (Reverse) position (Automatic (DCT) models, move the shift lever to the P (Park) position).
- 6. Turn off the hybrid system.
- 7. Open the bonnet (for details, see "Bonnet" (P.137)) in order to:

- Warn other traffic
- Signal to professional road assistance that you require assistance.
- 8. Have all passengers exit the vehicle and stand in a safe place, away from traffic and clear of the vehicle.

CHANGING FLAT TYRE (Models with spare wheel, where fitted)



Blocking the wheels

A WARNING


Make sure to block the appropriate wheel to prevent the vehicle from moving, which may cause personal injury.

Place suitable blocks (1) in front of and behind the wheel diagonally opposite the flat tyre (A) to prevent the vehicle from moving when it is on the jack.

Getting the tools and spare wheel


The spare wheel, jack and tools are located inside the luggage compartment.





- Open the tailgate.
- Remove the luggage boards and luggage compartment floor cover.

- Remove the retainer by turning it anticlockwise.
- Remove the jack, tools and spare wheel. 4.



Removing wheel cover (where fitted)

A WARNING

Take care when removing the wheel cover as the cover may detach suddenly.


Remove the wheel covers as illustrated with a suitable tool or carefully remove the wheel covers with both hands.

Removing the wheel

A WARNING

- Make sure to read the caution label attached to the jack body before use.
- DO NOT GET UNDER A VEHICLE THAT IS SUPPORTED BY A JACK.

- Never use a jack which was not provided with vour vehicle.
- The lack, which is provided with your vehicle is designed only to lift your vehicle during a tyre change.
- Use the correct jacking points. Never use any other part of the vehicle for jack support.
- Never lift the vehicle more than necessary.
- Never use blocks on or under the iack.
- Do not start the hybrid system while the vehicle is on the jack. The vehicle may move suddenly, and this may cause an accident.
- Never allow passengers to stay in the vehicle while the tyre is off the ground.
- Make sure to read the caution label attached to the jack body before use.
- Remove all loads before lifting the vehicle with the jack.



Jack-up points


Place the jack directly under the jack-up point as illustrated so that the top of the jack contacts the vehicle at the jack-up point.

CAUTION

The jack should be placed on firm level ground.

- Align the centre of both the jack head and the notches at the jack-up point as shown.
- Fit the groove of the lack head between the two notches as shown

Alloy wheels (where fitted): Alloy wheel bolts have a plastic cap that can be removed using tweezers (where fitted) from the tool kit.



Loosen each wheel bolt by one or two turns anticlockwise with the wheel wrench.


Do not remove the wheel bolts until the tyre is off the ground.

Models with wheel lock bolts (where fitted): If the wheel is equipped with a wheel lock bolt, insert the wheel lock key (1) and loosen it as previously described.

The wheel lock bolt can only be removed with the wheel lock key. A key number is necessary if you need to duplicate the wheel lock key.

Record the key number as shown on the key code card on the "Security information" page at the end of this manual and keep it in a safe place, not in the vehicle. If you lose the wheel lock key, see your NISSAN dealer for a duplicate with the original wheel lock key code

Make sure to keep the lock key in the vehicle. Otherwise, wheels cannot be removed and the service cannot be performed.



- To lift the vehicle, securely hold and turn the handle clockwise as shown.
- Carefully raise the vehicle until the tyre clears the ground.

Remove the wheel bolts, then remove the wheel with the flat tyre.


CAUTION

The wheel is heavy. Be sure that your feet are clear of the wheel and use gloves as necessary to avoid injury.

Installing the wheel

A WARNING

- The temporary use spare tyre (where fitted) is designed for emergency use. See "Spare tyre" (P.292).
- Never use wheel bolts other than those provided with your vehicle. Incorrect wheel bolts or improperly tightened wheel bolts may cause the wheel to become loose or come off. This could cause an accident.
- Never use oil or grease on the wheel bolts.
 This may cause the wheel bolts to become loose.



- A Tighten
- B Loosen
- Clean any mud or dirt from the surface between the wheel and the hub.
- Carefully fit the wheel and tighten the wheel bolts with your fingers. Check that all the wheel bolts contact the wheel surface horizontally and on the bevelled side.

Models with wheel lock bolt (where fitted):

Insert the wheel lock key into the wheel lock bolt and tighten into the wheel finger tight.

- With the wheel wrench, tighten the wheel bolts alternately and evenly in the sequence as illustrated (①-⑤) until they are tight.
- Lower the vehicle slowly until the tyre touches the ground.
- Tighten the wheel bolts securely using the wheel wrench in the sequence as illustrated.
- Lower the vehicle completely.
- 7. Install the wheel cover (where fitted).

NOTE:

Before installation, align NISSAN logo (centre cap) with the wheel bolts/or perpendicular to valve hole (where fitted), to correctly align to the centre.

Wheel bolt tightening torque:

113 N·m (12 kg-m, 83 ft-lb)

As soon as possible, tighten the wheel bolts to the specified torque with a torque wrench.

A WARNING

Retighten the wheel bolts after the vehicle has been driven for 1.000 km (600 miles) (also in cases of a flat tyre, etc.).

The wheel bolts must be kept tightened to specification at all times. It is recommended that the wheel bolts be tightened to specification at each maintenance interval

Adjust the tyre pressure to the COLD pressure.

COLD pressure is the tyre pressure as measured after the vehicle has been parked for three hours or more or driven for less than 1.6 km (1 mile).

COLD tyre pressures are shown on the tyre placard affixed to the driver's side centre pillar.


Stowing the wheel and tools

Securely store the wheel with the flat tyre, the jack and the tools in the specified storage areas.

Wheel lock bolts (where fitted)

In order to prevent theft, a specially designed wheel lock bolt is installed on each wheel. The wheel lock bolt cannot be removed with the commonly used tools.

When removing tyres, use the lock key provided with your vehicle.



Removing the wheel lock bolt:

- Insert the wheel lock key (1) to the wheel lock bolt.
- To remove the wheel lock bolt, turn the wheel lock key anticlockwise using the wheel wrench.

CAUTION


- Do not use a power tool to remove the wheel lock bolts.
- When installing the wheel, tighten the wheel lock bolts to the same tightening torque as the normal wheel bolts. For details, see "Installing the wheel" (P.295).

NOTE:

The wheel lock bolt has an individual code. A wheel lock key with other than the individual code cannot remove the wheel lock bolt. If you lose the wheel lock key, contact a NISSAN dealer for a duplicate with the original wheel lock key code.

- Record the key number as shown on the key code card on the "Security information" page at the end of this manual and keep it in a safe place, not in the vehicle.
- When you ask for a service at a NISSAN dealer or qualified workshop, make sure to keep the lock key in the vehicle. Otherwise, wheels cannot be removed and the service cannot be performed.

TYRE PRESSURE MONITORING SYSTEM (TPMS) (where fitted)



Tyre valve with sensor

A WARNING

- If the TPMS indicator light illuminates while driving:
 - avoid sudden steering manoeuvres
 - avoid abrupt braking
 - reduce vehicle speed
 - pull off the road to a safe location
 - stop the vehicle as soon as possible

- Driving with under-inflated tyres may permanently damage the tyres and increase the likelihood of tyre failure. Serious vehicle damage could occur which may lead to an accident and could result in serious personal injury.
- Check the tyre pressure for all four tyres. Adjust the tyre pressure to the recommended COLD tyre pressure shown on the tyre placard to turn the TPMS indicator light "OFF". In case of a flat tyre, replace it with a spare tyre as soon as possible.
- When a spare tyre is mounted or a wheel is replaced, the TPMS will not function and the TPMS indicator light will flash for approximately 1 minute. The light will remain on after 1 minute. Be sure to follow all instructions for wheel replacement and make sure the TPMS system is mounted correctly.
- Replacing tyres with those not originally specified by NISSAN could affect the proper operation of the TPMS.
- The Genuine NISSAN Emergency Tyre Repair Sealant can be used for temporarily repairing a tyre. Do not inject any other tyre liquid or aerosol tyre sealant into the tyres, as this may cause a malfunction of the tyre pressure sensors.
- NISSAN recommends using only Genuine NISSAN Emergency Tyre Sealant provided with your vehicle. Other tyre sealants may damage the valve stem seal which can cause the tyre to lose air pressure. Visit a

NISSAN dealer or qualified workshop as soon as possible after using tyre repair sealant (for models equipped with the emergency tyre puncture repair kit).

CAUTION

- The TPMS may not function properly when the wheels are equipped with tyre chains or the wheels are buried in snow.
- Do not place metalised film or any metal parts (antenna, etc.) on the windows. This may cause poor reception of the signals from the tyre pressure sensors, and the TPMS will not function properly.

Some devices and transmitters may temporarily interfere with the operation of the TPMS and cause the TPMS indicator light to illuminate. Some examples are:

- Facilities or electric devices using similar radio frequencies are near the vehicle.
- If a transmitter set to similar frequencies is being used in or near the vehicle.
- If a computer (or similar equipment) or a DC/AC converter is being used in or near the vehicle.
- When inflating the tyres and checking the tyre pressure, never bend the valves.
- Use Genuine NISSAN valve caps that comply with the factory-fitted valve cap specifications.

- Do not use metal valve caps.
- Fit the valve caps properly. Without the valve caps the valve and tyre pressure monitor sensors could be damaged.
- Do not damage the valves and sensors when storing the wheels or fitting different tvres.
- Replace the TPMS sensor valve stem (including valve core and cap) and screw (where fitted) when the tyres are replaced due to wear or age. The screw (where fitted) must be fitted correctly with a torque setting of 1.4 ± 0.1 N.m. The TPMS sensors can be used again.

The Tyre Pressure Monitoring System (TPMS) monitors the tyre pressure of the four wheels except the spare wheel. When the TPMS indicator light comes on together with the TPMS tyre location indicator light (in the meter panel), one or more of the tyres is significantly under-inflated. If the vehicle is being driven with low tyre pressure, the TPMS will activate and TPMS indicator light together with the TPMS tyre location indicator light remains on. This system will deactivate only when tyre pressure is corrected and the vehicle is driven at speeds above 25 km/h (16 MPH).

For more details about the TPMS, see "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186).

REPAIRING FLAT TYRE (Models with emergency tyre puncture repair kit)


The emergency tyre puncture repair kit is supplied with the vehicle instead of a spare tyre. This repair kit must be used for temporarily fixing a minor tyre puncture. After using the repair kit, see a NISSAN dealer or qualified workshop as soon as possible for tyre inspection and repair/replacement.

CAUTION

Do not use the emergency tyre puncture repair kit under the following conditions. Contact a NISSAN dealer or qualified workshop or professional road assistance.

- when the sealant has passed its expiration date (shown on the label attached to the bottle)
- when the cut or the puncture is approximately 4 mm (0.16 in) or longer
- when the side of the tyre is damaged
- when the vehicle has been driven with a considerable loss of air from the tyre
- when the tyre is completely displaced inside or outside the rim
- when the tyre rim is damaged
- when two or more tyres are flat

Getting emergency tyre puncture repair kit



Take the emergency tyre puncture repair kit out of the boot. The repair kit consists of the following items:

- (T) Tyre sealant bottle
- Air compressor
- Speed restriction sticker


NOTE:

For models with the emergency tyre puncture repair kit, a spare tyre, lack and rod are not equipped as standard. These parts are dealer options. Contact a NISSAN dealer or qualified workshop about obtaining these parts. See "Removing the wheel" (P.293) for usage of jacking tools and tyre replacement.

Before using emergency tyre puncture repair kit


If any foreign object (for example, a screw or nail) is embedded in the tyre, do not remove it. Check the expiration date of the sealant (shown on the label attached to the bottle). Never use a sealant which has passed its expiration date.

Repairing tyre




Shake the sealant bottle well ①.

- 2. Remove the bottle cap 3 and the orange plug (2) from the top of the compressor.
- 3. Screw the bottle 4 into the opening of the compressor (where the orange plug was).



Remove the speed restriction sticker from the compressor, then place it in a location where the driver can see it while driving.



- 5. Screw the air tube (A) of the compressor securely onto the tyre valve. Make sure that the air compressor switch is in the "OFF" position and the pressure release valve (B) is securely closed.
- 6. Insert its power plug into the power outlet in the vehicle. Make sure no other accessories are fitted to the power outlet. For details, see "Power outlet" (P.113).
- Start the hybrid system.
- Switch on the compressor, and inflate the tyre to the pressure that is specified on the tyre placard affixed to the driver's side centre pillar.

CAUTION

Do not operate the compressor for more than 10 minutes.

If the tyre pressure does not increase to the specified pressure within 10 minutes, the tyre may be seriously damaged and the tyre cannot be repaired with this tyre repair kit. Contact a NISSAN dealer or qualified workshop. Contact a NISSAN dealer or qualified workshop.

- 9. Remove the air compressor from the tyre valve. Immediately drive the vehicle at a speed of 80 km/h (50 MPH) or less.
- 10. After 10 minute or 10 km (6 miles) drive, check the tyre pressure. The temporary repair is completed if the tyre pressure does not drop.


If the tyre pressure is lower than specified, repeat the steps from step 5.

If the pressure drops again or under 130 kPa (1.3) bar, 19 psi), the tyre cannot be repaired with this tyre repair kit. Contact a NISSAN dealer or qualified workshop.

After repairing tyre

See a NISSAN dealer or qualified workshop for tyre repair/replacement, inspection/replacement of the TPMS sensor and for a new tyre sealant bottle and hose, as soon as possible.

JUMP-STARTING



A WARNING

- Incorrect jump-starting can lead to a battery explosion. The battery explosion may result in severe injury or death. It may also result in damage to the vehicle. Be sure to follow the instructions in this section.
- Explosive hydrogen gas is always present

in the vicinity of the battery. Keep all sparks and flames away from the battery.

- Always wear suitable eye protection glasses and remove rings, bracelets, and any other jewellery whenever working on or near a battery.
- Never lean over the battery while jumpstarting.

- Never allow battery fluid to come into contact with eyes, skin, clothes or the vehicle's painted surfaces. Battery fluid is a corrosive sulphuric acid which can cause severe burns. If the fluid comes into contact with anything, immediately flush the contacted area with plenty of water.
- Keep the battery out of the reach of children.
- The booster battery must be rated at 12 volts. Use of an incorrectly rated battery will damage your vehicle.
- Never attempt to jump-start a frozen battery. It could explode and cause serious injury.
- Check if the parking brake is applied.

If not, after connecting the vehicle with the booster battery (after step 8), apply the parking brake.

The vehicle has an electric parking brake, for more information, see "Electric parking brake" (P.138).

2. Prepare vehicle (A) with the booster battery for the vehicle (B) being jump-started.

CAUTION

Do not allow the two vehicles to touch.

- 3. Move the shift lever to the P (Park) position.
- 4. Switch off all unnecessary electrical systems (headlights, hazard lights, etc.).

PUSH STARTING

- Ensure that the ignition switch of the vehicle being jump-started is in the LOCK position.
- Open the bonnet. For details, see "Bonnet" (P.137).
- 7. Remove the positive terminal cover.
- 8. Connect the jump leads in the sequence (1) \rightarrow (2) \rightarrow (3) \rightarrow (4)) as illustrated.

CAUTION

- Always connect positive ⊕ to positive ⊕ and negative ⊝ to negative ⊝.
- An incorrect connection could damage the charging system.
- Be sure that the jumper cables do not touch moving parts in the engine compartment.
- Be careful not to allow contact between the positive jump lead connector and the vehicle or the negative lead during connection and disconnection.
- Start the engine of the other vehicle (A) and let it run for a few minutes. Keep the engine speed at about 2,000 rpm.
- Start the hybrid system of your vehicle (B) in the normal way.

CAUTION

Do not keep the starter motor engaged for more than 10 seconds. If the hybrid system does not start immediately, turn the ignition switch to "OFF" and wait 10 seconds before trying again.

- 11. After starting the hybrid system of your vehicle, carefully disconnect the negative lead and then the positive lead ($\textcircled{4} \rightarrow \textcircled{3} \rightarrow \textcircled{2} \rightarrow \textcircled{1}$).
- Remove and dispose of the cloth that was used to cover the vent holes as it may be contaminated with corrosive acid.
- 13. Install the vent caps (where fitted).
- 14. Close the bonnet.

CAUTION

- Three-way catalyst equipped models should not be started by pushing the vehicle as the three-way catalyst may be damaged.
- Hybrid gearbox models cannot be started by pushing the vehicle. This may cause hybrid gearbox damage.

IF YOUR VEHICLE OVERHEATS

A WARNING

- Never continue driving if the engine of your vehicle overheats. Doing so could cause a vehicle fire.
- Never open the bonnet if steam is coming out.
- Never remove the radiator cap (where fitted) or engine coolant reservoir cap when the engine is hot. If the radiator cap (where fitted) or engine coolant reservoir cap is removed while the engine is hot, pressurised hot water will spurt out and possibly cause burning, scalding or serious injury.
- If steam or coolant is coming out of the engine, stand clear of the vehicle to prevent getting injured.
- The engine cooling fan will start whenever the coolant temperature exceeds preset degrees.
- Be careful not to allow your hands, hair, jewellery or clothing to come into contact with, or get caught in, the cooling fan.

If the engine of your vehicle is overheating (indicated in the vehicle information display or if you feel a lack of engine power, detect unusual noise, etc., proceed as follows:

- Move and park the vehicle safely off the road and away from traffic.
- 2. Turn on the hazard warning flasher lights.

- 3. Apply the parking brake.
- Move the shift lever to the P (Park) position.DO NOT STOP THE HYBRID SYSTEM.
- 5. Open all windows.
- Switch off the air conditioner system (where fitted).
- Set the heater or air conditioner temperature control to maximum "HOT" and fan speed control to maximum speed.
- 8. Exit the vehicle.
- Visually inspect and listen for steam or coolant escaping from the radiator before opening the bonnet. Wait until no steam or coolant can be seen before proceeding.
- Open the bonnet. For details, see "Bonnet" (P.137).
- 11. Visually check if the cooling fan is running.
- 12. Visually check the radiator and radiator hoses for leakage.

A WARNING

If coolant is leaking or the cooling fan is not running, stop the engine.

- After the engine cools down, check the coolant level in the engine coolant reservoir with the engine running. Do not open the radiator cap (where fitted).
- 14. If the level is low, remove the engine coolant reservoir cap and add coolant slowly into the reservoir. After refilling the reservoir to the MAX level, install the reservoir cap.

A WARNING

Before removing the engine coolant reservoir cap and to avoid the danger of being scalded, cover the reservoir cap with a rag and loosen the reservoir cap to the first notch to allow the steam to escape.

15. Close the bonnet.

Have your vehicle inspected or repaired by a NISSAN dealer or qualified workshop.

TOWING YOUR VEHICLE

When towing your vehicle, local regulations for towing must be followed. Incorrect towing equipment could damage your vehicle. To assure proper towing and to prevent accidental damage to your vehicle, NISSAN recommends that you have a service operator tow your vehicle. It is advisable to have the service operator carefully read the following precautions.


A WARNING

- Do not allow any occupants in the vehicle that is being towed.
- Never get under your vehicle after it has been lifted by a tow truck.

TOWING PRECAUTIONS

- When towing: Make sure that the hybrid gearbox, axles, steering system and power train are in working condition before towing. If any units are damaged, the vehicle must be towed using a dolly or be placed on a flat bed lorry.
- Release the parking brake and shift the hybrid gearbox into the N (Neutral) position before starting to tow the vehicle.
- Always attach safety chains before towing.

RECOMMENDED TOWING





CAUTION

NEVER tow hybrid gearbox models with the front wheels on the ground or with all four wheels on the ground (forwards or backwards), this may cause serious and expensive damage to the hybrid gearbox. If it is necessary to tow the vehicle with the rear wheels raised, always use towing dollies under the front wheels.

NISSAN recommends that your vehicle should be towed with the driving (front) wheels off the ground or that the vehicle be placed on a flat bed lorry as illustrated.

TOWING EYE





The towing eye is stored with the vehicle tools and located in the spare wheel recess (luggage compartment area).

- Remove the cover from the bumper.
- Securely install the towing eye, as illustrated. Make sure that the towing eye is properly stored in its designated location after use.

FREEING THE VEHICLE FROM SAND, SNOW OR MUD

A WARNING

- Never allow anyone to stand near the towing line during the pulling operation.
- Never spin the tyres at high speed. This could cause them to explode and result in serious injury. Parts of the vehicle could also overheat and be damaged.

Towing eye usage

The towing eye should be used in the event that your vehicle becomes trapped in sand, snow or mud, and is unable to drive away without being pulled, use the towing eye.

- Use the towing eye only, not other parts of the vehicle. Otherwise, the vehicle body will be damaged.
- **Only** use the towing eye to free a vehicle stuck in sand, snow, mud, etc.
- Never tow the vehicle for a long distance using only the towing eye.
- The towing eye is under tremendous force when used to free a stuck vehicle. Always pull the cable straight out from the front of the vehicle. Never pull on the towing eye at a sideways angle.

CAUTION

In order not to break the towing line, tension it slowly.

7 Appearance and care

Cleaning exterior	306
Washing	306
Removing spots	307
Waxing	307
Cleaning glass	307
Cleaning rear-view camera (where fitted)	307
Underbody	307
Care of wheels	307
Cleaning aluminium alloy wheels	307
Chrome parts	308
Cleaning interior	308
Monitor display's maintenance (where fitted)	308

Air fresheners	308
Floor mats	309
Cleaning Glass	309
Plastic parts	309
Seat belts	309
Corrosion protection	310
Most common factors contributing to	
vehicle corrosion	310
Environmental factors influence the rate	
of corrosion	310
To protect your vehicle from corrosion	310

CLEANING EXTERIOR

In order to maintain the appearance of your vehicle, it is important to take proper care of it.

Whenever possible, park your vehicle inside a garage or in a covered area to minimise the chances of damaging the paint surface of your vehicle.

When it is necessary to park outside, park in a shady area or protect the vehicle with a body cover. Be careful not to scratch the paint surface when putting on or removing the body cover.

WASHING

In the following instances, wash your vehicle as soon as possible to protect the paint surface:

- After a rainfall, which may cause the paint surface damage from acid rain.
- After driving on coastal roads, which may cause rusting from the sea breeze.
- When contaminants such as soot, bird droppings, tree sap, metal particles or bugs get on the paint surface.
- When dust or mud builds up on the paint surface
- Wash the vehicle surface with a wet sponge and plenty of water.
- 2. Clean the vehicle surface gently and thoroughly using a mild soap or a special vehicle wash shampoo mixed with clean, lukewarm (never hot) water.

CAUTION

- Never wash the engine compartment and Lithium-ion battery using a high-pressure jet. This risks damaging the electric circuit.
- Do not wash the vehicle with strong household soap, strong chemical detergents, gasoline or solvents.
- Do not wash the vehicle in direct sunlight or while the vehicle body is hot, as the paint surface may become water-spotted.
- Avoid using tight-napped or rough cloths, such as washing mitts. Care must be taken when removing caked-on dirt or other foreign substances so the paint surface is not scratched or damaged.
- Rinse the vehicle thoroughly with plenty of clean water
- 4. Use a damp chamois to dry the paint surface to avoid leaving water spots.

When washing the vehicle, take care of the followina:

- Inside flanges, joints and folds on the doors. tailgate and bonnet are particularly vulnerable to the effects of road salt. Therefore, these areas must be cleaned regularly.
- Be sure that the drain holes in the lower edge of the doors are not cloqued.
- Spray water on the underbody and in the wheel wells to loosen the dirt and/or wash away road salt.

- If using a high pressure washer always follow the recommendations on the equipment (pressure and spraying distance).
- If there are damaged areas on the vehicle (e.g. painted bumpers or headlight assembly), it is not recommended to direct the high pressure jet onto them. Carefully wash these areas by hand.
- Avoid the entry of water into the locks.

Badges, stripes or graphics (where fitted)

To maintain the premium finish of stickers, stripes and graphics on your vehicle, please observe the following care points:

- Only hand wash the surface, using PH neutral. detergents.
- Do not use an automated car wash.
- Do not use chemical agents (abrasive products, polishes, petrol, wax, protective products, corrosive solvents, etc).
- Wash your vehicle as soon as you can if any insects, bird droppings, soot or metallic particles appear on the paint surface.
- The finish may deteriorate if it is marked by road oil (tar, etc.). Wash any dirt off the vehicle with a wet microfibre cloth and plenty of clean water.
- Avoid parking your vehicle under trees and remove any tree sap as soon as possible.
- Gently wash stickers using a clean sponge. Do not use a pressure washer.

REMOVING SPOTS

Remove tar and oil spots, industrial dust, insects, and tree sap as quickly as possible from the paint surface to avoid lasting damage or staining. Special cleaning products are available at a NISSAN dealer or any automotive accessory store.

WAXING

Regular waxing protects the paint surface and helps to retain a new vehicle appearance.

After waxing, polishing is recommended to remove built-up residue.

A NISSAN dealer or qualified workshop can assist you in choosing the appropriate waxing products.

CAUTION

- Wash your vehicle thoroughly and completely before applying wax to the paint surface.
- Always follow the manufacturer's instructions supplied with the wax.
- Do not use a wax containing any abrasives. cutting compounds or cleaners that may damage the vehicle finish.
- If the vehicle surface cannot polish easily, apply a road tar remover prior to waxing the vehicle.
- Machine compounding or aggressive polishing on a base coat/clear coat paint finish may dull the finish or leave swirl marks.

CLEANING GLASS

Use glass cleaner to remove smoke and dust film from the glass surfaces. It is normal for glass to become coated with a film after the vehicle is parked in the hot sun. Glass cleaner and a soft cloth will easily remove this film.

CLEANING REAR-VIEW CAMERA (where fitted)

Clean the transparent camera cover regularly. If dirt, rain or snow attaches to the cover, the monitor may not display objects clearly.

CAUTION

- Do not use alcohol, benzene or thinner to clean the transparent camera cover. This will cause discolouration. To clean the cover, first use a cloth dampened with diluted mild cleaning agent and then wipe with a dry cloth.
- Do not use body wax on the transparent camera cover.
- When washing the vehicle with a high pressure water spray, make sure not to spray it around the transparent camera cover. Otherwise, water may enter the camera unit causing water condensation on the lens and it may result in a malfunction or an electric shock.

UNDERBODY

In areas where road salt is used in the winter, the vehicle's underbody must be cleaned regularly. This will prevent dirt and salt from building up and causing underbody and suspension corrosion.

Before the winter period and again in the spring, the underseal must be checked and, if necessary, re-treated.

CARE OF WHEELS

- Wash the wheels when washing the vehicle to maintain their appearance.
- Clean the inner side of the wheels when the wheel is changed or the underside of the vehicle is washed.
- Do not use abrasive cleaners when washing the wheels
- Inspect wheel rims regularly for dents or corrosion. This may cause loss of pressure or damage the tyre bead.
- NISSAN recommends that the road wheels be waxed to protect against road salt in areas where it is used during winter.

CLEANING ALUMINIUM ALLOY WHEELS

Wash the wheels regularly with a sponge dampened in a mild soap solution, especially during winter in areas where road salt is used. The salt residue from road salt could discolour the wheels if it is not washed off regularly.

CLEANING INTERIOR

CAUTION

Follow the directions as described below in order to avoid staining or discolouring of the wheels.

- Do not use a cleaner that contains strong contents of acid or alkali to clean the wheels.
- Do not apply wheel cleaner when the wheels are hot. The wheel temperature should be the same as ambient temperature.
- Rinse the wheel to completely remove the cleaner within 15 minutes after the cleaner has been applied.

CHROME PARTS

Clean all chrome parts regularly with a nonabrasive chrome polish to maintain the finish.

Occasionally remove loose dust from the interior trim, plastic parts and seats using a vacuum cleaner or soft bristled brush. Wipe the vinyl and leather surfaces with a clean, soft cloth dampened in mild soap solution, then wipe clean with a dry, soft cloth.

Regular care and cleaning is required in order to maintain the appearance of the leather.

Before using any fabric protector, read the manufacturer's recommendations. Some fabric protectors contain chemicals that may stain or bleach the seat material.

Use a soft cloth dampened only with water to clean the meter and gauge lens covers.

CAUTION

- Never use benzene, thinner or any similar material.
- Small dirt particles can be abrasive and damaging to leather surfaces and should be removed promptly. Do not use saddle soap, car waxes, polishes, oils cleaning fluids, solvents, detergents or ammonia based cleaners as they may damage the leather's natural finish.
- Never use fabric protectors unless recommended by the manufacturer.
- Do not use glass or plastic cleaner on meter or gauge lens covers. It may damage the lens covers.

MONITOR DISPLAY'S MAINTENANCE (where fitted)

- To clean the display screen, first turn the ignition off and wipe it with a dry soft cloth.
- Never use a rough cloth, alcohol, benzene, thinner, any kind of solvent, or paper tissues with chemical cleaning agent. They would scratch or deteriorate the panel.
- Do not splash any liquid such as water or car fragrance on the display. Contact with liquid could cause the system to malfunction and damage the hardware.
- In case of extreme stain, use a small amount of neutral detergent with a soft cloth. Never soak the screen display with water detergent.

AIR FRESHENERS

Most air fresheners use a solvent that could affect the vehicle interior. If you use an air freshener, take the following precautions:


- Hanging-type air fresheners can cause permanent discolouration when they contact vehicle interior surfaces. Place the air freshener in a location that allows it to hang free and not contact an interior surface.
- Liquid-type air fresheners typically clip on the vents. These products can cause immediate damage and discolouration when spilled on interior surfaces

Carefully read and follow the manufacturer's instructions before using air fresheners.

FLOOR MATS

The use of NISSAN floor mats can extend the life of your vehicle carpet and make it easier to clean the interior. Regardless of what mats are used, be sure they are fitted for your vehicle and are properly positioned in the foot well to prevent interference with pedal operation. Mats should be maintained with regular cleaning and replaced if they become excessively worn.

Floor mat positioning aid



Note that the above illustration is for LHD models This vehicle includes front floor mat brackets (A) to act as a floor mat positioning aid. NISSAN floor mats have been specially designed for your vehicle. Position the mat by placing the floor mat bracket hook into the floor mat grommet hole until the mat clips into position on the hooks while centring

the mat in the foot area

Periodically check that the mats are properly positioned.

CLEANING GLASS

Use glass cleaner to remove smoke and dust film from the glass surfaces. It is normal for glass to become coated with a film after the vehicle is parked in the hot sun. Glass cleaner and a soft cloth will easily remove this film.

CAUTION

When cleaning the inside of the windows, do not use sharp-edged tools, abrasive cleaners or chlorine based disinfectant cleaners. They could damage electrical conductors such as the rear window defogger.

Do not stick labels on the inside surface of the glass. Removing stickers and its residue could damage electrical conductors such as the rear window defogger.

Take care that any objects stored in the luggage room, do not come in contact with the inside surface of the rear window. This is to avoid damage to electrical conductors such as the rear window defogger.

Automatic anti-dazzling inside rear-view mirror (where fitted) Use a soft cloth dampened only with water to clean the automatic anti-dazzling inside rear view mirror (where fitted).

CAUTION

Do not use glass cleaner. Doing so will reduce the sensitivity of the sensor, resulting in improper operation.

PLASTIC PARTS

Plastic parts can be cleaned with a mild soap solution. If the dirt cannot be easily removed, use a plastic cleaner. Do not use any solvents.

SEAT BELTS

A WARNING

- Do not allow wet seat belts to roll up in the retractor.
- Never use bleach, dye or chemical solvents to clean the seat belts, since these materials may severely weaken the seat belt webbina.

The seat belts can be cleaned by wiping them with a sponge dampened in a mild soap solution.

Allow the belts to dry completely in the shade before using them.

CORROSION PROTECTION

MOST COMMON FACTORS CONTRI-BUTING TO VEHICLE CORROSION

- The accumulation of moisture-retaining dirt and debris in body panel sections, cavities, and other areas.
- Damage to the paint surface and other protective coatings caused by gravel and stone chips or minor traffic accidents.

ENVIRONMENTAL FACTORS INFLUENCE THE RATE OF CORROSION

Moisture

Accumulation of sand, dirt and water on the vehicle body underside can accelerate corrosion. Wet floor coverings will not dry completely inside the vehicle, and should be removed for drying to avoid floor panels corrosion.

Relative humidity

Corrosion will be accelerated in areas of high relative humidity, especially those areas where the temperatures stay above freezing, where atmospheric pollution exists and road salt is used.

Temperature

A temperature increase will accelerate the rate of corrosion to those parts which are not well ventilated.

Corrosion will also accelerate in areas where the temperatures stay above freezing.

Air pollution

Industrial pollution, the presence of salt in the air in coastal areas, or heavy road salt use will accelerate the corrosion process. Road salt will also accelerate the disintegration of paint surfaces.

TO PROTECT YOUR VEHICLE FROM CORROSION

- Wash and wax your vehicle often to keep the vehicle clean.
- Always check for minor damage to the paint surface and if any exists, repair it as soon as possible.
- Keep the drain holes at the bottom of the doors and back door opened to avoid water accumulation.
- Check the vehicle underbody for accumulation of sand, dirt or salt. If present, wash with water as soon as possible.

CAUTION

- Never remove dirt, sand or other debris from the passenger compartment by washing it out with a hose. Remove dirt with a vacuum cleaner or broom.
- Never allow water or other liquids to come in contact with electronic components inside the vehicle as this may damage them.

Chemicals used for road surface de-icing are extremely corrosive. They accelerate corrosion and deterioration of underbody components such as the exhaust system, fuel and brake lines, brake cables, floor pan and fenders.

In the winter, the underbody must be cleaned periodically.

For additional protection against rust and corrosion, which may be required in some areas, consult a NISSAN dealer or qualified workshop.

8 Maintenance and do-it-yourself

Maintenance requirements	313
Scheduled maintenance	313
General maintenance	313
Where to go for service	313
General maintenance	313
Explanation of general maintenance items	313
Maintenance precautions	315
Engine compartment	316
Engine cooling system	317
Checking engine coolant level	317
Changing engine coolant	317
Inverter cooling / Battery cooling system	318
Checking inverter coolant level	319
Changing inverter coolant	319
Engine oil	320
Checking engine oil level	320
Changing engine oil and oil filter	320
Protect the environment	322
Hybrid gearbox oil	322
Brakes	323
Checking parking brake	323
Checking brake pedal	323
Brake fluid	323
Window washer fluid	324

Battery	32
Vehicle 12v battery	32
Jump-starting	32
Intelligent Key battery replacement	32
Spark plugs	32
Wiper blades	32
Cleaning	32
Front window wiper replacement	32
Tailgate window wiper replacement	32
Windscreen washer nozzle	33
Fuses	33
Passenger compartment	33
Lights	33
Headlights	33
Exterior lights	33
Interior lights	33
Light locations	33
Wheels and tyres	33
Tyre inflation pressure	33
Types of tyres	33
Snow chains	33
Tyre rotation	33
Tyre wear and damage	33
Tyre age	33
Changing tyres and wheels	33

Four-wheel drive (4WD) models	336	Spare tyre	336
Wheel balance	336	Care of wheels	337

MAINTENANCE REQUIREMENTS

Some day-to-day and regular maintenance is essential to maintain your vehicle's good mechanical condition, as well as its emission and engine performance.

It is the owner's responsibility to make sure that the specified maintenance, as well as general maintenance, is performed.

As the vehicle owner, you are the only one who can ensure that your vehicle receives the proper maintenance care.

SCHEDULED MAINTENANCE

For your convenience, the required scheduled maintenance items are described and listed in the separate Warranty Information and Maintenance booklet. You must refer to that booklet to ensure that necessary maintenance is performed on your vehicle at regular intervals.

GENERAL MAINTENANCE

General maintenance includes those items which should be checked during normal day-to-day operation of the vehicle. They are essential if your vehicle is to continue to operate properly. It is your responsibility to perform these procedures reqularly as prescribed.

Performing general maintenance checks requires minimal mechanical skill and a few general automotive tools.

These checks or inspections can be done by yourself, a qualified technician or, if you prefer, your NISSAN dealer or qualified workshop.

WHERE TO GO FOR SERVICE

If maintenance service is required or your vehicle appears to malfunction, have the systems checked and tuned by an authorised NISSAN dealer or qualified workshop.

GENERAL MAINTENANCE

During the normal day-to-day operation of the vehicle, general maintenance should be performed regularly as prescribed in this section. If you detect any unusual sounds, vibrations or smell, be sure to check for the cause or have a NISSAN dealer or qualified workshop do it promptly. In addition, you should notify a NISSAN dealer or qualified workshop if repairs are required.

When performing any checks or maintenance work, closely observe the "Maintenance precautions" later in this section

EXPLANATION OF GENERAL MAINTENANCE ITEMS

Additional information on the following items with an asterisk (*) is found later in this section.

The maintenance items listed here should be performed from time to time, unless otherwise specified.

Outside the vehicle

Tailgate, doors and bonnet:

Check that the tailgate, all doors and the bonnet operate properly. Also ensure that all latches lock securely. Lubricate hinges and latches if necessary. Make sure that the secondary latch keeps the bonnet from opening when the primary latch is released.

When driving in areas using road salt or other corrosive materials, check for lubrication frequently.

Liahts*:

Clean the headlights on a regular basis. Make sure that the headlights, brake lights, tail lights, turn signal lights, and other lights are all operating properly and installed securely. Also check head-light aim.

Tyres*:

Check the pressure with a gauge periodically when at a service station (including the spare) and adjust to the specified pressure if necessary. Check carefully for damage, cuts or excessive wear.

Tyre rotation*:

In the case of Two-Wheel Drive (2WD), and front and rear tyres are the same size; tyres should be rotated every 10,000 km (6,000 miles). Tyres marked with directional indicators can only be rotated between front and rear. Make sure that the directional indicators point in the direction of wheel rotation after the tyre rotation is completed.

In the case of Four-Wheel Drive and All Wheel Drive (4WD/AWD), and front and rear tyres are the same size; tyres should be rotated every 5,000 km (3,000 miles). Tyres marked with directional indicators can only be rotated between front and rear. Make sure that the directional indicators point in the direction of wheel rotation after the tyre rotation is completed.

In the case that front tyres are different size from rear tyres; tyres cannot be rotated.

The timing for tyre rotation may vary according to your driving habits and the road surface conditions.

Tyre Pressure Monitoring System (TPMS) transmitter components (where fitted):

Replace the TPMS sensor valve stem (including valve core and cap) and screw (where fitted) when the tyres are replaced due to wear or age. The

screw (where fitted) must be fitted correctly with a torque setting of 1.4 \pm 0.1 N.m. The TPMS sensors can be used again.

Wheel alignment and balance:

If the vehicle pulls to either side while driving on a straight and level road, or if you detect uneven or abnormal tyre wear, there may be a need for wheel alignment. If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed.

Wheel nuts:

When checking the tyres, make sure no wheel nuts are missing, and check for any loose wheel nuts. Tighten if necessary.

Windscreen:

Clean the windscreen on a regular basis. Check the windscreen at least every six months for cracks or other damage. Have a damaged windscreen repaired by a qualified repair facility.

Wiper blades*:

Check for cracks or wear if they do not wipe properly.

Under the bonnet and vehicle

The maintenance items listed here should be checked periodically, e.g. each time you check the engine oil or refuel.

Battery (except for maintenance free batteries)*:

Check the fluid level in each cell. It should be between the <UPPER> and <LOWER> lines. Vehicles operated in high temperatures or under severe conditions require frequent checks of the battery fluid level.

Brake fluid level(s)*:

Make sure that the brake fluid level is between the <MAX> and <MIN> lines on the reservoir.

Engine coolant level*:

Check the coolant level when the engine is cold. Make sure that the coolant level is between the <MAX> and <MIN> lines on the reservoir.

Inverter coolant level*:

Check the coolant level when the engine and inverter are cold. Make sure that the coolant level is between the <MAX> and <MIN> lines on the reservoir. See "Inverter coolingBattery cooling system" (P.318).

Engine oil level*:

Check the level after parking the vehicle on a level surface and turning off the engine.

Fluid leaks:

Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If you should notice any leaks or if petrol fumes are evident, check for the cause and have it corrected immediately.

Window washer fluid*:

Check that there is adequate fluid in the tank.

MAINTENANCE PRECAUTIONS

Inside the vehicle

The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance, cleaning the vehicle, etc.

Accelerator pedal:

Check the pedal for smooth operation and make sure that the pedal does not catch or require uneven effort. Keep the floor mats away from the pedal.

Brake pedal*:

Check the pedal for smooth operation. If the brake pedal suddenly goes down further than normal, the pedal feels spongy or the vehicle seems to take longer to stop, contact a NISSAN dealer or qualified workshop immediately. Keep the floor mat away from the pedal.

Parking brake*:

Confirm that your vehicle is held securely on a fairly steep hill with only the parking brake applied.

Seats:

Check seat position controls such as seat adjusters, seatback recliner, etc. to ensure they operate smoothly and all latches lock securely in every position. Check that the head restraints move up and down smoothly and the locks hold securely in all latched positions.

Seat belts:

Check that all parts of the seat belt system (e.g. buckles, anchors, adjusters and retractors) operate properly and smoothly, and are installed securely. Check the belt webbing for cuts, fraying, wear or damage. See "Seat belts" (P.36) for further details.

Steering wheel:

Check for any change in the steering conditions, such as excessive free play, hard steering or strange noises.

Warning lights and audible reminders:

Make sure that all warning/indicator lights and audible reminders are operating properly.

Windscreen defogger:

Check that the air comes out of the defogger outlets properly when operating the heater or air conditioner.

Windscreen wiper and washer*:

Check that the wipers and washer operate properly and that the wipers do not streak.

When performing any inspection or maintenance work on your vehicle, always take care to prevent serious accidental injury to yourself or damage to the vehicle. The following are general precautions which should be closely observed.

- Never disassemble, remove or replace highvoltage parts and cables as well as their connectors. High-voltage cables are colored orange.
- Disassembling, removing or replacing highvoltage parts or cables can cause severe burns or electric shock that may result in serious injury or death. The vehicle high voltage system has no user serviceable parts. Take your vehicle to the NISSAN dealer or qualified workshop for any necessary maintenance.
- Park the vehicle on a level surface, apply the parking brake securely and block the wheels to prevent the vehicle from moving.
- Do not work under the engine bonnet while the engine is hot. Turn off the engine and wait until it cools down.
- Be sure to turn the ignition switch to the "OFF" or LOCK position.
 - When the ignition switch is in the ON or ACC position, the cooling fan may start to operate suddenly even when the engine is not running. To avoid injury, always disconnect the negative battery cable before working near the engine.
- If you must work with the engine running, keep your hands, clothing, hair and tools away from moving fans, belts and any other moving parts.

ENGINE COMPARTMENT

 It is advisable to remove ties and any jewellery, such as rings, watches, etc. before working on your vehicle.

- If you must run the engine in an enclosed space such as a garage, be sure there is proper ventilation for exhaust gases.
- DO NOT GET UNDER A VEHICLE THAT IS SUPPORTED BY A JACK.
- Keep smoking materials, flame and sparks away from fuel and battery.
- Never connect or disconnect either the battery or any transistorised component connector while the ignition switch is in the ON position.
- Never leave the engine or hybrid gearbox related component harness connector disconnected while the ignition switch is in the ON position.
- On petrol engine models with the multiport fuel injection (MFI) system, the fuel filter or fuel lines should be serviced by a NISSAN dealer or qualified workshop because the fuel lines are under high pressure even when the engine is off.
- Always wear eye protection whenever you work on your vehicle.
- Failure to follow these or other common sense guidelines may lead to serious injury or vehicle damage.

Improperly disposed engine oil and/or other vehicle fluids can pollute the environment. Always conform to local regulations for disposal of vehicle fluid.

This section gives instructions regarding only

those items which are relatively easy for an owner to perform.

You should be aware that incomplete or improper servicing may result in operating difficulties or excessive emissions, and could affect your warranty coverage. If in doubt about any servicing, have it done by your NISSAN dealer or qualified workshop.

For an overview of the engine compartment, see "Engine compartment" (P.316).

ENGINE COOLING SYSTEM

A WARNING

- Never remove the engine coolant reservoir cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the engine coolant reservoir. Wait until the engine and radiator have cooled down.
- Engine coolant is poisonous and should be stored carefully in marked containers out of the reach of children.


The engine cooling system is filled at the factory with a high-quality, year-round and extended life engine coolant. The high quality engine coolant contains the specific solutions effective for the anti-corrosion and the anti-freeze function. Therefore, additional cooling system additives are not necessary.

CAUTION

- Never use any cooling system additives such as radiator sealer. Additives may cloq the cooling system and cause damage to the engine, hybrid gearbox and/or cooling system.
- Since the radiator is not equipped with a filling cap, please fill it from the engine coolant reservoir.
- When adding or replacing engine coolant, be sure to use Genuine NISSAN engine coolant or equivalent in its quality with the proper mixture ratio. The use of other types of coolant solutions may damage the engine cooling system.

Composition		
Engine coolant (concentrated)	Demineralized or distilled water	
54%	46%	

CHECKING ENGINE COOLANT LEVEL



Check the coolant level in the reservoir when the engine is cold. If the coolant level is below MIN level ①, add coolant up to the MAX level ①. If the reservoir is empty, check the coolant level in the radiator when the engine is cold. If there is insufficient coolant in the radiator, fill the radiator with coolant up to the filler opening and also add it to the reservoir up to the MAX level (1).

CAUTION

If the cooling system frequently requires coolant, have it checked by a NISSAN dealer or qualified workshop.

CHANGING ENGINE COOLANT

Major cooling system repairs should be performed by a NISSAN dealer or qualified workshop. The service procedures can be found in the appropriate NISSAN Service Manual.

When checking or replacement is required, NISSAN recommends contacting a NISSAN dealer or qualified workshop for servicing.

Improper servicing or engine coolant change can result in reduced heater performance and engine overheating.

A WARNING

- To avoid the danger of being scalded, never change the coolant when the engine is hot.
- Avoid direct skin contact with used coolant. If skin contact is made, wash thoroughly with soap or hand cleaner and plenty of water as soon as possible.
- Keep coolant out of reach of children and pets.

Engine coolant must be disposed of properly. Check your local regulations.

The battery uses the same cooling system as the inverter, for details, see the instructions for the inverter cooling system below.

A WARNING

- Never remove the inverter coolant reservoir cap when the engine and/or inverter is hot.
 - Serious burns could be caused by high pressure fluid escaping from the inverter coolant reservoir. Wait until the engine and inverter have cooled down.
- Coolant is poisonous and should be stored carefully in marked containers out of the reach of children.

The inverter cooling system is filled at the factory with a high-quality, year-round and extended life engine coolant. The high quality coolant contains the specific solutions effective for the anti-corrosion and the anti-freeze function. Therefore, additional cooling system additives are not necessary.


CAUTION

- Never use any cooling system additives such as radiator sealer. Additives may clog the cooling system and cause damage to the engine, inverter and/or cooling system.
- When adding or replacing coolant, be sure to use Genuine NISSAN engine coolant or equivalent in its quality with the proper mixture ratio.

The use of other types of coolant solutions may damage the inverter cooling system.

Composition		
Engine coolant (concentrated)	Demineralized or dis- tilled water	
54%	46%	

CHECKING INVERTER COOLANT LEVEL



Check the coolant level in the reservoir (A) when the engine and inverter are cold. If the coolant level is below MIN level 2, add coolant up to the MAX level (1).

CAUTION

If the cooling system frequently requires coolant, have it checked by a NISSAN dealer or qualified workshop.

CHANGING INVERTER COOLANT

Major cooling system repairs should be performed by a NISSAN dealer or qualified workshop. The service procedures can be found in the appropriate NISSAN Service Manual.

When checking or replacement is required, NISSAN recommends contacting a NISSAN dealer or qualified workshop for servicing.

Improper servicing or coolant change can result in reduced heater performance and engine or inverter overheating.

A WARNING


- Avoid direct skin contact with used coolant. If skin contact is made, wash thoroughly with soap or hand cleaner and plenty of water as soon as possible.
- Keep coolant out of reach of children and pets.

Coolant must be disposed of properly. Check your local regulations.


CHECKING ENGINE OIL LEVEL

CAUTION

The oil level should be checked regularly. Operating with an insufficient amount of oil can damage the engine, and such damage is not covered by warranty.



Dipstick



- MIN level
- MAX level
- Normal range HR16DE engine
- Park the vehicle on a level surface and apply the parking brake.
- Start the engine. If the engine is cold, start and let the engine idle until it reaches the operational temperature (approximately 5 minutes).
- Turn the engine off.
- Wait at least 15 minutes for the engine oil to drain back into the oil pan.
- Remove the dipstick and wipe it clean.
- Re-insert it all the way.
- Remove the dipstick again and check the oil level. It should be in the normal range (C).
- If the oil level is below the minimum mark (A). remove the engine oil filler cap and pour the recommended oil through the opening. Do not overfill (B).
- Recheck the oil level with the dipstick.

It is normal to add some engine oil between oil maintenance intervals depending on the severity of operating conditions or depending on the property of the engine oil used. More engine oil is consumed by frequent acceleration/deceleration especially when the engine rpm is high. Consumption is likely to be higher when the engine is new. If the rate of oil consumption, after having driven for 5,000 km (3,000 miles), is more than 0.5 litre per 1.000 km (621 miles). consult a NISSAN dealer or qualified workshop.

CHANGING ENGINE OIL AND OIL FILTER

A WARNING

Used oil must not be poured into the ground, canals, rivers, etc. It should be disposed of at a rubbish tip having proper facilities.


- NISSAN recommends contacting a NISSAN dealer or qualified workshop for engine oil servicina.
- Be careful not to burn vourself, as the engine oil is hot.
- Prolonged and repeated contact with used engine oil may cause skin cancer.
- Avoid direct skin contact with used oil. If skin contact is made, wash thoroughly with soap or hand cleaner and plenty of water as soon as possible.
- Store used engine oil in marked containers out of the reach of children.

CAUTION

Waste oil must be disposed of properly.

Check your local regulations.

Engine oil replacement



HR16DE engine model

- Oil filler cap
- Oil drain plug
- Oil filter
- Park the vehicle on a level surface and apply the parking brake.

- 2. Start the engine. If the engine is cold, start and let the engine idle until the engine temperature reaches the operational temperature (approximately 5 minutes).
- 3. Turn the engine off.
- 4. Wait at least 15 minutes to let the engine oil drain back into the oil pan.
- Remove the underbody cover (where fitted).
- Place a large drain pan under the drain plug.
- Remove the drain plug with a wrench.
- Remove the oil filler cap and completely drain the oil

If the engine oil filter needs to be changed, remove and replace it at this time. See "Changing engine oil filter" (P.321).

9. Clean and re-install the drain plug along with a new washer. Securely tighten the drain plug with a wrench. Do not use excessive force.

Drain plug tightening torques: HR16DE

25 N·m (18 ft-lb)


10. Refill the engine with recommended engine oil and quantity. (See "Capacities and recommended fluids/lubricants" (P.341).)

When filling the engine oil, do not remove the dipstick.

- 11. Install the engine oil filler cap securely.
- Start the engine.
- 13. Check for any leakage around the drain plug. Correct as required.

14. Check the oil level with the dipstick. For details. see "Checking engine oil level" (P.320).

Changing engine oil filter



HR16DE engine model

- Oil filler cap
- Oil drain plug
- Oil filter

HYBRID GEARBOX OIL

- 1. Park the vehicle on a level surface and apply the parking brake.
- 2. Turn the engine off.
- 3. Drain the engine oil according to the proper procedure. (See "Engine oil replacement" (P.321).)
- 4. Loosen the engine oil filter with an oil filter wrench
 - Depending on the engine model, a special cap type wrench may be required. See a NISSAN dealer or qualified workshop for more information.
- 5. Remove the engine oil filter by turning it by hand.
- 6. Wipe the engine oil filter mounting surface with a clean cloth
 - Be sure to remove any old gasket remaining on the mounting surface.
- 7. Apply the new engine oil to the gasket of the new oil filter
- 8. Screw in the oil filter until a slight resistance is felt, and then tighten an additional 2/3 of turn to secure the oil filter

Oil filter cap tightening torque:

HR16DE 32 N·m (24 ft-lb)

- 9. Refill the engine oil. (See "Engine oil replacement" (P.321).)
- Start the engine and check for leakage around the oil filter. Correct as required.

- 11. Turn the engine off and wait several minutes.
- 12. Check the engine oil level according to the proper procedure. (See "Checking engine oil level" (P.320).)

PROTECT THE ENVIRONMENT

It is illegal to pollute drains, water courses and soil. Use authorised waste collection facilities, including civic amenity sites and garages providing facilities for the disposal of used oil and used oil filters. If in doubt, contact your local authority for advice on disposal.

The regulations concerning the pollution of the environment will vary from country to country.

When checking or replacement is required, NISSAN recommends contacting a NISSAN dealer or qualified workshop for servicing.

CAUTION

- Use only Genuine NISSAN Hybrid Gearbox Oil. Do not mix with other fluids.
- Using hybrid gearbox fluid other than Genuine NISSAN Hybrid Gearbox Oil will cause deterioration in driveability and hybrid gearbox durability, and may damage the hybrid gearbox. Such damage is not covered by the warranty.

BRAKE FLUID

CHECKING PARKING BRAKE

Periodically check the holding ability of the parking brake by parking on a steep hill and restraining the vehicle by using only the parking brake. If it does not hold satisfactorily, see a NISSAN dealer or qualified workshop.


CHECKING BRAKE PEDAL

If the brake pedal suddenly goes down further than normal, the pedal feels "spongy" or the vehicle seems to take longer to stop, see a NISSAN dealer or qualified workshop.

Self-adjusting brakes

Your vehicle is equipped with self-adjusting brakes. The disc-type brakes self-adjust every time the brake pedal is applied.

If the brakes do not operate properly, have the brakes checked by a NISSAN dealer or qualified workshop.



A WARNING

- Use only new fluid. Old, inferior, or contaminated fluid may damage the brake system. The use of improper fluids can damage the brake system and affect the vehicle's stopping ability.
- Clean the filler cap before removing.
- Brake fluid is poisonous and should be stored carefully in marked containers out of the reach of children.


Check the fluid level in the reservoir. If the fluid level is between the MIN (2) and MAX (1) lines or the brake warning light comes on, add fluid up to the MAX line

See "Capacities and recommended fluids/lubricants" (P.341) for the recommended brake fluid type.

If fluid must be added frequently, the system should be thoroughly checked by a NISSAN dealer or qualified workshop.

CAUTION

- NISSAN recommends that refilling and checking the brake system should be left to a NISSAN dealer or qualified workshop who will have the necessary fluids and technical knowledge.
- Do not spill the fluid on painted surfaces. This will damage the paint. If fluid is spilled. wash with water.



A WARNING

Anti-freeze window washer fluid is poisonous and should be stored carefully in marked containers out of the reach of children.

- Check the fluid level in the window washer reservoir. If the fluid level is low or when the low washer fluid warning light (where fitted) comes on, add window washer fluid up to the MAX level.
- Refill the reservoir more frequently when driving conditions require an increased amount of window washer fluid.
- Add a washer solvent to the water for better cleaning. In the winter season, add a window washer anti-freeze. Follow the manufacturer's instructions for the mixture ratio.

CAUTION


- Do not substitute anti-freeze engine coolant for window washer solution. This may result in damage to the paint.
- Always use window washer fluid recommended by NISSAN.

Caution symbols for battery			⚠ WARNING
0	8	No smoking No exposed flames No sparks	Never smoke around the battery. Never expose the battery to open flames or electrical sparks.
2	9	Shield eyes	Handle the battery cautiously. Always wear eye protection glasses to protect against explosion or battery acid.
3	8	Keep away from children	Never allow children to handle the battery. Keep the battery out of reach of children.
(4)	A	Battery acid	Do not allow battery fluid to contact your skin, eyes, fabrics, or painted surfaces. After handling the battery or battery cap, immediately wash your hands thoroughly. If the battery fluid gets into your eyes, or onto your skin or clothing, flush with water immediately for at least 15 minutes and seek medical attention. Battery fluid is acid. If the battery fluid gets into your eyes or onto your skin, it could cause eyesight loss or burns.
(5)	(1)	Note operating instructions	Before handling the battery, read this instruction carefully to ensure correct and safe handling.
6	A	Explosive gas	Hydrogen gas, generated by battery fluid, is explosive.

VEHICLE 12V BATTERY

A WARNING

Do not operate the vehicle if the fluid in the battery is low. Low battery fluid can cause a higher load on the battery which can generate heat, reduce battery life, and in some cases lead to an explosion.




The 12-volt battery ① is located in the luggage area.

To access the 12-volt battery, remove the luggage floor board and remove the carpet. Remove the right hand side foam cover and the left hand side foam cover. Remove the six bolts as illustrated and remove the battery cover.

For a maintenance free battery it is not required to check the fluid level. However, NISSAN recommends to have the battery checked periodically at a NISSAN dealer or qualified workshop.

- Keep the battery surface clean and dry. Any corrosion should be washed off with a solution of baking soda and water.
- Make certain the terminal connections are clean and securely tightened.
- If the vehicle is not used for 30 days or longer, disconnect the "-" negative battery terminal cable to prevent discharge.
- If battery replacement or check is required, contact a NISSAN dealer or qualified workshop.


Battery (Type A)



Check the fluid level in each cell. It should be between the UPPER (1) and LOWER (2) level lines.

If it is necessary to add fluid, add only distilled water to bring the level to the indicator in each filler opening. Do not overfill.

Remove the cell plugs (A) using a suitable tool.



Indicator

- OK
- ADD
- 2. Add distilled water up to the UPPER level line **①**.


If the side of the battery is not clear, check the electrolyte water level by looking directly above the cell, as illustrated.

3. Tighten cell plugs.

CAUTION

Do not overfill battery cells. Excessive electrolyte may leak out of the battery during charging, and cause paint damage.

Maintenance free battery (Type B)



For a maintenance free battery it is not required to check the fluid level. However, NISSAN recommends to visually check the green indicator (A) status periodically. If it is not visible, replace the battery as soon as possible.

Reinitialisation procedure after battery reconnection If the battery has been reconnected, check the following items:

- Clock setting (where fitted).
- Reset the desired radio stations to the preset station buttons

For details, see "Vehicle information display" (P.82), or the separately provided NissanConnect Owner's Manual.

JUMP-STARTING

If jump-starting is necessary, see "Jump-starting" (P.300). If the engine does not start by jump starting, the battery may have to be replaced. Contact a NISSAN dealer or qualified workshop.

INTELLIGENT KEY BATTERY REPLACEMENT

CAUTION


- The A symbol noted on the Intelligent key is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.
- Be careful not to allow children to swallow the battery and removed parts.
- There is danger of explosion if the lithium battery is incorrectly replaced. Replace only with the same or equivalent type.
- Do not expose the battery to excessive heat such as concentrated sunshine, fire or the like.
- Do not crush or cut the battery.
- Do not subject the battery to extremely low air pressure at high altitude.
- When changing batteries, do not let dust or oil get on the components.
- Be careful not to touch a circuit board or a battery terminal.

An improperly disposed battery can harm the environment. Always conform to local regulations for battery disposal.

- The Intelligent Kev is water-resistant: however, if it does get wet, immediately wipe it until it gets completely dry. To replace the battery, open the Intelligent Key carefully in the sequence shown in the illustration.
- When changing the battery, do not let dust or oil get on the Intelligent Key.

A WARNING

- Do not ingest the battery.
 - This product contains a coin button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.




CAUTION

Always hold the battery by the edges, as shown. Holding the battery across the contact points will seriously deplete the storage capacitv.

SPARK PLUGS

Replacement



Intelligent Key

- Slide the locking pin to the unlock position.
- Remove the key.
- 3. Insert a flat blade screwdriver or a suitable tool into the slot and twist it to open the lid.
- Replace the battery with a new one with the same specifications.

For models equipped with Intelligent Key, use the following battery type:

CR2032

- Do not touch the internal circuit and electric terminals as doing so could cause a malfunction
- Make sure that the + side faces the bottom of the case, as illustrated.
- Install the lid in the reverse order of removal.
- Operate the buttons to check that the key works correctly.

Contact a NISSAN dealer or qualified workshop if you need assistance for battery replacement.

A WARNING

Be sure the engine and ignition switch are off and that the parking brake is engaged securely.

CAUTION

- Be sure to use the correct socket to remove the spark plugs. An incorrect socket can cause damage to the spark plugs.
- Always replace spark plugs with recommended or equivalent ones.

Replace spark plugs according to the maintenance schedule shown in the separately provided Warranty Information & Maintenance Booklet.

If replacement is required, see a NISSAN dealer or qualified workshop for servicing.

WIPER BLADES

CLEANING

If the windscreen or tailgate window is not clear after using the window washer or if a wiper blade chatters when running, wax or other material may be on the blade or windscreen


Clean the outside of the windscreen or tailgate window with a washer solution or a mild detergent. The windscreen or tailgate window is clean if beads do not form when rinsing with clear water.

Clean the blade by wiping it with a cloth soaked in a washer solution or a mild detergent. Then rinse the blade with clear water. If the windscreen or tailgate window is still not clear after cleaning the blades and using the wiper, replace the blades.

CAUTION

- After wiper blade replacement, return the wiper arm to its original position. Otherwise it may be damaged when the bonnet is opened.
- Make sure the wiper blade contacts the glass. Otherwise, the arm may be damaged by wind pressure.
- Do not open the bonnet when the front wiper is in the servicing position, otherwise it can damage the paint surface of the bonnet.


FRONT WINDOW WIPER REPLACEMENT



- Pull up the wiper arm (1). For more information, see "Pulling up the wiper arms" (P.105).
- 2. Press the lock pin (2), then remove the wiper blade as illustrated (3).
- 3. Install the new wiper blade in the reverse order of removal.

4. Return the wiper arm to its original position.

TAILGATE WINDOW WIPER REPLACEMENT




- 1. Lift the wiper arm ①.
- 2. Hold and carefully rotate the wiper blade clockwise until the blade becomes free (2).
- 3. Insert the new wiper blade onto the wiper arm and snap it into place.

FUSES


4. Return the wiper arm to its original position.

WINDSCREEN WASHER NOZZLE




If you wax the surface of the engine bonnet, be careful not to let wax get into the washer nozzle (A). This may cause clogging or improper windscreen washer operation. If wax gets into the nozzle, remove it with a needle or small pin (B).

PASSENGER COMPARTMENT



Left hand drive



Right hand drive

CAUTION

- Never use a fuse of higher or lower amperage rating than that specified on the fuse box cover.
- Never pull the wiring loom or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

If any electrical equipment does not operate, check for an open fuse.

The fuse box is located in the lower part of the instrument panel at the driver's side on left hand drive vehicles. On right hand drive vehicles, it is located at the back of the glove box.

The affected circuits (2) are shown on the inside of the fuse box lid.

- 1. Make sure the ignition switch and the headlight switch are in the "OFF" position.
- Open the fuse box lid.
- 3. Locate and remove the fuse with the fuse puller (1) (where fitted). The fuse puller (where fitted) is located in the fuse box.

NOTE:

The fuse puller is stored in the fuse box.

- 4. If the fuse is open (a), replace it with a new fuse (B),
- 5 Close the fuse box lid

LIGHTS

NOTE:

If the new fuse opens again, after installing, have the electrical system checked and repaired by a NISSAN dealer or qualified workshop.

HEADLIGHTS

LED headlight

The LED headlight is a projector style which uses a LED module without serviceable parts.

CAUTION

- To prevent an electric shock, never attempt to modify or disassemble the LED headlights assembly.
- If replacement is required, contact a NISSAN dealer or qualified workshop.

EXTERIOR LIGHTS

Item	Wattage (W)
Headlight (Low or high beam) *1	LED
Front combination light	
DTRL (Day time running light) *1	LED
Front turn signal light	21
Front side light *1	LED
Front fog light (where fitted) *1	LED
Side turn signal light *1	LED
Rear combination light	
Turn signal light	21
Stop/Tail light *1	LED
Reverse light *1	16
High-mounted brake light *1	LED


ltem	Wattage (W)
Number plate light	5
Rear fog light *1 (where fitted)	LED

If replacement is required, contact a NISSAN dealer or qualified workshop.

INTERIOR LIGHTS

ltem	Wattage (W)
Room light/Map lights (where fitted)	10
Room light — rear (where fitted)	8
Luggage compartment light	5

LIGHT LOCATIONS




Light locations

- Side turn signal light
- Room light / Map lights (where fitted)
- DTRL (day time running light) and front side light
- Front turn signal light
- Low/high beam headlight


- 6 Front fog light (where fitted)
- Ø High mounted brake light
- Room light (where fitted)
- Number plate light
- Tail light
- Reverse light (LHD) or rear fog light (RHD)
- Rear turn signal light
- Brake light

Replacing procedures




All other lights are either type A, B. When replacing a bulb, first remove the lens and/or cover.

- REMOVE
- INSTALL




MNIC3796 Room light / Map lights (where fitted)



Luggage compartment light

Front turn signal light

WHEFIS AND TYRES



Rear turn signal light

In case of a flat tyre, see "Spare tyre" (P.292).

TYRE INFLATION PRESSURE

Periodically check the tyre pressure (including the spare tyre). An incorrect tyre pressure may adversely affect tyre life and vehicle handling. After adjusting the tyre pressure, perform a TPMS temperature calibration (see "Tyre Pressure Monitoring System (TPMS) (where fitted)" (P.186)).

NOTE:

Incorrectly inflated tyres can also lead to poor steering ability and make the driver suspect a steering problem: keep the vehicle's tyres inflated to the correct pressure at all times.

The tyre pressure should be checked when tyres are COLD. Tyres are considered COLD after the vehicle has been parked for three or more hours, or driven less than 1.6 km (1 mile). COLD tyre pressures are shown on the tyre placard affixed to the driver's side centre pillar.

Insufficient pressure can lead to an overheating of the tyre and subsequent internal damage. At high speeds, this could result in tread separation and even bursting of the tyre.

TYPES OF TYRES

CAUTION

- When changing or replacing tyres, be sure all four tyres are of the same type (i.e., summer, all season or snow) and construction.
- A NISSAN dealer or qualified workshop may be able to help you with information

- about tyre type, size, speed rating and availability.
- Replacement tyres may have a lower speed rating than the factory equipped tyres, and may not match the potential maximum vehicle speed. Never exceed the maximum speed rating of the tyre.

All season tyres

NISSAN specifies all season tyres on some models to provide good performance for use all year around, including snowy and icy road conditions. All season tyres are identified by ALL SEASON and/ or M&S on the tyre sidewall. Snow tyres have better snow traction than all season tyres and may be more appropriate in some areas.

Summer tyres

NISSAN specifies summer tyres as standard fit. These tyres provide superior performance under typical mild weather conditions.

If you plan to operate your vehicle in snowy or icy conditions, NISSAN recommends the use of SNOW or ALL SEASON tyres on all four wheels.

Snow tyres

If snow tyres are needed, it is necessary to select tyres equivalent in size and load rating to the original equipment tyres. If you do not, it can adversely affect the safety and handling of your vehicle

Generally, snow tyres will have lower speed ratings than factory equipped tyres and may not match

the potential maximum vehicle speed. Never exceed the maximum speed rating of the tyre.

For additional traction on icy roads, studded tyres may be used. However, some provinces and states prohibit their use. Check local, state and provincial laws before installing studded tyres. Skid and traction capabilities of studded snow tyres, on wet or dry surfaces, may be poorer than that of non-studded snow tyres.

SNOW CHAINS

Use of snow chains may be prohibited in some areas. Check the local laws before installing snow chains. When installing snow chains, make sure they are of proper size for the tyres on your vehicle and are installed according to the chain manufacturer's suggestions. Use chain tensioners when recommended by the snow chain manufacturer to ensure a tight fit. Loose end links of the snow chain must be secured or removed to prevent the possibility of whipping action damage to the fenders or undercarriage.

In addition, drive at a reduced speed. Otherwise, your vehicle can be damaged and/or vehicle handling and performance may be adversely affected


Snow chains must be installed only on the front wheels and not on the rear wheels.

CAUTION

- Never install snow chains on a temporaryuse or small size spare tyre.
- Do not drive with snow chains on paved roads which are clear of snow. Driving with

chains in such conditions can cause damage to the various mechanisms of the vehicle due to some overstress.

TYRE ROTATION



NISSAN recommends that tyres be rotated every 10,000 km (6,000 miles) for Two-Wheel Drive (2WD) vehicles and 5.000 km (3.000 miles) for Four-Wheel Drive (4WD) vehicles.

However, the timing for tyre rotation may vary according to your driving habits and the road surface conditions. See "Spare tyre" (P.292) for tyre replacing procedures.

A WARNING

- After rotating the tyres, adjust the tyre pressure.
- Retighten the wheel nuts when the vehicle has been driven for the first 1.000 km (600 miles) (also in cases of a flat tyre, etc.).


- Do not include the temporary-use spare tvre in the tvre rotation.
- Incorrect tyre selection, fitting, care or maintenance can affect vehicle safety with risk of accident and injury. If in doubt, consult a NISSAN dealer or the tyre manufacturer.

NOTE:

Models with Tyre Pressure Monitoring System (TPMS).

After rotating the tyres, the TPMS must be reinitailised. For details, see "Activation" (P.188).

TYRE WEAR AND DAMAGE



Tyres should be periodically inspected for wear, cracking, bulging or objects caught in the tread. If excessive wear, cracks, bulging or deep cuts are found, the tyre should be replaced.

The original tyres have a built-in tread wear

indicator (1). When the wear indicator is visible, the tyre should be replaced.

The wear indicator locations are indicated by the location marks (2).

TYRE AGE

Remember tyre age. Never use a tyre over six years old, regardless of whether they have been used or not.

Tyres degrade with age as well as the use they are subjected to. Have the tyres checked and balanced frequently by a NISSAN dealer or qualified workshop. Report all accidents where the tyre is knocked even if it is minor.

CHANGING TYRES AND WHEELS

A WARNING

Do not install a deformed wheel or tyre even if it has been repaired. Such wheels or tyres could have structural damage and could fail without warning.

When replacing a tyre, use the same size, speed rating and load carrying capacity as originally equipped. Recommended types and sizes are mentioned in "Wheels and tyres" (P.334).

The use of tyres other than those recommended or the mixed use of tyres of different brands. construction (bias, bias-belted or radial), or tread patterns can adversely affect the ride, braking, handling, ground clearance, body-to-tyre clearance, snow chain clearance, speedometer calibration, headlight aim and bumper height.

A WARNING

Some of these effects may lead to accidents and could result in serious personal injury.

FOUR-WHEEL DRIVE (4WD) MODELS

CAUTION

- Always use tyres of the same size, brand, construction (bias, bias-belted or radial), and tread pattern on all four wheels. Failure to do so may result in a circumference difference between tyres on the front and rear axles which will cause excessive tyre wear and may damage the transmission, transfer case and differential gears.
- ONLY use spare tyres specified for the four wheel drive (4WD) models.

WHEEL BALANCE

Unbalanced wheels may affect vehicle handling and tyre life. Even with regular use, wheels can get out of balance. Therefore, they should be balanced as required.

Wheel balance service should be performed with the wheels off the vehicle. Spin balancing the front wheels on the vehicle could lead to transmission damage.

SPARE TYRE

Conventional spare wheel/tyre (where fitted)

A standard wheel/tyre is supplied with your vehicle.

Temporary-use spare wheel/tyre (where fitted)

The temporary-use spare wheel/tyre can be identified by the temporary-use spare tyre label which contrasts to the standard road wheels. If in doubt, contact a NISSAN dealer, qualified workshop or see "Spare tyre" (P.292).

Emergency tyre puncture repair kit (where fitted)

The emergency tyre puncture repair kit is supplied to the vehicle instead of a spare tyre. The repair kit must be used for temporarily fixing a minor tyre puncture. After using the repair kit, see a NISSAN dealer or qualified workshop as soon as possible for tyre inspection and repair/replacement.

CAUTION

Do not use the emergency tyre puncture repair kit under the following conditions. Contact a NISSAN dealer or qualified workshop or professional road assistance.

- when the sealant has passed its expiration date (shown on the label attached to the sealant bottle)
- when the cut or the puncture is approximately 4 mm (0.16 in) or longer
- when the side of the tyre is damaged
- when the vehicle has been driven with a considerable loss of air from the tyre

- when the tyre is completely displaced inside or outside the rim
- when the tyre rim is damaged
- when two or more tyres are flat

See "Repairing flat tyre (Models with emergency tyre puncture repair kit)" (P.298) for more details.

CARE OF WHEELS

For details, see "Care of wheels" (P.307).

MEMO

9 Technical information

Capacities and recommended fluids/lubricants		
Fuel information	343	
Recommended SAE viscosity number	343	
Air conditioner system refrigerant		
and lubricant	343	
Engine	344	
Wheels and Tyres	344	
Dimensions	345	
When travelling or registering in another country $\ldots \ldots$	345	
Vehicle identification	345	
Vehicle identification plate	345	
Vehicle identification number (VIN)		
(chassis number)	345	
Engine serial number	346	
Tyre placard	346	
Air conditioner specification label		
(where fitted)	346	
Additional data recording (where fitted)	346	

Installation of an RF transmitter	347
Event Data Recorders (EDR) (where fitted)	347
Additional data recording (on vehicles equipped with	
optional ProPILOT)	347
Additional data recording (on vehicles equipped with	
TSA system)	348
Approval numbers	348
NISSAN Anti-Theft System (NATS), Intelligent or re	mote
keyless system	348
Tyre Pressure Monitoring System	
(TPMS) (Transmitter)	350
Radar systems	352
Audio systems	353
Wireless charger	354
Radio frequency approval	355
CE Approval details	356
UKCA Approval details	358

CAPACITIES AND RECOMMENDED FLUIDS/LUBRICANTS

The following are approximate capacities. The actual refill quantities may be slightly different. When refilling, follow the procedures instructed in the "8. Maintenance and do-it-yourself" section to determine the proper refill capacity.

Fluid type		Capacity (Approximate)			
		Metric Measure	Imperial Measure	US Measure	Recommended Fluids/Lubricants
		46 L	10-1/8 gal.	12-1/8 gal.	See "Fuel information" (P.343).
Engine oil*					*: For additional information, see "Engine oil" (P.320).
Drain and refill					 Genuine "Nissan Motor Oil Synthetic Technology 5W-30 C3" is recommended.
UDICE	With oil filter change	4.8 L	4-1/4 qt	5-1/16 qt	 If above engine oil is not available, use equivalent that matches the following grade and viscosity: ACEA C3 SAE 5W-30.
HR16DE	Without oil filter change	3.6 L	3-3/16 qt	3-3/4	_ Tollowing grade and viscosity. Act A cs sAc sw so.
Engine coolant					 Use "NISSAN Genuine Engine Coolant L255N" or equivalent in its quality.
(including reservoir	tank capacity)				in order to avoid possible aluminium corrosion within the engine cooling system caused by the use of non-genuine engine coolant.
HR16DE	Hybrid gearbox models	6.9 L	6 qt	7 1/4 qt	Note that any repairs for the incidents within the engine cooling system while using non-genuine engine coolant may not be
	Reservoir tank	Pasanyoir tank 101 7/8 at 11/8 at		 covered by the warranty, even if such incidents occurred during the warranty period. Contact a NISSAN dealer or qualified workshop for 	
Inverter cooling system (including reservoir tank capacity)		5.5 L	4-3/4 qt	5-3/4 qt	more information regarding the coolant type and capacity. If dilution of new coolant is necessary to achieve the correct
Reservoir tank		0.7 L	5/8 qt	3/4 qt	 concentration, only use demineralized or distilled water for dilution.
Hybrid gearbox fluid		2.0 L	1-3/4 qt	2-1/8 qt	 Genuine "NISSAN Hybrid Gearbox oil" Use only Genuine NISSAN Hybrid Gearbox oil. Using hybrid gearbox fluid other than NISSAN Hybrid Gearbox oil will damage the hybrid gearbox. Such damage is not covered by the warranty. Contact a NISSAN dealer or qualified workshop for details or servicing.
Brake fluid		Refill to the proper fluid level according to the instructions in the "8. Maintenance and do-it-yourself" section.		•	Genuine NISSAN Brake Fluid or equivalent DOT 4

Multi-purpose grease	-	NLGI No. 2 (Lithium soap base)
Air conditioner system refrigerant	0.50 ± 0.0025 kg [500 ± 25 g]	● HFO1234yf (R1234yf)
Air conditioner system lubricants	110 cc	ND-OIL 11

FUEL INFORMATION

Petrol engine

CAUTION

Do not use leaded petrol. Using leaded petrol will damage the catalytic converter.

Compatible Fuels for Petrol Engines

The petrol engines are compatible with current and future European standards for bio-fuel.



Petrol conforming to EN228 and mixed with a bio-fuel conforming to EN15376.



HR16DE engine

For all destinations use UNIFADED PREMIUM petrol with an octane rating of at least 95 (RON).

RECOMMENDED SAE VISCOSITY NUMBER

Petrol engine oil

HR16DE engine:

Only use 5W-30

AIR CONDITIONER SYSTEM REFRIGERANT AND LUBRICANT

The air conditioner system of your vehicle must be charged with the refrigerant HFO1234yf (R1234yf) and the lubricant NISSAN A/C System Oil Type ND-OIL 11 or equivalents.

CAUTION

Use of any other refrigerants or lubricants will cause severe damage, and you may need to replace your vehicle's entire air conditioner system.

The release of refrigerants into the atmosphere is prohibited in many countries and regions. This refrigerant contains fluorinated greenhouse gases (GWP 0,501). It will not harm the earth's ozone layer. However, it may contribute in a small part to the global warming effect. NISSAN recommends that the refrigerant be appropriately recovered and recycled. Contact a NISSAN dealer or qualified workshop when servicing the air conditioner system.

Model		HR16DE		
Туре		Petrol, 4-cycle		
Cylinder arrangement		4-cylinder in-line		
Bore x Stroke	mm /in)	78 x 83.6		
BOI'E X SLIOKE	mm (in)	(3.071 x 3.291)		
Displacement	cm³cu in)	1,598 (97.51)		
Idling speed in N position	rpm	1,200		
Ignition timing (BTDC)	degree	-		
Spark plugs	Standard	DILKAR6K		
Spark plug gap	mm (in)	1.0 - 1.1 (0.0393 - 0.0433)		
Camshaft operation		Silent timing chain		

			Unit: mm (in)	
Item		Size	Offset	
	Steel	17 x 7.0J	35	
	Steel	17 X 7.03	(1.38)	
	Steel		30*	
Road	Temp- spare	16 X 4T*	(1.18)	
wheel	· · · · · · · · · · · · · · · · · · ·	17 x 7.0J	35	
	Alumi-		(1.38)	
	nium*	19 x 7.5J	35	
		19 X 7.5J	(1.38)	
Tyre size	Spare	T145/90	T145/90R16 *	

Temporary-use spare tyre (where fitted)

DIMENSIONS

	mm (in.)
Overall length	4,210 (165.7)
Overall width	1,800 (70.9)
Overall height	1,577 (62.1)
Front tread	1,560 (61.4)
Rear tread	1,552 (61.1)
Wheelbase	2,636 (103.8)
Front overhang	857 (33.7)
Rear overhang	717 (28.2)

WHEN TRAVELLING OR REGIS-**TERING IN ANOTHER COUNTRY**

When planning to travel in another country, you should first find out if the fuel available is suitable for your vehicle's engine.

Using fuel with too low octane rating may cause engine damage. Therefore, avoid taking your vehicle to areas where appropriate fuel is not available.


When transferring your vehicle registration to another country, check with the appropriate authorities that the vehicle complies with the requirements as it may not be possible to adapt it. In some cases, a vehicle cannot meet the legal requirements and in other cases, it may be necessary to modify the vehicle to meet specific laws and regulations.

The laws and regulations for motor vehicle emission control and safety standards vary according to the country; therefore, vehicle specifications may differ.

NISSAN is not responsible for any inconvenience when the vehicle is taken and registered into another country. The necessary modifications, transportation and registration are the owner's responsibility.


VEHICLE IDENTIFICATION

VEHICLE IDENTIFICATION PLATE




The plate is affixed on the B pillar as shown.

VEHICLE IDENTIFICATION NUMBER (VIN) (chassis number)



The VIN number is located as shown.


ENGINE SERIAL NUMBER



HR16DE engine

The number is stamped on the engine as shown.

TYRE PLACARD



The cold tyre pressure is shown on the tyre placard fixed to the side of the driver's side centre pillar.

AIR CONDITIONER SPECIFICATION LABEL (where fitted)

Open the bonnet. The label is affixed at the front section of the bonnet.

ADDITIONAL DATA RECORDING (where fitted)

If your vehicle is fitted with the ProPILOT Assist System, it will also be fitted with supplemental data recording function intended to assist in understanding how the ProPILOT Assist System performs in certain non-trivial crash or near-crash scenarios. Specifically, supplemental recording is designed to capture the following:

- Driver operational status of the accelerator, brakes, steering, etc.
- Detection status of a vehicle ahead and lane markers.
- Vehicle information including distance to vehicle ahead and lateral position.
- Information on the operation of the ProPILOT Assist system and other crash avoidance features.
- ProPILOT Assist system malfunction diagnosis information.
- External images from the multi-sensing front camera (Available only when the SRS air bag or IEB system is activated).

The ProPILOT Assist system does not record conversations, sounds or images of the inside of the vehicle.

To read this supplemental data, special equipment is required and access to the vehicle or the recording unit is needed. This supplemental data will only be accessed with the consent of the

vehicle owner or lessee or as otherwise required or permitted by law.

If downloaded, NISSAN and third parties entrusted by NISSAN may use the data recorded for the purpose of improving NISSAN's vehicle safety performance.

NISSAN and third parties entrusted by NISSAN will not disclose/provide the recorded data to a third party except:

- With the consent of the vehicle owner or with the consent of the lessee.
- In response to an official request from law enforcement, court order, governmental agency, or other legally enforceable request.
- For research purposes after the data is modified such that it is no longer tied to a specific vehicle or vehicle owner (anonymously)

INSTALLATION OF AN RF TRANSMITTER

EVENT DATA RECORDERS (EDR) (where fitted)

ADDITIONAL DATA RECORDING (on vehicles equipped with optional ProPILOT)

For countries conforming to UN regulation No.10 or equivalent:

The installation of an RF transmitter in your vehicle could affect electric equipment systems. Be sure to check with your NISSAN dealer or qualified workshop for precautionary measures or special instructions regarding installation. Upon request, your NISSAN dealer or qualified workshop will provide the detailed information (frequency band, power, antenna position, installation guide, etc.) regarding installation.

This vehicle is equipped with an Event Data Recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating:
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.
- Sounds are not recorded.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a nontrivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g. name, gender, age and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

EDR data will only be accessed with the consent of the vehicle owner or lessee or as otherwise required or permitted by law.

If your vehicle is equipped with the optional ProPILOT, it will also be equipped with supplemental data recording function intended to assist in understanding how ProPILOT performs in certain non-trivial crash or near-crash scenarios. Specifically, supplemental recording is designed to capture the following:

- Driver operational status of the accelerator, brakes, steering, etc.
- Detection status of a vehicle ahead and lane markers
- Vehicle information including distance to vehicle ahead and lateral position
- Information on the operation of the ProPILOT and other crash avoidance features
- ProPILOT malfunction diagnosis information
- External images from the multi-sensing front camera (Available only when the SRS air bag or Intelligent Emergency Braking system is activated)

The ProPILOT does not record conversations, sounds or images of the inside of the vehicle.

To read this supplemental data, special equipment is required and access to the vehicle or the recording unit is needed. This supplemental data will only be accessed with the consent of the vehicle owner or lessee or as otherwise required or permitted by law. If downloaded, NISSAN and third parties entrusted by NISSAN may use the data recorded for the purpose of improving NISSAN's vehicle safety performance.

NISSAN and third parties entrusted by NISSAN will not disclose/provide the recorded data to a third party except:

ADDITIONAL DATA RECORDING (on vehicles equipped with TSA system)

The TSA system is equipped with usage record collection capability that is required by regulations. It is designed to record such data as:

- Driving time and distance with the TSA function turned on and off
- Driving time and distance in compliance with the speed limits at anytime during the driving
- Driving time and distance exceeding the speed limits which TSA system recognized.
- The number of times the customer changes the TSA function settings

The collected data will be accessed with the consent of the vehicle owner when the vehicle is garaged in a dealer. Then the collected data will be converted to statistical information which does not enable the identification of the specific individual, and the submitted only to the European Commission

APPROVAL NUMBERS

All radio frequency or audio frequency products fitted to the NISSAN range during production conform to the requirements of the R&TTE Directive.

NISSAN ANTI-THEFT SYSTEM (NATS), IN-TELLIGENT OR REMOTE KEYLESS SYSTEM

Remote keyless entry system (where fitted)

Simplified EU conformity

Hereby, ALPS ALPINE CO., LTD., **declaration of** | declares that the radio equipment type TWB1G767 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

> https://www.alpsalpine.com/common/pdf/HandUnit/TWB1G767.pdf

Frequency band(s) in which the radio equipment operates:

433.92MHz

Maximum radio-frequency power transmitted in the frequency band (s) in which the radio equipment operates:

< 10dBm

CAUTION

- Do not expose to excessive heat such as sunshine, fire or the like.
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

With the consent of the vehicle owner or with

In response to an official request from law

agency, or other legally enforceable request

enforcement, court order, governmental

For research purposes after the data is

modified such that it is no longer tied to a

specific vehicle or vehicle owner (anonymised)

the consent of the lessee

Intelligent Key system (where fitted)

Simplified EU declaration of conformity

Hereby, Continental declares that the radio equipment type HFM401 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:


https://continental-homologation.com/nissan

Frequency band(s) in which the radio equipment operates:

433,92MHz

Maximum radio-frequency power transmitted in the frequency band(s) in which the radio equipment operates: < 10dBm

- Intelligent Key (where fitted):
 - Manufacturer name: Continental Automotive GmbH
 - Model name: HFM401 / HFM4C01
- Alarm (Siren) system (where fitted):
 - 116RAI-002868
 - 116RI-002869





MNTI586

For Serbia

NISSAN Anti-Theft System (NATS) immobilizer

Simplified EU declaration of conformity

Hereby, Continental declares that the radio equipment type BCM, HFM, Immobilizer is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

https://continental-homologation.com/nissan

Frequency band(s) in which the radio equipment operates: 125KHz

Maximum radio-frequency power transmitted in the frequency band(s) in which the radio equipment operates: < 40 dB µA/m @10m

TYRE PRESSURE MONITORING SYSTEM (TPMS) (Transmitter)



Hereby, Continental declares that the radio equipment type TIS-03 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

https://continental-homologation.com/en-gl/ Nissan

- Frequency band: 433.92 MHz.
- Maximum transmitter power: <10 dBm




Hereby, Continental declares that the radio equipment type TIS-09DL is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

https://continental-homologation.com/en-gl/ Nissan

- Frequency band: 433.92 MHz.
- Maximum transmitter power: -17 dBm



For Ukraine



For Ukraine














For Ukraine For Serbia

RADAR SYSTEMS

Front radar sensor (where fitted)



For Ukraine



For Ukraine


AGREE PAR L'ARNT MAROC Numéro d'agrément: MR 9778 ANRT 2014 Date d'agrément: 2014-11-11

MNTI444

For Morocco

Manufacturer Postal Address:

ADC Automotive Distance Control Systems GmbH Peter-Dornier-Strasse 10, 88131 Lindau, Germany



For Serbia

Simplified UK declaration of conformity

Hereby, ADC Automotive Distance Control Systems GmbH declares that the radio equipment type ARS4-B is in compliance with Radio Equipment Regulations of the United Kingdom. The full text of the UK declaration of conformity is available at the following internet address:

http://continental.automotive-approvals.com/

Frequency band(s) in which the radio equipment operates:

76-77 GHz

Maximum radio-frequency power transmitted in the frequency band(s) in which the radio equipment operates:

3.16W (35dBm RMS EIRP)

Side radar sensor (where fitted)

Manufacturer Postal Address:

ADC Automotive Distance Control Systems GmbH Peter-Dornier-Strasse 10, 88131 Lindau, Germany

Simplified UK declaration of conformity

Hereby, ADC Automotive Distance Control Systems GmbH declares that the radio equipment type SRR3-B is in compliance with Radio Equipment Regulations of the United Kingdom. The full text of the UK declaration of conformity is available at the following internet address:

http://continental.automotive-approvals.com/

Frequency band(s) in which the radio equipment operates: 24.05-24.25 GHz

Maximum radio-frequency power transmitted in the frequency band (s) in which the radio equipment operates:


100mW (20dBm) Peak EIRP



For Ukraine



For Ukraine



For Serbia

AUDIO SYSTEMS

FM AM radio with CD player (where fitted)

Simplified EU declaration of conformity

Hereby Visteon Automotive Electronics Co., Ltd. declares that this system is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

http://www.visteon.com/g17ahudirective.2014.53.eu.pdf

Frequency band(s) in which the radio equipment operates: 2400-2483.5 MHz

Maximum radio-frequency power transmitted in the frequency band (s) in which the radio equipment operates:

Bluetooth <10 mW (EIRP)

WIRELESS CHARGER



For Israel

RADIO FREQUENCY APPROVAL

The countries covered by this directive, or those which accept it, are: Albania, Austria, Belgium, Bosnia & Herzegovina, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, French Guiana, Georgia, Germany, Greece, Guadeloupe, Hungary, Iceland, Ireland, Italy, Kosovo, Latvia, Liechtenstein, Lithuania, Luxembourg, Macedonia, Malta, Martinique, Mayotte, Monaco, Montenegro, Netherlands, Norway, Poland, Portugal, Reunion, Romania, Saint Pierre & Miquelon, San Marino, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey, Tuvalu, United Kingdom.

	VEHICLE RADIO FUNCTIONS	
Frequency Range	Technology	Power/Magnetic Field
125 kHz (119 – 135 kHz)	Remote Keyless Entry Transponder Ring	≤ 42 dBµA/m at 10m
433 MHz (433.05 - 434.79 MHz)	Tyre Pressure Monitoring	≤ 10 mW e.r.p.
433.92 MHz (433.05 - 434.79 MHz)	Remote Keyless Entry	≤ 10 mW e.r.p.
20 kHz (9 - 90 kHz)	Keyless Go system	≤ 72 dBµA/m at 10m
2.4 GHz (2400 - 2483.5 MHz)	Bluetooth	≤ 100 mW e.i.r.p.
824 - 894 MHz	GSM 850 (2G)	≤ 39 dBm e.i.r.p.
880 - 960 MHz	GSM 900 (2G)	≤ 39 dBm e.i.r.p.
1710 - 1880 MH	GSM 1800 (2G)	≤ 36 dBm e.i.r.p.
1850 - 1890 MHz	GSM 1900 (2G)	≤ 33 dBm e.i.r.p.
1922 - 2168 MHz	W-CDMA Band I (3G)	≤ 24 dBm e.i.r.p.
24.05 - 24.25 GHz	24 GHz ISM Radar	100 mW e.i.r.p.
24.25 - 26.65 GHz	24 GHz UWB Radar	≤ -41,3 dBm/MHz e.i.r.p. mean ≤ 0 dBm/50 MHz e.i.r.p. peak
76 - 77 GHz	77 GHz Radar	≤ 55 dBm e.i.r.p.

CE APPROVAL DETAILS



Description	Supplier	Supplier Address	CE Certificate #	Link to Certificate	Importer	Importer Address
Telematics Control Unit (TCU)	Continental	Continental Automotive Sin- gapore Pte Ltd Continental Building 80 Boon Keng Road Singapore 339780	Refer to Link	https://www.continental-homo- logation.com/en-gl/Nissan		
Tyre Pressure Monitoring System (TPMS) Model TIS-09DL	Continental Automotive GmbH.	Siemensstrasse 12 D-93055 Regensburg Germany	Refer to Link	https://www.continental-homo- logation.com/en-gl/Nissan		
Front Radar Sensor Model ARS4-B	ADC Automatic Distance Control Systems GmbH	Peter-Domier-Str.10, 88131 Lindau, Gerany	T817940E-02-1EC	https://ita.bosch.com		
Side Radar Sensor Model SRR3-B	ADC Automatic Distance Control Systems GmbHH	Peter-Domier-Str.10, 88131 Lindau, Gerany	T817940E-02-1EC	https://www.aptiv.com/en/auto- motive-homologation		
Immobiliser Model A2C93178600	Continental Automotive GmbH	Continental Automotive GmbH Siemensstrasse 12 D- 93055 Regensburg Germany	Refer to Link	https://doc-ita.bosch.com/	Nissan Automotive Europe	Montigny-le- Bretonneux
Intelligent Key system control unit Model HFM401	Continental Automotive GmbH.	Continental Automotive GmbH Siemensstrasse 12 D- 93055 Regensburg Germany	Refer to Link	https://www.continental-homo- logation.com/en-gl/Nissan	(NAE)	
Passive Entry System Model TWB1G767 (Hand Unit)	ALPS ALPNE CO., LTD.	6-3-36, Furukwawnakazato, Osaki-city, Miyagi-pref., JAPAN 989-6181	Refer to Link	https://www.alpsalpine.com/ common/pdf/HandUnit/ TWB1G767.pdf		
Passive Entry System Model TXPZ1 (Hand Unit)	Continental Automotive GmbH.	Continental Automotive GmbH Siemensstrasse 12 D- 93055 Regensburg Germany	Refer to Link	https://www.continental-homo- logation.com/en-gl/Nissan		
Intelligent Key System (iKey)	Continental Automotive GmbH.	Continental Automotive GmbH Siemensstrasse 12 D- 93055 Regensburg Germany	Refer to Link	https://www.continental-homo- logation.com/en-gl/Nissan		

Description	Supplier	Supplier Address	CE Certificate #	Certificate	Importer	Importer Address
AIVI Models AI- VICMFBO, AI- VIP32RO, AIVI- H60AO and AIVIL42PO,	Robert Bosch GmbH	Robert Bosch Gmb Postfach 31132 Hildesheim Germany	Refer to Link	https://doc-ita.bosch.com/	Nissan Automotive Europe (NAE)	Montigny-le- Bretonneux

UKCA APPROVAL DETAILS

UK $\mathsf{C}\mathsf{A}$

Description	Supplier	Supplier Address	UKCA Certificate #	Link to Certificate	Importer	Importer Address
Telematics Control Unit (TCU)	Continental	Continental Automotive Singa- pore Pte Ltd Continental Building 80 Boon Keng Road Singapore 339780	Refer to Link	https://www.continental-homologa- tion.com/en-gl/Nissan		
Tyre Pressure Moni- toring System (TPMS) Model TIS-03, TIS- 09DL	Continental Auto- motive GmbH.	Siemensstrasse 12 D-93055 Regensburg Germany	Refer to Link	https://www.continental-homologa- tion.com/en-gl/Nissan		
Front Radar Sensor Model ARS4-B	ADC Automatic Distance Control Systems GmbH	Peter-Domier-Str.10, 88131 Lindau, Gerany	LO104ADC1.AMK	https://www.continental.automo- tive-approvals.com		
Side Radar Sensor Model SRR3-B	ADC Automatic Distance Control Systems GmbHH	Peter-Domier-Str.10, 88131 Lindau, Gerany	LO121ADC1.AMK	https://www.continental.automo- tive-approvals.com		Rivers OFFice Park
Immobiliser Model A2C93178600	Continental Auto- motive GmbH	Continental Automotive GmbH Siemensstrasse 12 D-93055 Re- gensburg Germany	Refer to Link	https://www.continental-homologation.com/en-gl/Nissan	Nissan Motors Great Britain (NMGB)	Denham Way Rick- mansworth WD3 9YS
Intelligent Key sys- tem control unit Model HFM401	Continental Auto- motive GmbH.	Continental Automotive GmbH Siemensstrasse 12 D-93055 Re- gensburg Germany	Refer to Link	https://www.continental-homologa- tion.com/en-gl/Nissan		
Passive Entry Sys- tem Model TWB1G767 (Hand Unit)	ALPS ALPNE CO., LTD.	6-3-36, Furukwawnakazato, Osa- ki-city, Miyagi-pref., JAPAN 989- 6181	Refer to Link	https://www.alpsalpine.com/com- mon/pdf/HandUnit/TWB1G767.pdf		
Passive Entry System Model TXPZ1 (Hand Unit)	Continental Auto- motive GmbH.	Continental Automotive GmbH Siemensstrasse 12 D-93055 Re- gensburg Germany	Refer to Link	https://www.continental-homologa- tion.com/en-gl/Nissan		
Intelligent Key Sys- tem (iKey)	Continental Auto- motive GmbH.	Continental Automotive GmbH Siemensstrasse 12 D-93055 Re- gensburg Germany	Refer to Link	https://www.continental-homologation.com/en-gl/Nissan		
AIVI Models AIVICMFBO, AIVIP32RO, AIVI- H60AO and AI- VIL42PO,	Robert Bosch GmbH	Robert Bosch Gmb Postfach 31132 Hildesheim Ger- many	Refer to Link	https://doc-ita.bosch.com/	Nissan Motors Great Britain (NMGB)	Rivers OFFice Park Denham Way Rick- mansworth WD3 9YS

MEMO

10 Regulatory information

Environmental information	362
Environmental concern	362
Compliance at every step	362
We build our vehicles with recycling in mind	362

Consumer and user safety	
information (REACh)	362
Protect the environment when driving	362
AIRBAG LABEL (where fitted)	364

ENVIRONMENTAL INFORMATION

ENVIRONMENTAL CONCERN

Today, the efforts made by NISSAN to fulfil our responsibilities to protect and sustain the environment are far-reaching. Within NISSAN, we promote the highest levels of practice in every region and in every area of operations.

COMPLIANCE AT EVERY STEP

NISSAN focuses on ensuring that end of life vehicle components are reused, recycled or recovered, and guarantees compliance with EU legislation (the End of Life Vehicle Directive).

WE BUILD OUR VEHICLES WITH RECYCLING IN MIND

Reducing landfill waste, emissions, conserving natural resources, and enhancing recycling activities are emphasised daily in our manufacturing, sales and service operations and in the disposal of end of life vehicles (ELV).

Design phase

To reduce environmental impact we have developed your NISSAN vehicle to be 95% recoverable. We mark the components to facilitate dismantling, recycling and to reduce hazardous substances. We carefully verify and control substances of concern. We have already reduced to a minimum the cadmium, mercury and lead in your NISSAN vehicle. NISSAN includes recycled material in your vehicle and looks for opportunities to increase the percentage of recycled materials used.

Manufacturing phase

NISSAN plants based in the UK already achieve a recycling rate of over 90% and are looking for further improvements. The UK plant installed 10 wind turbines to cut carbon dioxide emissions at power plants by more than 3,000 tonnes per year.

Production and distribution phase

Using resources efficiently to reduce the amount of waste generated during the production and distribution stage.NISSAN promotes activities based on Reducing, Reusing, and Recycling materials whenever possible. NISSAN 's goal is to achieve a 100% recycling rate for operations in globally.

Use and service phase

NISSAN dealers are our window to you, our customer. In order to meet your expectations they provide not only high quality services but are also environmentally responsible. NISSAN promotes activities to recycle the waste generated as a result of service centre activities

Disposal phase

Recycle your end of life vehicle or its components. When your NISSAN reaches the end of its life, and is no longer suitable for daily use, it still has value. You can help prevent waste affecting the environment by bringing your NISSAN to be recycled at our collection networks in your area. Our collection networks guarantee no cost for the treatment of your ELV. For further information on how and where to dispose of your ELV refer to your local NISSAN dealeror consult: www.nissan-europe.com

CONSUMER AND USER SAFETY INFORMATION (REACh)

REACh is the chemical regulation in the EU, focusing on Registration, Evaluation, Authorisation and Restriction of Chemicals manufactured in or imported into the European Economic Area. NISSAN complies with REACh obligations, and fully supports its underlying goals: to protect human health and reduce the environment from risks posed by chemicals. For more information, visit:

www.nissan-safetvsheets.com

This website provides information on substances present in the NISSAN product(s) that you buy, and recommendations for their safe use

PROTECT THE ENVIRONMENT WHEN DRIVING

Your driving behaviour has significant impact on fuel economy and the environment. Follow the tips below for better fuel-efficiency, better driving habits, and to be environmentally friendly by reducing emissions:

Fuel efficient driving

Anticipating traffic conditions and acting accordingly reduces fuel consumption. Take your foot off the accelerator while approaching traffic lights and avoid last minute braking when the light turns red.

Avoid speeding, harsh acceleration, and strong braking. The gain in time does not offset pollution of the environment. Try to maintain speed when driving uphill to reduce fuel consumption and pollution. Maintain speed or allow the vehicle to go slower where traffic allows.

Close windows when driving

Driving with a window open at higher speeds increases fuel consumption. Driving with the windows closed allows for better fuel economy.

Use the roof rack only when necessary

Only install the roof luggage system when you really need it, otherwise put it inside the vehicle or store it in your garage. Do not drive around with an empty roof rack, kayak holder, or ski rack, as this will increase your aerodynamic drag significantly.

Optimise the use of air conditioning

The air conditioning system has a positive effect on driving and vehicle safety through comfort cooling and dehumidifying, drivers are more alert and have better visibility when window demisting/ defogging becomes necessary. However, use of the air conditioning system will increase fuel consumption substantially in an urban environment. Optimise the use of air conditioning by using the vents as much as possible.

Use the parking brake on slopes

Use the parking brake when holding your vehicle on a slope. Avoid using the accelerator (Hybrid Gearbox) to hold your vehicle as this leads to unnecessary fuel consumption and wear.

Maintain a safe distance

Anticipate traffic conditions for a smoother drive and to assure comfort and safety during your trip. Drive and maintain a safe distance from other vehicles while in traffic. This will help reduce fuel consumption as you will not be constantly tapping your brakes.

Check your tyre pressure

Low tyre pressure increases fuel consumption as well as the use of non-recommended tyres. Correct tyre pressure will maximise the grip of your vehicle and optimise fuel consumption.

Have your car serviced regularly

Regular service allows you to run your vehicle in optimal condition and with the best fuel efficiency. Have your vehicle serviced by your NISSAN dealer or a qualified workshop to ensure that it is maintained to its original standard.

AIRBAG LABEL (where fitted)



NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.

NE JAMAIS utiliser un dispositif de retenue pour enfant de type dos à la route sur un siège protégé par un AIRBAG ACTIVÉ placé devant lui. Cela peut entrainer la MORT de l'ENFANT ou des BLESS URES GRAVES.

Installieren Sie niemals ein entgegen der Fahrtrichtung angeordnetes Kinderrückhaltesystem auf einem Sitz mit aktiviertem Frontairbag. Es könnte zum Tod oder schweren Verletzungen des Kindes führen.

No instalar nunca los sistemas de retención para niños (sillitas de niño) de espaldas al sentido de la marcha en el asiento del pasajero protegido por un AIRBAG frontal ACTIVO. Esto puede provocar la MUERTE del niño o DAÑARLE SER IAMENTE.

«NON INSTALLARE MAI un seggiolino per bambini rivolto con verso opposto al senso di marcia su un sedile protetto da un AIRBAG frontale ATTIVO. In caso di incidente questo potrebbe risultare molto pericoloso per l'incolumità del bambino.»

Plaats nooit een kinderzitje achterstevoren op de passagiersstoel voorin als de airbags van de voorpassagier niet zijn uitgeschakeld. Dit kan ernstige of zelfs dodelijke verwondingen van het kind veroorzaken.

NUNCA utilize um sistema de retenção de criança virado para a traseira num banco protegido por um AIRBAG ACTIVO à sua frente, porque pode ocorrer MORTE ou FERIMENTOS GRAVES na CRIANCA.

W żadnym przypadku NIE NALEŻY stosować fotelików dla dzieci skierowanych twarza do tylu siedzeniami chronionymi przed AKTYWNA PODUSZKA POWIETRZNA. Może doprowadzić do POWAŻNYCH OBRAŻEŃ lub nawet ŚMIERCI DZIECKA.

NIKDY nepoužívejte dětskou sedačku směřující dozadu na sedadle s AKTIVNÍM čelním AIRBAGEM, mohlo by dojít k USMRCENÍ nebo VÁŽNÉMU ZRANĚNÍ DÍTĚTE.

Önünde AKTİF BİR HAVA YASTIĞI ile korununan bir koltuğa hiç bir zaman yüzü geriye bakan bir cocuk koltuğu KOYMAYIN, bu COCUĞUN ÖLÜMÜNE veva CIDDI SEKILDE YARALANMASINA neden olabilir.

Nu folositi NICIODATĂ un scaun pentru copil cu spatele la directia de deplasare pe un scaun proteiat de un AIRBAG ACTIV amplasat în fata sa. deoarece există riscul de DECES sau RĂNIRE GRAVĂ a copilului.

SOHA ne használion hátrafelé néző gyermekülést olyan ülésen, amelyet elölről AKTÍV LÉGZSÁK véd, mert az a GYERMEK HALÁLÁT vagy SÚLYOS SÉRÜLÉSÉT okozhatja.

"ΑΠΑΓΟΡΕΥΕΤΑΙ η τοποθέτηση παιδικού καθίσματος, με την πλάτη προς το εμπρόσθιο μέρος του αυτοκινήτου, στο κάθισμα του συνοδηγού, επειδή μπροστά του υπάρχει ΕΝΕΡΓΟΣ ΜΕΤΩΠΙΚΟΣ ΑΕΡΟΣΑΚΟΣ. Μπορεί να επέλθει, ΘΑΝΑΤΟΣ ή ΣΟΒΑΡΟΣ ΤΡΑΥΜΑΤΙΣΜΟΣ του ΠΑΙΔΙΟΥ".

Använd ALDRIG en bakåtvänd barnstol på ett säte som skyddas av en AKTIVERAD AIRBAG framför det: LIVSFARA eller risk för ALLVARLIGA SKADOR.

ÄLÄ KOSKAAN käytä kasvot taaksepäin suunnattua lastenistuinta istuimella, jossa on KÄYTÖSSÄ OLEVA TURVATYYNY. Seurauksena voi olla KUOLEMA tai LAPSEN VAKAVA LOUKKAANTUMINEN.

Brug ALDRIG et bagudvendt barnesæde på et sæde, der er beskyttet af en AKTIV AIRBAG foran det. Det kan resultere i DØD eller ALVORLIG PERSONSKADE på BARNET.

MNSY829



NEMOJTE upotrebljavati sjedalicu za djecu okrenutu prema natrag na sjedalu ispred kojega se nalazi zaštićeni AKTIVNI ZRAČNI JASTUK, može doći do SMRTONOSNIH ili OZBILJNIH OZLJEDA za DIJETE.

NIKOLI ne namestite otroškega sedeža, obrnjenega v nasprotni smeri smeri vožnje, v primeru VKLOPLJENE varnostne blazine. To lahko povzroči OTROKOVO SMRT ali HUDE TELESNE POŠKODBE

Никогда не устанавливайте обращенное назад детское удерживающее сиденье на переднем пассажирском сиденье при неотключенной подушке безопасности. Это может привести к смерти ребенка или к тяжелым повреждениям.

NIKDY nepoužívajte detskú sedačku smerujúcu dozadu na sedadle s AKTÍVNYM čelným AIRBAGOM, mohlo by prist k USMRTENIU alebo VÁŽNEMU ZRANENIU DIEŤAŤA.

ÄRGE kasutage seljaga sõidusuunas laste turvatooli istmel, mille ees on AKTIIVNE saada TÕSISE TURVAPADI. LAPS võib KEHAVIGASTUSE või HUKKUDA.

NEIEVIETOJIET ar skatu pretēii braukšanas virzienam vērstu bērnu sēdeklīti šajā sēdeklī, ja tā priekšā uzstādītais GAISA SPILVENS ir AKTIVIZĒTS. - tas BĒRNAM var radīt NOPIETNAS TRAUMAS vai pat izraisīt BĒRNA NĀVI.

NUNCA utilize uma cadeirinha protetora para crianças voltada para a traseira em um assento que seja protegido por um AIRBAG ATIVO na frente do assento. Podem ocorrer MORTE OII FERIMENTOS GRAVES para a CRIANCA.

NIEKADA nevežkite vaikų prie automobilio sėdynės atvirkščiai judėjimo krypčiai pritvirtintoje specialioje kėdutėje, jeigu ši sėdynė apsaugota VEIKIANČIA SAUGOS PAGALVE, nes VAIKUI kyla MIRTINAS ar SUNKAUS SUŽEIDIMO pavojus.

Ніколи не встановлюйте дитяче крісло спинкою вперед на сидінні, передня ПОДУШКА БЕЗПЕКИ якого не заблокована. Ризик ЗАГИБЕЛІ або ТЯЖКИХ ТРАВМ дитини.

"Никога на използвайте детско столче за автомобил, монтирано с гръб към движението, на седалка оборудвана с предпазна въздушна възглавница пред нея. Съществува риск за живота или сериозно нараняване на детето!"

يحذر نهائيًا تثبيت مقعد الطفل بشكل عكسي على القعد المحمى بوسادة هوائية نشطة أمام مقعد الطفل، فمن الممكن أن يتسبب ذلك في وفاة الطفل أو إصابته بجروح خطيرة ALDREI má nota festingar sem snúa afturábak á sæti sem varið er með ACTIVE AIRBAG að framan, Það getur valdið DAUÐA eða ALVARLEGUM MEIÐSLUM á BARNINU.

Na sedež, ki je spredaj zaščiten z ZRAČNO BLAZINO, NIKOLI ne namestite otroškega sedeža tako, da otrok gleda nazaj: nevarnost SMRTI ali RESNE TELESNE POŠKODBE OTROKA

هر گز از کمر بند کو دک رو به پشت در روبروی صندلي حفاظت شده توسط ACTIVE AIRBAG (كيسه هواي فعال) استفاده نكنيد. اين كار ممكن است باعث مرگ با جر احت شدید در کو دک شود.

절대로 능동형 에어백이 전면에 설치된 좌 석에 후향식 어린이 보호시트를 사용하지 마십시오, 어린이에게 심각한 상해를 입히거 나 사망에 이르게 할 수 있습니다.

前部に作動可能なエアバッグが装着されて いるシートに、後ろ向きのチャイルドシート を絶対に使用しないでください。お子様に 死や大けがを招く恐れがあります。

禁止在座椅前部安全气囊激活的情况下,在 该座椅上使用后向儿童安全座椅,可能造成 儿童严重受伤甚至死亡。

MNSY831

MEMO

11 Index

	Armrests		- Checking	323
Α	- Storage	116	- Fluid	323
	Audible reminders	81	- Intelligent Emergency	
ABS (Anti-lock Braking System)	Audio	170	Braking (IEB)	250, 250
- Warning light	- NissanConnect	174	- Parking brake	138
Accident	- Precautions	170	- Precautions	272
- Emergency Response System 288	- Steering-wheel switches	179	- Trailer	
Aids	Automatic brake hold	140	- Warning light	74
- Blind Spot Warning (BSW) 200			Brightness	
- Chassis control 276	В		- Instrument panel	70
- Hill Start Assist (HSA) 277			F	-
- Intelligent Around View Monitor (IAVM) 153	Battery		С	
- Intelligent Blind Spot Intervention 200	- Caution label	324		
- Intelligent Emergency	- Information	325	Capacities and recommendations	341
Braking (IEB) 250, 250	 Intelligent Key battery discharge 	195	- Coolant	341
- Moving Object Detection (MOD) 163	- Jump-starting	300	- Fuel	341
- Overview	- Key battery replacement	327	- Oil	341
- Rear Cross Traffic Alert (RCTA) system 210	- Saver system	193	- Refrigerant	341
- Ultrasonic parking sensors 266	- Warning light	74	Changing	
Air bags	Blind Spot Intervention		- Engine coolant	317
- Repair and replacement 64	- Driving situations	206	- Engine oil	320
- Supplemental restraint System 57	Blind Spot Warning (BSW)	200	- Tyres and wheels	336
Air conditioner	- Driving situations	206	Chassis control	276
- Automatic 167	- Operation	202	- Intelligent Ride Control	276
- Heater and air conditioner 166	Bluetooth®		- Intelligent Trace Control	276
- Refrigerant and lubricant 343	- Precautions	172	Checking	
- Servicing 169	Bonnet		- Brake pedal	323
- Specification label 346	- Release	137	- Coolant level	
Antenna 173	Boot	118	- Engine oil level	320
Anti-Theft System (NISSAN) 136	Brakes		- Parking brake	
Approval numbers	- Adjustment		Child restraints	
Armrest	- Anti-lock Braking System (ABS)		- Anchorage	

-	ISOFIX	49
-	ISOFIX installation	50
-	Precautions	
-	Seat belt installation	53
Ch	ild safety 37	7, 42
Cle	eaning	
-	Alloy wheels	307
-	Automatic anti-dazzling inside mirror	309
-	Chrome parts	308
-	Exterior	306
-	Glass 307,	309
-	Interior	308
-	Plastic parts	309
-	Rear-view camera lens	307
-	Removing spots	307
-	Underbody	307
-	Waxing	307
Cle	eaning Wheels	
-	Wheels Care	307
Clo	ock	104
Co	at hooks	117
Co	ld weather	285
-	Battery	285
-	Corrosion protection	286
-	Engine coolant	285
-	Equipment	285
-	Winter equipment	286
Co	nsole box	116
Co	olant	
-	Capacities	341
-	Changing engine coolant	
-	Checking coolant level	
-	Cold weather	285
_	Engine cooling system	317
	- ·	

Сс	rrosion protection		310
_	Environmental factors		
Cr	uise control		
_	Operation		
_	Precautions		221
Cu	p holders		116
_	Bottle holder		116
	D		
De	fogger		
_	Switch		108
Dir	mensions		
_	Engine		
Dis	splay		
_	Maintenance		308
_	Rear-view monitor		148
_	Vehicle information		. 82
_	Warnings and indicators		. 92
Do	ors		
-	Child safety		135
-	Locks		133
-	Power door lock switch		134
-	Precautions		129
-	Remote keyless entry system		125
-	Tailgate		135
Dr	ive mode		278
Dr	iving		196
-	Care		192
-	Cold weather		285
-	Drive mode		278
-	Intelligent Emergency		
	Braking (IEB)	250,	250
-	Precautions	185,	190
_	Wet road		102

- Winter conditions 192

E	
·Call	288
DR (Event Data Recorder)	291
Electric power steering	
lectronic Stability Programme	
ESP) system	274
Deactivation	275
mergency	
Response System	288
mergency tyre puncture repair kit	336
Location	298
mergency/mechanical key	125
ingine	
Changing engine coolant	317
Changing engine oil	320
Checking coolant level	317
Checking engine oil level	320
Cold start period	192
Cooling system	317
Data	344
Engine overheat	302
Oil	320
Serial number	346
Spark plugs	328
Three-way catalyst	190
vent Data Recorder (EDR)	291
event Data Recorders (EDR)	347
xhaust gas (Carbon Monoxide)	185
exterior	
Cleaning	306
exterior lights	331

F	
F	
Flat tyre	292
Floor	118
Floor mats	309
Fluids	
- Air conditioner	341
- Brake	323
- Hybrid gearbox	322
- Window washer	324
Fog lights	
- Front — Location	332
- Front – Operation	111
- Rear — Location	332
- Rear — Operation	111
- Rear - Replacement	332
Four-wheel drive (4WD)	
- Four-wheel drive (4WD) model (Tyres)	336
Frequency approval numbers	355
Fuel	
- Capacities	341
- Gauge	70
- Information	343
Fuel filler lid	
- Cap	137
- Opening	137
Fuses	330
- Passenger compartment	330
G	
Gasoline particulate filter	101
Gauges	
- Fuel	
1 UCI	
- Meters and gauges	

Glove box	115
Guide lines	156
Н	
Hazard warning flasher switch	288
Head restraints	. 34
- Adjustment	. 35
- Installation	. 35
- Removal	. 34
Headlights	
- Aiming control	112
- Dynamic high beam assistant	109
- Operation	108
- Replacement (bulb)	331
- Switch	108
Heated seats	
- Operation	113
- Precautions	113
Heated windscreen	107
Heater and air conditioner	166
- Automatic air conditioner	167
- Servicing	169
- Vents	166
Hill Start Assist (HSA)	277
- Indicator light	. 80
Horn	112
Hybrid Gearbox	
- Driving	196
- Fluid	322
Hybrid system	
- Starting	195

	1	
Ignition		
-	– positions	10
Immobilize	·	17.
	- I Anti-Theft System (NATS)	13
	ights	
Indicators	igi 163	. , .
	information display	9
	rsons	
	r-view mirror	
	Around View Monitor (IAVM)	
	ines 156,	
	ion	
	Blind Spot Intervention	
_	Emergency Braking (IEB) 250,	
_	ion 252,	
	ion	
	g light 76, 252,	
	Key 127,	
	discharge	
	replacement	
] 126,	
	ing range	
	ion	
	ion failure	
	e keyless entry system	
	g	13
	ing 126,	
	Trace Control	
_	Trace Control	
Interior		
- Liahts	- Information	33
_	– operation	
ISOFIX	- F	
- Anchor	locations	4

- Child restraints	49	- Indicator lights	72	- Automatic anti-dazzling 143	3, 14
- Installation	50	- Interior	121, 332	- Folding	14
		- LED headlight	331	- Rear-view (Inside)	14
J		- Locations	332	- Rear-view (Outside)	14
Lucian at authoris	700	- Luggage compartment	122	- Vanity mirror	14
Jump-starting	300	- Replacement	331, 332	Moving Object Detection (MOD)	16
K		- Trailer direction indicator	269		
IX.		- Turn signal switch	111	N	
Keys		- Warning lights		NUCCANI Austi Tie oft Country (NIATC)	1.0
- Battery replacement	327	Locks		NISSAN Anti-Theft System (NATS)	
- Emergency key	125	- Child safety	135	- NATS key	12
- Immobilizer	124	- Door	133	- Radio approval number	
- Intelligent Key 12	7, 192	- Inside door handle	134	and information	34
- Intelligent Key battery discharge		- Power door lock switch	134	0	
- Keys		- Steering	194		
- Mechanical key	125	- Super Lock system	133	Odometer/trip/twin trip odometer	6
- Operating range (Intelligent Key)	128	- Tailgate	135	Off-road	
- Operation (Intelligent Key)		- Vehicle dead battery	133	- Precautions	19
- Operation failure	127	Luggage compartment		Oil	
- Radio approval number		- Luggage compartment floor	118	- Capacities and recommendations	34
and information	348			- Changing engine oil	32
- Remote keyless entry system	125	M		- Checking engine oil level	32
- Troubleshooting	132	AA-:		- Disposal	32
		Maintenance	717	- Engine oil	
L		- General maintenance		- SAE viscosity number	
	245	- Indicator		- Warning light	7
Lane Assist system		- Parking sensor system		Overheat	
Legal requirements	43	- Precautions		- Engine overheat	30
Lights	771	- Requirements		_	
- Exterior		- Seat belts		P	
- Fog light switch		Meters and gauges 6			
- Hazard warning flasher switch		- Fuel		Parcel shelf	
- Headlight aiming		- Odometer/trip/twin trip odometer		Parking	
- Headlight and turn signal switch		- Speedometer		- Brake	
- Headlight switch		Mirrors		- Intelligent Around View Monitor (IAVM)	
- Headlights	331	- Adjustment (Power)	144	- Ultrasonic parking sensors	26

Pa	rking sensors	
-	Maintenance	268
Pe	trol	
-	Fuel filler lid	
-	Fuel recommendation	343
-	Gauge	70
Ро	wer	
-	Door lock switch	
-	Electric power steering	271
-	Outlet	113
-	Windows	119
Pre	ecautions	
-	Audio	170
-	Brakes	272
-	Child restraints	. 43
-	Cruise control	221
-	Door locks	129
-	Exhaust gas	185
-	Intelligent Emergency	
	Braking (IEB) 250,	250
-	Maintenance	315
-	Off-road driving	190
-	On-pavement driving	190
-	Predictive guide lines 149,	158
-	Push-button ignition switch	192
-	Safety	148
-	Seat belts	36
-	Starting and driving	185
-	Supplemental Restraint System	. 57
-	Towing	303
-	Trailer	268
Pre	egnant women	38
	PILOT Assist	
-	Operation	226

- Corrosion	286
- Environment	322
Push starting	301
R	
Radio	
- Approval number and information	348
- NissanConnect	174
Radio transmitter	347
Rear Cross Traffic Alert (RCTA)	
- Operation	211
Rear Cross Traffic Alert (RCTA) system	210
Rear seats	33
- Folding	33
Rear-view monitor	148
- Guide lines	149
- Settings	152
Recorders, Event data	347
Remote keyless entry system	125
- Operation	126
Repairing	
- Flat tyre	298
- Headlights	331
Replacement	
- Air bags	64
- Engine coolant	317
- Engine oil	320
- Spark plugs	328
- Wiper blades	329
Running-in schedule	184

Safety

-	Child safety rear door locks	3
-	Children 37,	4
-	Head restraints	3
-	Injured persons	3
-	Precautions	4
-	Pregnant women	3
-	Road Accident Emergency	
	Response System	28
Se	at belts 36,	3
-	Adjustment	
-	Child restraint installation	5
-	Child safety 37,	4
-	Children - Infants	4
-	Children - Larger	4
-	Cleaning	30
-	Legal requirements	4
-	Maintenance	4
-	Precautions	3
-	Rear centre position	4
-	Warning light 72,	7
-	Warnings	3
Se	ats	3
-	Adjustment (Manual)	3
-	Head restraints	3
-	Heating	1
-	Rear	3
-	Universal child restraints (front and	
	rear seats)	4
Se	curity system	
-	Alarm system	3
-	Interior movement sensors	3
-	NISSAN Anti-Theft System (NATS) 124, 1	3
Se	rvicing	
-	Air conditioner	6

5	Settings	
-	- Intelligent Around View Monitor (IAVM) 1	5
-	- Language	9
-	- Moving Object Detection (MOD) 1	6.
-	- Reset	9
-	- Vehicle	
-	- Vehicle information display	8
5	Snow chains 3	3
5	SOS Switch2	288
5	Spare tyre 2	9
9	Spark plugs3	328
5	Speed limiter 223, 2	48
-	- Operation 223, 2	48
5	Speedometer	6
9	Starting	
-	- Before starting 1	8
-	- Hybrid system 1	9
-	- Jump-starting 3	300
-	- Precautions 1	8
-	- Push starting3	0
5	Steering wheel	
-	- Adjustment 1	4
-	- Electric power steering 2	27
-	- Lock 1	9
-	- Switches — Audio control 1	7
-	- Warning light	7
5	Storage1	11
-	- Boot 1	11
-	- Bottle holder 1	11
-	- Coat hooks 1	1
-	- Console box 1	11
-	- Cup holders 1	11
-	- Glove box 1	11!
-	- Luggage hooks 1	119
-	- Seat pocket 1	11
-	- Trays 1	11

Sui	n visors	142
Sup	per Lock system	133
-	Emergency release	133
Sup	pplemental Restraint System	. 57
Sw	itches	
-	Automatic brake hold	140
-	Defogger	108
-	eCall	288
-	Fog light	111
-	Front passenger air bag	. 61
-	Hazard warning	288
-	Headlight aiming	112
-	Headlight and turn signal	108
-	Parking brake	138
-	Power door lock	134
-	SOS	288
-	Steering-wheel - Audio	179
-	ThermaClear	107
-	Ultrasonic parking sensors	267
-	Wiper and washer	105
	Т	
The	ermaClear Heated Windscreen	
-	Operation	107
Thi	ree-way catalyst	
-	Care	190
-	Information	190
Tilt	ing steering wheel	142
	ols	293
	wing	
	Eye	303
-	Precautions	
-	Recommended towing	303
-	Recommended towing Tow bar Installation	
-	Recommended towing Tow bar Installation Tow truck towing	269

-	Trailer	268
Tra	ailer	
-	Brakes	269
-	Precautions	268
-	Tow bar Installation	269
-	Towing	268
-	Trailer detection	269
Tra	ansferring registration to	
an	other country	345
Tra	ansmission	
-	Driving - Hybrid Gearbox	196
-	Hybrid gearbox fluid	322
Tra	evelling	345
Tro	publeshooting	
-	Keys	132
Tu	rn signal	
-	Operation	111
Tyr	re Pressure Monitoring System (TPMS)	186
-	Meter information	188
-	Settings	189
Tyr	res	
-	Age	336
-	Changing tyres and wheels	336
-	Emergency tyre puncture	
	repair kit	336
-	Equipment	
-	Flat tyre	292
-	Inflation pressure	
-	Placard	346
_	Repairing flat tyre	298
_	Rotation	
_	Snow chains	335
-	Spare	
_	Spare tyre	
_	Temporary-use spare tyre	292
	, , , , , , , , , , , , , , , , , , , ,	

Trailer tyre pressure	269
Types	334
Tyre Pressure Monitoring	
System (TPMS)	296
Wear and damage	335
Wheels and tyres	334
U	
iversal child restraints	
	42
·	170
Precautions	170
V	
hicle identification	345
hicle information display	82
Warnings and indicators	92
hicle security 136,	270
Alarm system	136
Interior movement sensors	136
nts	166
scosity number (SAE)	343
W	
	System (TPMS) Wear and damage Wheels and tyres U siversal child restraints Front and rear seats B (Universal Serial Bus) Precautions V hicle identification Air conditioner label Engine serial number Number (VIN) (chassis number) Plate Tyre placard hicle information display Settings Warnings and indicators hicle security 136, Alarm system

- Air bag 59

- Air bag - Passenger 59

Warning labels

Warning lights

Wa	arning/indicator lights and		
au	dible reminders		7 2
Wa	arnings		
-	Vehicle information display	!	92
Wa	shing	30	06
w٢	neel lock bolts	2	96
W٢	neels		
-	Balance	3	36
-	Blocking	2	93
-	Changing tyres and wheels	3	36
-	Cover	2	93
-	Installation	2	95
-	Removal	2	93
-	Sizes	3	44
-	Stowing	2	96
-	Tools and spare wheel	2	93
-	Wheel lock bolts	2	96
-	Wheels and tyres	3	34
Wii	ndows	1	19
-	Automatic function	1	2 C
-	Locking	1	2 C
-	Power	1	19
Wij	pers	10	05
-	Blade replacement	3	29
-	Operation (Rear window)	10	06
-	Operation (Windscreen)	10	05
-	Rain-sensing auto wiper	10	06
-	Reverse synchronisation	10	07
-	Washer nozzle	3	3 C
-	Window washer cleaner fluid	3	24

QUICK REFERENCE

- In case of emergency ... (P.288)
 (Flat tyre, engine will not start, overheating, towing)
- How to start the hybrid system... (P.195)
- How to read the meters and gauges ... (P.67)
- Maintenance and do-it-yourself ... (P.313)
- Technical information ... (P.341)

SECURITY INFORMATION

As owner of this vehicle important codes have been supplied to you that may be required by your NISSAN dealer to duplicate keys or repair the radio.

Please fill in the allocated areas or attach sticker(s) if available. Remove this page and keep it in a safe place, **not in the vehicle**.

When selling your vehicle, we kindly request you to hand over this page to the buyer.

SECURITY INFORMATION

Radio security code (where fitted)			
Key number			

Wheel lock key code (where fitted)

Remove this page from the manual and keep it in a safe place, **not in the vehicle**.

When selling your vehicle, we kindly request you to hand over this page to the buyer.





Printing: July 2024 (01) Publication No.: OM24EN-HF16E1EUR Printed in France Nissan Automotive Europe SAS - France





